

506953-01
3/2014
Supersedes 8/2012

**MSAV® Supply Air Blower
VFD Kit**

**INSTALLATION INSTRUCTIONS FOR MSAV® (MULTI-STAGE AIR VOLUME) SUPPLY AIR
BLOWER VFD KIT USED WITH TAA090 - 240 SERIES UNITS**

⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause personal injury, loss of life, or damage to property.

Installation and service must be performed by a licensed professional installer (or equivalent) or a service agency.

⚠ CAUTION

Physical contact with metal edges and corners while applying excessive force or rapid motion can result in personal injury. Be aware of, and use caution when working near these areas during installation or while servicing this equipment.

Shipping and Packing List

Check parts for shipping damage; if any damage is found, immediately contact the last shipping carrier. All parts are shipped inside the VFD sheet metal box. Please remove all packaging prior to installation and locate all parts listed below.

Package 1 of 1 contains the following:

- 1 - Mounting bracket, long
- 1 - Mounting bracket, short
- 2 - Mounting brackets, 90°, long
- 2 - Mounting brackets, 90°, short
- 1 - Economizer control harness (only used with economizer)
- 1 - Bag assembly that consists of the following:
 - 1 - Adapter harness, splice connector, and 8" single wire
 - 1 - 24V conversion harness (only used on units without 24VAC terminal on TB1)
 - 6 - Large wire nuts
 - 3 - Small wire nuts
 - 6 - Screws
 - 5 - Wire ties
- 1 - 1/4" diameter metal plug
- 1 - Wiring diagram (537533-01)
- 1 - Wiring diagram (537531-01) used on units with the 24VAC terminal on TB1.
- 1 - Wiring diagram (537532-01) used on units without the 24VAC terminal on TB1.

Application

⚠ WARNING



Electric Shock Hazard. Can cause injury or death.

Line voltage is present at all components on units with single-pole contactors, even when unit is not in operation!

Unit may have multiple power supplies. Disconnect all remote electric power supplies before opening access panel.

Unit must be grounded in accordance with national and local codes.

An externally mounted enclosure houses a variable frequency drive (VFD) and a control that stages the supply air blower airflow. Designed for use on dual-stage split systems ranging from 7.5 to 20 ton capacity (TAA090 – TAA240). The VFD alters the frequency and voltage of the power supply to control blower motor speed and airflow. Split dual-stage systems equipped with this option comply with California Code of Regulations Title 24 and ASHRAE 90.1-2010 Section 6.4.3.10 requirements for staged indoor airflow.

NOTE - The VFD has an operational range of -40°F to 125°F ambient air temperature. Attic temperatures may exceed the 125°F operating range. If the air handler is installed in an attic the MSAV kit must be mounted remotely away from the air handler in a location where the maximum operating temperature range is not exceeded.

After the MSAV kit is installed, the supply air blower has two speeds:

1. Low speed for part-load cooling operation.

NOTE - Low speed is 66% of high speed.

2. High speed for full load cooling and all heat modes.

Full speed blower operation is set by adjusting the motor pulley to deliver the desired air volume as with a conventional CAV system.

The ventilation speed is selectable between high and low speed.

NOTE - Part load airflow in cooling mode on MSAV units should not be set below 220 cfm/nominal full load ton to reduce the risk of evaporator coil freeze-up.

Lower operating costs are obtained when the blower is operated on lower speeds.



Dimensions and Weights




Figure 1. Dimensions

Table 1. Weights

Motor Size	Voltage	Model Information	Cat #	Approx. Weight (lbs.)
2HP	208/240V-3ph	T2MSAV20LM1Y	92W63	23
	460V-3ph	T2MSAV20LM1G	92W64	23
	575V-3ph	T2MSAV20LM1J	92W65	24
3HP	208/240V-3ph	T2MSAV20LN1Y	92W66	23
	460V-3ph	T2MSAV20LN1G	92W67	23
	575V-3ph	T2MSAV20LN1J	92W68	24
5HP	208/240V-3ph	T2MSAV20MN1Y	92W69	24
	460V-3ph	T2MSAV20MN1G	92W70	23
	575V-3ph	T2MSAV20MN1J	92W71	28
7.5HP	208/240V-3ph	T2MSAV20N-1Y	92W72	28
	460V-3ph	T2MSAV20N-1G	92W73	27
	575V-3ph	T2MSAV20N-1J	92W74	28

Installation

MOUNTING AND WIRE ROUTING

There are several possible mounting locations based on your application and installation requirement. The VFD mounting box is configured for the most used configuration (wires exiting left), but can be reconfigured so that wires exit to the right, if needed. The four most common mounting locations are outlined below. If another location is desired, please be sure there is enough wire length to reach the TAA control panel and that the chosen mounting location does not interfere with servicing the unit.

1. Mounting Option 1, Horizontal Applications

Preparation: Attach the two (2) short 90° brackets to the box as shown.

- 1.1. Remove the three (3) top and three (3) bottom screws that mount the wrapper to the side.
- 1.2. Add the brackets so they are flush with the left side of the box, and fasten brackets and wrapper using the same screws that were removed in step 1.1.




Figure 2. Horizontal Mounting

Mount box to the TAA blower coil in location shown using the (6) sheet metal screws provided in kit.




Figure 3. Mounting VFD Box - Horizontal

2. Mounting Option 2, Upflow Applications

Preparation: Attach the one (1) short 90° bracket and one (1) short flat bracket to the box as shown.

- 2.1. Remove the three (3) top and three (3) bottom screws that mount the wrapper to the side.
- 2.2. Add the brackets so that the bottom 90° bracket is flush with the left side of the box. The top flat bracket extends out. Fasten brackets and wrapper using the same screws that were removed in step 2.1.




Figure 4. Upflow Mounting

Mount box to the TAA blower coil in location shown using the (6) sheet metal screws provided in kit.




Figure 5. Mounting VFD Box - Upflow

3. Mounting Option 3, Upflow Applications

Preparation: Attach the one (1) long 90° bracket and one (1) long flat bracket to the box as shown.

- 3.1. Remove the three (3) top and three (3) bottom screws that mount the wrapper to the rear of the box.
- 3.2. Add the brackets so that the 90° bracket is on the bottom of the box. Both, the top flat bracket and the bottom bracket extend out. Fasten brackets and wrapper using the same screws that were removed in step 3.1.




Figure 6. Upflow Mounting (Surface Mount)




Figure 7. Mounting VFD Box - Upflow (Surface Mount)

4. Mounting Option 4, Upflow Applications with Alternate Control Panel Location

Preparation: Attach the one (1) long 90° bracket and one (1) flat long bracket to the box as shown.

- 4.1. Remove the three (3) top and three (3) bottom screws that mount the wrapper to the rear of the box.
- 4.2. Add the brackets so that the 90° bracket is on the bottom of the box. Both, the top flat bracket and the bottom bracket extend out. Fasten brackets and wrapper using the same screws that were removed in step 4.1.




Figure 8. Upflow Mounting (Surface Mount)




Figure 9. Mounting VFD Box - Upflow (Surface Mount - Alternate Location)

ELECTRICAL CONNECTIONS

Wire Routing: Wiring must conform to the current National Electric Code ANSI/NFPA No. 70, or Canadian Electric Code Part I, CSA Standard C22.1, and local building codes.

Separate openings (knock-outs) have been provided for the 24V low voltage control wires, the line voltage wires to the box, and the load voltage wires from the box back to the blower. Refer to the dimension illustration for specific location

All wires are hot stamped for identification and are approx. 8 feet long exiting the VFD mounting box.

Route wires to the TAA control box. Route the 24V low voltage control wires, the line voltage wires to the box, and the load voltage wires from the box back to the blower in three (3) separate metal conduits. **Use metal conduit since it will be serving as the grounding means between the VFD mounting box and the unit.**

NOTE: When an economizer is used, please refer to page 6 and route the 2-wire economizer harness before you route the VFD control wires. The 2-wire economizer harness has quick connect terminals and may be hard to pull through the conduit if not done first. Do not trim economizer wire harness!

Leave enough length to make the connections and trim excess wires.

Low Voltage Connections – Before proceeding it must be determined whether there is a 24VAC terminal on the TB1 terminal board (see figure 10 for location if present). There are two electrical installation sections, one for units with a TB1 24VAC terminal and one without.




Figure 10. Typical TAA Control Panel

5. Low Voltage Connections – Units with 24VAC Terminal:




Figure 11. Low Voltage Connections – Units with 24VAC Terminal

- 5.1. Disconnect all power to unit.
- 5.2. Locate pink wires marked **KIT-1** and **KIT-2** (Quick connect) in the TAA control box and disconnect from each other.
- 5.3. Make wiring connections according to figure 11.
- 5.4. In the low voltage wire bundle coming from the VFD mounting box, find three wires marked **K3-A**, **KIT-1**, **KIT-2** and strip ends.
- 5.5. Take the short adapter harness shipped with the kit marked **K3-A**, **KIT-1**, **KIT-2**, strip ends and using the three small wire nuts, connect to the wires mentioned in step 5.1. Secure wire nut connections with electrical tape (Field supplied).
- 5.6. Connect the kit harness wire marked **K3-A** to the **K3 blower contactor terminal A**.
- 5.7. Connect the kit harness wire marked **KIT-1** to the factory wire marked **KIT-1**.
- 5.8. Connect the kit harness wire marked **KIT-2** to the factory wire marked **KIT-2**.
- 5.9. Connect remaining low voltage wires to the terminal block **TB1** as shown in figure 11 and as per wire marking. Replace existing wiring diagrams on TAA unit with diagrams provided in kit.

- * Use 537531-01 if TB1 has the 24VAC terminal.
- * Use 537532-01 if TB1 does not have the 24VAC terminal.

6. Low Voltage Connections – Units without 24VAC Terminal

Older units that are not equipped with a 24VAC terminal on the TB1 terminal board require the addition of a harness in order to connect the accessory kit. In addition to the new harness a change to the 24VAC power supply wiring connection must be made. Use the following procedure and figure 12 to make the necessary changes.

- 6.1. Disconnect all power to unit.
- 6.2. **Adding the Accessory Connection Harness**
 - 6.2.1. Remove the TB1 terminal board and disconnect the pink wire attached to the **R** terminal on the rear side of the terminal board. Once wire has been removed, connect it to the splice connector provided in kit. Connect the single pink wire provided in kit to the other end of the splice connector.
 - 6.2.2. Connect the 24VAC power supply wire coming from the outdoor unit to the pink wire that was just added to the one side of the splice connector using wire nut provided in kit. Secure wire nut connection with electrical tape (field-provided).

- 6.2.3. Disconnect the factory wire marked **K43-5** from the **K43** relay and connect to the short kit harness wire marked **K43-5**.
- 6.2.4. Connect the other short kit harness wires marked **K43-5** to the **K43** relay.
- 6.2.5. Connect the short kit harness wire marked **TB1-R** to the TB1 terminal board.
- 6.2.6. Re-attach the TB1 terminal board to the control panel.
- 6.2.7. Refer to the procedures listed under **Low Voltage Connections - Units with 24VAC Terminal, section 5** to continue the installation process.




Figure 12. Units without TB1 24VAC Terminal

7. Units with Standard Economizer

- 7.1. This kit includes a 2-wire, 20-foot economizer harness needed to connect the VFD control board (A183) with the economizer enthalpy controller (A6).
- 7.2. Connect the plug of the harness to the VFD board by inserting it into the open 2-position slot of the VFD control board. Make sure the wire marking of the harness wires (**P, P1**) is aligned with the board marking (**P, P1**). The plug is keyed to only fit into slot one way.
- 7.3. Route the 2-wire economizer harness with the other low voltage wires to the TAA control panel. From there route the harness to the economizer. Route alongside the harness that is coming from the economizer to the TAA control panel.
- 7.4. Remove the jumper between **P** and **P1** terminals on the economizer enthalpy controller **A6**. See figure 13.
- 7.5. Connect the **P** and **P1** wires to the **P** and **P1** terminal on A6 respectively.
- 7.6. Adjust the minimum position potentiometer (MIN POS) on **A6** to fully open (completely clockwise) and cover hole with the .25" dia. plug provided in kit.




Figure 13. A6 Enthalpy Control

8. High Voltage Connections

If you install the VFD kit as an add on installation and the TAA blower coil unit has been wired, please disconnect the line voltage wires and the blower motor wires from the K3 blower contactor. Rewire the **line voltage wires** to the high voltage wires going to the VFD marked **A96-R,S,T**. Rewire the blower motor wires to the high voltage wires coming from the VFD marked **A96-U,V,W** using the large wire nuts provided in kit as shown below.

If this is a new install, please connect the incoming line voltage wires to the high voltage wires going to the VFD marked **A96-R,S,T**. Disconnect the blower motor wires and rewire to the high voltage wires coming from the VFD marked **A96-U,V,W** using the large wire nuts provided in kit as shown below.




Figure 14. High Voltage Connections

IMPORTANT !

The MSAV® supply air blower VFD kit is factory-set to run the blower at full speed when there is a blower (G) demand without a heating or cooling demand.

SET MAXIMUM BLOWER CFM

Use the following procedure to adjust the motor pulley to deliver the full load cooling or heating CFM.

- 1** RUN THE BLOWER WITHOUT A COOLING DEMAND.
- 2** MEASURE THE STATIC PRESSURE EXTERNAL TO THE UNIT.
- 3** MEASURE THE INDOOR BLOWER MOTOR'S RPM.
- 4** USE THE STATIC PRESSURE AND REV/MIN READINGS TO DETERMINE THE UNIT'S AIR VOLUME (SEE APPLICABLE BLOWER PERFORMANCE TABLES).
- 5** LOOSEN THE ALLEN SCREW ON THE ADJUSTABLE PULLEY.
- 6** TURN THE ADJUSTABLE SHEAVE CLOCKWISE TO INCREASE THE AIR VOLUME OR COUNTERCLOCKWISE TO DECREASE THE AIR VOLUME.
- 7** ONCE THE DESIRED AIR VOLUME HAS BEEN ACHIEVED, TIGHTEN THE ALLEN SCREW.

NOTE — THE INDOOR COIL MUST BE DRY AND THE AIR FILTERS MUST BE IN PLACE WHEN THE FOLLOWING MEASUREMENTS ARE TAKEN.

Figure 15. Typical Air Volume Adjustment Procedure

- 1** PLACE BELT OVER ALL THREE PULLEYS.
- 2** USING A 15/16" WRENCH ON THE TENSIONER BODY NUT, APPLY FORCE UNTIL MARKS ALIGN AS SHOWN.
- 3** WHILE HOLDING THE TENSIONER IN THIS POSITION, TIGHTEN THE MOUNTING BOLT TO 23 FT-LBS USING A 9/16" WRENCH.

Figure 16. Typical Blower Belt Tensioner Adjustment Procedure

MSAV® Sequence of Operation

1. Ventilation speed is determined by the VENT SPEED switch setting on VFD control board (LO or HI).
2. Blower operates in low speed for mechanical cooling (Y1).
3. Blower operates in high speed for any other mode (free cooling, mechanical cooling Y1+Y2, and heating).
4. Economizer damper minimum position is fully closed in unoccupied mode.

In occupied mode, the economizer damper minimum position is determined by the setting of the two potentiometers on VFD control board.

- 4.1. LO SPD MIN POS potentiometer sets the minimum position when blower is operating at low speed.
- 4.2. HI SPD MIN POS potentiometer sets the minimum position when blower is operating at high speed.

Units With An Optional Economizer

SET BLOWER SPEED DURING VENTILATION

To save energy during ventilation, the blower speed can be set to low. This is accomplished by changing the ventilation speed switch on the VFD control board to **LO**. See figure 17.

The following sections describe how to set the economizer minimum damper positions only. For other information please refer to the economizer instructions included with the economizer.

STANDARD ECONOMIZER MINIMUM POSITION SETTINGS

Note - AFTER setting minimum positions, set the "VENT SPEED" switch on the VFD control board to the desired speed. See figure 17.




Figure 17. VFD Control Board

1. Set thermostat to occupied mode if the feature available. Make sure a jumper is in place between TB1 terminals R and OC when using a thermostat which does not have this feature. See figure 18.





Figure 18. VFD Control Board

2. **Minimum damper position setting - Low Speed.** Switch the "Vent Speed" switch on the VFD control board to "LO".
3. Turn on the indoor blower using the thermostat or by placing a jumper between TB1 terminals R and G. The inverter or variable frequency drive (VFD) should display "40.00Hz".
4. Adjust the low speed minimum position potentiometer on the VFD control board to the approximate setting. See chart 1.
5. Measure outdoor air temperature. Mark the point on the bottom line of chart 1 and label the point "A" (40°F, 4°C shown).
6. Measure return air temperature. Mark that point on the top line of chart 1 and label the point "B" (74°F, 23°C shown).
7. Measure mixed air (outdoor and return air) temperature. Mark that point on the top line of chart 1 and label point "C" (70°F, 21°C shown).
8. Draw a straight line between points A and B.
9. Draw a vertical line through point C.
10. Draw a horizontal line where the two lines meet. Read the percent of fresh air intake on the side.
11. Repeat steps 4 through 10 until calculation reads desired fresh air percentage. If fresh air percentage is less than desired, adjust MIN POS SET potentiometer clockwise (further open). If fresh air percentage is more than desired, adjust MIN POS SET potentiometer counterclockwise (less open).
12. **Minimum damper position setting - High Speed.** Switch the "Vent Speed" switch on the VFD control board to "HI". The VFD should display "60.00HZ".
13. Adjust the high speed minimum position potentiometer on the VFD control board to the approximate setting. See chart 1.

14. Measure outdoor air temperature. Mark the point on the bottom line of chart 1 and label the point "A" (40°F/4°C shown).
15. Measure return air temperature. Mark that point on the top line of chart 1 and label the point "B" (74°F, 23°C shown).
16. Measure mixed air (outdoor and return air) temperature. Mark that point on the top line of chart and label point "C" (70°F, 21°C shown). 1
17. Draw a straight line between points A and B.
18. Draw a vertical line through point C.
19. Draw a horizontal line where the two lines meet. Read the percent of fresh air intake on the side.
20. Repeat steps 13 through 19 until calculation reads desired fresh air percentage. If fresh air percentage is less than desired, adjust MIN POS SET potentiometer clockwise (further open). If fresh air percentage is more than desired, adjust MIN POS SET potentiometer counterclockwise (less open).
21. *AFTER setting both minimum positions, set the "VENT SPEED" switch on the VFD control board to the desired speed. See figure 17.*



HIGH PERFORMANCE ECONOMIZER MINIMUM POSITION SETTINGS

Note - AFTER setting minimum positions, set the "VENT SPEED" switch on the VFD control board to "LO". See figure 19. Minimum position potentiometers do not function when the unit is equipped with a W7220 economizer control.

1. Set thermostat to occupied mode if the feature is available. Make sure a jumper is in place between TB1 terminals R and OC when using a thermostat which does not have this feature.
2. **Minimum damper position setting - Low Speed**
Switch the blower speed setting on the VFD control board to "LO".
3. Turn on the indoor blower using the thermostat or by placing a jumper between TB1 terminals R and G. The inverter or variable frequency drive (VFD) should display "40.00Hz".

4. Navigate to the "SETPOINTS" menu and select "MIN POS L". Adjust value (2-10VDC) to the approximate desired fresh air percentage and save the input.

- 3.0 VDC - 12% Open Damper
- 3.5 VDC - 18% Open Damper
- 4.0 VDC - 25% Open Damper
- 4.5 VDC - 31% Open Damper
- 5.0 VDC - 37% Open Damper
- 5.5 VDC - 43% Open Damper
- 6.0 VDC - 50% Open Damper

Note - Damper minimum position can be set lower than traditional minimum air requirements when an IAQ sensor is specified.

5. Navigate to the "CHECKOUT" menu and select "VMAX-LS". Press ←.
6. Display will read "DAMPER VMAX-LS RUN?". Press ←.




FIGURE 19

7. Damper will drive to the setpoint value stored in step 4.
8. Measure outdoor air temperature. Mark the point on the bottom line of chart 1 and label the point "A" (40°F, 4°C shown).
9. Measure return air temperature. Mark that point on the top line of chart 1 and label the point "B" (74°F, 23°C shown).
10. Measure mixed air (outdoor and return air) temperature. Mark that point on the top line of chart 1 and label point "C" (70°F, 21°C shown).
11. Draw a straight line between points A and B.
12. Draw a vertical line through point C.
13. Draw a horizontal line where the two lines meet. Read the percent of fresh air intake on the side.
14. Repeat steps 4 through 13 until calculation reads desired fresh air percentage.

If fresh air percentage is less than desired, use the A6 keypad to adjust "MIN POS L" values higher (further open). If fresh air percentage is more than desired, adjust "MIN POS L" values lower (less open).

15. **Minimum damper position setting - High Speed**
Switch the blower speed setting on the VFD control board to "HI". The VFD should display "60.00HZ".
16. Navigate to the "SETPOINTS" menu and select "MIN POS H". Adjust value (2-10VDC) to the approximate desired fresh air percentage.

- 3.0 VDC - 12% Open Damper
- 3.5 VDC - 18% Open Damper
- 4.0 VDC - 25% Open Damper
- 4.5 VDC - 31% Open Damper
- 5.0 VDC - 37% Open Damper
- 5.5 VDC - 43% Open Damper
- 6.0 VDC - 50% Open Damper

Note - Damper minimum position can be set lower than traditional minimum air requirements when an IAQ sensor is specified.

17. Navigate to the "CHECKOUT" menu and select "VMAX-HS". Press ←.
18. Display will read "DAMPER VMAX-HS RUN?". Press ←.
19. Damper will drive to the setpoint value stored in step 16.
20. Measure outdoor air temperature. Mark the point on the bottom line of chart 1 and label the point "A" (40°F, 4°C shown).
21. Measure return air temperature. Mark that point on the top line of chart 1 and label the point "B" (74°F, 23°C shown).
22. Measure mixed air (outdoor and return air) temperature. Mark that point on the top line of chart 1 and label point "C" (70°F, 21°C shown).
23. Draw a straight line between points A and B.
24. Draw a vertical line through point C.
25. Draw a horizontal line where the two lines meet. Read the percent of fresh air intake on the side.
26. Repeat steps 16 through 25 until calculation reads desired fresh air percentage.

If fresh air percentage is less than desired, use the A6 keypad to adjust "MIN POS H" values higher (further open). If fresh air percentage is more than desired, adjust "MIN POS H" values lower (less open).

27. **Set the "VENT SPEED" switch on the VFD control board to "LO".**

DEMAND CONTROL VENTILATION (DCV)

When a 2-10VDC CO₂ sensor is wired to the controller (leads provided), the DCV SET, VENT MIN, and VENT MAX parameters will appear under "SETPOINTS" menu. Navigate to the "SETPOINTS" menu to adjust setpoints as desired. Refer to the Honeywell manual provided for more details.

High Performance Economizer - Sequence of Operation

Refer to tables 2 or 3.

When the outdoor air is suitable and a thermostat demand calls for 1st. stage cooling (Y1), the economizer will modulate the dampers between the minimum and fully open positions to maintain a 55°F (12.8°C) mixed air temperature. When there is an increased thermostat demand for second stage cooling (Y2), the economizer damper opens 100% and the economizer controller (A6) will bring on the compressor. At that point, K8 relay will switch from the R1 mixed air sensor to R51 resistor allowing the economizer damper to stay open 100%. The

damper will stay open 100% with the compressor running simultaneously until Y2 demand is met.

NOTE – Because of the sensor location, the mixed air temperature displayed on the economizer controller (A6) is only true when no mechanical cooling or heating is initiated. During mechanical cooling (compressor running), the MA temperature displayed will be the temperature equivalent of the fixed resistor and not the actual MA temperature.

TROUBLESHOOTING, ALARMS AND CHECKOUT TESTS

Refer to the Honeywell manual provided for details.

**TABLE 2
ECONOMIZER OPERATION - NO DCV (CO₂ SENSOR, 2-SPEED SUPPLY FAN)**

DCV	OA Good to Economize?	Y1-I	Y2-I	Fan Speed	Y1-O	Y2-O	Occupied	Unoccupied
None	No	Off	Off	Low	0-v/Off	0-v/Off	MIN POS L	Closed
		On	Off	Low	24-v/On	0-v/Off	MIN POS L	Closed
		On	On	High	24-v/On	24-v/On	MIN POS H	Closed
None	Yes	Off	Off	Low	0-v/Off	0-v/Off	MIN POS L	Closed
		On	Off	High	0-v/Off	0-v/Off	MIN POS L to Full-Open	Closed to Full-Open
		On	On	High	Delay (b) 24-v/On	0-v/Off	Full-Open	Full-Open

(b) With 2SP FAN DELAY (Advance Setup Menu), when in the economizing mode, there is a delay for the high speed fan to try to satisfy the call for second-stage cooling by turning on the fan to high and opening the OA dampers to 100% before the first-stage mechanical cooling is enabled.

**TABLE 3
ECONOMIZER OPERATION - WITH DCV (CO₂ SENSOR, 2-SPEED SUPPLY FAN)**

DCV	OA Good to Economize?	Y1-I	Y2-I	Fan Speed	Y1-O	Y2-O	Occupied	Unoccupied
Below set	No	Off	Off	Low	0-v/Off	0-v/Off	VENTMIN L	Closed
		On	Off	Low	24-v/On	0-v/Off	VENTMIN L	Closed
		On	On	High	24-v/On	24-v/On	VENTMIN H	Closed
	Yes	Off	Off	Low	0-v/Off	0-v/Off	VENTMIN L	Closed
		On	Off	High	0-v/Off	0-v/Off	VENTMIN L to Full-Open	Closed to Full-Open
		On	On	High	Delay (b) 24-v/On	0-v/Off	Full-Open	Full-Open
Above set	No	Off	Off	Low	0-v/Off	0-v/Off	VENTMIN L to VENTMAX L	Closed
		On	Off	Low	24-v/On	0-v/Off	VENTMIN L to VENTMAX L	Closed
		On	On	High	24-v/On	24-v/On	VENTMIN H to VENTMAX H	Closed
	Yes	Off	Off	Low	0-v/Off	0-v/Off	VENTMIN L to VENTMAX L	Closed
		On	Off	High	0-v/Off	0-v/Off	VENTMIN L to Full-Open	Closed to Full-Open
		On	On	High	Delay (b) 24-v/On	0-v/Off	Full-Open	Full-Open

(b) With 2SP FAN DELAY (Advance Setup Menu), when in the economizing mode, there is a delay for the high speed fan to try to satisfy the call for second-stage cooling by turning on the fan to high and opening the OA dampers to 100% before the first-stage mechanical cooling is enabled.

Blower Performance

TA 090 BLOWER PERFORMANCE

Air Volume cfm	STATIC PRESSURE EXTERNAL TO UNIT - Inches Water Gauge															
	0.1		0.2		0.3		0.4		0.5		0.6		0.7		0.8	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
1600	430	0.52	485	0.62	539	0.71	590	0.77	636	0.83	680	0.88	721	0.94	758	0.99
1700	439	0.55	494	0.65	548	0.74	599	0.80	645	0.86	688	0.91	729	0.97	766	1.03
1800	448	0.58	503	0.68	558	0.77	608	0.83	654	0.89	697	0.95	737	1.01	774	1.08
1900	457	0.62	513	0.72	567	0.80	617	0.86	663	0.93	705	0.99	745	1.06	781	1.12
2000	467	0.65	523	0.75	577	0.83	627	0.90	672	0.96	714	1.03	753	1.10	789	1.17
2100	477	0.68	533	0.78	587	0.86	637	0.93	681	1.00	723	1.08	762	1.15	797	1.22
2200	487	0.72	543	0.82	597	0.90	646	0.97	691	1.05	732	1.12	770	1.20	805	1.27
2300	497	0.75	554	0.85	608	0.94	657	1.01	700	1.09	741	1.17	779	1.25	813	1.32
2400	508	0.79	565	0.89	619	0.98	667	1.06	710	1.14	750	1.23	787	1.30	822	1.38
2500	519	0.83	577	0.94	630	1.02	677	1.10	720	1.19	759	1.28	796	1.36	830	1.43
2600	531	0.87	588	0.98	641	1.07	688	1.16	729	1.25	769	1.34	805	1.42	839	1.49
2700	543	0.92	600	1.03	653	1.12	698	1.21	739	1.31	778	1.40	814	1.48	848	1.55
2800	555	0.97	613	1.08	664	1.17	709	1.27	749	1.37	788	1.46	824	1.54	857	1.62
2900	568	1.02	625	1.13	676	1.22	719	1.32	759	1.43	797	1.52	833	1.60	866	1.68
3000	581	1.07	638	1.18	687	1.28	730	1.39	769	1.49	807	1.58	842	1.67	875	1.75
3100	595	1.12	651	1.24	699	1.34	740	1.45	779	1.56	817	1.65	852	1.73	883	1.82
3200	609	1.18	664	1.30	710	1.41	751	1.52	789	1.63	827	1.72	861	1.80	892	1.89
3300	624	1.24	677	1.36	722	1.48	761	1.59	799	1.70	836	1.79	870	1.88	901	1.97
3400	639	1.30	690	1.43	733	1.55	772	1.67	810	1.77	846	1.86	879	1.95	909	2.05
3500	653	1.37	703	1.50	745	1.62	782	1.75	820	1.85	856	1.94	888	2.03	917	2.14
3600	668	1.44	715	1.57	756	1.70	793	1.83	830	1.93	865	2.02	897	2.12	925	2.24

Air Volume cfm	STATIC PRESSURE EXTERNAL TO UNIT - Inches Water Gauge													
	0.9		1.0		1.1		1.2		1.3		1.4		1.5	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
1600	793	1.05	826	1.1	859	1.15	891	1.21	923	1.27	952	1.34	981	1.42
1700	800	1.09	833	1.15	866	1.20	899	1.26	930	1.33	959	1.40	987	1.48
1800	807	1.13	840	1.19	873	1.25	906	1.31	936	1.38	966	1.46	994	1.54
1900	815	1.18	848	1.24	881	1.30	913	1.36	943	1.44	972	1.52	1000	1.60
2000	823	1.23	856	1.29	889	1.35	921	1.42	951	1.50	979	1.58	1007	1.67
2100	830	1.28	863	1.34	896	1.40	928	1.48	958	1.56	986	1.65	1013	1.74
2200	838	1.33	871	1.39	904	1.46	935	1.54	965	1.63	993	1.72	1020	1.81
2300	846	1.39	880	1.45	912	1.52	943	1.61	972	1.70	999	1.79	1026	1.88
2400	855	1.44	888	1.51	920	1.59	950	1.67	979	1.77	1006	1.86	1033	1.96
2500	863	1.50	896	1.57	928	1.65	958	1.74	986	1.84	1013	1.94	1039	2.04
2600	872	1.56	904	1.64	936	1.72	965	1.82	993	1.92	1019	2.02	1045	2.12
2700	880	1.62	913	1.70	943	1.79	972	1.89	1000	2.00	1026	2.10	1052	2.20
2800	889	1.69	921	1.77	951	1.87	979	1.97	1006	2.08	1033	2.18	1058	2.29
2900	898	1.76	929	1.85	959	1.95	987	2.05	1013	2.16	1039	2.26	1064	2.37
3000	906	1.83	937	1.93	966	2.03	994	2.13	1020	2.24	1046	2.35	1070	2.46
3100	914	1.91	944	2.01	973	2.11	1001	2.22	1027	2.33	1052	2.44	1077	2.55
3200	922	1.99	952	2.09	980	2.20	1008	2.30	1033	2.41	1058	2.53	1083	2.64
3300	930	2.07	959	2.18	987	2.29	1014	2.39	1040	2.50	1065	2.62	1089	2.73
3400	938	2.16	966	2.27	994	2.38	1021	2.49	1046	2.60	1071	2.71	1095	2.83
3500	945	2.26	973	2.37	1001	2.48	1028	2.58	1053	2.69	1077	2.81	1101	2.93
3600	953	2.35	980	2.47	1008	2.58	1034	2.68	1059	2.79	1084	2.91	1107	3.03

TA 120 BLOWER PERFORMANCE

Air Volume cfm	STATIC PRESSURE EXTERNAL TO UNIT - Inches Water Gauge															
	0.1		0.2		0.3		0.4		0.5		0.6		0.7		0.8	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
2200	428	0.09	463	0.2	501	0.32	541	0.45	585	0.60	632	0.75	674	0.84	712	0.88
2400	441	0.19	476	0.29	513	0.41	553	0.54	596	0.68	642	0.82	681	0.9	715	0.94
2600	455	0.29	489	0.39	525	0.50	565	0.63	608	0.77	654	0.90	687	0.96	720	1.01
2800	469	0.40	502	0.49	538	0.60	577	0.72	621	0.85	667	0.99	693	1.03	727	1.09
3000	484	0.51	516	0.60	552	0.70	591	0.82	635	0.95	677	1.07	699	1.10	736	1.18
3200	499	0.62	531	0.70	566	0.80	606	0.92	651	1.06	684	1.15	707	1.18	746	1.28
3400	514	0.73	546	0.81	582	0.91	622	1.03	667	1.17	690	1.22	717	1.28	758	1.40
3600	529	0.84	562	0.93	598	1.03	639	1.15	679	1.28	697	1.31	730	1.40	772	1.52
3800	545	0.96	579	1.05	616	1.15	658	1.28	686	1.37	706	1.41	745	1.53	786	1.65
4000	562	1.09	596	1.18	634	1.29	674	1.41	693	1.46	720	1.54	761	1.67	802	1.79
4200	580	1.23	615	1.31	654	1.42	684	1.52	702	1.57	737	1.69	778	1.82	819	1.94
4400	600	1.37	635	1.45	672	1.56	691	1.62	717	1.72	756	1.86	796	1.98	836	2.09
4600	619	1.51	655	1.59	683	1.68	702	1.76	736	1.89	775	2.02	814	2.13	853	2.24
4800	639	1.65	673	1.73	692	1.81	719	1.93	757	2.08	795	2.19	832	2.30	871	2.40
5000	659	1.78	685	1.87	706	1.97	740	2.12	778	2.26	814	2.37	851	2.46	889	2.56

Air Volume cfm	STATIC PRESSURE EXTERNAL TO UNIT - Inches Water Gauge													
	0.9		1.0		1.1		1.2		1.3		1.4		1.5	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
2200	751	0.96	795	1.08	839	1.21	884	1.34	928	1.48	971	1.61	1014	1.73
2400	755	1.03	801	1.16	847	1.29	892	1.43	936	1.56	981	1.70	1024	1.83
2600	762	1.11	808	1.24	855	1.38	901	1.52	946	1.65	990	1.79	1034	1.92
2800	770	1.20	816	1.33	863	1.47	910	1.61	955	1.75	1000	1.88	1044	2.01
3000	779	1.29	826	1.42	873	1.56	919	1.70	964	1.84	1009	1.98	1054	2.11
3200	790	1.40	836	1.53	882	1.66	929	1.80	974	1.94	1019	2.07	1063	2.21
3400	802	1.51	847	1.64	893	1.77	938	1.91	983	2.04	1028	2.17	1072	2.31
3600	815	1.64	859	1.76	904	1.89	949	2.03	993	2.16	1037	2.29	1080	2.42
3800	829	1.77	873	1.90	917	2.03	961	2.16	1005	2.29	1048	2.42	1090	2.55
4000	845	1.91	888	2.04	932	2.17	975	2.31	1018	2.43	1060	2.56	1102	2.69
4200	861	2.06	904	2.19	948	2.32	990	2.46	1033	2.59	1074	2.71	1116	2.84
4400	878	2.21	921	2.34	963	2.47	1006	2.60	1048	2.73	1089	2.86	1130	2.98
4600	894	2.36	936	2.49	979	2.61	1021	2.74	1063	2.87	1104	3.00	1145	3.12
4800	911	2.51	953	2.63	995	2.76	1036	2.88	1078	3.01	1119	3.13	1161	3.26
5000	928	2.67	969	2.78	1011	2.90	1052	3.03	1094	3.15	1135	3.27	1176	3.40

TA 150 BLOWER PERFORMANCE

Air Volume cfm	STATIC PRESSURE EXTERNAL TO UNIT - Inches Water Gauge															
	0.1		0.2		0.3		0.4		0.5		0.6		0.7		0.8	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
2800	500	0.49	537	0.59	578	0.72	622	0.86	668	0.99	694	1.03	729	1.10	771	1.20
3000	519	0.60	556	0.71	597	0.83	642	0.97	681	1.08	704	1.11	743	1.20	785	1.30
3200	538	0.71	576	0.82	618	0.95	663	1.10	690	1.15	717	1.21	758	1.31	800	1.42
3400	558	0.83	597	0.95	640	1.09	680	1.21	698	1.24	734	1.33	776	1.44	818	1.55
3600	579	0.97	620	1.09	664	1.23	689	1.30	712	1.35	753	1.47	795	1.58	837	1.69
3800	602	1.11	644	1.24	681	1.35	698	1.39	731	1.49	773	1.61	815	1.72	857	1.84
4000	627	1.26	669	1.39	690	1.45	714	1.52	754	1.65	795	1.76	835	1.87	877	1.98
4200	653	1.42	684	1.52	701	1.57	736	1.69	777	1.82	816	1.92	856	2.02	897	2.13
4400	676	1.57	694	1.63	721	1.73	761	1.87	800	1.99	838	2.08	877	2.18	917	2.28
4600	688	1.70	710	1.79	747	1.93	787	2.06	823	2.16	860	2.24	898	2.33	938	2.43
4800	702	1.85	735	1.99	774	2.14	812	2.25	846	2.32	882	2.40	920	2.49	959	2.58
5000	725	2.06	763	2.21	801	2.34	837	2.44	869	2.49	903	2.55	941	2.64	979	2.73
5200	754	2.30	791	2.43	828	2.55	862	2.63	891	2.66	925	2.71	962	2.79	1000	2.88
5400	783	2.53	819	2.65	855	2.75	887	2.82	913	2.82	946	2.86	983	2.95	1021	3.03
5600	810	2.74	845	2.85	881	2.95	912	3.01	935	2.98	967	3.01	1004	3.10	1041	3.19
5800	835	2.95	871	3.05	906	3.15	936	3.19	957	3.14	987	3.16	1024	3.25	1062	3.34
6000	860	3.14	896	3.25	931	3.35	960	3.37	978	3.30	1008	3.31	1045	3.40	1083	3.48

T

Air Volume cfm	STATIC PRESSURE EXTERNAL TO UNIT - Inches Water Gauge															
	0.9		1.0		1.1		1.2		1.3		1.4		1.5			
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP		
2800	815	1.31	862	1.43	908	1.56	954	1.68	999	1.81	1043	1.93	1087	2.05		
3000	829	1.41	875	1.53	921	1.66	966	1.78	1011	1.91	1056	2.03	1100	2.15		
3200	844	1.53	889	1.65	934	1.77	979	1.89	1024	2.01	1067	2.14	1111	2.26		
3400	862	1.66	906	1.78	950	1.90	994	2.02	1038	2.14	1081	2.26	1124	2.38		
3600	881	1.81	925	1.93	968	2.05	1011	2.17	1054	2.29	1097	2.41	1139	2.53		
3800	900	1.96	944	2.08	987	2.20	1030	2.32	1072	2.44	1114	2.56	1156	2.67		
4000	920	2.10	963	2.22	1006	2.34	1048	2.46	1091	2.58	1133	2.69	1174	2.81		
4200	939	2.24	982	2.36	1024	2.48	1067	2.59	1109	2.71	1151	2.83	1193	2.95		
4400	959	2.39	1001	2.50	1043	2.61	1085	2.73	1127	2.85	1169	2.96	1211	3.08		
4600	979	2.53	1020	2.64	1062	2.76	1104	2.87	1146	2.99	1188	3.10	1230	3.22		
4800	999	2.68	1040	2.79	1082	2.90	1123	3.01	1165	3.12	1207	3.24	1248	3.35		
5000	1019	2.83	1060	2.93	1101	3.04	1142	3.15	1184	3.26	1226	3.38	1267	3.49		
5200	1040	2.98	1080	3.08	1121	3.19	1162	3.29	1203	3.41	1245	3.52	1286	3.63		
5400	1060	3.13	1100	3.23	1140	3.33	1181	3.44	1222	3.55	1264	3.66	1305	3.77		
5600	1080	3.28	1120	3.37	1160	3.48	1201	3.58	1242	3.69	1283	3.80	1324	3.91		
5800	1101	3.43	1140	3.52	1180	3.62	1220	3.72	1261	3.83	1302	3.94	1343	4.05		
6000	1121	3.57	1160	3.67	1200	3.77	1240	3.87	1280	3.97	1321	4.08	1362	4.19		

TA 180 BLOWER PERFORMANCE

Air Volume cfm	STATIC PRESSURE EXTERNAL TO UNIT - Inches Water Gauge															
	0.1		0.2		0.3		0.4		0.5		0.6		0.7		0.8	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
3400	393	0.60	439	0.81	486	1.00	533	1.16	579	1.28	624	1.41	667	1.56	708	1.71
3600	398	0.66	444	0.87	491	1.06	538	1.21	583	1.33	628	1.47	671	1.62	711	1.79
3800	403	0.72	449	0.92	496	1.11	542	1.26	587	1.39	632	1.53	675	1.69	715	1.86
4000	408	0.78	454	0.98	501	1.17	547	1.32	592	1.45	636	1.60	679	1.76	718	1.94
4200	413	0.84	459	1.04	506	1.23	552	1.38	597	1.52	641	1.67	683	1.84	722	2.03
4400	419	0.90	465	1.10	512	1.29	558	1.44	602	1.58	645	1.74	687	1.92	726	2.12
4600	424	0.97	470	1.17	517	1.35	563	1.50	607	1.65	651	1.82	692	2.01	730	2.21
4800	430	1.03	476	1.23	523	1.42	569	1.57	613	1.73	656	1.90	697	2.10	735	2.31
5000	436	1.09	482	1.30	530	1.49	575	1.64	619	1.81	661	1.99	702	2.19	739	2.42
5200	442	1.15	489	1.37	536	1.56	582	1.72	625	1.89	667	2.08	707	2.29	744	2.52
5400	448	1.21	495	1.44	543	1.64	588	1.80	631	1.98	673	2.18	712	2.40	749	2.63
5600	454	1.28	502	1.52	550	1.72	595	1.89	638	2.08	679	2.28	718	2.51	754	2.75
5800	460	1.35	510	1.60	558	1.80	602	1.98	645	2.18	686	2.39	724	2.62	759	2.87
6000	467	1.43	517	1.68	566	1.89	610	2.07	652	2.28	692	2.50	729	2.74	764	2.99
6200	475	1.51	526	1.78	574	1.98	617	2.17	659	2.39	699	2.61	735	2.86	770	3.12
6400	483	1.60	534	1.87	582	2.08	625	2.28	666	2.50	705	2.73	741	2.99	775	3.25
6600	491	1.70	544	1.97	591	2.18	633	2.39	674	2.62	712	2.86	747	3.12	781	3.38
6800	501	1.81	553	2.08	600	2.29	642	2.51	682	2.74	719	2.99	753	3.26	786	3.52
7000	511	1.92	563	2.19	609	2.40	650	2.63	689	2.87	725	3.13	759	3.40	792	3.66
7200	521	2.04	573	2.30	618	2.52	659	2.76	697	3.01	732	3.27	765	3.54	798	3.80



Air Volume cfm	STATIC PRESSURE EXTERNAL TO UNIT - Inches Water Gauge															
	0.9		1.0		1.1		1.2		1.3		1.4		1.5			
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP		
3400	746	1.87	783	2.02	819	2.16	857	2.31	897	2.48	936	2.65	976	2.83		
3600	749	1.95	786	2.11	822	2.26	860	2.42	900	2.58	939	2.76	979	2.93		
3800	752	2.04	789	2.21	825	2.36	863	2.52	903	2.69	943	2.86	983	3.04		
4000	756	2.13	792	2.30	829	2.47	867	2.63	906	2.80	946	2.97	986	3.15		
4200	759	2.22	795	2.40	832	2.57	870	2.74	910	2.91	950	3.08	990	3.26		
4400	763	2.32	799	2.51	836	2.68	874	2.85	913	3.02	953	3.19	993	3.37		
4600	767	2.42	803	2.61	840	2.79	878	2.96	917	3.13	957	3.31	997	3.48		
4800	771	2.53	807	2.72	844	2.91	882	3.08	921	3.25	961	3.42	1001	3.59		
5000	775	2.63	811	2.84	848	3.02	886	3.20	925	3.37	965	3.54	1005	3.71		
5200	780	2.75	815	2.95	852	3.14	890	3.32	929	3.49	969	3.67	1009	3.84		
5400	784	2.86	820	3.07	857	3.26	895	3.44	934	3.62	974	3.80	1014	3.97		
5600	789	2.98	824	3.19	861	3.38	900	3.57	939	3.75	978	3.93	1018	4.11		
5800	794	3.10	829	3.32	866	3.51	905	3.70	944	3.88	983	4.07	1023	4.25		
6000	799	3.23	834	3.44	871	3.64	910	3.83	949	4.02	988	4.21	1028	4.40		
6200	804	3.36	839	3.57	876	3.77	915	3.97	954	4.16	994	4.35	1033	4.55		
6400	809	3.49	844	3.70	881	3.90	920	4.10	960	4.30	999	4.50	1039	4.70		
6600	815	3.62	850	3.83	887	4.04	926	4.24	965	4.45	1005	4.65	1044	4.85		
6800	820	3.76	855	3.97	892	4.18	931	4.39	971	4.59	1011	4.80	1050	5.01		
7000	826	3.89	861	4.11	898	4.32	937	4.53	977	4.74	1016	4.95	1056	5.16		
7200	831	4.03	866	4.25	904	4.46	943	4.67	982	4.89	1022	5.10	1062	5.32		

TA 240 BLOWER PERFORMANCE

Air Volume cfm	STATIC PRESSURE EXTERNAL TO UNIT - Inches Water Gauge															
	0.1		0.2		0.3		0.4		0.5		0.6		0.7		0.8	
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP
4400	449	1.05	493	1.22	539	1.38	584	1.52	628	1.68	670	1.85	711	2.04	748	2.24
4600	456	1.11	501	1.29	546	1.45	591	1.60	635	1.76	677	1.94	717	2.14	754	2.35
4800	463	1.17	509	1.36	554	1.53	599	1.68	642	1.85	684	2.03	723	2.24	760	2.46
5000	471	1.24	517	1.44	563	1.60	607	1.76	650	1.94	691	2.14	729	2.35	766	2.58
5200	479	1.32	525	1.52	571	1.69	615	1.85	657	2.04	698	2.24	736	2.47	772	2.70
5400	487	1.40	534	1.60	580	1.77	623	1.95	665	2.14	705	2.36	743	2.59	778	2.82
5600	496	1.48	544	1.69	589	1.87	632	2.05	674	2.25	713	2.48	749	2.72	785	2.95
5800	506	1.58	554	1.79	599	1.96	641	2.16	682	2.37	720	2.60	756	2.85	791	3.08
6000	516	1.68	564	1.89	608	2.07	650	2.27	691	2.49	728	2.73	763	2.98	798	3.22
6200	527	1.78	574	1.99	618	2.18	660	2.39	699	2.62	736	2.87	771	3.12	805	3.36
6400	538	1.89	585	2.09	628	2.29	669	2.51	708	2.75	743	3.01	778	3.26	812	3.50
6600	550	2.00	596	2.21	638	2.41	679	2.64	716	2.89	751	3.15	785	3.41	819	3.65
6800	562	2.12	607	2.33	649	2.54	688	2.78	725	3.04	759	3.30	793	3.56	826	3.79
7000	574	2.24	619	2.45	659	2.68	698	2.93	733	3.19	767	3.46	800	3.71	834	3.95
7200	587	2.36	630	2.59	670	2.83	707	3.08	742	3.34	775	3.61	808	3.87	841	4.10
7400	600	2.50	642	2.73	680	2.98	717	3.23	750	3.50	783	3.77	815	4.03	849	4.25
7600	612	2.64	653	2.88	691	3.13	726	3.40	759	3.67	791	3.94	823	4.19	856	4.41
7800	625	2.79	664	3.03	701	3.29	735	3.56	767	3.84	799	4.10	831	4.35	864	4.56
8000	638	2.94	676	3.20	711	3.46	744	3.73	776	4.01	807	4.27	839	4.51	872	4.72
8200	650	3.11	687	3.36	721	3.63	753	3.91	784	4.18	815	4.44	847	4.67	880	4.88
8400	662	3.27	698	3.54	731	3.81	762	4.08	793	4.36	823	4.61	855	4.84	888	5.04
8600	674	3.45	708	3.72	740	3.99	771	4.26	801	4.54	832	4.79	863	5.00	896	5.20
8800	685	3.63	719	3.90	750	4.17	780	4.45	809	4.72	840	4.96	871	5.17	904	5.36
9000	697	3.81	729	4.09	759	4.36	788	4.63	818	4.90	848	5.13	880	5.34	913	5.52
9200	708	4.00	739	4.28	768	4.55	797	4.82	826	5.08	857	5.30	888	5.50	921	5.69
9400	718	4.20	748	4.47	777	4.74	806	5.01	835	5.26	865	5.48	897	5.67	929	5.85
9600	729	4.39	758	4.67	786	4.94	814	5.20	843	5.44	874	5.65	905	5.84	938	6.01

Air Volume cfm	STATIC PRESSURE EXTERNAL TO UNIT - Inches Water Gauge															
	0.9		1.0		1.1		1.2		1.3		1.4		1.5			
	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP		
4400	785	2.44	821	2.61	858	2.78	897	2.93	936	3.09	977	3.24	1017	3.40		
4600	790	2.55	826	2.73	864	2.90	902	3.06	942	3.21	982	3.37	1022	3.53		
4800	796	2.66	832	2.85	869	3.02	908	3.18	948	3.34	988	3.50	1028	3.66		
5000	801	2.79	837	2.97	875	3.14	914	3.31	954	3.48	994	3.64	1034	3.81		
5200	807	2.91	843	3.10	881	3.27	920	3.45	960	3.62	1000	3.79	1040	3.96		
5400	813	3.04	850	3.23	888	3.41	927	3.58	967	3.76	1007	3.94	1047	4.11		
5600	820	3.17	856	3.36	894	3.54	934	3.73	974	3.91	1014	4.09	1053	4.27		
5800	826	3.30	863	3.49	901	3.68	941	3.87	981	4.06	1021	4.24	1060	4.43		
6000	833	3.43	869	3.63	908	3.82	948	4.01	988	4.21	1028	4.40	1068	4.59		
6200	840	3.57	876	3.77	915	3.96	955	4.16	995	4.36	1035	4.55	1075	4.75		
6400	847	3.71	883	3.91	922	4.11	962	4.31	1002	4.51	1042	4.71	1082	4.91		
6600	854	3.86	890	4.06	929	4.25	969	4.45	1009	4.66	1049	4.86	1089	5.06		
6800	861	4.00	898	4.20	936	4.40	976	4.60	1016	4.80	1056	5.00	1096	5.20		
7000	868	4.15	905	4.35	943	4.54	983	4.74	1023	4.94	1063	5.14	1103	5.34		
7200	876	4.30	912	4.50	950	4.69	990	4.88	1030	5.08	1070	5.28	1110	5.48		
7400	883	4.45	920	4.64	958	4.83	997	5.03	1037	5.22	1077	5.42	1117	5.62		
7600	891	4.61	927	4.79	965	4.98	1004	5.17	1044	5.37	1084	5.56	1124	5.76		
7800	899	4.76	935	4.95	973	5.13	1012	5.32	1051	5.51	1091	5.71	1131	5.90		
8000	907	4.91	943	5.10	980	5.28	1019	5.47	1059	5.66	1098	5.85	1138	6.04		
8200	914	5.07	950	5.25	988	5.43	1027	5.62	1066	5.80	1106	5.99	1145	6.18		
8400	922	5.23	958	5.41	996	5.58	1034	5.77	1073	5.95	1113	6.14	1153	6.33		
8600	930	5.38	966	5.56	1003	5.74	1042	5.92	1081	6.10	1120	6.28	1160	6.47		
8800	938	5.54	974	5.71	1011	5.89	1049	6.07	1088	6.25	1128	6.43	1167	6.62		
9000	947	5.70	982	5.87	1019	6.04	1057	6.22	1096	6.40	1135	6.58	1175	6.76		
9200	955	5.86	990	6.03	1027	6.20	1065	6.37	1104	6.54	1143	6.72	1182	6.91		
9400	963	6.02	998	6.18	1035	6.35	1073	6.52	1111	6.69	1150	6.87	1190	7.05		
9600	971	6.18	1007	6.34	1043	6.50	1081	6.67	1119	6.84	1158	7.02	1197	7.20		

Wiring Diagrams



KEY	COMPONENT
A96	CONTROL INVERTER
A183	CONTROL VFD BOARD
B3	MOTOR-BLOWER
J7	JACK-ELECT HT SUB-BASE KIT
K3,-1	RELAY-BLOWER
K43,-1	RELAY-ECONOMIZER BLOWER
K220,-1	RELAY-OVERFLOW
K232,-1	RELAY-INVERTER PROTECTION
P7	PLUG-ELECT HT SUB-BASE KIT
S49	SWITCH-FREEZESTAT COMPRESSOR 1
S50	SWITCH-FREEZESTAT COMPRESSOR 2
S149	SWITCH-OVERFLOW
TB1	TERMINAL STRIP-CLASS II VOLT

IF ANY WIRE IN THIS APPLIANCE IS REPLACED, IT MUST BE REPLACED WITH WIRE OF LIKE SIZE, RATING, INSULATION THICKNESS AND TERMINATION

WARNING-ELECTRIC SHOCK HAZARD, CAN CAUSE INJURY OR DEATH. UNIT MUST BE GROUNDED IN ACCORDANCE WITH NATIONAL AND LOCAL CODES

DISCONNECT ALL POWER BEFORE SERVICING

← DENOTES OPTIONAL COMPONENTS

- △ S149 SWITCH AND K220 RELAY MAY BE FIELD SUPPLIED OR USE AVAILABLE KIT
- △ S50 USED ON TWO STAGE UNITS
- △ FOR USE WITH COPPER CONDUCTORS ONLY
- △ MITSUBISHI VFD




04/12		WIRING DIAGRAM	04/12
		537531-01	
BLOWER			
TAA 090 - 240 -G,J,Y WITH VFD ID BLOWER			
SECTION B1		REV 0	
Supersedes	New Form No.		
	537531-01		

Figure 20. TAA090 - 240 G, J, Y with VFD ID Blower (with 24VAC on TB1 Terminal)



KEY	COMPONENT
A96	CONTROL INVERTER
A183	CONTROL VFD BOARD
B3	MOTOR-BLOWER
J7	JACK-ELECT HT SUB-BASE KIT
K3,-1	RELAY- BLOWER
K43,-1	RELAY-ECONOMIZER BLOWER
K220,-1	RELAY-OVERFLOW
K232,-1	RELAY-INVERTER PROTECTION
P7	PLUG-ELECT HT SUB-BASE KIT
S49	SWITCH-FREEZESTAT COMPRESSOR 1
S50	SWITCH-FREEZESTAT COMPRESSOR 2
S149	SWITCH-OVERFLOW
TB1	TERMINAL STRIP-CLASS II VOLT

IF ANY WIRE IN THIS APPLIANCE IS REPLACED, IT MUST BE REPLACED WITH WIRE OF LIKE SIZE, RATING, INSULATION THICKNESS AND TERMINATION

WARNING-ELECTRIC SHOCK HAZARD, CAN CAUSE INJURY OR DEATH. UNIT MUST BE GROUNDED IN ACCORDANCE WITH NATIONAL AND LOCAL CODES

DISCONNECT ALL POWER BEFORE SERVICING

← DENOTES OPTIONAL COMPONENTS

- ⚠ S149 SWITCH AND K220 RELAY MAY BE FIELD SUPPLIED OR USE AVAILABLE KIT
- ⚠ S50 USED ON TWO STAGE UNITS
- ⚠ FOR USE WITH COPPER CONDUCTORS ONLY
- ⚠ MITSUBISHI VFD



04/12		WIRING DIAGRAM	04/12
		537532-01	
BLOWER			
TAA 090 - 240 -G,J,Y WITH VFD ID BLOWER			
SECTION B1		REV 0	
Supersedes		New Form No. 537532-01	
© 2012		Lennox Commercial	

Figure 21. TAA090 - 240 G, J, Y with VFD ID Blower (without 24VAC on TB1 Terminal)



KEY	COMPONENT
A2	SENSOR-ELECTRONIC
A63	SENSOR-CO2
J3	JACK-UNIT ECONOMIZER
P3	PLUG-LESS ECONOMIZER
RT2	SENSOR-REMOTE
TB1	TERMINAL STRIP-CLASS II VOLTAGE

- △ THERMOSTAT SUPPLIED BY USER
- △ REMOVE P3 WHEN ECONOMIZER IS USED
- △ J3 MAXIMUM LOAD 20VA 24VAC CLASS II

————— DESIGNATES OPTIONAL WIRING
 - - - - - CLASS II FIELD WIRING


03/14		WIRING DIAGRAM	03/14
		537533-01	
ACCESSORIES			
TOUCHSCREEN THERMOSTAT TSA, TPA UNITS WITH VFD ID BLOWER			
SECTION C			REV. 1
Supersedes	New Form No.		
535, 775W	537533-01		

Figure 22. Touch Screen Thermostat - TSA and TPA Units with VFD ID Blower

TROUBLESHOOT VFD CONTROL BOARD (A183)

Refer to wiring diagrams located at the end of this instruction.

1. Inspect the VFD control board for damaged components. Replace the control board if damaged components are found.
2. Check all wire connections to VFD control board; secure if loose.
3. Check for 24VAC signal at the thermostat blower input (G to GND terminal).




Figure 23. VFD Control Board Terminal Designations

4. If there is no thermostat signal, troubleshoot back toward the thermostat.
5. Check the power LED on the board. See figure 17.

6. If the power LED is not on, check voltage between VFD control board terminals PC (H2-1) and SD (H2-5). Voltage should read 24VDC.
7. If voltage does not read 24VDC, disconnect the H2 header from the VFD control board inputs terminal block (to make sure the VFD control board is not shorting 24VDC supply from the inverter). Measure the voltage between the end terminals on the H2 header. If 24VDC is present, replace the VFD control board. If no voltage is read, troubleshoot the VFD.
8. When VFD control board 24VAC thermostat blower (G) input and 24VDC power are present, check the VFD control board low and high speed outputs. The VFD control board uses inverse logic to enable the blower; 1VDC will be read at the enabled blower speed terminal. See table 4.
9. If all inputs are correct and the unit still does not operate as intended, replace VFD control board.

Table 4. VFD Control Board Blower Output

Output Terminals	Voltage	Blower Operation
RL-SD	1VDC	Low Speed
RH-SD	24VDC	
RL-SD	24VDC	High Speed
RH-SD	1VDC	
RL-SD	1VDC	Illegal State (replace board)
RH-SD	1VDC	
RL-SD	24VDC	Blower Off (replace board)
RH-SD	24VDC	