

## INSTALLATION INSTRUCTIONS A93UH1EK & 92G1UHEK

Warm Air Gas Furnace Upflow/Horizontal Left/Right Air Discharge Direct Vent & Non-Direct Vent

This manual must be left with the homeowner for future reference.

This is a safety alert symbol and should never be ignored. When you see this symbol on labels or in manuals, be alert to the potential for personal injury or death.

### 

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a licensed professional installer (or equivalent), service agency or the gas supplier.

### 

As with any mechanical equipment, personal injury can result from contact with sharp sheet metal edges. Be careful when you handle this equipment.

### 

This furnance is equipped with an ignition control factory enabled for use with Allied A2L refrigerant systems. Disabling the refrigerant detection functionality on A2L system is prohibited by safety codes. Refer to furnace installation instructions for non-A2L and non-Allied refrigerant system setup.


> Manufactured By Allied Air Enterprises LLC 215 Metropolitan Drive West Columbia, SC 29170

### Table of Contents

| Unit Dimensions                                  | 2  |
|--|----|
| Parts Arrangement                                | 3  |
| Gas Furnace                                      | 4  |
| Shipping and Packing List                        | 4  |
| Safety Information                               | 4  |
| General  | 6  |
| Combustion, Dilution & Ventilation Air           | 7  |
| Installation                                     |    |
| Filters  | 13 |
| Duct System                                      | 13 |
| Venting Practices                                | 16 |
| Condensate Piping                                |    |
| Gas Piping                                       |    |
| Electrical                                       |    |
| Ignition Control                                 |    |
| Twinning   |    |
| Low GWP Application                              |    |
| Unit Start-Up                                    |    |
| Testing for Proper Venting and Sufficient Combus |    |
| Air for Non-Direct Vent Applications             |    |
| Other Unit Adjustments                           |    |
| Blower Performance                               |    |
| Service  |    |
| Planned Service                                  |    |
| Repair Parts List                                | 58 |

## (P) 508616-01

### **Unit Dimensions**



| Madal                            | Madel Cooling                    |        | А   |        | В   |        | )   | D     |     |  |
|----------------------------------|----------------------------------|--------|-----|--------|-----|--------|-----|-------|-----|--|
| Model                            | Capacity                         | in.    | mm  | in.    | mm  | in.    | mm  | in.   | mm  |  |
| 030-В<br>040-В<br>070-В          | 3 ton<br>3 ton<br>3 ton          | 17-1/2 | 446 | 16-3/8 | 416 | 16     | 406 | 1-5/8 | 194 |  |
| 090-C<br>090-C<br>110-C<br>110-C | 3 ton<br>4 ton<br>4 ton<br>5 ton | 21     | 533 | 19-7/8 | 505 | 19-1/2 | 495 | 9-3/8 | 238 |  |

### **Parts Arrangement**




Figure 1.

### Gas Furnace

The A93UH1EK & 92G1UHEK Category IV gas furnace is shipped ready for installation in the upflow or horizontal position. The furnace is shipped with the bottom panel in place. The bottom panel must be removed if the unit is to be installed in horizontal or upflow applications with bottom return air.

The A93UH1EK & 92G1UHEK can be installed as either a Direct Vent or a Non-Direct Vent gas central furnace

The furnace is equipped for installation in natural gas applications. A conversion kit (ordered separately) is required for use in propane/LP gas applications.

**NOTE:** In Direct Vent installations, combustion air is taken from outdoors and flue gases are discharged outdoors. In Non-Direct Vent installations, combustion air is taken from indoors and flue gases are discharged outdoors. See Figure 2 and Figure 3 for applications involving roof termination.




Figure 2.




Figure 3.

### **Shipping and Packing List**

- 1 Assembled Gas Furnace
- 1 Bag assembly containing the following:
  - 1 Snap bushing
  - 1 Snap Plug
  - 1 Wire tie
  - 1 Condensate trap
  - 1 Condensate trap cap
  - 1 Condensate trap clamp
  - 1 2" diameter debris screen
  - 1 3/4" Threaded street elbow

RDS Sensor kit can be ordered separately and is field installed.

Check equipment for shipping damage. If you find any damage, immediately contact the last carrier.

Please refer to specification sheets for available accessories

### **Safety Information**

### 

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a licensed professional installer (or equivalent), service agency or the gas supplier.

### 

As with any mechanical equipment, personal injury can result from contact with sharp sheet metal edges. Be careful when you handle this equipment.

### 

### DANGER OF EXPLOSION!

There are circumstances in which odorant used with LP/Propane gas can lose its scent. In case of a leak, LP/Propane gas will settle close to the floor and may be difficult to smell. An LP/Propane leak detector should be installed in all LP applications.

Use only the type of gas approved for use with this furnace. Refer to unit nameplate.

A93UH1EK & 92G1UHEK units are CSA International certified to ANSI Z21.47 and CSA 2.3 standards.

### **Building Codes**

In the USA, installation of gas furnaces must conform with local building codes. In the absence of local codes, units must be installed according to the current National Fuel Gas Code (ANSI Z223.1/NFPA 54). The National Fuel Gas Code is available from the American National Standards Institute, Inc., 11 West 42nd Street, New York, NY 10036.

In Canada, installation must conform with current National Standard of Canada CSA-B149 Natural Gas and Propane Installation Codes, local plumbing or waste water codes and other applicable local codes.

In order to ensure proper unit operation in non-direct vent applications, combustion and ventilation air supply must be provided according to the current National Fuel Gas Code or CSA-B149 standard.

### Installation Locations

This furnace is CSA International certified for installation clearances to combustible material as listed on the unit nameplate and in the table in Figure 13 and Figure 18. Installers should also consider the greater of either accessibility/service clearances or fire protection clearances.

**NOTE:** For installation on combustible floors, the furnace shall not be installed directly on carpeting, tile, or other combustible material other than wood flooring.

For installation in a residential garage, the furnace must be installed so that the burner(s) and the ignition source are located no less than 18 inches (457 mm) above the floor. The furnace must be located or protected to avoid physical damage by vehicles. When a furnace is installed in a public garage, hangar, or other building that has a hazardous atmosphere, the furnace must be installed according to recommended good practice requirements and current National Fuel Gas Code or CSA B149 standards.

**NOTE:** Furnace must be adjusted to obtain a temperature rise within the range specified on the unit nameplate. Failure to do so may cause erratic limit operation and premature heat exchanger failure.

This furnace must be installed so that its electrical components are protected from water.


### Installed in Combination with a Cooling Coil

When this furnace is used with cooling units (Figure 4), it shall be installed in parallel with, or on the upstream side of, cooling units to avoid condensation in the heating compartment. With a parallel flow arrangement, a damper (or other means to control the flow of air) must adequately prevent chilled air from entering the furnace. If the damper is manually operated, it must be equipped to prevent operation of either the heating or the cooling unit, unless it is in the full HEAT or COOL setting.

When installed, this furnace must be electrically grounded according to local codes. In addition, in the United States, installation must conform with the current National Electric Code, ANSI/NFPA No. 70. The National Electric Code (ANSI/NFPA No. 70) is available from the following address:

National Fire Protection Association 1 Battery March Park Quincy, MA 02269

In Canada, all electrical wiring and grounding for the unit must be installed according to the current regulations of the Canadian Electrical Code Part I (CSA Standard C22.1) and/or local codes.



### Figure 4. Heating Unit Installed Parallel to Air Handler Unit

**NOTE:** This furnace is designed for a minimum continuous return air temperature of  $60^{\circ}$ F ( $16^{\circ}$ C) or an intermittent operation down to  $55^{\circ}$ F ( $13^{\circ}$ C) dry bulb for cases where a night setback thermostat is used. Return air temperature must not exceed  $85^{\circ}$ F ( $29^{\circ}$ C) dry bulb.

This furnace may be installed in alcoves, closets, attics, basements, garages, and utility rooms in the upflow or horizontal position.

This furnace design has not been CSA certified for installation in mobile homes, recreational vehicles, or outdoors.

### Use of Furnace as a Construction Heater

Units may be used for heating of buildings or structures under construction, if the following conditions are met to ensure proper operation.

#### DO NOT USE THE UNIT FOR CONSTRUCTION HEAT UNLESS ALL OF THE FOLLOWING CRITERIA ARE MET:

- a. Furnace must be in its final location. The vent system must be permanently installed per these installation instructions.
- b. Furnace must be installed as a two pipe system and one hundred percent (100%) outdoor air must be provided for combustion air requirements during construction.
- c. A room thermostat must control the furnace. The use of fixed jumpers that will provide continuous heating is prohibited.
- d. The input rate and temperature rise must be set per the furnace rating plate.
- e. Supply and Return air ducts must be provided and sealed to the furnace. Return air must be terminated outside of the space where furnace is installed.
- f. The refrigerant leak detection sensor must be inspected for dust/debris deposits. Please refer to the evaporator coil and/or refrigerant detection sensor kit instructions for additional information.
- g. Return air temperature range between 60°F (16°C) and 80°F (27°C) must be maintained.
- h. MERV 11 or greater air filters must be installed in the system and must be regularly inspected and maintained (e.g., regular static checks and replaced at end of life) during construction.
- i. Blower and vestibule access panels must be in place on the furnace at all times.
- j. The furnace heat exchanger, components, duct system, and evaporator coils must be thoroughly cleaned following final construction clean–up.
- k. Air filters must be replaced upon construction completion.
- I. All furnace operating conditions (including ignition, input rate, temperature rise and venting) must be verified in accordance with these installation instructions.

EQUIPMENT MAY EXPERIENCE PREMATURE COMPONENT FAILURE AS A RESULT OF FAILURE TO FOLLOW THE ABOVE INSTALLATION INSTRUCTIONS. FAILURE TO FOLLOW THE ABOVE INSTALLATION INSTRUCTIONS VOIDS THE MANUFACTURER'S EQUIPMENT LIMITED WARRANTY. ALLIED AIR DISCLAIMS ALL LIABILITY IN CONNECTION WITH INSTALLER'S FAILURE TO FOLLOW THE ABOVE INSTALLATION INSTRUCTIONS.

NOTWITHSTANDING THE FOREGOING, INSTALLER IS RESPONSIBLE FOR CONFIRMING THAT THE USE OF CONSTRUCTION HEAT IS CONSISTENT WITH THE POLICIES AND CODES OF ALL REGULATING ENTITIES. ALL SUCH POLICIES AND CODES MUST BE ADHERED TO.

### General

These instructions are intended as a general guide and do not supersede local codes in any way. Consult authorities having jurisdiction before installation.

In addition to the requirements outlined previously, the following general recommendations must be considered when installing one of these furnaces:

- Place the furnace as close to the center of the air distribution system as possible. The furnace should also be located close to the vent termination point.
- When the furnace is installed in non-direct vent applications, do not install the furnace where drafts might blow directly into it. This could cause improper combustion and unsafe operation.
- When the furnace is installed in non-direct vent applications, do not block the furnace combustion air opening with clothing, boxes, doors, etc. Air is needed for proper combustion and safe unit operation.
- When the furnace is installed in an attic or other insulated space, keep insulation away from the furnace.
- When the furnace is installed in an unconditioned space, consider provisions required to prevent freezing of condensate drain system.

**NOTE:** The Commonwealth of Massachusetts stipulates these additional requirements:

- Gas furnaces shall be installed by a licensed plumber or fitter only.
- The gas cock must be "T handle" type.
- When a furnace is installed in an attic, the passageway to and service area surrounding the equipment shall be floored.

### 

These units should not be installed in areas normally subject to freezing temperatures.

### **Combustion, Dilution & Ventilation Air**

If this unit is installed as a Non-Direct Vent Furnace, follow the guidelines in this section.

**NOTE:** In Non-Direct Vent Installations, combustion air is taken from indoors and flue gases are discharged outdoors.



Insufficient combustion air can cause headaches, nausea, dizziness or asphyxiation. It will also cause excess water in the heat exchanger resulting in rusting and premature heat exchanger failure. Excessive exposure to contaminated combustion air will result in safety and performance related problems. Avoid exposure to the following substances in the combustion air supply:

- Permanent wave solutions
- Chlorinated waxes and cleaners
- Chlorine base swimming pool chemicals
- Water softening chemicals
- · De-icing salts or chemicals
- Carbon tetrachloride
- Halogen type refrigerants
- Cleaning solvents (such as perchloroethylene)
- Printing inks, paint removers, varnishes, etc.
- · Hydrochloric acid
- · Cements and glues
- Antistatic fabric softeners for clothes dryers
- Masonry acid washing materials

In the past, there was no problem in bringing in sufficient outdoor air for combustion. Infiltration provided all the air that was needed. In today's homes, tight construction practices make it necessary to bring in air from outside for combustion. Take into account that exhaust fans, appliance vents, chimneys, and fireplaces force additional air that could be used for combustion out of the house. If sufficient combustion air is not available, the furnace or other appliance will operate inefficiently and unsafely.

Unless outside air is brought into the house for combustion, negative pressure (outside pressure is greater than inside pressure) will build to the point that a down draft can occur in the furnace vent pipe or chimney. As a result, combustion gases enter the living space creating a potentially dangerous situation.

In addition to providing combustion air, fresh outdoor air dilutes contaminants in the indoor air. These contaminants may include bleaches, adhesives, detergents, solvents and other contaminants which can corrode furnace components.

### 

Do not install the furnace in a corrosive or contaminated atmosphere. Meet all combustion and ventilation air requirements, as well as all local codes.

In the absence of local codes concerning air for combustion and ventilation, use the guidelines and procedures in this section to install these furnaces to ensure efficient and safe operation. You must consider combustion air needs and requirements for exhaust vents and gas piping. A portion of this information has been reprinted with permission from the National Fuel Gas Code (ANSI-Z223.1/NFPA 54). This reprinted material is not the complete and official position of ANSI on the referenced subject, which is represented only by the standard in its entirely.

In Canada, refer to the CSA B149 Installation codes.

The requirements for providing air for combustion and ventilation depend largely on whether the furnace is installed in an unconfined or a confined space.

### **Unconfined Space**

An unconfined space is an area such as a basement or large equipment room with a volume greater than 50 cubic feet (1.42 m<sup>3</sup>) per 1,000 Btu (.29 kW) per hour of the combined input rating of all appliances installed in that space. This space also includes adjacent rooms which are not separated by a door. Though an area may appear to be unconfined, it might be necessary to bring in outdoor air for combustion if the structure does not provide enough air by infiltration. If the furnace is located in a building of tight construction with weather stripping and caulking around the windows and doors, follow the procedures in the "Air from Outside" section.

### **Confined Space**

A confined space is an area with a volume less than 50 cubic feet (1.42 m<sup>3</sup>) per 1,000 Btu (.29 kW) per hour of the combined input rating of all appliances installed in that space. This definition includes furnace closets or small equipment rooms.

When the furnace is installed so that supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air must be handled by ducts which are sealed to the furnace casing and which terminate outside the space containing the furnace. This is especially important when the furnace is mounted on a platform in a confined space such as a closet or small equipment room. Even a small leak around the base of the unit at the platform or at the return air duct connection can cause a potentially dangerous negative pressure condition. Air for combustion and ventilation can be brought into the confined space either from inside the building or from outside.

### Air from Inside

If the confined space that houses the furnace adjoins a space categorized as unconfined, air can be brought in by providing two permanent openings between the two spaces. Each opening must have a minimum free area of 1 square inch (645 mm<sup>2</sup>) per 1,000 Btu (.29 kW) per hour of total input rating of all gas-fired equipment in the confined space. Each opening must be at least 100 square inches (64516 mm<sup>2</sup>). One opening shall be within 12 inches (305 mm) of the top of the enclosure and one opening within 12 inches (305 mm) of the bottom. See Figure 5.





Figure 5. Equipment in Confined Space - All Air From Inside


### Air from Outside

If air from outside is brought in for combustion and ventilation, the confined space shall be provided with two permanent openings. One opening shall be within 12" (305 mm) of the top of the enclosure and one within 12" (305 mm) of the bottom. These openings must communicate directly or by ducts with the outdoors or spaces (crawl or attic) that freely communicate with the outdoors or indirectly through vertical ducts. Each opening shall have a minimum free area of 1 square inch per 4,000 Btu (645 mm<sup>2</sup> per .59 kW) per hour of total input rating of all equipment in the enclosure (see Figure 6 and Figure 7). It is also permissible to bring in air for combustion from a ventilated attic (Figure 10) or ventilated crawl space (Figure 9).





Ventilated Attic)



#### Figure 7. Equipment in Confined Space - All Air from Outside (All Air through Ventilated Attic)

When communicating with the outdoors through horizontal ducts, each opening shall have a minimum free area of 1 square inch (645 mm<sup>2</sup>) per 2,000 Btu (.56 kW) per total input rating of all equipment in the enclosure. See Figure 8.

When ducts are used, they shall be of the same crosssectional area as the free area of the openings to which they connect. The minimum dimension of rectangular air ducts shall be no less than 3 inches (75 mm). In calculating free area, the blocking effect of louvers, grilles, or screens must be considered. If the design and free area of protective covering is not known for calculating the size opening required, it may be assumed that wood louvers will have 20 to 25 percent free area and metal louvers and grilles must be fixed in the open position or interlocked with the equipment so that they are opened automatically during equipment operation.




Figure 8. Equipment in Confined Space - All Air from Outside




Figure 9. Equipment in Confined Space (Inlet Air from Ventilated Crawl Space & Outlet Air to Outside)




Figure 10. Equipment in Confined Space (Inlet Air from Ventilated Attic & Outlet Air to Outside)

### Shipping Bolt Removal

Units with 1/2 hp and 3/4 hp blower motors are equipped with three flexible legs and one rigid leg. The rigid leg is equipped with a shipping bolt and a flat white plastic washer (rather than the rubber mounting grommet used with a flexible mounting leg). See Figure 11. The bolt and washer must be removed before the furnace is placed into operation. After the bolt and washer have been removed, the rigid leg will not touch the blower housing.




Figure 11.

### Installation

### Setting Equipment

### 

Improper installation of the furnace can result in personal injury or death. Combustion and flue products must never be allowed to enter the return air system or air in the living space. Use sheet metal screws and joint tape to seal return air system to furnace.

In platform installations with furnace return, the furnace should be sealed airtight to the return air plenum. A door must never be used as a portion of the return air duct system. The base must provide a stable support and an airtight seal to the furnace. Allow absolutely no sagging, cracks, gaps, etc.

For no reason should return and supply air duct systems ever be connected to or from other heating devices such as a fireplace or stove, etc. Fire, explosion, carbon monoxide poisoning, personal injury and/or property damage could result.

### 

Blower access panel must be securely in place when blower and burners are operating. If panels are left off, gas fumes, which could contain carbon monoxide, can be drawn into living space resulting in personal injury or death.

The gas furnace can be installed as shipped in either the upflow position or the horizontal position.

Select a location that allows for the required clearances that are listed on the unit nameplate. Also consider gas supply connections, electrical supply, vent connection, and installation and service clearances [24 inches (610 mm) at unit front]. The unit must be level.

### 

Do not connect the return air ducts to the back of the furnace. Doing so will adversely affect the operation of the safety control devices, which could result in personal injury or death.

### **Upflow Applications**


The gas furnaces can be installed as shipped in the upflow position. Refer to Figure 13 for clearances. The unit must be level from side to side. Tilt the unit slightly (maximum 1/2 in. from level) from back to front to aid in the draining of the heat exchanger. See Figure 12.

Allow for clearances to combustible materials as indicated on the unit nameplate.

### **Return Air Guidelines**

Return air can be brought in through the bottom or either side of the furnace installed in an upflow application. If the furnace is installed on a platform with bottom return, make an airtight seal between the bottom of the furnace and the platform to ensure that the furnace operates properly and safely. The furnace is equipped with a removable bottom panel to facilitate installation.

Markings are provided on both sides of the furnace cabinet for installations that require side return air. Cut the furnace cabinet at the maximum dimensions shown on Page 2.



### Figure 12. Setting Equipment

| Left Side   | Top<br>Right Side<br>ttom (floor) |  |  |  |  |  |  |
|---|-----------------------------------|--|--|--|--|--|--|
| Top/Plenum  | 1 in. (25 mm)                     |  |  |  |  |  |  |
| *Front  | 0                                 |  |  |  |  |  |  |
| Back  | 0                                 |  |  |  |  |  |  |
| Sides   | 0†                                |  |  |  |  |  |  |
| Vent  | 0                                 |  |  |  |  |  |  |
| Floor   | 0‡                                |  |  |  |  |  |  |
| * Front clearance in alcove installation must be 24 in (610 |                                   |  |  |  |  |  |  |

\* Front clearance in alcove installation must be 24 in. (610 mm). Maintain a minimum of 24 in. (610 mm) for front service access.

† Allow proper clearances to accommodate condensate trap.

‡ For installations on a combustible floor, do not install the furnace directly on carpeting, tile or other combustible materials other than wood flooring.

#### Figure 13. Upflow Applications Installation Clearances

Furnace applications which include side return air and a condensate trap installed on the same side of the cabinet (trap can be installed remotely within 5 ft.) require either a

return air base or field-fabricated transition to accommodate an optional IAQ accessory taller than 14.5". See Figure 14.





Figure 14. Side Return Air (with Transition and Filter)

**NOTE:** C20 (5 Ton) size units installed in upflow applications that require air volumes of 1800 cfm (850 L/s) or greater must have one of the following:

- Single side return air with transition, to accommodate 20 x 25 x 1 in. (508 x 635 x 25 mm) cleanable air filter. (Required to maintain proper air velocity.)
- Single side return air with optional "RAB" **R**eturn **A**ir **B**ase.
- Bottom return air.
- Return air from both sides.
- Bottom and one side return air.



Minimum unit side return air opening dimensions for units requiring 1800 cfm of air and over (W x H): 23 x 11 in. (584 x279 mm).

The opening can be cut as needed to accommodate plenum or IAQ cabinet while maintaining dimensions shown.

Side return air openings must be cut in the field. There are cutting guides stenciled on the cabinet for the side return air opening. The size of the opening must not extend beyond the markings on the furnace cabinet.

<sup>2</sup> To minimize pressure drop, the largest opening height possible (up to 14 inches) is preferred.

### Figure 15. Optional Return Air Base (Upflow Applications Only)

### Removing the Bottom Panel

Remove the two screws that secure the bottom cap to the furnace. Pivot the bottom cap down to release the bottom panel. Once the bottom panel has been removed, reinstall the bottom cap. See Figure 16.




Figure 16. Removing the Bottom Panel

### **Horizontal Applications**

### 

Do not install the furnace on its front or its back. See Figure 17.





Figure 17.

This furnace can be installed in horizontal applications with either right or left hand air discharge.

Refer to Figure 18 for clearances in horizontal applications.



\* Front clearance in alcove installation must be 24 in. (610 mm). Maintain a minimum of 24 in. (610 mm) for front service access.

† Allow proper clearances to accommodate condensate trap.

‡ For installations on a combustible floor, do not install the furnace directly on carpeting, tile or other combustible materials other than wood flooring.

### Figure 18. Horizontal Application Installation Clearances

### Suspended Installation of Horizontal Unit

This furnace may be installed in either an attic or a crawl space. Either suspend the furnace from roof rafters or floor joists, as shown in Figure 19, or install the furnace on a platform, as shown in Figure 20. A horizontal suspension kit (51W10) may be ordered from your distributor or use equivalent.




Figure 19. Typical Horizontal Application

**NOTE:** Heavy-gauge sheet metal straps may be used to suspend the unit from roof rafters or ceiling joists. When straps are used to suspend the unit in this way, support must be provided for both the ends. The straps must not interfere with the plenum or exhaust piping installation.

Cooling coils and supply and return air plenums must be supported separately.

**NOTE:** When the furnace is installed on a platform or with the horizontal suspension kit in a crawl space, it must be elevated enough to avoid water damage, accommodate drain trap and to allow the evaporator coil to drain.

#### Platform Installation of Horizontal Unit

- 1. Select location for unit keeping in mind service and other necessary clearances. See Figure 18.
- Construct a raised wooden frame and cover frame with a plywood sheet. If unit is installed above finished space, fabricate an auxiliary drain pan to be installed under unit. Set unit in drain pan as shown in Figure 20. Leave 8 inches for service clearance below unit for condensate trap.
- 3. Provide a service platform in front of unit. When installing the unit in a crawl space, a proper support platform may be created using cement blocks.
- 4. Route auxiliary drain line so that water draining from this outlet will be easily noticed by the homeowner.
- 5. If necessary, run the condensate line into a condensate pump to meet drain line slope requirements. The pump must be rated for use with condensing furnaces. Protect the condensate discharge line from the pump to the outside to avoid freezing.
- 6. Continue with exhaust, condensate and intake piping installation according to instructions.




Figure 20.

### **Return Air - Horizontal Applications**

Return air may be brought in only through the end of a furnace installed in the horizontal position. The furnace is equipped with a removable bottom panel to facilitate installation. See Figure 16.

### Filters

This unit is not equipped with a filter or rack. A field provided filter is required for the unit to operate properly. Table 1 list recommended filter sizes.

A filter must be in place whenever the furnace is operating.

| Furnace Cabinet | Filter Size     |                 |  |  |  |
|-----------------|-----------------|-----------------|--|--|--|
| Width           | Side Return     | Bottom Return   |  |  |  |
| B (17-1/2")     | 16 x 25 x 1 (1) | 16 x 25 x 1 (1) |  |  |  |
| C (21")         | 16 x 25 x 1 (1) | 20 x 25 x 1 (1) |  |  |  |

#### Table 1.

### **Duct System**

Use industry approved standards to size and install the supply and return air duct system. This will result in a quiet and low-static system that has uniform air distribution.

**NOTE:** This furnace is not certified for operation in heating mode (indoor blower operating at selected heating speed) with an external static pressure which exceeds 0.5 inches w.c. Operation at these conditions may result in improper limit operation.

### **Supply Air Plenum**

If the furnace is installed without a cooling coil, a removable access panel should be installed in the supply air duct. The access panel should be large enough to permit inspection (by reflected light) of the heat exchanger for leaks after the furnace is installed. The furnace access panel must always be in place when the furnace is operating and it must not allow leaks into the supply air duct system.

### **Return Air Plenum**

**NOTE:** Return air must not be drawn from a room where this furnace, or any other gas fueled appliance (i.e., water heater), or carbon monoxide producing device (i.e., wood fireplace) is installed.

When return air is drawn from a room, a negative pressure is created in the room. If a gas appliance is operating in a room with negative pressure, the flue products can be pulled back down the vent pipe and into the room. This reverse flow of the flue gas may result in incomplete combustion and the formation of carbon monoxide gas. This raw gas or toxic fumes might then be distributed throughout the house by the furnace duct system.

Return air can be brought in through the bottom or either side of the furnace. If a furnace with bottom return air is installed on a platform, make an airtight seal between the bottom of the furnace and the platform to ensure that the unit operates properly and safely. Use fiberglass sealing strips, caulking, or equivalent sealing method between the plenum and the furnace cabinet to ensure a tight seal. If a filter is installed, size the return air duct to fit the filter frame.

### **Pipe & Fittings Specifications**

All pipe, fittings, primer and solvent cement must conform with American National Standard Institute and the American Society for Testing and Materials (ANSI/ASTM) standards. The solvent shall be free flowing and contain no lumps, undissolved particles or any foreign matter that adversely affects the joint strength or chemical resistance of the cement. The cement shall show no gelation, stratification, or separation that cannot be removed by stirring. Refer to Table 2 for approved piping and fitting materials.

### 

Solvent cements for plastic pipe are flammable liquids and should be kept away from all sources of ignition. Do not use excessive amounts of solvent cement when making joints. Good ventilation should be maintained to reduce fire hazard and to minimize breathing of solvent vapors. Avoid contact of cement with skin and eyes.

### 

A93UH1EK & 92G1UHEK exhaust and intake connections are made of PVC. Use PVC primer and solvent cement when using PVC vent pipe. When using ABS vent pipe, use transitional solvent cement to make connections to the PVC fitting in the unit.

Use PVC primer and solvent cement or ABS solvent cement meeting ASTM specifications, refer to Table 2. As an alternate, use all purpose cement, to bond ABS, PVC, or CPVC pipe when using fittings and pipe made of the same materials. Use transition solvent cement when bonding ABS to either PVC or CPVC.

Low temperature solvent cement is recommended during cooler weather. Metal or plastic strapping may be used for vent pipe hangers. Uniformly apply a liberal coat of PVC primer for PVC or use a clean dry cloth for ABS to clean inside socket surface of fitting and male end of pipe to depth of fitting socket.

### **Canadian Applications Only**

Pipe, fittings, primer and solvent cement used to vent (exhaust) this appliance must be certified to ULC S636 and supplied by a single manufacturer as part of an approved vent (exhaust) system. When bonding the vent system to the furnace, use ULC S636 approved One-Step Transition Cement to bond the pipe to the flue collar, or to bond the 90° elbow or reducing 90° elbow to the flue collar. In addition, the first three feet of vent pipe from the furnace flue collar must be accessible for inspection.

| Piping and Fittings Specifica   | tions                 |
|---|-----------------------|
| Schedule 40 PVC (Pipe)  | D1785                 |
| Schedule 40 PVC (Fittings)  | D2466                 |
| Schedule 40 CPVC (Pipe)   | F441                  |
| Schedule 40 CPVC (Fittings)   | F438                  |
| SDR-21 PVC or SDR-26 PVC (Pipe)   | D2241                 |
| SDR-21 CPVC or SDR-26 CPVC (Pipe)   | F442                  |
| Schedule 40 ABS (Pipe)  | D1527                 |
| Schedule 40 ABS (Fittings)  | D2468                 |
| ABS-DWV (Drain Waste & Vent)<br>(Pipe & Fittings)                           | D2661                 |
| PVC-DWV (Drain Waste & Vent)<br>(Pipe & Fittings)                           | D2665                 |
| Primer & Solvent Cement   | ASTM<br>SPECIFICATION |
| PVC & CPVC Primer   | F656                  |
| PVC Solvent Cement  | D2564                 |
| CPVC Solvent Cement   | F493                  |
| ABS Solvent Cement  | D2235                 |
| PVC/CPVC/ABS All Purpose Cement For<br>Fittings & Pipe of the same material | D2564, D2235,<br>F493 |
| ABS to PVC or CPVC Transition Solvent<br>Cement                             | D3138                 |
| Canada Pipe & Fitting & Solvent Cement                                      | MARKING               |
| PVC & CPVC Pipe and Fittings  |                       |
| PVC & CPVC Solvent Cement   | ULCS636               |
| ABS to PVC or CPVC Transition Cement  |                       |
| Polypropylene Venting System  | ULC-S636              |
| PolyPro® by Duravent  | 010-3030              |
| InnoFlue® by Centrotherm  | ULC-S636              |
| ECCO Polypropylene Vent™  | ULC-S636              |

#### Table 2.

### **Joint Cementing Procedure**

All cementing of joints should be done according to the specifications outlined in ASTM D 2855.

**NOTE:** A sheet metal screw may be used to secure the intake pipe to the connector, if desired. Use a drill or self tapping screw to make a pilot hole.

|          |                            | S   | TANDARD  | CONCENTRIC         |                             |                         |                         |  |
|----------|----------------------------|---|--|--------------------|-----------------------------|-------------------------|-------------------------|--|
| Capacity | VENT<br>PIPE DIA.<br>(in.) | Outdoor Exhaust<br>Accelerator<br>(Dia. X Length) | Outdoor<br>Exhaust<br>Accelerator<br>(Dia. X Length) | Flush<br>Mount Kit | 1-1/2"<br>Concentric<br>Kit | 2"<br>Concentric<br>Kit | 3"<br>Concentric<br>Kit |  |
|          | (,                         | 1-1/2" X 12"                                      | 2" X 12"   | 51W11 **           | 71M80<br>or<br>+44W92++     | 69M29<br>or<br>+44W92++ | 60L46<br>or 44W93+      |  |
|          | 1-1/2                      | YES   |  | YES                | YES                         |                         |                         |  |
| 030      | 2                          | YES   |  | YES                | YES                         |                         |                         |  |
| 030      | 2-1/2                      | YES   |  | YES                | YES                         |                         |                         |  |
|          | 3                          | YES   |  | YES                | YES                         |                         |                         |  |
|          | 1-1/2                      | YES   |  | YES                | YES                         |                         |                         |  |
| 045      | 2                          | YES   |  | YES                | YES                         |                         |                         |  |
| 045      | 2-1/2                      | YES   |  | YES                | YES                         |                         |                         |  |
|          | 3                          | YES   |  | YES                | YES                         |                         |                         |  |
|          | 1-1/2                      | YES   |  | YES                | YES                         |                         |                         |  |
| 070      | 2                          | YES   |  | YES                | YES                         |                         |                         |  |
| 070      | 2-1/2                      | YES   |  | YES                | YES                         |                         |                         |  |
|          | 3                          | YES   |  | YES                | YES                         |                         |                         |  |
|          | 2                          |   |  | YES                |                             | YES                     | YES                     |  |
| 090      | 2-1/2                      |   | YES  | YES                |                             | YES                     | YES                     |  |
|          | 3                          |   | YES  | YES                |                             | YES                     | YES                     |  |
|          | 2                          |   |  | YES                |                             | YES                     | YES                     |  |
| 110      | 2-1/2                      |   | YES  | YES                |                             | YES                     | YES                     |  |
|          | 3                          |   | YES  | YES                |                             | YES                     | YES                     |  |

\*\* Kit 51W11 is provided with a 1-1/2" accelerator which must be for all 2 and 2-1/2" PVC installations.

+ Termination kits 44W92 and 44W93 are approved for use in Canadian installations to meet CSAB149.

++ The 44W92 Concentric kit is provided with a 1-1/2" accelerator, which must be installed on the exhaust outlet when this kit is used with this furnace.

**NOTE**: When using 1-1/2" piping and terminating with a flush mount kit or concentric kit, the pipe must be transitioned to 2" pipe before attaching to the flush mount kit or the concentric kit.

### Table 3. Outdoor Termination Kits Usage



DANGER OF EXPLOSION!

Fumes from PVC glue may ignite during system check. Allow fumes to dissipate for at least 5 minutes before placing unit into operation.

- 1. Measure and cut vent pipe to desired length.
- 2. Debur and chamfer end of pipe, removing any ridges or rough edges. If end is not chamfered, edge of pipe may remove cement from fitting socket and result in a leaking joint.
- 3. Clean and dry surfaces to be joined.
- 4. Test fit joint and mark depth of fitting on outside of pipe.

5. Uniformly apply a liberal coat of PVC primer for PVC or use a clean dry cloth for ABS to clean inside socket surface of fitting and male end of pipe to depth of fitting socket.

**NOTE:** *Time is critical at this stage. Do not allow primer to dry before applying cement.* 

- 6. Promptly apply solvent cement to end of pipe and inside socket surface of fitting. Cement should be applied lightly but uniformly to inside of socket. Take care to keep excess cement out of socket. Apply second coat to end of pipe.
- 7. Immediately after applying last coat of cement to pipe, and while both inside socket surface and end of pipe are wet with cement, forcefully insert end of pipe into socket until it bottoms out. Turn PVC pipe 1/4 turn

during assembly (but not after pipe is fully inserted) to distribute cement evenly. Do not turn ABS or cellular core pipe.

**NOTE:** Assembly should be completed within 20 seconds after last application of cement. Hammer blows should not be used when inserting pipe.

- After assembly, wipe excess cement from pipe at end of fitting socket. A properly made joint will show a bead around its entire perimeter. Any gaps may indicate an improper defective assembly due to insufficient solvent.
- 9. Handle joints carefully until completely set.

### Venting Practices

**NOTE:** For any Low GWP refrigerant systems with exposed line set joints installed in the same space, each non-direct vent furnace system must have a refrigerant detection sensor installed below the level of the burners (See SECONDARY SENSOR REQUIREMENTS on page 48). Any direct vent furnace system is not subject to this requirement.




Figure 21.

### 

### CARBON MONOXIDE POISONING HAZARD

Failure to follow the steps outlined below for each appliance connected to the venting system being placed into operation could result in carbon monoxide poisoning or death.

The following steps shall be followed for each appliance connected to the venting system being placed into operation, while all other appliances connected to the venting system are not in operation.

### **Removal of the Furnace from Common Vent**

In the event that an existing furnace is removed from a venting system commonly run with separate gas appliances, the venting system is likely to be too large to properly vent the remaining attached appliances.

Conduct the following test while each appliance is operating and the other appliances (which are not operating) remain connected to the common venting system. If the venting system has been installed improperly, you must correct the system as indicated in the general venting requirements section.

- 1. Seal any unused openings in the common venting system.
- 2. Inspect the venting system for proper size and horizontal pitch. Determine that there is no blockage, restriction, leakage, corrosion, or other deficiencies which could cause an unsafe condition.
- 3. Close all building doors and windows and all doors between the space in which the appliances remaining connected to the common venting system are located and other spaces of the building. Turn ON clothes dryers and any appliances not connected to the common venting system. Turn ON any exhaust fans, such as range hoods and bathroom exhausts, so they will operate at maximum speed. Do not operate a summer exhaust fan. Close fireplace dampers.
- 4. Follow the lighting instructions. Turn ON the appliance that is being inspected. Adjust the thermostat so that the appliance operates continuously.
- 5. After the main burner has operated for 5 minutes, test for leaks of flue gases at the draft hood relief opening. Use the flame of a match or candle.




Figure 22.

- After determining that each appliance connected to the common venting system is venting properly, (step 3) return all doors, windows, exhaust fans, fireplace dampers, and any other gas burning appliances to their previous mode of operation.
- 7. If a venting problem is found during any of the preceding tests, the common venting system must be modified to correct the problems.

Resize the common venting system to the minimum vent pipe size determined by using the appropriate tables in Appendix G. (These are in the current standards of the National Fuel Gas Code ANSI Z223.1.

### Exhaust Piping

See Figure 25 and Figure 26

- 1. In areas where piping penetrates joist or interior walls, hole must be large enough to allow clearance on all sides of pipe through center of hole using a hanger.
- 2. When furnace is installed in a residence where unit is shut down for an extended period of time, such as a vacation home, make provisions for draining condensate collection from trap and lines.
- 3. Route piping to outside of structure. Continue with installation following instructions given in piping termination section.

### 

Do not discharge exhaust into an existing stack or stack that also serves another gas appliance. If vertical discharge through an existing unused stack is required, insert PVC pipe inside the stack until the end is even with the top or outlet end of the metal stack.

### 

The exhaust vent pipe operates under positive pressure and must be completely sealed to prevent leakage of combustion products into the living space.

### Vent Piping Guidelines

This gas furnace can be installed as either a Non-Direct Vent or a Direct Vent gas central furnace.

**NOTE:** In non-Direct Vent installations, combustion air is taken from indoors and flue gases are discharged outdoors. In Direct Vent installations, combustion air is taken from outdoors and flue gases are discharged outdoors.

Intake and exhaust pipe sizing - Size pipe according to Table 4 and Table 5 through Table 6. Table 4 lists the minimum vent pipe lengths permitted. Table 5 and Table 6 list the maximum pipe lengths permitted for A93UH1EK & 92G1UHEK.

Regardless of the diameter of pipe used, the standard roof and wall terminations described in section Exhaust Piping Terminations should be used. Exhaust vent termination pipe is sized to optimize the velocity of the exhaust gas as it exits the termination. Refer to Table 8.

In some applications which permit the use of several different sizes of vent pipe, a combination vent pipe may be used. Contact Allied Air Technical Service for assistance in sizing vent pipe in these applications.




Figure 23.

**NOTE:** *It is acceptable to use any pipe size which fits within the guidelines allowed in Table 5 and Table 6.* 

**NOTE:** The exhaust collar on all models is sized to accommodate 2" Schedule 40 vent pipe. In horizontal applications, transition to exhaust pipe larger than 2" must be made in vertical runs of the pipe. A 2" elbow must be added before the pipe is transitioned to any size larger than 2". This elbow must be added to the elbow count used to determine acceptable vent lengths. Contact the Application Department for more information concerning sizing of vent systems which include multiple pipe sizes.

| Capacity  | Min. Vent Length*  |  |  |  |  |  |
|---|--|--|--|--|--|--|
| 030, 045, 070, 090, 110   | 15 ft. or<br>5 ft plus 2 elbows or<br>10 ft plus 1 elbow |  |  |  |  |  |
| * Any approved termination may be added to the minimum length listed.                           |  |  |  |  |  |  |
| ** This gas furnace must have 3" to 2" reducing elbow installed directly into unit flue collar. |  |  |  |  |  |  |

### Table 4. Minimum Vent Pipe Lengths

### 

Do not use screens or perforated metal in exhaust or intake terminations. Doing so will cause freeze-ups and may block the terminations.

Use Figure 24 to correctly size vent pipe diameter.




Figure 24.

#### Standard Termination at Elevation 0 - 10,000 ft 1-1/2" Pipe 2" Pipe 2-1/2" Pipe 3" Pipe Number of Capacity Capacity Capacity Capacity 90° Elbows Used 030 / 030 / 030 / 030 / n/a n/a n/a n/a n/a n/a n/a Concentric Termination Elevation 0 - 10,000 ft 1-1/2" Pipe 2" Pipe 2-1/2" Pipe 3" Pipe Number of Capacity Capacity Capacity Capacity 90° Elbows Used 030 / 030 / 030 / 030 / n/a n/a n/a n/a n/a n/a

### A93UH1EK & 92G1UHEK Maximum Allowable Intake or Exhaust Vent Length in Feet

\*Size intake and exhaust pipe length separately. Values in table are for Intake OR Exhaust, not combined total. Both Intake and Exhaust must be same pipe size.


n/a

Table 5.


#### A93UH1EK & 92G1UHEK Maximum Allowable Exhaust Vent Length with Furnace Installed in a Closet or Basement Using Ventilated Attic or Crawl Space for Intake in Feet

| Standard Termination at Elevation 0 - 10,000 ft |              |             |       |     |              |         |       |     |              |        |        |     |              |      |       |     |    |    |    |    |    |   |    |    |    |
|---|--------------|-------------|-------|-----|--------------|---------|-------|-----|--------------|--------|--------|-----|--------------|------|-------|-----|----|----|----|----|----|---|----|----|----|
|   |              | 1-1/2" Pipe |       |     |              | 2" Pipe |       |     |              | 2-1/2' | ' Pipe |     | 3" Pipe      |      |       |     |    |    |    |    |    |   |    |    |    |
| Number of<br>90° Elbows                         |              | Сара        | acity |     |              | Сара    | acity |     |              | Сара   | acity  |     |              | Сара | acity |     |    |    |    |    |    |   |    |    |    |
| Used  | 030 /<br>045 | 070         | 090   | 110 | 030 /<br>045 | 070     | 090   | 110 | 030 /<br>045 | 070    | 090    | 110 | 030 /<br>045 | 070  | 090   | 110 |    |    |    |    |    |   |    |    |    |
| 1   | 20           | 15          |       |     | 66           | 51      | 29    | 9   | 95           | 80     | 48     | 23  | 112          | 112  | 93    | 93  |    |    |    |    |    |   |    |    |    |
| 2   | 15           | 10          | ]     |     | 61           | 46      | 24    | 4   | 90           | 75     | 43     | 18  | 107          | 107  | 88    | 88  |    |    |    |    |    |   |    |    |    |
| 3   | 10           |             | n/a   |     |              | 56      | 41    | 19  | 19           | 85     | 70     | 38  | 13           | 102  | 102   | 83  | 83 |    |    |    |    |   |    |    |    |
| 4   |              |             |       |     |              |         |       |     |              |        |        |     |              |      | 51    | 36  | 14 |    | 80 | 65 | 33 | 8 | 97 | 97 | 78 |
| 5   |              |             |       | n/a | 46           | 31      | 9     |     | 75           | 60     | 28     | 3   | 92           | 92   | 73    | 73  |    |    |    |    |    |   |    |    |    |
| 6   | n/a          | n/a         | n/a   | n/a |              |         |       | 41  | 26           | 4      | n/a    | 70  | 55           | 23   |       | 87  | 87 | 68 | 68 |    |    |   |    |    |    |
| 7   | n/a          |             |       |     | 36           | 21      |       |     | 65           | 50     | 18     | n/a | 82           | 82   | 63    | 63  |    |    |    |    |    |   |    |    |    |
| 8   |              |             |       |     | 31           | 16      | n/a   |     | 60           | 45     | 13     |     | 77           | 77   | 58    | 58  |    |    |    |    |    |   |    |    |    |
| 9   |              |             |       |     | 26           | 11      |       |     | 55           | 40     | 8      |     | 72           | 72   | 53    | 53  |    |    |    |    |    |   |    |    |    |

Table 6.













Figure 27.

### TYPICAL INTAKE PIPE CONNECTIONS IN HORIZONTAL DIRECT OR NON-DIRECT VENT APPLICATION (RIGHT-HAND DISCHARGE SHOWN)





### **Intake Piping**


See Figure 27 through Figure 30

This gas furnace may be installed in either direct vent or non-direct vent applications. In non-direct vent applications, when intake air will be drawn into the furnace from the surrounding space, the indoor air quality must be considered and guidelines listed in Combustion, Dilution and Ventilation Air section must be followed.

Follow the next two steps when installing the unit in Direct Vent applications, where combustion air is taken from outdoors and flue gases are discharged outdoors. The provided air intake screen must not be used in direct vent applications (outdoors).

- 1. Use transition solvent cement or a sheet metal screw to secure the intake pipe to the inlet air connector.
- Route piping to outside of structure. Continue with installation following instructions given in general guide lines for piping terminations and in intake and exhaust piping terminations for direct vent sections. Refer to Table 5 and Table 6.

# TYPICAL AIR INTAKE PIPE CONNECTIONS UPFLOW NON-DIRECT VENT APPLICATIONS



**NOTE**: Debris screen and elbow may be rotated so that the screen may be positioned to face forward or to either side.

Figure 29.

### 

If this unit is being installed in an application with combustion air coming in from a space serviced by an exhaust fan, power exhaust fan, or other device which may create a negative pressure in the space, take care when sizing the inlet air opening. The inlet air opening must be sized to accommodate the maximum volume of exhausted air as well as the maximum volume of combustion air required for all gas appliances serviced by this space.

Follow the next two steps when installing the unit in Non– Direct Vent applications where combustion air is taken from indoors and flue gases are discharged outdoors.

 Use field-provided materials and the factory-provided air intake screen to route the intake piping as shown in Figure 29 or Figure 30. Maintain a minimum clearance of 3" (76 mm) around the air intake opening. The air intake opening (with the protective screen) should always be directed forward or to either side in the upflow position, and either straight out or downward in the horizontal position.






Figure 30.

The air intake piping must not terminate too close to the flooring or a platform. Ensure that the intake air inlet will not be obstructed by loose insulation or other items that may clog the debris screen.

- If intake air is drawn from a ventilated attic (Figure 31) or ventilated crawlspace (Figure 32) the exhaust vent length must not exceed those listed in Table 6. If 3" diameter pipe is used, reduce to 2" diameter pipe at the termination point to accommodate the debris screen.
- 3. Use a sheet metal screw to secure the intake pipe to the connector, if desired.



#### Figure 31. Equipment in Confined Space (Inlet Air from Ventilated Attic & Outlet Air to Outside)



#### Figure 32. Equipment in Confined Space (Inlet Air from Ventilated Crawl Space & Outlet Air to Outside)

### **General Guidelines for Vent Terminations**

In Non–Direct Vent applications, combustion air is taken from indoors and the flue gases are discharged to the outdoors. This furnace is then classified as a non–direct vent, Category IV gas furnace.

In Direct Vent applications, combustion air is taken from outdoors and the flue gases are discharged to the outdoors. This furnace is then classified as a direct vent, Category IV gas furnace.




Figure 33. Insulating Exhaust Pipe in an Unconditioned Space

| Maximum Allowable Exhaust Vent Pipe Length (in ft.) without Insulation in Unconditioned Space for Winter Design |
|---|
| Temperatures Single - Stage High Efficiency Furnace   |

| Winter Design                     | Vent Pipe |     |                        |     | Unit Input Size        |     |                 |     |                        |     |                        |
|-----------------------------------|-----------|-----|------------------------|-----|------------------------|-----|-----------------|-----|------------------------|-----|------------------------|
| Temperatures <sup>1</sup> °F (°C) | Diameter  | 030 |                        | 04  | 045                    |     | 070             |     | 090                    |     | 0                      |
|                                   |           | PVC | <sup>2</sup> <b>PP</b> | PVC | <sup>2</sup> <b>PP</b> | PVC | <sup>2</sup> PP | PVC | <sup>2</sup> <b>PP</b> | PVC | <sup>2</sup> <b>PP</b> |
|                                   | 1-1/2 in. | N/A | N/A                    | 25  | N/A                    | 25  | N/A             | N/A | N/A                    | N/A | N/A                    |
| 32° to 21°<br>(0 to -6)           | 2 in.     | N/A | N/A                    | 18  | 16                     | 31  | 28              | 50  | 48                     | 30  | 30                     |
|                                   | 2-1/2 in. | N/A | N/A                    | 13  | N/A                    | 24  | N/A             | 42  | N/A                    | 56  | N/A                    |
|                                   | 3 in.     | N/A | N/A                    | 9   | 9                      | 18  | 18              | 35  | 35                     | 47  | 47                     |
|                                   | 1-1/2 in. | N/A | N/A                    | 15  | N/A                    | 20  | N/A             | N/A | N/A                    | N/A | N/A                    |
| 20° to 1°                         | 2 in.     | N/A | N/A                    | 9   | 8                      | 18  | 16              | 32  | 29                     | 30  | 30                     |
| (-7 to -17)                       | 2-1/2 in. | N/A | N/A                    | 5   | N/A                    | 13  | N/A             | 24  | N/A                    | 34  | N/A                    |
|                                   | 3 in.     | N/A | N/A                    | N/A | N/A                    | 8   | 8               | 19  | 19                     | 26  | 26                     |
| 0° to -20°<br>(-18 to -29)        | 1-1/2 in. | N/A | N/A                    | 10  | N/A                    | 15  | N/A             | N/A | N/A                    | N/A | N/A                    |
|                                   | 2 in.     | N/A | N/A                    | 5   | 3                      | 12  | 10              | 22  | 19                     | 30  | 27                     |
|                                   | 2-1/2 in. | N/A | N/A                    | N/A | N/A                    | 7   | N/A             | 15  | N/A                    | 22  | N/A                    |
|                                   | 3 in.     | N/A | N/A                    | N/A | N/A                    | N/A | N/A             | 10  | 10                     | 16  | 16                     |

<sup>1</sup> Refer to 99% Minimum Design Temperature table provided in the current edition of the ASHRAE Fundamentals Handbook.


<sup>2</sup> Poly-Propylene vent pipe (PP) by Duravent and Centrotherm

**NOTE** - Concentric terminations are the equivalent of 5' and should be considered when measuring pipe length.


**NOTE-** Maximum uninsulated vent lengths listed may include the termination (vent pipe exterior to the structure) and cannot exceed 5 linear feet or the maximum allowable intake or exhaust vent length listed in Table 5 and Table 6.

**NOTE** - If insulation is required in an unconditioned space, it must be located on the pipe closest to the furnace. See Figure 33.

Table 7.



### Figure 34. Vent Termination Clearances for Non-Direct Vent Installations



### Figure 35. Vent Termination Clearances for Direct Vent Installations

In both Non–Direct Vent and Direct Vent applications, the vent termination is limited by local building codes. In the absence of local codes, refer to the current National Fuel Gas Code ANSI Z223-1/NFPA 54 in U.S.A., and current CSA-B149 Natural Gas and Propane Installation Codes in Canada for details.

Position termination according to location given in Figure 34 or Figure 35. In addition, position termination so it is free from any obstructions and 12" above the average snow accumulation.

At vent termination, care must be taken to maintain protective coatings over building materials (prolonged exposure to exhaust condensate can destroy protective coatings). It is recommended that the exhaust outlet not be located within 6 feet (1.8 m) of a condensing unit because the condensate can damage the painted coating.

**NOTE:** See Table 7 for maximum allowed exhaust pipe length without insulation in unconditioned space during winter design temperature is below  $32^{\circ}$  F (0° C). If required, exhaust piping should be insulated with 1/2" (13 mm), Armaflex or equivalent. In extremely cold climate areas with temperature below 20° F (6.7° C) it is recommended that, 3/4" (19 mm) Armaflex or equivalent be used. Insulation on outside runs of exhaust pipe may be painted or wrapped to protect insulation from deterioration in accordance with the insulation manufacturers recommendation. Exhaust pipe insulation may not be necessary in some specific applications.

**NOTE:** During extremely cold temperatures, below approximately 20° F (6.7° C), units with long runs of vent pipe through unconditioned space, even when insulated, may form ice in the exhaust termination that prevents the unit from operating properly. Longer run times of at least 5 minutes will alleviate most icing problems. Also, a heating cable may be installed on exhaust piping and termination to prevent freeze-ups. Heating cable installation kits are available. See unit specification sheets for part numbers.

### 

Do not use screens or perforated metal in exhaust terminations. Doing so will cause freeze-ups and may block the terminations.

### 

### For Canadian Installations Only:

In accordance to CSA International B149 installation codes, the minimum allowed distance between the combustion air intake inlet and the exhaust outlet of other appliances shall not be less than 12 inches (305 mm).

### Details of Intake and Exhaust Piping Terminations for Direct Vent Installations

**NOTE:** In Direct Vent installations, combustion air is taken from outdoors and flue gases are discharged to outdoors.

**NOTE:** Flue gas may be slightly acidic and may adversely affect some building materials. If any vent termination is used and the flue gases may impinge on the building material, a corrosion-resistant shield (minimum 24 inches square) must be used to protect the wall surface. If the optional tee is used, the protective shield is required. The shield should be constructed using wood, plastic, sheet metal or other suitable material. All seams, joints, cracks, etc. in the affected area should be sealed using an appropriate sealant. See Figure 44.


Intake and exhaust pipes may be routed either horizontally through and outside wall or vertically through the roof. In attic or closet installations, vertical termination through the roof is preferred. Figure 36 through Figure 43 show typical terminations.


- Intake and exhaust terminations are not required to be in the same pressure zone. You may exit the intake on one side of the structure and the exhaust on another side (Figure 37). You may exit the exhaust out the roof and the intake out the side of the structure (Figure 38).
- Intake and exhaust pipes should be placed as close together as possible at termination end (refer to illustrations). Minimum separation is 3" (76 mm) on roof terminations and 6" (152 mm) on sidewall terminations.
- 3. On roof terminations, the intake piping should terminate straight down using two 90° elbows (see Figure 36).
- 4. Exhaust piping must terminate straight out or up as shown. A reducer may be required on the exhaust piping at the point where it exits the structure to improve the velocity of exhaust away from the intake piping. See Table 8.

| Capacity   | Exhaust Pipe Size   | Termination Pipe Size |  |  |  |  |  |
|--|---|-----------------------|--|--|--|--|--|
| *030, 045<br>and 070   | 1-1/2" (38 mm),<br>2" (51 mm),<br>2-1/2" (64 mm),<br>3" (76 mm) | 1-1/2" (38 mm)        |  |  |  |  |  |
| *090   | 2" (51 mm),<br>2-1/2" (64 mm),                                  | 2" (51 mm)            |  |  |  |  |  |
| 110  | 3" (76 mm)  |                       |  |  |  |  |  |
| * -030, -045, -070, and -090 units with the flush mount termination must use the 1-1/2" accelerator supplied with the kit. |   |                       |  |  |  |  |  |

### Table 8. Exhaust Pipe Termination Size Reduction

**NOTE:** Care must be taken to avoid recirculation of exhaust back into intake pipe.








Figure 37.




Figure 38.

- On field supplied terminations for sidewall exit, exhaust piping may extend a maximum of 12 inches (305 mm) for 2" PVC and 20 inches (508 mm) for 3" (76 mm) PVC beyond the outside wall. Intake piping should be as short as possible. See Figure 44.
- 6. On field supplied terminations, a minimum distance between the end of the exhaust pipe and the end of the intake pipe without a termination elbow is 8" and a minimum distance of 6" with a termination elbow. See Figure 44.
- 7. If intake and exhaust piping must be run up a side wall to position above snow accumulation or other obstructions, piping must be supported every 24" (610 mm) as shown in Figure 44. Exhaust and intake piping that is run up a wall is considered to be in an unconditioned space, so piping should be sized according to Table 7. The intake piping may be equipped with a 90° elbow turndown. Using turndown will add 5 feet (1.5 m) to the equivalent length of the pipe.
- 8. A multiple furnace installation may use a group of up to four terminations assembled together horizontally, as shown in Figure 42.




Figure 39.





Figure 40. Direct Vent Concentric Rooftop Termination 71M80, 69M29 or 60L46 (US) 44W92 or 44W93 (Canada)



#### Figure 41. Direct Vent Concentric Wall Termination 71M80, 69M29 or 60L46 (US) 44W92 or 44W93 (Canada)




Figure 42.





Figure 43. Direct Vent Application Using Existing Chimney





EXTENDED

APPLICATION


Ć2

|   | 2" (51mm)<br>Vent Pipe | 3" (76mm)<br>Vent Pipe |
|---|------------------------|------------------------|
| <ul> <li>A- Minimum clearance<br/>above grade or average<br/>snow accumulation</li> </ul> | 12" (305 mm)           | 12" (305 mm)           |
| <ul> <li>B- Maximum horizontal<br/>separation between<br/>intake and exhaust</li> </ul>   | 6" (152 mm)            | 6" (152 mm)            |
| <b>C1</b> -Minimum from end of exhaust to inlet of intake                                 | 8" (203 mm)            | 8" (203 mm)            |
| <b>C2 -</b> Minimum from end of exhaust to inlet of intake                                | 6" (152 mm)            | 6" (152 mm)            |
| D− Maximum exhaust<br>pipe length   | 12" (305 mm)           | 20" (508 mm)           |
| E- Maximum wall support<br>distance from top of each<br>pipe (intake/exhaust)             | 6" (152 mm)            | 6" (152 mm)            |

\* Use wall support every 24" (610 mm). Use two wall supports if extension is greater than 24" (610 mm) but less than 48" (1219 mm).
NOTE - One wall support must be within 6" (152 mm) from top of each pipe (intake and exhaust) to prevent movement in any direction.

#### ALTERNATE TERMINATIONS (TEE & FORTY-FIVE DEGREE ELBOWS ONLY)

B



|   | 2" (51MM)<br>Vent Pipe                 | 3" (76MM)<br>Vent Pipe                 |
|---|--|--|
| A− Clearance above<br>grade or average snow<br>accumulation                     | 12" (305 mm) Min.                      | 12" (305 mm) Min.                      |
| <ul> <li>B- Horizontal<br/>separation between<br/>intake and exhaust</li> </ul> | 6" (152 mm) Min.<br>24" (610 mm) Max.  | 6" (152 mm) Min.<br>24" (610 mm) Max.  |
| C- Minimum from<br>end of exhaust to<br>inlet of intake                         | 9" (227 mm) Min.                       | 9" (227 mm) Min.                       |
| D- Exhaust pipe length  | 12" (305 mm) Min.<br>16" (405 mm) Max. | 12" (305 mm) Min.<br>20" (508 mm) Max. |
| E- Wall support distance<br>from top of each pipe<br>(intake/exhaust)           | 6" (152 mm) Max.                       | 6" (152 mm) Max.                       |
| Front View of<br>Intake and Exhaust   |  |  |

<sup>1</sup> The exhaust termination tee should be connected to the 2" or 3" PVC flue pipe as shown in the illustration. Do not use an accelerator in applications that include an exhaust termination tee. The accelerator is not required.

Exhaust

Intake


- <sup>2</sup> As required. Flue gas may be acidic and may adversely affect some building materials. If a side wall vent termination is used and flue gases will impinge on the building materials, a corrosion-resistant shield (24 inches square) should be used to protect the wall surface. If optional tee is used, the protective shield is recommended. The shield should be constructed using wood, sheet metal or other suitable material. All seams, joints, cracks, etc. in affected area, should be sealed using an appropriate sealant.
- <sup>3</sup> Exhaust pipe 45° elbow can be rotated to the side away from the combustion air inlet to direct exhaust away from adjacent property. The exhaust must never be directed toward the combustion air inlet.

Figure 44.


### Details of Exhaust Piping Terminations for Non-Direct Vent Applications


Exhaust pipes may be routed either horizontally through an outside wall or vertically through the roof. In attic or closet installations, vertical termination through the roof is preferred. Figure 45 through Figure 48 show typical terminations.


- Exhaust piping must terminate straight out or up as shown. The termination pipe must be sized as listed in Table 8. The specified pipe size ensures proper velocity required to move the exhaust gases away from the building.
- On field supplied terminations for side wall exit, exhaust piping may extend a maximum of 12 inches (305 mm) for 2" PVC and 20" (508 mm) for 3" (76 mm) PVC beyond the outside wall. See Figure 46.
- If exhaust piping must be run up a sidewall to position above snow accumulation or other obstructions, piping must be supported every 24" (610 mm) as shown in Figure 47. When exhaust piping must be run up an outside wall, any reduction in exhaust pipe size must be done after the final elbow.




### Figure 45. Non-Direct Vent Roof Termination Kit (15F75 or 44J41)







### Figure 47. Non-Direct Vent Field Supplied Wall Termination Extermination





### Exhaust through Crawl Space Vent Option

All 33" condensing gas furnaces (92%+) are now approved to be vented down through a crawl space. Ensure a vent pipe drain kit, 51W18 (USA) or 15Z70 (Canada), is used as directed through the floor joists and into the crawl space. See the following figures.

Consult the vent tables for vent lengths and approved materials.




Figure 49. Kit 51W18 (USA) / 15Z70 (Canada) Parts Identification and Assembly




Figure 50. Crawl Space Vent Pipe Drain Trap Assembled Incorrectly





Figure 51. Upflow or Downflow Furnace with Exhaust through Crawl Space

### **Condensate Piping**

This unit is designed for either right or left side exit of condensate piping in upflow applications. In horizontal applications, the condensate trap must extend below the unit. An 8" service clearance is required for the condensate trap.

Refer to Figure 52 and Figure 53 for condensate trap locations. Figure 58 shows trap assembly using 1/2" PVC or 3/4" PVC.





**NOTE:** If necessary the condensate trap may be installed up to 5' away from the furnace. Use PVC pipe to connect trap to furnace condensate outlet. Piping from furnace must slope down a minimum of 1/4" per ft. toward trap.

- 1. Determine which side condensate piping will exit the unit, location of trap, field-provided fittings and length of PVC pipe required to reach available drain.
- 2. Use a large flat head screw driver or an 1/2" drive socket extension and remove plug (Figure 52) from the cold end header box at the appropriate location on the side of the unit. Install provided 3/4 NPT street elbow fitting into cold end header box. Use Teflon tape or appropriate pipe dope.
- 3. Install the cap over the clean out opening at the base of the trap. Secure with clamp. See Figure 58.

4. Install drain trap using appropriate PVC fittings, glue all joints. Glue the provided drain trap as shown in Figure 58. Route the condensate line to an open drain. Condensate line must maintain a 1/4" downward slope from the furnace to the drain.

### 

Do not use copper tubing or existing copper condensate lines for drain line.

- Install field provided vent on trap assembly as shown in Figure 53 through Figure 59. Trap must extend at least 1" above the furnace condensate drain connection in upflow applications and 4-1/2" above the bottom of the cabinet in horizontal applications.
- 6. If unit will be started immediately upon completion of installation, prime trap per procedure outlined in Unit Start-Up section.

Condensate line must slope downward away from the trap to drain. If drain level is above condensate trap, condensate pump must be used. Condensate drain line should be routed within the conditioned space to avoid freezing of condensate and blockage of drain line. If this is not possible, a heat cable kit may be used on the condensate trap and line. Heating cable kit is available in various lengths: 6 ft. (1.8 m) - kit no. 26K68 and 24 ft. (7.3 m) - kit no. 26K69.




Figure 53. Condensate Trap Locations (Unit shown in upflow position with remote trap)

### IMPORTANT

When combining the furnace and evaporator coil drains together, the A/C condensate drain outlet must be vented to relieve pressure in order for the furnace pressure switch to operate properly.




Figure 54. Evaporator Coil Using a Separate Drain (Unit shown in horizontal right-hand discharge position)




Figure 55. Evaporator Coil Using a Separate Drain




Figure 56. Evaporator Coil Using a Common Drain




Figure 57. Evaporator Coil Using a Common Drain (Unit shown in horizontal left-hand discharge position)




Figure 58. Trap / Drain Assembly Using 1/2" PVC or 3/4" PVC




Figure 59. Condensate Trap with Optional Overflow Switch

### Gas Piping

### 

If a flexible gas connector is required or allowed by the authority that has jurisdiction, black iron pipe shall be installed at the gas valve and extend outside the furnace cabinet. The flexible connector can then be added between the black iron pipe and the gas supply line.

### 

Do not exceed 600 in.-lbs. (50 ft.-lbs.) torque when attaching the gas piping to the gas valve.

1. Gas piping may be routed into the unit through either the left or right hand side. Supply piping enters into the gas valve from the side of the valve as shown in Figure 61 and Figure 62.

### 

A low inlet pressure switch in LP/propane applications is recommended.

 When connecting gas supply, factors such as length of run, number of fittings and furnace rating must be considered to avoid excessive pressure drop. Table 9 list recommended pipe sizes for typical applications.

**NOTE:** Use two wrenches when connecting gas piping to avoid transferring to the manifold.

- Gas piping must not run in or through air ducts, clothes chutes, chimneys or gas vents, dumb waiters or elevator shafts. Center gas line through piping hole. Gas line should not touch side of unit. See Figure 61 and Figure 62.
- 4. Piping should be sloped 1/4 " per 15 feet (6 mm per 5.6 m) upward toward the gas meter from the furnace. The piping must be supported at proper intervals, every 8 to 10 feet (2.44 to 3.05 m), using suitable hangers or straps. Install a drip leg in vertical pipe runs to serve as a trap for sediment or condensate.
- 5. A 1/8" N.P.T. plugged tap or pressure post is located on the gas valve to facilitate test gauge connection. See Figure 60.
- In some localities, codes may require installation of a manual main shut-off valve and union (furnished by installer) external to the unit. Union must be of the ground joint type.

### 

Compounds used on threaded joints of gas piping must be resistant to the actions of liquified petroleum gases.

### Leak Check

After gas piping is completed, carefully check all fieldinstalled piping connections for gas leaks. Use a commercially available leak detecting solution specifically manufactured for leak detection. Never use an open flame to test for gas leaks.

The furnace must be isolated from the gas supply system by closing the individual manual shut-off valve during any gas supply system at pressures greater than or equal to 1/2 psig (3.48 kPa, 14 inches w.c.). This furnace and its components are designed, manufactured and independently certified to comply with all applicable ANSI/CSA standards. A leak check of the furnace and its components is not required.




Figure 60.

### 

When testing pressure of gas lines, gas valve must be disconnected and isolated. See Figure 60. Gas valves can be damaged if subjected to pressures greater than 1/2 psig (3.48 kPa).



#### FIRE OR EXPLOSION HAZARD

Failure to follow the safety warnings exactly could result in serious injury, death, or property damage. Never use an open flame to test for gas leaks. Check all connections using a commercially available soap solution made specifically for leak detection. Some soaps used for leak detection are corrosive to certain metals. Carefully rinse piping thoroughly after leak test has been completed.




Figure 61. Gas Piping Upflow Applications




Figure 62. Gas Piping Horizontal Applications Gas Pipe Capacity - FT<sup>3</sup>/HR (kL/HR)

| Nominal                               | Internal   | Length of Pipe - feet (m) |               |               |                |                |                |                |                |                |                 |
|---------------------------------------|--|---------------------------|---------------|---------------|----------------|----------------|----------------|----------------|----------------|----------------|-----------------|
| Iron Pipe<br>Size -<br>inches<br>(mm) | Diameter<br>- inches<br>(mm)   | 10<br>(3.048)             | 20<br>(6.096) | 30<br>(9.144) | 40<br>(12.192) | 50<br>(15.240) | 60<br>(18.288) | 70<br>(21.336) | 80<br>(24.384) | 90<br>(27.432) | 100<br>(30.480) |
| 1/2                                   | .622   | 175                       | 120           | 97            | 82             | 73             | 66             | 61             | 57             | 53             | 50              |
| (12.7)                                | (17.799)   | (4.96)                    | (3.40)        | (2.75)        | (2.32)         | (2.07)         | (1.87)         | (1.73)         | (1.61)         | (1.50)         | (1.42)          |
| 3/4                                   | .824   | 360                       | 250           | 200           | 170            | 151            | 138            | 125            | 118            | 110            | 103             |
| (19.05)                               | (20.930)   | (10.19)                   | (7.08)        | (5.66)        | (4.81)         | (4.28)         | (3.91)         | (3.54)         | (3.34)         | (3.11)         | (2.92)          |
| 1                                     | 1.049  | 680                       | 465           | 375           | 320            | 285            | 260            | 240            | 220            | 205            | 195             |
| (25.4)                                | (26.645)   | (19.25)                   | (13.17)       | (10.62)       | (9.06)         | (8.07)         | (7.36)         | (6.80)         | (6.23)         | (5.80)         | (5.52)          |
| 1-1/4                                 | 1.380  | 1400                      | 950           | 770           | 660            | 580            | 530            | 490            | 460            | 430            | 400             |
| (31.75)                               | (35.052)   | (39.64)                   | (26.90)       | (21.80)       | (18.69)        | (16.42)        | (15.01)        | (13.87)        | (13.03)        | (12.18)        | (11.33)         |
| 1-1/2                                 | 1.610  | 2100                      | 460           | 1180          | 990            | 900            | 810            | 750            | 690            | 650            | 620             |
| (38.1)                                | (40.894)   | (59.46)                   | (41.34)       | (33.41)       | (28.03)        | (25.48)        | (22.94)        | (21.24)        | (19.54)        | (18.41)        | (17.56)         |
| 2                                     | 2.067  | 3950                      | 2750          | 2200          | 1900           | 1680           | 1520           | 1400           | 1300           | 1220           | 1150            |
| (50.8)                                | (52.502)   | (111.85)                  | (77.87)       | (62.30)       | (53.80)        | (47.57)        | (43.04)        | (39.64)        | (36.81)        | (34.55)        | (32.56)         |
| 2-1/2                                 | 2.469  | 6300                      | 4350          | 3520          | 3000           | 2650           | 2400           | 2250           | 2050           | 1950           | 1850            |
| (63.5)                                | (67.713)   | (178.39)                  | (123.17)      | (99.67)       | (84.95)        | (75.04)        | (67.96)        | (63.71)        | (58.05)        | (55.22)        | (52.38)         |
| 3                                     | 3.068  | 11000                     | 7700          | 6250          | 5300           | 4750           | 4300           | 3900           | 3700           | 3450           | 3250            |
| (76.2)                                | (77.927)   | (311.48)                  | (218.03)      | (176.98)      | (150.07)       | (134.50)       | (121.76)       | (110.43)       | (104.77)       | (97.69)        | (92.03)         |
| 4                                     | 4.026  | 23000                     | 15800         | 12800         | 10900          | 9700           | 9700           | 8100           | 7500           | 7200           | 6700            |
| (101.6)                               | (102.260)  | (651.27)                  | (447.39)      | (362.44)      | (308.64)       | (274.67)       | (274.67)       | (229.36)       | (212.37)       | (203.88)       | (189.72)        |
| NOTE: Capac                           | NOTE: Capacity given in cubic feet of gas per hour (kilo liters of gas per hour) and based on 0.60 specific gravity gas. |                           |               |               |                |                |                |                |                |                |                 |

Table 9.

#### ELECTROSTATIC DISCHARGE (ESD)

#### **Precautions and Procedures**

### 

Electrostatic discharge can affect electronic components. Take precautions during furnace installation and service to protect the furnace's electronic controls. Precautions will help to avoid control exposure to electrostatic discharge by putting the furnace, the control and the technician at the same electrostatic potential. Neutralize electrostatic charge by touching hand and all tools on an unpainted unit surface, such as the gas valve or blower deck, before performing any service procedure.




Figure 63.




Figure 64.

The unit is equipped with a field makeup box. The makeup box may be moved to the right side of the furnace to facilitate installation. Seal unused openings on left side with plugs removed from right side. Secure the excess wire to the existing harness to protect it from damage. Refer Figure 66 for wiring diagram and troubleshooting.

The power supply wiring must meet Class I restrictions. Protected by either a fuse or circuit breaker, select circuit protection and wire size according to unit nameplate.

**NOTE:** Unit nameplate states maximum current draw. Maximum Over-Current Protection allowed is 15 AMP.

Holes are on both sides of the furnace cabinet to facilitate wiring.

Install a separate (properly sized) disconnect switch near the furnace so that power can be turned off for servicing.

Before connecting the thermostat check to make sure the wires will be long enough for servicing at a later date. Make sure that thermostat wire is long enough to facilitate future removal of blower for service.

Complete the wiring connections to the equipment. Use the provided unit wiring diagram shown in Figure 66. Use 18 gauge wire or larger that is suitable for Class II rating for thermostat connections.

Electrically ground the unit according to local codes or, in the absence of local codes, according to the current National Electric Code (ANSI/HFPA No. 70) for the USA and current Canadian Electric Code Part 1 (CSA standard C22.1) for Canada. A green ground wire is provided in the field makeup box.

**NOTE:** The gas furnace contains electronic components that are polarity sensitive. Make sure that the furnace is wired correctly and is properly grounded.

#### Thermostat

Install the room thermostat according to the instructions provided with the thermostat. See Figure 65 for thermostat designations. If the furnace is being matched with a heat pump, refer to the appropriate dual fuel thermostat installation instruction.




Figure 65.

#### **Generator Use - Voltage Requirements**

- The furnace requires 120 volts ± 10% (Range: 108 volts to 132 volts)
- The furnace operates at 60 Hz ± 5% (Range: 57 Hz to 63 Hz)
- The furnace integrated control requires both proper polarity and proper ground. Both polarity and proper grounding should be checked before attempting to operate the furnace on either permanent or temporary power.
- Generator should have a wave form distortion of less than 5% THD (total harmonic distortion).




Figure 66. Typical Wiring Diagram

#### **Ignition Control**

#### Ignition Control DIP Switch Settings

A93UH1EK & 92G1UHEK units are equipped with a single-stage integrated control. This control manages ignition timing, heating mode fan off delays and indoor blower speeds based on selections made using the control dip switches and jumpers. The control includes an internal watchguard feature which automatically resets the ignition control when it has been locked out. After one hour of continuous thermostat demand for heat, the watchguard will break and remake thermostat demand to the furnace and automatically reset the control to relight the furnace.

#### **Accessory Terminals FIGURE 69**

One line voltage "ACC" 1/4" spade terminal is provided on the furnace integrated control. . This terminal is energized when the indoor blower is operating. Any accessory rated up to one amp can be connected to this terminal with the neutral leg of the circuit being connected to one of the provided neutral terminals. If an accessory rated at greater than one amp is connected to this terminal, it is necessary to use an external relay.

One line voltage "HUM" 1/4" spade terminal is provided on the furnace integrated control. This terminal is energized in the heating mode when the combustion air inducer is operating. Any humidifier rated up to one amp can be connected to this terminal with the neutral leg of the circuit being connected to one of the provided neutral terminals. If a humidifier rated at greater than one amp is connected to this terminal, it is necessary to use an external relay.

One 24V "H" 1/4" spade terminal is provided on the furnace integrated control. The terminal is energized in the heating mode when the combustion air inducer is operating and the pressure switch is closed. Any humidifier rated up to 0.5 amp can be connected to this terminal with the ground leg of the circuit connected to ground or the "C" terminal **Indoor Blower Operation DIP Switch Setting** The heat fan-on time of 30 seconds is not adjustable The heat fan-off delay (amount of time that the blower operates after the heat demand has been satisfied) may be adjusted by changing the two position dip switch on the integrated control, to one of four selections. Blower off delay is factory set at 120 seconds. For other blower off delay settings, please refer to the following chart:

| Blower Delay Select    |     |     |  |  |
|------------------------|-----|-----|--|--|
| SW1-1 SW1-2            |     |     |  |  |
| 90                     | OFF | ON  |  |  |
| 120                    | OFF | OFF |  |  |
| 180                    | ON  | OFF |  |  |
| 210                    | ON  |     |  |  |
| Factory Setting is 120 |     |     |  |  |

#### ON BOARD LINKS AND DIAGNOSTIC PUSH BUTTON

#### See FIGURE 67 and FIGURE 68

### **MIMPORTANT**


Carefully review all configuration information provided. Failure to properly set DIP switches, jumpers and onboard links can result in improper operation!

#### On-Board Link W951 Heat Pump (R to O)


On-board link W951 is a clippable connection between terminals R and O on the integrated control. W951 must be cut when the furnace is installed in applications which include a heat pump unit and a thermostat which features dual fuel use. If the link is left intact, terminal "O" will remain energized eliminating the HEAT MODE in the heat pump.

#### **Diagnostic Push Button**

The diagnostic push button is located adjacent to the seven-segment diagnostic LED. This button is used to enable the Error Code Recall "E" mode and the Flame Signal "F" mode. Press the button and hold it to cycle through a menu of options. Every five seconds a new menu item will be displayed. When the button is released, the displayed item will be selected. Once all items in the menu have been displayed, the menu resumes from the beginning until the button is released.




**FIGURE 67** 



\*Connect W to W ONLY if using defrost tempering kit 67M41

**FIGURE 68** 



Single Stage, Constant Torque, Non-Communicating

#### FIGURE 69

#### TABLE 10

| 1/4" QUICK CONNECT TERMINALS  |   |  |  |  |
|-------------------------------|---|--|--|--|
| 120V HUM                      | POWER FOR HUMIDIFIER (120 VAC                                 |  |  |  |
| LINE                          | INCOMING POWER LINE (120 VAC)                                 |  |  |  |
| XFMR                          | TRANSFORMER PRIMARY (120 VAC)                                 |  |  |  |
| CIRC                          | INDOOR BLOWER MOTOR (120 VAC)                                 |  |  |  |
| ACC                           | ACCESSORY(120 VAC)  |  |  |  |
| 24V HUM                       | HUMIDIFIER (24 VAC)   |  |  |  |
| NEUTRALS                      | NEUTRAL (5)   |  |  |  |
| 3/16" QUICK CONNECT TERMINALS |   |  |  |  |
| COOL                          | COOL SPEED TAP FROM INDOOR BLOWER<br>MOTOR (24 VAC)           |  |  |  |
| HEAT                          | HEAT SPEED TAP FROM INDOOR BLOWER<br>MOTOR (24 VAC)           |  |  |  |
| FAN                           | CONTINUOUS FAN SPEED TAP FROM<br>INDOOR BLOWER MOTOR (24 VAC) |  |  |  |
| FLAME SENSE                   | FLAME SENSOR ELECTRODE (120 VAC)                              |  |  |  |
| COMMON                        | COMMON (24 VAC)   |  |  |  |
| TWIN                          | 24V TWINNING COMMUNICATION                                    |  |  |  |
| PARK                          | 3 TERMINALS TO PARK UNUSED MOTOR<br>SPEED TAPS                |  |  |  |

| TABLE | 11 |
|-------|----|
| IADLL |    |

| THERMOSTAT INPUT TERMINALS |  |  |  |
|----------------------------|--|--|--|
| W                          | HEAT                                   |  |  |
| С                          | COMMON GROUND                          |  |  |
| R                          | 24V AC                                 |  |  |
| G                          | FAN                                    |  |  |
| Y                          | COOL                                   |  |  |
| 0                          | REVERSING VALVE (when W951 is clipped) |  |  |

#### **TABLE 12**

| LOW GWP INTERFACE |  |  |  |
|-------------------|--|--|--|
| LGWP1             | LOW GWP SENSOR #1 INTERFACE                              |  |  |
| LGWP2             | LOW GWP SENSOR # 2 INTERFACE                             |  |  |
| ALARM             | INTERFACE TO LOW GWP LEAK AUDIBLE<br>ALARM (DRY CONTACT) |  |  |
| ZONE              | INTERFACE TO ZONING CONTROL (DRY<br>CONTACT)             |  |  |
| LGWP TEST         | PUSH BUTTON TO TEST LOW GWP<br>FUNCTIONALITY             |  |  |

| DIAGNOSTIC CODES / STATUS OF FURNACE  | CODE |
|---|------|
| IDLE MODE (DECIMALBLINKS AT 1 HERTZ 0.5 SECONDS ON, 0.5 SECONDS OFF   |      |
| INDOOR BLOWER OPERATION: CONTINUOUS FAN MODE (COSTANT TORQUE ONLY)  |      |
| INDOOR BLOWER OPERATION: FOLLOWED BY CFM SETTING FOR INDOOR BLOWER (1 SECOND ON, 0.5 SECOND OFF) / CFM SETTING FOR MODE DISPLAYED (VARIALBE SPEED ONLY) | Α    |
| COOLING STAGE (1 SECOND ON, 0.5 SECOND OFF) 1 OR 2 DISPLAYED / PAUSE / REPEAT CODES.<br>VARIABLE SPEED ONLY   | С    |
| GAS HEAT (1 SECOND ON, 0.5 SECOND OFF) PAUSE / CFM DISPLAYED / PAUSE / REPEAT CODES<br>BLINKING - IGNITION  | Н    |
| HEAT PUMP STAGE (1 SECOND ON, 0.5 SECOND OFF) 1 OR 2 DISPLAYED / PAUSE / CFM SETTING<br>DISPLAYED / PAUSE / REPEAT CODES                                | h    |
| DEFROST MODE  | dF   |
| ERROR/FAULT CONDTION  | CODE |
| NO ERROR IN THE MEMORY  | E000 |
| ELECTRICAL FAULTS (WAIT FOR RECOVERY)   |      |
| AC LINE VOLTAGE LOW   | E110 |
| TWIN COMMUNICATION FAULT (CONSTANT TORQUE ONLY)   | E106 |
| LINE VOLTAGE POLARITY REVERSED  | E111 |
| AC LINE VOLTAGE HIGH  | E113 |
| HARDWARE FAULT (5 MINUTES LOCKOUT)  |      |
| CONTROL HARDWARE (INCLUDE A/D ELECTRONICS AND FLAME TEST) FAILURE   | E125 |
| HARD LOCKOUT FAULT  |      |
| ROLLOUT OPEN OR PREVIOUSLY OPENED   | E200 |
| GAS VALVE/PRESSURE SWITCH/LIMT FAULTS (wait for recovery)   |      |
| GAS VALVE RELAY (1ST OR 2ND STAGE) PROBLEM  | E204 |
| LOW PRESSURE SW FAILED TO CLOSE (STUCK OPEN)  | E223 |
| LOW PRESSURE SW FAILED TO OPEN (STUCK CLOSED)   | E224 |
| LOW PRESSURE SWITCH OPENED IN RUN OR TFI  | E227 |
| FLAME SENSE OUT OF SEQUENCE-STILL PRESENT   | E241 |
| PRIMARY LIMIT SWITCH OPENED   | E250 |

#### **IGNITION CONTROLDIAGNOSTIC CODES (CONTINUED)**

| SOFT LOCKOUT FAULTS (60 MINUTES)  |      |
|---|------|
| SOFT LOCKOUT-FLAME FAILURE ON IGNITION, IGNITION RETRY>MAX, LAST FAILED RETRY DUE<br>TO FLAME FAILURE   | E270 |
| SOFT LOCKOUT-PRESSURE SWITCH OPEN, IGNITION RETRY>MAX, LAST FAILED RETRY DUE TO LPSW OPEN               | E271 |
| SOFT LOCKOUT-PRESSURE SWITCH OPEN, IN RUN MODE HEATING RECYCLES>MAX, LAST FAILED RETRY DUE TO LPSW OPEN | E272 |
| SOFT LOCKOUT-FLAME FAILURE IN RUN MODE, HEATING RECYCLES>MAX, LAST FAILED RETRY DUE TO LOSS OF FLAME    | E273 |
| SOFT LOCKOUT-LIMIT OPEN > 3 MINUTES   | E274 |
| SOFT LOCKOUT-FLAME OUT OF SEQUENCE AND IS GONE  | E275 |
| PERFORMANCE WARNING   |      |
| POOR GROUND DETECTED  | E117 |
| LOW FLAME CURRENT IN HEATING MODE   | E240 |
| INDOOR BLOWER UNABLE TO START (VARIABLE SPEED ONLY)   | E292 |
| LOW GWP REFRIGERANT FAULTS  |      |
| REFRIGERANT LEAK DETECTED, THERMOSTAT LOCKOUT   | E150 |
| REFRIGERANT LEAK DETECTOR SENSOR #1 FAULT   | E151 |
| REFRIGERANT LEAK DETECTOR SENSOR #2 FAULT   | E152 |
| REFRIGERANT LEAK DETECTOR SENSOR #1 COMM. LOST  | E154 |
| REFRIGERANT LEAK DETECTOR SENSOR #2 COMM. LOST  | E155 |
| REFRIGERANT LEAK DETECTOR SENSOR #1 TYPE INCORRECT  | E160 |
| REFRIGERANT LEAK DETECTOR SENSOR #2 TYPE INCORRECT  | E161 |
| REFRIGERANT LEAK DETECTOR CONTROL FAILURE   | E163 |
| LOW GWP TEST  | E164 |
| LOW GWP RELAY STUCK   | E390 |

#### **Indoor Blower Speeds**

- 1 When the thermostat is set to "FAN ON," the indoor blower will run continuously on the (FAN) speed when there is no cooling or heating demand. See table below for for allowable circulation speeds.
- 2 When the A93UH1EK & 92G1UHEK is running in the heating mode, the indoor blower will run on the heating speed (HEAT). See table below for allowable heating speeds.
- 3 When there is a cooling demand, the indoor blower will run on the cooling speed (COOL).

|       | Allowable Heating Speeds |             |                 |                 |                 |             |
|-------|--------------------------|-------------|-----------------|-----------------|-----------------|-------------|
| Model | Cooling<br>Capacity      | Red         | Yellow          | Blue            | Brown           | Black       |
| 030   | 3 ton                    | Allowed     | Factory Sotting | Allowed         |                 |             |
| 040   | 3 ton                    | Allowed     | Factory Setting | Allowed         | Allowed         |             |
| 070   | 3 ton                    |             | Allowed         | Factory Setting |                 | Not Allowed |
| 090   | 3 ton                    |             | Not Allowed     | Allowed         | Factory Setting |             |
| 090   | 4 ton                    | Not Allowed | Allowed         | Factory Setting | Allowed         |             |
| 110   | 4 ton                    |             | Not Allowed     | Allowed         | Factory Setting | Allowed     |
| 110   | 5 ton                    |             | Allowed         | Factory Setting | Allowed         | Not Allowed |

| TABLE 13                     |                 |             |             |             |             |
|------------------------------|-----------------|-------------|-------------|-------------|-------------|
| Allowable Circulation Speeds |                 |             |             |             |             |
| Model Number                 | Red             | Yellow      | Blue        | Brown       | Black       |
| All Models                   | Factory Setting | Not Allowed | Not Allowed | Not Allowed | Not Allowed |

#### TABLE 14

#### Twinning Two A93UH1EK & 92G1UHEK Furnaces

The control board in this furnace is equipped with a provision to "twin" (interconnect) two (2) adjacent furnaces with a common plenum such that they operate as one (1) large unit.


When twinned, the circulating blower speeds are synchronized between the furnaces. If either furnace has a need to run the blower, both furnaces will run the blower on the same speed. The cooling speed has highest priority, followed by heating speed and fan speed.

Field installation of twinning consists of connecting wires between the "C", "O" and "Twin" terminals of the two controls.

The 24 VAC secondary of the two systems must be in phase. All thermostat connections are made to one control only. See diagram below.

The twinned furnace without thermostat connections is to have the call for heat supplied by an external 24VAC isolation relay\* to prevent its rollout switch from being bypassed by the other twinned furnace. The coil of the isolation relay connects from the thermostat "W" to 24 VAC common. The contacts of the relay connect "R" to "W" on the non-thermostat twin.

\*Wiring and quick connects will be field provided.



Low GWP Application

### A WARNING

For use with Allied approved evaporator coil and LGWP sensors only. Use original manufacturer recommended LGWP sensors if using non Allied approved evaporator coil.

## CONNECTING THE FURNACE CONTROL BOARD SENSOR.

#### See FIGURE 72 and follow steps below:

- 1 Route sensor wire #1 through provided grommet. Form a drip loop below the control board on upflow installations to prevent condensate dripping on the control board.
- 2 Avoid sharp edges when routing sensor wire during installation.
- 3 Sensor wire must not block view of 7 segment LED.

Ensure the cable is properly seated into the SENSOR 1 plug (LGWP1). The Molex plug clip should lock into the Molex connection point for a secured connection, as shown below in FIGURE 70. Verify the connection is free of dust, debris, and moisture.

**NOTE -** In confined space applications, connect the second sensor to the SENSOR 2 plug (LGWP2). Refer to evaporator coil installation instructions for more detail.




FIGURE 70

#### Low GWP DIP SWITCH SETTINGS

Adjust the DIP switch settings to the sensor configuration. Failure to do so will cause faults on power-up. See FIG-URE 71 and TABLE 15.



**FIGURE 71** 

#### TABLE 15

**DIP Switch Settings** 

| Configuration                        | Switch 1 | Switch 2  |
|--------------------------------------|----------|-----------|
| One (1) sensor, connected to SENSOR  | OFF      | ON        |
| 1 plug                               | (enable) | (disable) |
| Two (2) sensors, connected to SENSOR | OFF      | OFF       |
| 1 plug and SENSOR 2 plug             | (enable) | (enable)  |

In single sensor configurations, the sensor must be connected to the SENSOR 1 plug (LGWP1). Configurations other than the ones shown in TABLE 15 will cause a servicing fault.

Each DIP switch corresponds to a sensor position (i.e., DIP switch 1 to sensor 1; DIP switch 2 to sensor 2). The default factory switch positions are set to OFF (ENABLED)

The furnace control board software reads the OFF position as an active sensor. A sensor should be present for the corresponding sensor connector. Setting the DIP switch to ON disables the sensor position.

#### SECONDARY SENSOR REQUIREMENTS

#### **Additional Line Sets**

If additional refrigerant line joints are present outside of the line set sleeve, and a secondary refrigerant detection sensor is required, its installation must comply with the requirements listed in Refrigerant Detection Sensor Kit (27V53). See FIGURE 72 for routing the secondary sensor cable through the furnace cabinet.

## FURNACE CONTROL BOARD LOW GWP MODES OF OPERATION

The modes of operation for the furnace control board are Initializing, Normal, Leak Detected, and Fault.

#### Initializing

The furnace control board is establishing connection with the refrigerant detection sensor and is completing an initial five-minute purge sequence.

#### Normal

The HVAC system is functioning normally. The furnace control board has not detected a refrigerant leak.

#### Leak Detected

When the furnace control board detects a refrigerant leak:

 The furnace control board shuts off the (R) input (24VAC power) to the thermostat, which deenergizes the outdoor unit compressor and heat sources, such as gas and/or electric strip heat. No heating or cooling demands will be met.


- 2. The furnace control board activates the blower (high speed). The blower purges refrigerant from the cabinet, plenum, and ductwork.
- 3. After the furnace control board determines the refrigerant levels are below the safety threshold, the blower will continue to operate for the remainder of the seven (7) -minute cycle.
- 4. After the blower sequence is complete, the HVAC system resumes normal operation.

**NOTE** - The HVAC system may not maintain a cooling or heating setpoint if a significant leak exists. Any refrigerant leaks that remain unaddressed for an extended time may cause the HVAC system to shut down on a low refrigerant pressure limit condition.

#### Fault

When a Low GWP fault is detected by the furnace control board, the indoor unit blower engages and remains engaged at a constant air flow output until the fault is cleared.

**NOTE -** See Ignition Control Diagnostic Codes on page 45 for Low GWP diagnostic error codes.



#### LGWP TEST BUTTON FUNCTIONALITY

The furnace control board is equipped with a Test/Reset push button. The Test button can be used to perform several functions, depending on the mode of operation of the furnace control board.

TABLE 16 lists the functions of the Test button during each mode of operation.

#### TABLE 16

#### LGWP Test Button Function

| Mode of Operation | Press the Test Button to:   |
|-------------------|---|
| Normal            | Trigger a leak detection<br>response.<br>Verify all equipment is wired<br>correctly into the furnace<br>blower control board (after<br>installation).   |
| Leak Detected     | Reset the furnace control<br>board to a normal mode of<br>operation after a previous<br>leak has been detected<br>and purged from the HVAC<br>system  |
| Fault             | Reset the furnace control<br>board after troubleshoot-<br>ing and resolving a fault<br>condition. If the fault is not<br>resolved, the furnace control<br>board will enter the Fault<br>mode again. |

#### LGWP Test Button - Additional Functions

TABLE 17 lists the additional functions of the Test Button while the furnace control board is functioning within the states of Initializing, Monitoring, Leak Detection, Servicing and Fault.

#### TABLE 17 Additional Button Functions

| State        | Press | Action   |
|--------------|-------|--|
| Initializing | Short | Skips remaining pre-purge after<br>sensors are recognized by the<br>furnace control board        |
| Initializing | Long  | Reset control  |
| Monitoring   | Short | Clear purge-counter if prior mitiga-<br>tion has occurred; Test mitigation                       |
| Monitoring   | Long  | Reset control  |
| Mitigating   | Short | If testing mitigation, end test  |
| Servicing    | Short | Reevaluate fault condition - if<br>cleared return to monitoring, other-<br>wise update indicator |
| Servicing    | Long  | Reset control  |
| Fault        | Short | Reevaluate fault condition - if<br>cleared return to monitoring, other-<br>wise update indicator |
| Fault        | Long  | Reset control  |

#### External Alarm

(For applications with external alarms wired directly to the furnace control board)

The furnace control board triggers the external alarm system when it enters Leak Detected mode. For alarm notifications, the furnace control board provides a dry relay contact that is rated 3A at 30 VAC/DC.

#### THERMOSTAT COMPATIBILITY

Thermostats that preserve memory settings are compatible with the furnace control board. Examples include:

- Battery-powered thermostats
- Analog Thermostat
- · Late-model programmable thermostats

# **NOTE -** Early-generation digital and programmable thermostats may not retain the operation mode and temperature setpoints after a power outage.

The following scenarios are likely to occur when home occupants are not available to adjust the thermostat setpoints as the system is recovering from leak detection and resuming normal operation:

- Heating could be lost during a cold night
- · Cooling could be lost during a hot day
- The thermostat could reset to an incorrect temperature setpoint

#### START UP PROCEDURE

The furnace control board is equipped with a LGWP Test/ Reset button, see Test Button Functionality. After the furnace control board has been mounted and wired, restore power to the HVAC system. The system will then run through a purge sequence for five minutes. After the purge sequence is complete, proceed to testing cooling demand and heating demand.

#### **Cooling Demand**

- 1. Prompt a cooling demand at the thermostat.
- 2. Press the LGWP Test button on the furnace control board.

The system then executes a leak detection response.

- 3. Observe the following sequence:
  - a. The LED indicator for leak detection. See Ignition Control Diagnostic Codes on on page 45.
  - b. The blower powers up.
  - c. The outdoor compressor powers down.
- 4. Press the LGWP Test button to terminate the simulated Leak Detected mode upon test completion

#### Heating Demand

- 1. Prompt a heating demand at the thermostat.
- 2. Observe the following sequence:
  - a. The LED indicator for leak detection. See Ignition Control Diagnostic Codes on page 45 .
  - b. The blower powers up.
  - c. The gas burners power down.
  - d. The outdoor compressor powers down.
- 3. Press the LGWP Test button to terminate the simulated Leak Detected mode upon test completion.

The installation of the furnace control board is complete after both sequences are successfully completed.

#### Unit Start-Up

#### FOR YOUR SAFETY READ BEFORE OPERATING

### 

Do not use this furnace if any part has been underwater. A flood-damaged furnace is extremely dangerous. Attempts to use the furnace can result in fire or explosion. Immediately call a qualified service technician to inspect the furnace and to replace all gas controls, control system parts, and electrical parts that have been wet or to replace the furnace, if deemed necessary.

### 

Danger of explosion. Can cause injury or product or property damage. Should the gas supply fail to shut off or if overheating occurs, shut off the gas valve to the furnace before shutting off the electrical blower deck, before performing any service procedure.

### 

Before attempting to perform any service or maintenance, turn the electrical power to unit OFF at disconnect switch.

**BEFORE LIGHTING** the unit, smell all around the furnace area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

The gas valve on the unit is equipped with a gas control switch (lever). Use only your hand to move switch. Never use tools. If the switch will not move by hand, do not try to repair it. Force or attempted repair may result in a fire or explosion.

#### Placing the Furnace into Operation

This furnace is equipped with an automatic hot surface ignition system. Do not attempt to manually light burners on this furnace. Each time the thermostat calls for heat, the burners will automatically light. The ignitor does not get hot when there is no call for heat on these units.

#### Priming Condensate Trap

The condensate trap should be primed with water prior to start-up to ensure proper condensate drainage. Either pour 10 fl. oz. (300 ml) of water into the trap, or follow these steps to prime the trap:

- 1. Follow the lighting instructions to place the unit into operation.
- 2. Set the thermostat to initiate a heating demand.
- 3. Allow the burners to fire for approximately 3 minutes.
- 4. Adjust the thermostat to deactivate the heating demand.
- 5. Wait for the combustion air inducer to stop. Set the thermostat to initiate a heating demand and again allow the burners to fire for approximately 3 minutes.
- 6. Adjust the thermostat to deactivate the heating demand and wait for the combustion air inducer to stop. At this point, the trap should be primed with sufficient water to ensure proper condensate drain operation.


### 

If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or death.

#### Gas Valve Operation

See Figure 73

- 1. **STOP!** Read the safety information at the beginning of this section.
- 2. Set the thermostat to the lowest setting.
- 3. Turn OFF all electrical power to the unit.
- 4. This furnace is equipped with an ignition device which automatically lights the burners. Do not try to light the burners by hand.
- 5. Remove the upper access panel.
- 6. Move gas valve switch to OFF. See Figure 73.
- 7. Wait five minutes to clear out any gas. If you then smell gas, **STOP!** Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions. If you do not smell gas go to next step.



#### Figure 73.

- 8. Move gas valve switch to ON. See Figure 73.
- 9. Replace the upper access panel.
- 10. Turn on all electrical power to the unit.

11. Set the thermostat to desired setting.

**NOTE:** When unit is initially started, steps 1 through 11 may need to be repeated to purge air from gas line.

12. If the appliance will not operate, follow the instructions "Turning Off Gas to Unit" and call your service technician or gas supplier.

#### Turning Off Gas to Unit

- 1. Set the thermostat to the lowest setting.
- Turn off all electrical power to the unit if service is to be performed.
- 3. Remove the upper access panel.
- 4. Move gas valve switch to OFF.
- 5. Replace the upper access panel.

#### Failure To Operate

If the unit fails to operate, check the following:

- 1. Is the thermostat calling for heat?
- 2. Are access panels securely in place?
- 3. Is the main disconnect switch closed?
- 4. Is there a blown fuse or tripped breaker?
- 5. Is the filter dirty or plugged? Dirty or plugged filters will cause the limit control to shut the unit off.
- 6. Is gas turned on at the meter?
- 7. Is the manual main shut–off valve open?
- 8. Is the internal manual shut-off valve open?
- 9. Is the unit ignition system in lockout? If the unit locks out again, inspect the unit for blockages.

#### **Heating Sequence of Operation**

- 1. When thermostat calls for heat, combustion air inducer starts.
- Combustion air pressure switch proves blower operation. Switch is factory set and requires no adjustment.
- 3. After a 15 second pre-purge, the hot surface ignitor energizes.
- 4. After a 20 second ignitor warm-up period, the gas valve solenoid opens. A 4-second "Trial for Ignition" period begins.
- 5. Gas is ignited, flame sensor proves the flame, and the combustion process continues.
- 6. If flame is not detected after first ignition trial, the ignition control will repeat steps 3 and 4 four more times before locking out the gas valve. The ignition control will then automatically repeat steps 1 through 6 after 60 minutes. To interrupt the 60 minute period, move thermostat from "Heat" to "OFF" then back to "Heat". Heating sequence then restarts at step 1.

#### **Gas Pressure Adjustment**

#### Gas Flow (Approximate)

|                          | Seconds for One Revolution |                 |                 |                 |  |
|--------------------------|----------------------------|-----------------|-----------------|-----------------|--|
| Capacity                 | Nat                        | ural            | LP              |                 |  |
| oupuony                  | 1 cu ft<br>Dial            | 2 cu ft<br>Dial | 1 cu ft<br>Dial | 2 cu ft<br>Dial |  |
| -030                     | 120                        | 240             | 300             | 600             |  |
| -045                     | 80                         | 160             | 200             | 400             |  |
| -070                     | 55                         | 110             | 136             | 272             |  |
| -090                     | 41                         | 82              | 102             | 204             |  |
| -110                     | 33                         | 66              | 82              | 164             |  |
| Natural - 1000 btu/cu ft |                            |                 | LP - 2500       | ) btu/cu ft     |  |

#### Table 18. Gas Meter Clocking Chart

Furnace should operate at least 5 minutes before checking gas flow. Determine time in seconds for two revolutions of gas through the meter. (Two revolutions assures a more accurate time.) Divide by two and compare to time in Table 18. If manifold pressure matches Table 20 and rate is incorrect, check gas orifices for proper size and restriction. Remove temporary gas meter if installed.

**NOTE:** To obtain accurate reading, shut off all other gas appliances connected to meter.

#### Supply Pressure Measurement

When testing supply gas pressure, use the 1/8" N.P.T. plugged tap or pressure post located on the gas valve to facilitate test gauge connection. See Figure 73. Check gas line pressure with unit firing at maximum rate. Low pressure may result in erratic operation or underfire. High pressure can result in permanent damage to gas valve or overfire.

On multiple unit installations, each unit should be checked separately, with and without other units operating. Supply pressure must fall within range listed in Table 20.

#### Manifold Pressure Measurement

- 1. Remove the threaded plug from the outlet side of the gas valve and install a field provided barbed fitting. Connect to a manometer to measure manifold pressure.
- 2. Start unit and allow 5 minutes for unit to reach steady state.
- 3. While waiting for the unit to stabilize, observe the flame. Flame should be stable and should not lift from burner. Natural gas should burn blue.
- 4. After allowing unit to stabilize for 5 minutes, record manifold pressure and compare to value given in Table 20.

**NOTE:** Shut unit off and remove manometer as soon as an accurate reading has been obtained. Take care to remove barbed fitting and replace threaded plug.

#### **Proper Combustion**

Furnace should operate minimum 15 minutes with correct manifold pressure and gas flow rate before checking combustion. Take combustion sample beyond the flue outlet and compare to the tables below.

| Capacity   | CO <sub>2</sub> % for Nat | CO <sub>2</sub> % for L.P. |  |  |
|--|---------------------------|----------------------------|--|--|
| 030  | 6.5 - 7.5                 | 7.5 - 8.5                  |  |  |
| 045, 070, 090, 110   | 7 - 9                     | 8 - 10                     |  |  |
| The maximum carbon monoxide reading should not exceed 100 ppm. |                           |                            |  |  |

Table 19.

#### High Altitude Information

**NOTE:** In Canada, certification for installations at elevations over 4500 feet (1371 m) is the jurisdiction of local authorities.

Units may be installed at altitudes up to 10,000 ft. above sea level. See Table 20 for derate manifold values. Units installed at altitude of 7501 - 10,000 feet require an orifice change. Units installed at altitudes of 4,501 - 10,000 feet (1371 -3048 m) may require a pressure switch change which can be ordered separately.

Table 21 and Table 22 list required orifice conversion kits and pressure switch changes at varying altitudes.

The combustion air pressure switches are factory set and require no adjustment.

|  |              | Manifold Pressure in. w.g. |                      |                      |                      |                       | Supply Line Pressure       |      |
|--|--------------|----------------------------|----------------------|----------------------|----------------------|-----------------------|----------------------------|------|
| Capacity   | Gas          | 0 - 4,500 ft.              | 4,501 - 5,500<br>ft. | 5,501 - 6,500<br>ft. | 6,501 - 7,500<br>ft. | 7,501 -<br>10,000 ft. | in. w.g.<br>0 - 10,000 ft. |      |
| All  | Natural      | 3.5                        | 3.3                  | 3.2                  | 3.1                  | 3.5                   | 4.5                        | 13.0 |
|  | LP / Propane | 10.                        | 9.4                  | 9.1                  | 8.9                  | 10.0                  | 11.0                       | 13.0 |
| <b>NOTE</b> : A natural to LP propane gas changeover kit is necessary to convert this unit. Refer to the changeover kit installation instruction for the conversion procedure. |              |                            |                      |                      |                      |                       |                            |      |

#### Manifold and Supply Line Pressure 0 - 10,000 ft.

Table 20.

|          | 0 - 7,5<br>(0 - 2,2   |                       | 7,501 - 10,000 ft<br>(2,286 - 3,048 m)      |   |  |
|----------|-----------------------|-----------------------|---|---|--|
| Capacity | Natural to LP/Propane | LP/Propane to Natural | High Altitude<br>Natural Burner Orifice Kit | High Altitude<br>LP/Propane Burner<br>Orifice Kit |  |
| 030      | 17H62+                | N/A                   | 14C90                                       | 17H90   |  |
| 045      |                       | 73W80*                | 51W01                                       | 11K45+  |  |
| 070      | 11K50+                |                       |   |   |  |
| 090      |                       |                       |   |   |  |
| 110      |                       |                       |   |   |  |

\* Conversion requires installation of a gas valve regulator spring which is provided with the gas conversion Kit.

+ LP Kits include low line pressure switch.

#### Table 21. Burner Orifice Conversion Kits at Varying Altitudes

| Capacity   | 0 - 4500 ft<br>(0 - 1371m) | 4501 - 7500 ft<br>(1371 - 2286m) | 7501 - 10000 ft<br>(2286 - 3048m) |  |
|--|----------------------------|----------------------------------|-----------------------------------|--|
| 030  |                            |                                  |                                   |  |
| 045  |                            |                                  |                                   |  |
| 070  | No Change                  | 11U65                            | 11U66                             |  |
| 090  |                            |                                  |                                   |  |
| 110  |                            |                                  |                                   |  |
| Pressure switch is factory set. No adjustment necessary. All models use the factory-installed pressure switch from 0-4500 feet (0-<br>1371 m). |                            |                                  |                                   |  |

#### Table 22. Pressure Switch Requirements at Varying Altitudes

#### Testing for Proper Venting and Sufficient Combustion Air for Non-Direct Vent Applications

## 

#### CARBON MONOXIDE POISONING HAZARD

Failure to follow the steps outlined below for each appliance connected to the venting system being placed into operation could result in carbon monoxide poisoning or death.

The following steps shall be followed for each appliance connected to the venting system being placed into operation, while all other appliances connected to the venting system are not in operation.

After the gas furnace has been started, the following test should be conducted to ensure proper venting and sufficient combustion air has been provided to the unit as well as to other gas–fired appliances which are separately vented.

If this furnace replaces a Category I furnace which was commonly vented with another gas appliance, the size of the existing vent pipe for that gas appliance must be checked. Without the heat of the original furnace flue products, the existing vent pipe is probably oversized for the single water heater or other appliance. The vent should be checked for proper draw with the remaining appliance.

The test should be conducted while all appliances (both in operation and those not in operation) are connected to the venting system being tested. If the venting system has been installed improperly, or if provisions have not been made for sufficient amounts of combustion air, corrections must be made as outlined in the previous section.

- 1. Seal any unused openings in the venting system.
- 2. Visually inspect the venting system for proper size and horizontal pitch. Determine there is no blockage or restriction, leakage, corrosion, or other deficiencies which could cause an unsafe condition.
- 3. To the extent that it is practical, close all building doors and windows and all doors between the space in which the appliances connected to the venting system are located and other spaces of the building.
- 4. Close fireplace dampers.
- 5. Turn on clothes dryers and any appliances not connected to the venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they will operate at maximum speed. Do not operate a summer exhaust fan.
- 6. Follow the lighting instruction to place the appliance being inspected into operation. Adjust thermostat so appliance will operate continuously.
- 7. Use the flame of match or candle to test for spillage of flue gases at the draft hood relief opening after 5 minutes of main burner operation.
- 8. If improper venting is observed during any of the above tests, the venting system must be corrected or sufficient combustion/makeup air must be provided. The venting system should be re–sized to approach the minimum size as determined by using the appropriate tables in appendix G in the current standards of the National Fuel Gas Code ANSI-Z223.1/NPFA 54 in the U.S.A., and the appropriate Natural Gas and Propane appliances venting sizing tables in the current standard of the CSA-B149 Natural Gas and Propane Installation Codes in Canada.
- 9. After determining that each appliance remaining connected to the common venting system properly vents when tested as indicated in step 3, return doors, windows, exhaust fans, fireplace dampers and any other gas burning appliance to their previous condition of use.

#### **Other Unit Adjustments**

#### **Primary Limit**

The primary limit is located on the heating compartment vestibule panel. This limit is factory set and requires no adjustment.

#### Flame Rollout Switches (Two)

These manually reset switches are located on the front of the burner box. These limits are factory set and require no adjustment.

#### **Pressure Switch**

The pressure switch is located in the heating compartment on the cold end header box. This switch checks for proper combustion air inducer operation before allowing ignition trial. The switch is factory set and must not be adjusted.

#### **Temperature Rise**

After the furnace has been started and supply and return air temperatures have been allowed to stabilize, check the temperature rise. If necessary, adjust the blower speed to maintain the temperature rise within the range shown on the unit nameplate. See Table 13 for allowable heating speeds. Increase the blower speed to decrease the temperature. Decrease the blower speed to increase the temperature rise. Failure to adjust the temperature rise may cause erratic limit operation.

#### **Thermostat Heat Anticipation**

Set the heat anticipator setting (if adjustable) according to the amp draw listed on the wiring diagram that is attached to the unit.

#### Electrical

- 1. Check all wiring for loose connections.
- 2. Check for the correct voltage at the furnace (with furnace operating). Correct voltage is 120 VAC ± 10%
- 3. Check amp–draw on the blower motor with the blower access panel in place.
- 4. Motor Nameplate\_\_\_\_\_Actual\_\_\_\_\_

#### **Blower Speeds**

Follow the steps below to change the blower speeds.

- 1. Turn off electrical power to furnace.
- 2. Remove blower access panel.
- 3. Disconnect existing speed tap at control board speed terminal.

**NOTE:** *Termination of any unused motor leads must be insulated.* 

- 4. Place unused blower speed tap on integrated control "PARK" terminal or insulate.
- Refer to blower speed selection chart on unit wiring diagram for desired heating or cooling speed. See Blower performance data beginning on the next page. See Table 13 for allowable heating speeds.
- 6. Connect selected speed tap at control board speed terminal.
- 7. Re-secure blower access panel.
- 8. Turn on electrical power to furnace.
- 9. Recheck temperature rise.

#### **Electronic Ignition**

The integrated control has an added feature of an internal Watchguard control. The feature serves as an automatic reset device for integrated control lockout caused by ignition failure. This type of lockout is usually due to low gas line pressure. After one hour of continuous thermostat demand for heat, the Watchguard will break and remake thermostat demand to the furnace and automatically reset the integrated control to begin the ignition sequence.

#### **Exhaust and Air Intake Pipe**

- 1. Check exhaust and air intake connections for tightness and to make sure there is no blockage.
- 2. Is pressure switch closed? Obstructed exhaust pipe will cause unit to shut off at pressure switch. Check termination for blockages.
- Obstructed pipe or termination may cause rollout switches to open. Reset manual flame rollout switches on burner box assembly if necessary.

**NOTE:** Please refer to the Product Specifications for airflow/blower data.

#### Service

### 

## ELECTRICAL SHOCK, FIRE, OR EXPLOSION HAZARD.

Failure to follow safety warnings exactly could result in dangerous operation, serious injury, death or property damage.

Improper servicing could result in dangerous operation, serious injury, death, or property damage.

Before servicing, disconnect all electrical power to furnace.

When servicing controls, label all wires prior to disconnecting. Take care to reconnect wires correctly. Verify proper operation after servicing.

At the beginning of each heating season, system should be checked as follows by a qualified service technician:

#### Blower

Check the blower wheel for debris and clean if necessary. The blower motors are pre-lubricated for extended bearing life. No further lubrication is needed.



The blower access panel must be securely in place when the blower and burners are operating. Gas fumes, which could contain carbon monoxide, can be drawn into living space resulting in personal injury or death.

#### Filters

All air filters are installed external to the unit. Filters should be inspected monthly. Clean or replace the filters when necessary to ensure proper furnace operation. Table 1 lists recommended filter sizes.

#### Exhaust and Air Intake Pipes

Check the exhaust and air intake pipes and all connections for tightness and to make sure there is no blockage.

**NOTE:** After any heavy snow, ice or frozen fog event the furnace vent pipes may become restricted. Always check the vent system and remove any snow or ice that may be obstructing the plastic intake or exhaust pipes.

#### Electrical

- 1. Check all wiring for loose connections.
- 2. Check for the correct voltage at the furnace (with furnace operating). Correct voltage is  $120 \text{ VAC} \pm 10\%$ .
- 3. Check amp-draw on the blower motor with the blower

access panel in place.

Motor Nameplate

Actual

#### Winterizing and Condensate Trap Care

- 1. Turn off power to the furnace.
- 2. Have a shallow pan ready to empty condensate water.
- 3. Remove the clean out cap from the condensate trap and empty water. Inspect the trap then reinstall the clean out cap.

#### **Cleaning the Burner Assembly**

- 1. Turn off gas and electrical power to the furnace. Remove heating compartment access panel.
- 2. Disconnect the gas supply line from the gas valve.
- 3. Disconnect and label wires from gas valve.
- 4. Disconnect ignitor wiring at 2 circuit plug.
- 5. Disconnect and label wires from rollout switch.
- 6. Disconnect and label flame sensor wire.
- 7. Disconnect and label ground wire from burner/manifold assembly.
- 8. Remove four screws that secures burner/manifold assembly to vestibule. Remove the assembly and make note not to allow ignitor plate to dislodge from the assembly.
- 9. Gently clean the face of the burners using the soft brush attachment on a vacuum cleaner. Visually inspect the inside of the burners and crossovers for any blockage caused by foreign matter. Remove any blockage and inspect for damage. Replace if damage by rust or foreign matter cannot be removed.
- 10. Reinstall the burner/manifold assembly using the existing four screws. Burners are self aligning to center of clam shells.
- 11. Reconnect ground wire.
- 12. Reconnect flame sensor wire.
- 13. Reconnect rollout switch wires.
- 14. Reconnect ignitor wires.
- 15. Reconnect gas valve wires.
- 16. Reconnect gas supply line to gas valve.
- 17. Refer to instructions on verifying gas and electrical connections when re-establishing supplies.
- 18. Follow instructions to place furnace in operation. Run furnace 5 minutes to ensure burners are clean and operating correctly.
- 19. Replace heating compartment access panel.

#### **Planned Service**

A service technician should check the following items during an annual inspection. Power to the unit must be shut off for safety.

**Fresh air grilles and louvers** (on the unit and in the room where the furnace is installed) - Must be open and unobstructed to provide combustion air.

Burners - Must be inspected for rust, dirt, or signs of water.

**Vent pipe** - Must be inspected for signs of water, cracked, damaged or sagging pipe, or disconnected joints.

**Unit appearance** - Must be inspected for rust, dirt, signs of water, burnt or damaged wires, or components.

**Blower access door** - Must be properly in place and provide a seal between the return air and the room where the furnace is installed.

**Return air duct** - Must be properly attached and provide an air seal to the unit.

**Operating performance** - Unit must be observed during operation to monitor proper performance of the unit and the vent system.

**Combustion gases** - Flue products should be analyzed and compared to the unit specifications.

Problems detected during the inspection may make it necessary to temporarily shut down the furnace until the items can be repaired or replaced.

**Instruct the homeowners to pay attention to their furnace.** Situations can arise between annual furnace inspections that may result in unsafe operation. For instance, items innocently stored next to the furnace may obstruct the combustion air supply. This could cause incomplete combustion and the production of carbon monoxide gas.

#### Low GWP Sensor/Sleeve

Inspect the low GWP sensor / sensors and rubber sleeve

#### **Repair Parts List**

The following repair parts are available through Allied Air dealers. When ordering parts, include the complete furnace model number listed on the CSA nameplate. All service must be performed by a licensed professional installer (or equivalent), service agency, or gas supplier.

#### **Cabinet Parts**

- Upper Access Panel
- Blower Access Panel
- Top Cap

#### **Control Panel Parts**

- Transformer
- Integrated Control Board
- Door Interlock Switch

#### **Blower Parts**

- Blower Wheel
- Motor
- Motor Mounting Frame
- Motor Capacitor
- Blower Housing Cutoff Plate

#### **Heating Parts**

- Flame Sensor
- Heat Exchanger Assembly
- Gas Manifold
- Combustion Air Inducer
- Gas Valve
- Main Burner Cluster
- Main Burner Orifices
- Pressure Switch
- Ignitor
- Primary Limit Control
- Flame Rollout Switches

#### Low GWP Refrigerant detection System Parts

- RDS sensor
- Refrigerant line set sleeve

#### Modifications to NFPA-54, Chapter 10

## Revise NFPA-54 section 10.8.3 to add the following requirements:

For all side wall, horizontally vented, gas-fueled equipment installed in every dwelling, building or structure used in whole or in part for residential purposes, including those owned or operated by the Commonwealth and where the side wall exhaust vent termination is less than seven (7) feet above the finished grade in the area of the venting, including but not limited to decks and porches, the following requirements shall be satisfied:

- INSTALLATION OF CARBON MONOXIDE 1. DETECTORS. At the time of installation of the side wall, horizontally vented, gas-fueled equipment, the installing plumber or gas fitter shall observe that a hard-wired carbon monoxide detector with an alarm and battery backup is installed on the floor level where the gas equipment is to be installed. In addition, the installing plumber or gas fitter shall observe that a battery-operated or hard-wired carbon monoxide detector with an alarm is installed on each additional level of the dwelling, building or structure served by the side wall, horizontally vented, gas-fueled equipment. It shall be the responsibility of the property owner to secure the services of qualified licensed professionals for the installation of hard-wired carbon monoxide detectors.
  - a. In the event that the side wall, horizontally vented, gas-fueled equipment is installed in a crawl space or an attic, the hard-wired carbon monoxide detector with alarm and battery backup may be installed on the next adjacent floor level.
  - b. In the event that the requirements of this subdivision cannot be met at the time of completion of installation, the owner shall have a period of thirty (30) days to comply with the above requirements; provided, however, that during said thirty (30) day period, a battery-operated carbon monoxide detector with an alarm shall be installed.
- APPROVED CARBON MONOXIDE DETECTORS. Each carbon monoxide detector as required in accordance with the above provisions shall comply with NFPA 720 and be ANSI/UL 2034 listed and IAS certified.
- 3. SIGNAGE. A metal or plastic identification plate shall be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade directly in line with the exhaust vent terminal for the horizontally vented, gas-fueled heating appliance or equipment. The sign shall read, in print size no less than one-half (1/2) inch in size, "GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS."

4. **INSPECTION**. The state or local gas inspector of the side wall, horizontally vented, gas-fueled equipment shall not approve the installation unless, upon inspection, the inspector observes carbon monoxide detectors and signage installed in accordance with the provisions of 248 CMR 5.08(2)(a) 1 through 4.

## EXEMPTIONS: The following equipment is exempt from 24 CMR 5.08(2)(a) 1 through 4:

- 1. The equipment listed in Chapter 10 entitled "Equipment Not Required to Be Vented" in the most current edition of NFPA 54 as adopted by the Board; and
- 2. Product Approved side wall, horizontally vented, gasfueled equipment installed in a room or structure separate from the dwelling, building or structure used in whole or in part for residential purposes.

## MANUFACTURER REQUIREMENTS - GAS EQUIPMENT VENTING SYSTEM PROVIDED.

When the manufacturer of Product Approved side wall, horizontally vented, gas-fueled equipment provides a venting system design or venting system components with the equipment, the instructions provided by the manufacturer for installation of the equipment and the venting system shall include:

- 1. Detailed instructions for the installation of the venting system design or the venting system components: and
- 2. A complete parts list for the venting system design or venting system.

## MANUFACTURER REQUIREMENTS - GAS EQUIPMENT VENTING SYSTEM NOT PROVIDED.

When the manufacturer of Product Approved sidewall, horizontally vented, gas-fueled equipment does not provide the parts for venting the flue gases, but identifies "special venting systems," the following requirements shall be satisfied by the manufacturer:

- 1. The referenced "special venting system" instructions shall be included with the appliance or equipment installation instructions; and
- 2. The "special venting systems" shall be Product Approved by the Board, and the instructions for that system shall include a parts list and detailed installation instructions.

A copy of all installation instructions for all Product Approved side wall, horizontally vented, gas-fueled equipment, all venting instructions, all parts lists for venting instructions, and/or all venting design instructions shall remain with the appliance or equipment at the completion of the installation.