CATERPILLAR®

Axle Service Manual

Models TH255, TH255C, TH306D

SN TBS00100 to Present SN JK200150 to Present SN JK300150 to Present SN TD200150 to Present SN TA200150 to Present SN TD300150 to Present SN TA300150 to Present

> 31200451 UENR6268-02

Revised January 18, 2018

DISCLAIMER: Information provided within (excluding Section 1) is supplied directly from the component manufacturer. Information within the machine Operation & Maintenance or Service Manuals supersedes any discrepancies which may be found within this manual. Due to continuous improvements, the component manufacturer reserves the right to make changes without prior notification.

EFFECTIVITY PAGE

August 29, 2008 - A - Original Issue Of Manual September 3, 2014 - B - Revised Manual January 18, 2018 - C - Update to include TH306D

EFFECTIVITY PAGE

SECTION CONTENTS

| Section | Subject | Page |
|------------------------|---|------------|
| Section 1 | | |
| Safety Practice | 25 | 1-1 |
| 1.1 | Introduction | 1-1 |
| 1.2 | Disclaimer. | 1-1 |
| 1.3 | Operation & Maintenance Manual | 1-1 |
| 1.4 | Do Not Operate Tags | 1-1 |
| 1.5 | Safety Information. | 1-1 |
| 1.6 | Safety Alert System and Signal Words | 1-2 |
| 1.7 | Safety Instructions | 1-2 |
| 1.8 | Safety Decals | 1-4 |
| Section 2 | | |
| General Inforn | nation and Specifications | 2-1 |
| 2.1 | Introduction | 2-1 |
| 2.2 | Specifications | 2-2 |
| 2.3 | Conversion Tables | 2-3 |
| 2.4 | Torque Specifications | 2-4 |
| 2.5 | Maintenance | 2-6 |
| 2.6 | Safety Precautions | 2-9 |
| Section 3 | | |
| Planetary Red | uction 1:6 and Steering Case | 3-1 |
| 3.1 | Exploded View | 3-1 |
| 3.2 | Planetary Reduction - 1.6 and Steering Case - Disassembly | 3-2 |
| 3.3 | Planetary Reduction - 1.6 and Steering Case - Assembly | 3-8 |
| Section 4 | dor | 1 1 |
| Steering Cynn | | 4-1 |
| 4.1 | Exploded View | 4-1 |
| 4.2 | Steering Cylinder - Disassembly | 4-2 |
| 4.3 | Steering Cylinder - Assembly | 4-5 |
| Section 5 | | |
| Brake: Service | Brake, Negative Brake, 45% Locked & 100% Locked | 5-1 |
| 5.1 | Exploded View | 5-1 |
| 5.2 | Brake Working Conditions | 5-2 |
| 5.3 | Emergency Release Instructions. | 5-6 |
| 5.4 | Reset of Fails Safe Brake Function | 5-6 |
| 5.5 | Brake: Service Brake, Negative Brake, 45% Locked & 100% Locked- Disassembly | 5-7 |
| 5.6 | Brake: Service Brake, Negative Brake, 45% Locked & 100% Locked - Assembly | 5-13 |
| 5.7 | Brake Piston Gap Check | 5-22 |
| Section 6 | e Bueles A Cup Springs Version | <i>с</i> 1 |
| Drake: Negativ | e brake 4 cup springs version | 0-I |
| 6.1 | Exploded View | 6-1 |
| 6.2 | Brake: Negative Brake 4 Cup Springs Version - Disassembly | 6-2 |
| 6.3 | Brake: Negative Brake 4 Cup Springs Version - Assembly | 6-3 |

| Section 7 | | |
|-----------------------|---|------|
| Normal Preloa | ded Differential Unit (Old Version) | 7-1 |
| 7.1 | Exploded View | 7-1 |
| 7.2 | Normal Preloaded Differential Unit (Old Version) - Disassembly | 7-2 |
| 7.3 | Normal Preloaded Differential Unit (Old Version) - Assembly | 7-6 |
| Section 8 | | |
| Normal Preloa | ded Differential Unit (Intermediate Version) | 8-1 |
| 8.1 | Exploded View | 8-1 |
| 8.2 | Normal Preloaded Differential Unit (Intermediate Version) - Disassembly | 8-2 |
| 8.3 | Normal Preloaded Differential Unit (Intermediate Version) - Assembly | 8-6 |
| Section 9 | | |
| Normal Preloa | Ided Differential Unit (Last Version) | 9-1 |
| 9.1 | Exploded View | 9-1 |
| 9.2 | Normal Preloaded Differential Unit (Last Version) - Disassembly | 9-2 |
| 9.3 | Normal Preloaded Differential Unit (Last Version) - Assembly | 9-5 |
| Section 10 | | |
| Flanged Redu | ction Gear 603 Type: Integral 603 Input Gear | 10-1 |
| 10.1 | Exploded View | 10-1 |
| 10.2 | Flanged Reduction Gear 603 Type: Integral 603 Input Gear - Disassembly | 10-2 |
| 10.3 | Flanged Reduction Gear 603 Type: Integral 603 Input Gear - Assembly | 10-5 |
| Section 11 | | |
| Bevel Pinion: | Normal Flange and Nut Revolution Counter Version | 11-1 |
| 11.1 | Exploded View | 11-1 |
| 11.2 | Bevel Pinion: Normal Flange and Nut Revolution Counter Version- Disassembly | 11-2 |
| 11.3 | Bevel Pinion: Normal Flange and Nut Revolution Counter Version - Assembly | 11-5 |
| Section 12 | | |
| Ring and Pinio | on Adjusting: Step for Preloaded Differential | 12-1 |
| 12.1 | Exploded View | 12-1 |
| 12.2 | Ring and Pinion Adjusting: Step for Preloaded Differential - Install and Adjust | 12-2 |
| Section 13 | | |
| Swinging Sup | port | 13-1 |
| 13.1 | Exploded View | 13-1 |
| 13.2 | Swinging Support - Disassembly | 13-2 |
| 13.3 | Swinging Support - Assembly | 13-4 |
| Section 14 | | |
| Planetary Red | uction: 1:4, 23 | 14-1 |
| 14.1 | Exploded View | 14-1 |
| 14.2 | Planetary Reduction: 1:4, 23 - Disassembly | 14-2 |
| 14.3 | Planetary Reduction: 1:4, 23 - Assembly | 14-3 |

| Page |
|------|
|------|

| 15.1 Exploded View. 15.2 Brake: Incoming Disc Brake - Disassembly. 15.4 Checking Wear and Replacing the Braking Pads. Section 16 Brake: Incoming Disc Brake - Assembly 16.1 Exploded View. 16.2 Brake: Incoming Disc Brake - Disassembly. 16.3 Brake: Incoming Disc Brake - Disassembly. 16.4 Exploded View. 16.5 Brake: Incoming Disc Brake - Disassembly. 16.6 Brake: Incoming Disc Brake - Assembly Section 17 Brake: Incoming Disc Brake - Assembly. Section 17 Brake: Incoming Disc Brake - Disassembly. 17.1 Exploded View. 17.2 Brake: Incoming Disc Brake - Assembly. Section 18 Differential Objec K to Spheres 100% (Old Version) 18.1 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Assembly. 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Olsassembly. | Section 15 Brake: Incom | ing Disc Brake | 1 |
|---|----------------------------|---|---|
| 15.2 Brake: Incoming Disc Brake - Assembly. 15.3 Brake: Incoming Disc Brake - Assembly. 15.4 Checking Wear and Replacing the Braking Pads. Section 16 Brake: Service and Mechanical Parking Brake 16.1 Exploded View. 16.2 Brake: Incoming Disc Brake - Disassembly. 16.3 Brake: Incoming Disc Brake - Assembly 16.3 Brake: Incoming Disc Brake - Assembly Section 17 Brake: Incoming Disc Brake - Assembly Section 17 Brake: Incoming Disc Brake - Disassembly. 17.1 Exploded View. 17.2 Brake: Incoming Disc Brake - Assembly 17.3 Brake: Incoming Disc Brake - Assembly. 17.3 Brake: Incoming Disc Brake - Assembly. 17.3 Brake: Incoming Disc Brake - Assembly. 18.1 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Last Version) 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version)- Disassembly. 19.3 Differential (Old Version) 20.1 Exploded View. | 15.1 | Exploded View | |
| 15.3 Brake: Incoming Disc Brake - Assembly 15.4 Checking Wear and Replacing the Braking Pads. Section 16 Brake: Service and Mechanical Parking Brake 16.1 Exploded View. 16.2 Brake: Incoming Disc Brake - Disassembly. 16.3 Brake: Incoming Disc Brake - Assembly Section 17 Brake: Parking Brake and Differential Hydraulic 100% 17.1 Exploded View. 17.2 Brake: Incoming Disc Brake - Disassembly. 17.3 Brake: Incoming Disc Brake - Assembly 17.4 Exploded View. 17.3 Brake: Incoming Disc Brake - Assembly 17.4 Brake: Incoming Disc Brake - Assembly 17.3 Brake: Incoming Disc Brake - Assembly 17.3 Brake: Incoming Disc Brake - Assembly 17.3 Brake: Incoming Disc Brake - Disassembly 17.4 Exploded View. 17.5 Brake: Incoming Disc Brake - Disassembly 18.0 Differential Wth Block to Spheres 100% (Old Version) - Disassembly. 18.1 Exploded View. 18.2 Differential Wth Block to Spheres 100% (Last Version) - Disassembly. 19.1 Exploded View. | 15.2 | Brake: Incoming Disc Brake - Disassembly | |
| 15.4 Checking Wear and Replacing the Braking Pads. Section 16 Brake: Service and Mechanical Parking Brake 16.1 Exploded View. 16.2 Brake: Incoming Disc Brake - Disassembly. 16.3 Brake: Incoming Disc Brake - Assembly Section 17 Brake: Parking Brake and Differential Hydraulic 100% 17.1 Exploded View. 17.2 Brake: Incoming Disc Brake - Assembly 17.3 Brake: Incoming Disc Brake - Assembly. Section 18 Differential Hydraulic 100% (Old Version) 18.1 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Old Version) - Assembly. 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version). 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version). 19.3 Differential (Old Version) 20.4 Kapided View. 20.5 Normal Differential (Old Version) - Disassembly. 20.1 Exploded View. 20.2 Normal Differential (Last Version) - Disassembly. | 15.3 | Brake: Incoming Disc Brake - Assembly | |
| Section 16 Brake: Service and Mechanical Parking Brake 16.1 Exploded View. 16.2 Brake: Incoming Disc Brake - Disassembly. 16.3 Brake: Incoming Disc Brake - Assembly Section 17 Brake: Parking Brake and Differential Hydraulic 100% 17.1 Exploded View. 17.2 Brake: Incoming Disc Brake - Assembly. 17.3 Brake: Incoming Disc Brake - Assembly. 17.3 Brake: Incoming Disc Brake - Assembly. 17.3 Brake: Incoming Disc Brake - Assembly. Section 18 Differential With Block to Spheres 100% (Old Version) 18.1 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Uast Version) - Disassembly. 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential (Old Version) 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Old Version) - Disassembly. 20.4 Exploded View. 21.1 Exploded Vi | 15.4 | Checking Wear and Replacing the Braking Pads | |
| Brake: Service and Mechanical Parking Brake 16.1 Exploded View. 16.2 Brake: Incoming Disc Brake - Disassembly. 16.3 Brake: Incoming Disc Brake - Assembly 16.3 Brake: Incoming Disc Brake - Assembly. 16.3 Brake: Incoming Disc Brake - Assembly. Section 17 Brake: Incoming Disc Brake - Disassembly. 17.1 Exploded View. 17.2 Brake: Incoming Disc Brake - Disassembly. 17.3 Brake: Incoming Disc Brake - Disassembly. 17.3 Brake: Incoming Disc Brake - Disassembly. 17.3 Brake: Incoming Disc Brake - Assembly. 17.4 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Disassembly. 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly. | Section 16 | | |
| 16.1 Exploded View | Brake: Servic | e and Mechanical Parking Brake | 1 |
| 16.2 Brake: Incoming Disc Brake - Disassembly. 16.3 Brake: Incoming Disc Brake - Assembly Section 17 Brake: Parking Brake and Differential Hydraulic 100% 17.1 Exploded View. 17.2 Brake: Incoming Disc Brake - Disassembly 17.3 Brake: Incoming Disc Brake - Disassembly 17.4 Exploded View. 17.3 Brake: Incoming Disc Brake - Assembly. Section 18 Differential With Block to Spheres 100% (Old Version) 18.1 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Assembly. 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Old Version) - Disassembly. 20.4 Kaploded View. 20.5 Normal Differential (Old Version) - Assembly. | 16.1 | Exploded View | |
| 16.3 Brake: Incoming Disc Brake - Assembly Section 17 Brake: Parking Brake and Differential Hydraulic 100% 17.1 Exploded View. 17.2 Brake: Incoming Disc Brake- Disassembly 17.3 Brake: Incoming Disc Brake- Disassembly 17.3 Brake: Incoming Disc Brake- Assembly 18.1 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Last Version) 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version)- Disassembly. 19.3 Differential (Old Version) 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Last Version) - Dis | 16.2 | Brake: Incoming Disc Brake - Disassembly | |
| Section 17 Brake: Parking Brake and Differential Hydraulic 100% 17.1 Exploded View. 17.2 Brake: Incoming Disc Brake- Disassembly. 17.3 Brake: Incoming Disc Brake- Assembly. 17.3 Brake: Incoming Disc Brake- Assembly. Section 18 Differential With Block to Spheres 100% (Old Version) 18.1 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Old Version) - Assembly. 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential (Old Version) 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Old Version) - Assembly. 21.1 Exploded View. 21.2 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Disassembly. 21.4 Exploded View. | 16.3 | Brake: Incoming Disc Brake - Assembly | |
| Brake: Parking Brake and Differential Hydraulic 100% 17.1 Exploded View. 17.2 Brake: Incoming Disc Brake- Disassembly. 17.3 Brake: Incoming Disc Brake- Assembly. Section 18 Differential With Block to Spheres 100% (Old Version) 18.1 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Last Version) - Assembly. Section 19 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Assembly. 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Last Version) - Disassembly. 21.1 Exploded View. 21.2 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Disassembly. 21.4 Ex | Section 17 | | |
| 17.1 Exploded View. 17.2 Brake: Incoming Disc Brake- Disassembly 17.3 Brake: Incoming Disc Brake- Assembly. 17.3 Brake: Incoming Disc Brake- Assembly. Section 18 Differential With Block to Spheres 100% (Old Version) 18.1 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Old Version) - Assembly. Section 19 Differential With Block to Spheres 100% (Last Version) - Assembly. 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version)- Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version)- Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version)- Assembly. 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Last Version) - Disassembly. 21.1 Exploded View. 21.2 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Disassembly. 21.4 Expl | Brake: Parkin | g Brake and Differential Hydraulic 100% | 1 |
| 17.2 Brake: Incoming Disc Brake- Disassembly. 17.3 Brake: Incoming Disc Brake- Assembly. Section 18 Differential With Block to Spheres 100% (Old Version) 18.1 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Old Version) - Assembly. Section 19 Differential With Block to Spheres 100% (Last Version) - Assembly. 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Assembly. Section 20 Normal Differential (Old Version) - Disassembly. 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Assembly. 20.3 Normal Differential (Old Version) - Assembly. 21.1 Exploded View. 21.2 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Assembly. 21.4 Exploded View. 21.5 Normal Differential (Last Version) - Disassembly. 21.6 | 17.1 | Exploded View | |
| 17.3 Brake: Incoming Disc Brake- Assembly. Section 18 Differential With Block to Spheres 100% (Old Version) 18.1 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Old Version) - Assembly. Section 19 Differential With Block to Spheres 100% (Last Version) - Assembly. 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Assembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Assembly. 20.4 Kxploded View. 20.5 Normal Differential (Old Version) 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Old Version) - Assembly. 20.4 Exploded View. 21.1 Exploded View. 21.2 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Disassembly. 21.4 Exploded View. <td>17.2</td> <td>Brake: Incoming Disc Brake- Disassembly</td> <td></td> | 17.2 | Brake: Incoming Disc Brake- Disassembly | |
| Section 18 Differential With Block to Spheres 100% (Old Version) 18.1 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Old Version) - Assembly. Section 19 Differential With Block to Spheres 100% (Last Version) 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version)- Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version)- Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version)- Assembly. 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Old Version) - Assembly. 20.3 Normal Differential (Last Version) - Assembly. 21.1 Exploded View. 21.2 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Disassembly. 21.4 Exploded View. 22.5 Limited Slip Differential Unit 45% (Old Version) - Assembly. 22.1 Exploded View. 22.2 | 17.3 | Brake: Incoming Disc Brake- Assembly | |
| Differential With Block to Spheres 100% (Old Version) 18.1 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Old Version) - Assembly. Section 19 Differential With Block to Spheres 100% (Last Version) 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version)- Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version)- Assembly. 19.3 Differential With Block to Spheres 100% (Last Version)- Assembly. 19.3 Differential With Block to Spheres 100% (Last Version)- Assembly. 20 Normal Differential (Old Version) 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Old Version) - Assembly. 20.3 Normal Differential (Last Version) - Assembly. 21.1 Exploded View. 21.2 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Assembly. 21.4 Exploded View. 21.3 Normal Differential (Last Version) - Assembly. 22.1 Exploded View. < | Section 18 | | |
| 18.1 Exploded View. 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Old Version) - Assembly. Section 19 Differential With Block to Spheres 100% (Last Version) 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Assembly. Section 20 Normal Differential (Old Version) 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Old Version) - Disassembly. 20.4 Exploded View. 20.5 Normal Differential (Last Version) - Disassembly. 20.1 Exploded View. 20.2 Normal Differential (Last Version) - Assembly. 20.3 Normal Differential (Last Version) - Disassembly. 21.1 Exploded View. 21.2 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Assembly. 21.4 Exploded View. | Differential W | Vith Block to Spheres 100% (Old Version) | 1 |
| 18.2 Differential With Block to Spheres 100% (Old Version) - Disassembly. 18.3 Differential With Block to Spheres 100% (Old Version) - Assembly. Section 19 Differential With Block to Spheres 100% (Last Version) . 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Assembly. 19.3 Differential (Old Version) 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Old Version) - Assembly. 20.4 Exploded View. 20.5 Normal Differential (Last Version) - Disassembly. 20.1 Exploded View. 20.2 Normal Differential (Last Version) - Disassembly. 21.1 Exploded View. 21.2 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Assembly. 22.4 Exploded View. 22.5 Limited Slip Differential Unit 45% (Old Version) - | 18.1 | Exploded View | |
| 18.3 Differential With Block to Spheres 100% (Old Version) - Assembly. Section 19 Differential With Block to Spheres 100% (Last Version) 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version) - Disassembly. 19.3 Differential (Old Version) 20.1 Exploded View. 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Old Version) - Assembly. 20.4 Exploded View. 20.5 Normal Differential (Old Version) - Disassembly. 20.1 Exploded View. 20.2 Normal Differential (Last Version) - Assembly. 20.3 Normal Differential (Last Version) - Disassembly. 21.1 Exploded View. 21.2 Normal Differential (Last Version) - Assembly. 21.3 Normal Differential (Last Version) - Assembly. 22.1 Exploded View. 22.1 Exploded View. 22.2 Limited Slip Differential Unit 45% (Old Version) - Disassembly. 22.3 Limited Slip Differential Uni | 18.2 | Differential With Block to Spheres 100% (Old Version) - Disassembly | |
| Section 19 Differential With Block to Spheres 100% (Last Version) 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version)- Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version)- Assembly. 19.3 Differential With Block to Spheres 100% (Last Version)- Assembly. Section 20 Normal Differential (Old Version) 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly. 20.3 Normal Differential (Old Version) - Assembly. 20.3 Normal Differential (Old Version) - Assembly. 21.1 Exploded View. 21.2 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Disassembly. 21.4 Exploded View. 22.1 Exploded View. 22.2 Limited Slip Differential Unit 45% (Old Version) - Disassembly. 22.3 Limited Slip Differential Unit 45% (Old Version) - Assembly. | 18.3 | Differential With Block to Spheres 100% (Old Version) - Assembly | |
| Differential With Block to Spheres 100% (Last Version) 19.1 Exploded View. 19.2 Differential With Block to Spheres 100% (Last Version)- Disassembly. 19.3 Differential With Block to Spheres 100% (Last Version)- Assembly. Section 20 Normal Differential (Old Version) 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly 20.3 Normal Differential (Old Version) - Assembly 20.3 Normal Differential (Old Version) - Assembly 21.1 Exploded View. 21.2 Normal Differential (Last Version) - Disassembly 21.3 Normal Differential (Last Version) - Disassembly 21.3 Normal Differential (Last Version) - Assembly Section 22 Limited Slip Differential Unit 45% (Old Version) - Assembly 21.1 Exploded View. 21.3 Normal Differential Unit 45% (Old Version) - Assembly Section 22 Limited Slip Differential Unit 45% (Old Version) - Disassembly 22.1 Exploded View. 22.2 Limited Slip Differential Unit 45% (Old Version) - Disassembly 22.3 Limited S | Section 19 | | |
| 19.1Exploded View.19.2Differential With Block to Spheres 100% (Last Version)- Disassembly.19.3Differential With Block to Spheres 100% (Last Version)- Assembly.Section 20Normal Differential (Old Version)20.1Exploded View.20.2Normal Differential (Old Version) - Disassembly.20.3Normal Differential (Old Version) - Disassembly.20.3Normal Differential (Old Version) - Disassembly.20.1Exploded View.20.2Normal Differential (Old Version) - Disassembly.20.3Normal Differential (Clast Version) - Disassembly.21.1Exploded View.21.1Exploded View.21.2Normal Differential (Last Version) - Disassembly.21.1Exploded View.21.1Exploded View.22.1Exploded View.22.1Exploded View.22.1Exploded View.22.1Exploded View.22.1Exploded View.22.1Exploded View.22.1Exploded View.22.1Exploded View.22.2Limited Slip Differential Unit 45% (Old Version) - Disassembly . <td>Differential V</td> <td>Vith Block to Spheres 100% (Last Version)</td> <td>1</td> | Differential V | Vith Block to Spheres 100% (Last Version) | 1 |
| 19.2Differential With Block to Spheres 100% (Last Version)- Disassembly.19.3Differential With Block to Spheres 100% (Last Version)- Assembly.Section 20Normal Differential (Old Version)20.1Exploded View.20.2Normal Differential (Old Version) - Disassembly20.3Normal Differential (Old Version) - Assembly.20.3Normal Differential (Old Version) - Assembly.Section 21Normal Differential (Last Version)21.1Exploded View.21.2Normal Differential (Last Version) - Disassembly.21.3Normal Differential (Last Version) - Assembly.21.3Normal Differential (Last Version) - Disassembly.21.4Exploded View.21.5Ection 22Limited Slip Differential Unit 45% (Old Version) - Assembly22.1Exploded View.22.2Limited Slip Differential Unit 45% (Old Version) - Disassembly .22.3Limited Slip Differential Unit 45% (Old Version) - Disassembly . | 19.1 | Exploded View | |
| 19.3 Differential With Block to Spheres 100% (Last Version)- Assembly. Section 20 Normal Differential (Old Version) 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly 20.3 Normal Differential (Old Version) - Assembly 20.3 Normal Differential (Old Version) - Assembly 20.3 Normal Differential (Old Version) - Assembly 20.4 Exploded View. 20.5 Version) 21.1 Exploded View. 21.2 Normal Differential (Last Version) - Disassembly. 21.3 Normal Differential (Last Version) - Assembly 21.3 Normal Differential (Last Version) - Assembly 21.3 Normal Differential (Last Version) - Assembly 22.1 Exploded View. 22.2 Limited Slip Differential Unit 45% (Old Version) - Disassembly 22.1 Exploded View. 22.2 Limited Slip Differential Unit 45% (Old Version) - Disassembly 22.3 Limited Slip Differential Unit 45% (Old Version) - Assembly | 19.2 | Differential With Block to Spheres 100% (Last Version)- Disassembly | |
| Section 20 Normal Differential (Old Version) 20.1 Exploded View. 20.2 Normal Differential (Old Version) - Disassembly | 19.3 | Differential With Block to Spheres 100% (Last Version)- Assembly | |
| Normal Differential (Old Version)20.1Exploded View.20.2Normal Differential (Old Version) - Disassembly20.3Normal Differential (Old Version) - Assembly20.3Normal Differential (Old Version) - AssemblySection 21Normal Differential (Last Version)21.1Exploded View.21.2Normal Differential (Last Version) - Disassembly21.3Normal Differential (Last Version) - Disassembly21.3Normal Differential (Last Version) - Assembly21.3Normal Differential (Last Version) - Assembly21.4Exploded View.21.5Limited Slip Differential Unit 45% (Old Version)22.1Exploded View.22.2Limited Slip Differential Unit 45% (Old Version) - Disassembly22.3Limited Slip Differential Unit 45% (Old Version) - Assembly | Section 20 | | |
| 20.1Exploded View.20.2Normal Differential (Old Version) - Disassembly20.3Normal Differential (Old Version) - AssemblySection 21Normal Differential (Last Version)21.1Exploded View.21.2Normal Differential (Last Version) - Disassembly.21.3Normal Differential (Last Version) - Disassembly.21.3Normal Differential (Last Version) - Assembly21.1Exploded View.21.2Normal Differential (Last Version) - Disassembly.21.3Normal Differential (Last Version) - Assembly22.1Exploded View.22.1Exploded View.22.2Limited Slip Differential Unit 45% (Old Version) - Disassembly22.3Limited Slip Differential Unit 45% (Old Version) - Assembly | Normal Diffe | rential (Old Version) | 2 |
| 20.2Normal Differential (Old Version) - Disassembly20.3Normal Differential (Old Version) - AssemblySection 21Normal Differential (Last Version)21.1Exploded View21.2Normal Differential (Last Version) - Disassembly21.3Normal Differential (Last Version) - Assembly21.3Normal Differential (Last Version) - AssemblySection 22Limited Slip Differential Unit 45% (Old Version)22.1Exploded View22.2Limited Slip Differential Unit 45% (Old Version) - Disassembly22.3Limited Slip Differential Unit 45% (Old Version) - Assembly | 20.1 | Exploded View | |
| 20.3Normal Differential (Old Version) - AssemblySection 21Normal Differential (Last Version)21.1Exploded View21.2Normal Differential (Last Version) - Disassembly21.3Normal Differential (Last Version) - Assembly21.3Normal Differential (Last Version) - AssemblySection 22Limited Slip Differential Unit 45% (Old Version)22.1Exploded View22.2Limited Slip Differential Unit 45% (Old Version) - Disassembly22.3Limited Slip Differential Unit 45% (Old Version) - Assembly | 20.2 | Normal Differential (Old Version) - Disassembly | |
| Section 21 Normal Differential (Last Version) | 20.3 | Normal Differential (Old Version) - Assembly | |
| Normal Differential (Last Version)21.1Exploded View.21.2Normal Differential (Last Version) - Disassembly.21.3Normal Differential (Last Version) - AssemblySection 22Limited Slip Differential Unit 45% (Old Version)22.1Exploded View.22.2Limited Slip Differential Unit 45% (Old Version) - Disassembly22.3Limited Slip Differential Unit 45% (Old Version) - Assembly | Section 21 | | |
| 21.1Exploded View.21.2Normal Differential (Last Version) - Disassembly.21.3Normal Differential (Last Version) - AssemblySection 22Limited Slip Differential Unit 45% (Old Version)22.1Exploded View.22.2Limited Slip Differential Unit 45% (Old Version) - Disassembly22.3Limited Slip Differential Unit 45% (Old Version) - Assembly | Normal Diffe | rential (Last Version) | 2 |
| 21.2Normal Differential (Last Version) - Disassembly.21.3Normal Differential (Last Version) - AssemblySection 22Limited Slip Differential Unit 45% (Old Version)22.1Exploded View.22.2Limited Slip Differential Unit 45% (Old Version) - Disassembly22.3Limited Slip Differential Unit 45% (Old Version) - Assembly | 21.1 | Exploded View | |
| 21.3Normal Differential (Last Version) - AssemblySection 22Limited Slip Differential Unit 45% (Old Version)22.1Exploded View22.2Limited Slip Differential Unit 45% (Old Version) - Disassembly22.3Limited Slip Differential Unit 45% (Old Version) - Assembly | 21.2 | Normal Differential (Last Version) - Disassembly | |
| Section 22Limited Slip Differential Unit 45% (Old Version)22.1Exploded View.22.2Limited Slip Differential Unit 45% (Old Version) - Disassembly22.3Limited Slip Differential Unit 45% (Old Version) - Assembly | 21.3 | Normal Differential (Last Version) - Assembly | |
| Limited Slip Differential Unit 45% (Old Version)22.1Exploded View.22.2Limited Slip Differential Unit 45% (Old Version) - Disassembly22.3Limited Slip Differential Unit 45% (Old Version) - Assembly | Section 22 | | |
| 22.1 Exploded View 22.2 Limited Slip Differential Unit 45% (Old Version) - Disassembly 22.3 Limited Slip Differential Unit 45% (Old Version) - Assembly | Limited Slip [| Differential Unit 45% (Old Version) | 2 |
| 22.2Limited Slip Differential Unit 45% (Old Version) - Disassembly22.3Limited Slip Differential Unit 45% (Old Version) - Assembly | 22.1 | Exploded View | |
| 22.3 Limited Slip Differential Unit 45% (Old Version) - Assembly | 22.2 | Limited Slip Differential Unit 45% (Old Version) - Disassembly | |
| | 22.3 | Limited Slip Differential Unit 45% (Old Version) - Assembly | |

| Section 23 | | |
|----------------------|---|------|
| Limited Slip D | Differential Unit 45% (Last Version) | 23-1 |
| 23.1 | Exploded View | 23-1 |
| 23.2 | Limited Slip Differential Unit 45% (Last Version) - Disassembly | 23-2 |
| 23.3 | Limited Slip Differential Unit 45% (Last Version) - Assembly. | 23-4 |
| Section 24 | | |
| Preloaded Lin | nited Slip Differential Unit 45% Unit (Old Version) | 24-1 |
| 24.1 | Exploded View | 24-1 |
| 24.2 | Preloaded Limited Slip Differential Unit 45% Unit (Old Version) - Disassembly | 24-2 |
| 24.3 | Preloaded Limited Slip Differential Unit 45% Unit (Old Version) - Disassembly | 24-6 |
| Section 25 | | |
| Preloaded Lin | nited Slip Differential Unit 45%(Intermediate Version) | 25-1 |
| 25.1 | Exploded View | 25-1 |
| 25.2 | Preloaded Limited Slip Differential Unit45% (Intermediate Version) - Disassembly | 25-2 |
| 25.3 | Preloaded Limited Slip Differential Unit 45% (Intermediate Version) - Assembly | 25-7 |
| Section 26 | | |
| Preloaded Lin | nited Slip Differential Unit 45%(Last Version) | 26-1 |
| 26.1 | Exploded View | 26-1 |
| 26.2 | Preloaded Limited Slip Differential Unit 45%(Last Version) - Disassembly | 26-2 |
| 26.3 | Preloaded Limited Slip Differential Unit 45%(Last Version) - Assembly | 26-5 |
| Section 27 | | |
| Bevel Pinion: | Flanged to Reduction Gear 603 | 27-1 |
| 27.1 | Exploded View | 27-1 |
| 27.2 | Bevel Pinion: Flanged to Reduction Gear 603 - Disassembly | 27-2 |
| 27.3 | Bevel Pinion: Flanged to Reduction Gear 603 - Assembly | 27-4 |
| Section 28 | | |
| Ring and Pini | on Adjusting: Version Pinion Cover and Single Arm | 28-1 |
| 28.1 | Exploded View | 28-1 |
| 28.2 | Ring and Pinion Adjusting: Version Pinion Cover and Single Arm - Install and Adjust | 28-2 |
| Section 29 | | |
| Ring and Pini | on Adjusting: Version Pinion Integral and Double Arm | 29-1 |
| 29.1 | Exploded View | 29-1 |
| 29.2 | Ring and Pinion Adjusting: Version Pinion Integral and Double Arm -install and Adjust | 29-2 |

_

Section 30

| | 30-1 |
|-----|--|
| Τ1 | 30-1 |
| Τ2 | 30-2 |
| Т3 | 30-3 |
| Τ4 | 30-4 |
| Τ5 | 30-5 |
| Τ6 | 30-6 |
| Τ7 | 30-7 |
| Т8 | 30-8 |
| Т9 | 30-9 |
| T10 | 30-10 |
| T11 | 30-11 |
| T12 | 30-12 |
| T13 | 30-13 |
| T14 | 30-14 |
| T16 | 30-15 |
| T17 | 30-16 |
| T18 | 30-17 |
| | T1 T2 T3 T4 T5 T6 T7 T8 T9 T10 T11 T12 T13 T14 T16 T17 T18 T18 |

1.1 INTRODUCTION

This service manual provides general directions for accomplishing service and repair procedures. Following the procedures in this manual will help assure safety and equipment reliability.

Read, understand and follow the information in this manual, and obey all locally approved safety practices, procedures, rules, codes, regulations and laws.

These instructions cannot cover all details or variations in the equipment, procedures, or processes described, nor provide directions for meeting every possible contingency during operation, maintenance, or testing. When additional information is desired consult the local *Caterpillar* dealer.

Many factors contribute to unsafe conditions: carelessness, fatigue, overload, inattentiveness, unfamiliarity, even drugs and alcohol, among others. For optimal safety, encourage everyone to think, and to act safely.

Appropriate service methods and proper repair procedures are essential for the safety of the individual doing the work, for the safety of the operator, and for the safe, reliable operation of the machine. All references to the right side, left side, front and rear are given from the operator seat looking in a forward direction.

Supplementary information is available from the manufacturer in the form of Service Bulletins, Service Campaigns, Service Training Schools, the service website, other literature, and through updates to the manual itself.

1.2 DISCLAIMER

All information in this manual is based on the latest product information available at the time of publication. The manufacturer reserves the right to make changes and improvements to its products, and to discontinue the manufacture of any product, at its discretion at any time without public notice or obligation.

1.3 OPERATION & MAINTENANCE MANUAL

The mechanic must not operate the machine until the Operation & Maintenance Manual has been read and understood, training has been accomplished and operation of the machine has been completed under the supervision of an experienced and qualified operator.

An Operation & Maintenance Manual is supplied with each machine and must be kept in the manual holder located in the cab. In the event that the Operation & Maintenance Manual is missing, consult the local *Caterpillar* dealer before proceeding.

1.4 DO NOT OPERATE TAGS

Place Do Not Operate Tags on the ignition key switch and the steering wheel before attempting to perform any service or maintenance. Remove key and disconnect battery leads.

1.5 SAFETY INFORMATION

To avoid possible death or injury, carefully read, understand and comply with all safety messages.

In the event of an accident, know where to obtain medical assistance and how to use a first aid kit and fire extinguisher/ fire suppression system. Keep emergency telephone numbers (fire department, ambulance, rescue squad/ paramedics, police department, etc.) nearby. If working alone, check with another person routinely to help assure personal safety.

1.6 SAFETY ALERT SYSTEM AND SIGNAL WORDS

DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

1.7 SAFETY INSTRUCTIONS

Following are general safety statements to consider **before** performing maintenance procedures on the telehandler. Additional statements related to specific tasks and procedures are located throughout this manual and are listed prior to any work instructions to provide safety information before the potential of a hazard occurs.

For all safety messages, carefully read, understand and follow the instructions *before* proceeding.

1.7.1 Personal Hazards

PERSONAL SAFETY GEAR: Wear all the protective clothing and personal safety gear necessary to perform the job safely. This might include heavy gloves, safety glasses or goggles, filter mask or respirator, safety shoes or a hard hat.

LIFTING: **NEVER** lift a heavy object without the help of at least one assistant or a suitable sling and hoist.

1.7.2 Equipment Hazards

LIFTING OF EQUIPMENT: Before using any lifting equipment (chains, slings, brackets, hooks, etc.), verify that it is of the proper capacity, in good working order, and is properly attached.

NEVER stand or otherwise become positioned under a suspended load or under raised equipment. The load or equipment could fall or tip.

DO NOT use a hoist, jack or jack stands only to support equipment. Always support equipment with the proper capacity blocks or stands properly rated for the load.

HAND TOOLS: Always use the proper tool for the job; keep tools clean and in good working order, and use special service tools only as recommended.

1.7.3 General Hazards

SOLVENTS: Only use approved solvents that are known to be safe for use.

HOUSEKEEPING: Keep the work area and operator cab clean, and remove all hazards (debris, oil, tools, etc.).

FIRST AID: Immediately clean, dress and report all injuries (cuts, abrasions, burns, etc.), no matter how minor the injury may seem. Know the location of a First Aid Kit, and know how to use it.

CLEANLINESS: Wear eye protection, and clean all components with a high pressure or steam cleaner before attempting service.

When removing hydraulic components, plug hose ends and connections to prevent excess leakage and contamination. Place a suitable catch basin beneath the machine to capture fluid run off.

It is good practice to avoid pressure-washing electrical/ electronic components. In the event pressure-washing the machine is needed, ensure the machine is shut down before pressure-washing. Should pressure-washing be utilized to wash areas containing electrical/electronic components, it is recommended a maximum pressure of 52 bar (750 psi) at a minimum distance of 30.5 cm (12 in) away from these components. If electrical/electronic components are sprayed, spraying must not be direct and for brief time periods to avoid heavy saturation.

Check and obey all Federal, State and/or Local regulations regarding waste storage, disposal and recycling.

1.7.4 Operational Hazards

ENGINE: Stop the engine before performing any service unless specifically instructed otherwise.

VENTILATION: Avoid prolonged engine operation in enclosed areas without adequate ventilation.

SOFT SURFACES AND SLOPES: **NEVER** work on a machine that is parked on a soft surface or slope. The machine must be on a hard level surface, with the wheels blocked before performing any service.

FLUID TEMPERATURE: **NEVER** work on a machine when the engine, cooling or hydraulic systems are hot. Hot components and fluids can cause severe burns. Allow systems to cool before proceeding.

FLUID PRESSURE: Before loosening any hydraulic or diesel fuel component, hose or tube, turn the engine OFF. Wear heavy, protective gloves and eye protection. **NEVER** check for leaks using any part of your body; use a piece of cardboard or wood instead. If injured, seek medical attention immediately. Diesel fluid leaking under pressure can explode. Hydraulic fluid and diesel fuel leaking under pressure can penetrate the skin, cause infection, gangrene and other serious personal injury.

Refer to the engine manufacturers manual for specific details concerning the fuel system.

Relieve all pressure before disconnecting any component, part, line or hose. Slowly loosen parts and allow release of residual pressure before removing any part or component. Before starting the engine or applying pressure, use components, parts, hoses and pipes that are in good condition, connected properly and are tightened to the proper torque. Capture fluid in an appropriate container and dispose of in accordance with prevailing environmental regulations.

COOLANT SYSTEM CAP: The cooling system is under pressure, and escaping coolant can cause severe burns and eye injury. To prevent personal injury, NEVER remove the coolant system cap while the cooling system is hot. Wear safety glasses. Turn the coolant system cap to the first stop and allow pressure to escape before removing the cap completely. Failure to follow the safety practices could result in death or serious injury.

Properly disconnect battery(s) prior to service the fuel or hydraulic systems.

FLUID FLAMABILTITY: **DO NOT** service the fuel or hydraulic systems near an open flame, sparks or smoking materials.

NEVER drain or store fluids in an open container. Engine fuel and hydraulic fluid are flammable and can cause a fire and/or explosion.

DO NOT mix gasoline or alcohol with diesel fuel. The mixture can cause an explosion.

PRESSURE TESTING: When conducting any test, only use test equipment that is correctly calibrated and in good condition. Use the correct equipment in the proper manner, and make changes or repairs as indicated by the test procedure to achieve the desired result.

LEAVING MACHINE: Lower the forks or attachment to the ground before leaving the machine.

TIRES: Always keep tires inflated to the proper pressure to help prevent tipover. **DO NOT** over inflate tires.

NEVER use mismatched tire types, sizes or ply ratings. Always use matched sets according to machine specifications.

MAJOR COMPONENTS: Never alter, remove, or substitute any items such as counterweights, tires, batteries or other items that may reduce or affect the overall weight or stability of the machine.

BATTERY: **DO NOT** charge a frozen battery. Charging a frozen battery may cause it to explode. Allow the battery to thaw before jump starting or connecting a battery charger.

1.8 SAFETY DECALS

Check that all safety decals are present and readable on the machine. Refer to the Operation & Maintenance Manual supplied with machine for information.

Section 2 General Information and Specifications

2.1 INTRODUCTION

The efficiency and continued operation of mechanical units depend on constant, correct maintenance and also on efficient repair work, should there be a break-down or malfunction. The instructions contained in this manual have been based on a complete overhaul of the unit. However, it is up to the mechanic to decide whether or not it is necessary to assemble only individual components, when partial repair work is needed. The manual provides a quick and sure guide which, with the use of photographs and diagrams illustrating the various phases of the operations, allows accurate work to be performed.

All the information needed for correct disassembly, checks and assembly of each individual component is set out below. In order to remove the differential unit from the vehicle, the manuals provided by the vehicle manufacturer should be consulted. In describing the following operations it is presumed that the unit has already been removed from the vehicle.

IMPORTANT: In order to facilitate work and protect both working surfaces and operators, it is advisable to use proper equipment such as: trestles or supporting benches, plastic or copper hammers, appropriate levers, pullers and specific spanners or wrenches.

Before going on to disassemble the parts and drain the oil, it is best to thoroughly clean the unit, removing any encrusted or accumulated grease. Before going on to disassemble the parts and drain the oil, it is best to thoroughly clean the unit, removing any encrusted or accumulated grease.

INTRODUCTORY REMARKS

All the disassembled mechanical units should be thoroughly cleaned with appropriate products and restored or replaced if damage, wear, cracking or seizing have occurred.

In particular, thoroughly check the condition of all moving parts (bearings, gears, crown wheel and pinion, shafts) and sealing parts (O-rings, oil shields) which are subject to major stress and wear. In any case, it is advisable to replace the seals every time a component is overhauled or repaired. During assembly, the sealing rings must be lubricated on the sealing edge. In the case of the crown wheel and pinion, replacement of one component requires the replacement of the other one. During assembly, the prescribed pre-loading, backlash and torque of parts must be maintained.

CLASSIFICATION

This manual classifies units according to part numbers. For a correct interpretation, classification is indicated as follows:



= up to the part number.

= from the part number on.

When no classification is given, disassembly and assembly operations are the same for all versions.

SPECIFIC EQUIPMENT AND SPARE PARTS

The drawings of all specific tools required for maintenance and repair work can be found at the end of this manual; spare parts may be ordered from your Caterpillar dealer.

2.2 SPECIFICATIONS

2.2.1 DEFINITION OF VIEWPOINTS



2.2.2 DATA PLATE



2.3 CONVERSION TABLES

2.3.1 UNITS OF PRESSURE

• 1 ATM=1 BAR=10⁵ PA=14.4 PSI

2.3.2 UNIT OF WEIGHT

| UNIT | N | daN | kN | kg | lbs |
|------|------|-------|---------|-------|-------|
| 1N | 1 | 0.1 | 0.001 | 0.102 | 0.225 |
| 1daN | 10 | 1 | 0.01 | 1.02 | 2.25 |
| 1kN | 1000 | 100 | 1 | 102 | 225 |
| 1kg | 9.81 | 0.981 | 0.00981 | 1 | 2.205 |

2.3.3 UNITS OF TORQUE

| UNIT | Nm | daNm | kNm | kgm | lb-in |
|---------|--------|---------|-----------|---------|-------|
| 1Nm | 1 | 0.1 | 0.001 | 0.102 | 8.854 |
| 1daNm | 10 | 1 | 0.01 | 1.02 | 88.54 |
| 1kNm | 1000 | 100 | 1 | 102 | 8854 |
| 1kgm | 9.81 | 0.981 | 0.00981 | 1 | 86.8 |
| 1 lb-in | 0.1129 | 0.01129 | 0.0001129 | 0.01152 | 1 |

2.4 TORQUE SPECIFICATIONS

2.4.1 BOLT TIGHTENING TORQUES

| SIZE OF BOLT | | TYPE OF BOLT | | | | | | |
|--------------|---------------|--------------|----------------------|-------------|-----------------------|-------------|-----------------------|--|
| | | 8.8 | 8.8 + Loctite 270 | 10.9 | 10.9 + Loctite 270 | 12.9 | 12.9 + Loctite 270 | |
| | M6 X 1 mm | 9.5 – 10.5 | 10.5 – 11.5 | 14.3 – 15.7 | 15.2 – 16.8 | 16.2 – 17.8 | 18.1 – 20 | |
| | M8 X 1.25 mm | 23.8 – 26.2 | 25.6 – 28.4 | 34.2 – 37.8 | 36.7 – 40.5 | 39 – 43 | 43.7 – 48.3 | |
| | M10 X 1.5 mm | 48 – 53 | 52 – 58 | 68 – 75 | 73 – 81 | 80 - 88 | 88 – 97 | |
| | M12 X 1.75 mm | 82 – 91 | 90 – 100 | 116 – 128 | 126 – 139 | 139 – 153 | 152 – 168 | |
| Ë | M14 X 2 mm | 129 – 143 | 143 – 158 | 182 – 202 | 200 – 221 | 221 – 244 | 238 – 263 | |
| EPIT | M16 X 2 mm | 200 – 221 | 219 – 242 | 283 – 312 | 309 – 341 | 337 – 373 | 371 – 410 | |
| ARSE | M18 X 2.5 mm | 276 – 305 | 299 – 331 | 390 – 431 | 428 – 473 | 466 – 515 | 509 – 562 | |
| lo CO | M20 X 2.5 mm | 390 – 431 | 428 – 473 | 553 – 611 | 603 – 667 | 660 – 730 | 722 – 798 | |
| | M22 X 2.5 mm | 523 – 578 | 575 – 635 | 746 – 824 | 817 – 903 | 893 – 987 | 974 – 1076 | |
| | M24 X 3 mm | 675 – 746 | 732 – 809 | 950 – 1050 | 1040 – 1150 | 1140 – 1260 | 1240 – 1370 | |
| | M27 X 3 mm | 998 – 1103 | 1088 – 1202 | 1411 – 1559 | 1539 – 1701 | 1710 – 1890 | 1838 – 2032 | |
| | M30 X 3.5 mm | 1378 – 1523 | 1473 – 1628 | 1914 – 2115 | 2085 – 2305 | 2280 – 2520 | 2494 – 2757 | |
| | | | | | | | | |
| | M8 X 1 mm | 25.7 – 28.3 | 27.5 – 30.5 | 36.2 – 39.8 | 40 – 44 | 42.8 - 47.2 | 47.5 – 52.5 | |
| | M10 X 1.25 mm | 49.4 – 54.6 | 55.2 – 61 | 71.5 – 78.5 | 78 – 86 | 86 – 94 | 93 – 103 | |
| | M12 X 1.25 mm | 90 – 100 | 98 – 109 | 128 – 142 | 139 – 154 | 152 – 168 | 166 – 184 | |
| | M12 X 1.5 mm | 86 – 95 | 94 – 104 | 120 – 132 | 133 – 147 | 143 – 158 | 159 – 175 | |
| т | M14 X 1.5 mm | 143 – 158 | 157 – 173 | 200 – 222 | 219 – 242 | 238 – 263 | 261 – 289 | |
| PITC | M16 X 1.5 mm | 214 – 236 | 233 – 257 | 302 - 334 | 333 - 368 | 361 – 399 | 394 – 436 | |
| NEI | M18 X 1.5 mm | 312 – 345 | 342 – 378 | 442 – 489 | 485 – 536 | 527 – 583 | 580 – 641 | |
| Ξ | M20 X 1.5 mm | 437 – 483 | 475 – 525 | 613 – 677 | 674 – 745 | 736 – 814 | 808 - 893 | |
| | M22 X 1.5 mm | 581 – 642 | 637 – 704 | 822 – 908 | 903 – 998 | 998 – 1103 | 1078 – 1191 | |
| | M24 X 2 mm | 741 – 819 | 808 - 893 | 1045 – 1155 | 1140 – 1260 | 1235 – 1365 | 1363 – 1507 | |
| | M27 X 2 mm | 1083 – 1197 | 1178 – 1302 | 1520 – 1680 | 1672 – 1848 | 1834 – 2027 | 2000 – 2210 | |
| | M30 X 2 mm | 1511 – 1670 | 1648 – 1822 | 2138 – 2363 | 2332 – 2577 | 2565 – 2835 | 2788 – 3082 | |

Unit - Nm

2.4.2 WHEEL NUT TIGHTENING TORQUES

| | WHEEL STUD | RECOMMENDED WHEEL NUTS TORQUE | | | |
|--|--------------|----------------------------------|-------------------------|-----------------------|--|
| WHEEL NUTS CHARACTERISTIC | THREAD | AD MATERIAL QUALITY | | NUT FIXING'S SOLUTION | |
| | | ST 37 | **ST 52 | | |
| | M18 X 1.5 mm | 330 Nm (243 ft. lb.) | 460 Nm (339 ft. lb.) | | |
| WHEEL NUTS WITH INTEGRATED SPHERICAL COLLAR | M20 X 1.5 mm | 490 Nm (361 ft. lb.) | 630 Nm (464 ft. lb.) | | |
| | M22 X 1.5 mm | 630 Nm (464 ft. lb.) | 740 Nm (545 ft. lb.) | MAP3930 | |
| | M18 X 1.5 mm | 270 Nm (199 ft. lb.) | 360 Nm (265 ft. lb.) | A D | |
| WITH SEPARATE SPHERICAL | M20 X 1.5 mm | 360 Nm (265 ft. lb.) | 450 Nm (332 ft. lb.) | | |
| LUCK WASHER | M22 X 1.5 mm | 460 Nm (339 ft. lb.) | 550 Nm (406 ft. lb.) | MAP3940 | |
| | M18 X 1.5 mm | 260 Nm (192 ft. lb.) | 360 Nm (265 ft. lb.) | പി | |
| INTEGRATED SEAT CAPTIVE | M20 X 1.5 mm | 350 Nm (258 ft. lb.) | 500 Nm (369 ft. lb.) | | |
| WASHER | M22 X 1.5 mm | 450 Nm (332 ft. lb.) | 650 Nm (479 ft. lb.) | марзэ50 | |

Wheel nut tightening torques recommended from rim's manufacturer with reference to the quality of the rim's material.

IMPORTANT: **Rim's material ST 52 is recommended by manufacturer on axle application. It is the optimum material for tightening the rim to the hub.

Note: The wheel nut tightening torque is related only on nut thread and stud thread dry. (Without oil or any lubricant).

Note: The wheel nut tightening torque takes into consideration not only the nut + stud characteristics, but also the quality of the rim material.

| TIGHTENING TORQUE TABLE, SHOWS THE TORQUE FIGURE RELATED TO THE BOLT CHARACTERISTIC ONLY. | | | | | | |
|---|-----------------------|--------------------------------|--|--|--|--|
| TIGHTENING TORQUE TABLE | | | | | | |
| NUT MATERIAL QUALITY 8.8 & 10.9 | STUD MATERIAL QUALITY | *TORQUE RANGE | | | | |
| M18 X1.5 mm | M18 X1.5 mm | 442 - 489 Nm/ 326 - 360 ft.lb. | | | | |
| M20 X1.5 mm | M20 X1.5 mm | 613 - 677 Nm/ 452 - 499 ft.lb. | | | | |
| M22 X1.5 mm | M22 X1.5 mm | 822 - 908 Nm/ 606 - 669 ft.lb. | | | | |

Note: The torque figure on nut and stud coupling must be related on stud material quality

2.5 MAINTENANCE

2.5.1 MAINTENANCE POINTS



2.5.2 MAINTENANCE INTERVALS

| OPE | RATION | INTERVAL | LUBRICANT | |
|-------------------------------------|------------------------------------|----------------------|--|--|
| Chack Lovals | Differential | Monthly | SAE85W90 (API GL4 - MIL L-2105) With additives for oil-bath brakes SAE85W90 (API GL5 - MIL 2105-B) | |
| Clieck Levels | Planetary reduction | Every 200 hours | | |
| | Differential | Every 800 hrs * | | |
| Oil change | Planetary reduction | Every 1000 hrs * | With additives for oil-bath brakes, for units presenting hypoid crown | |
| | L.S. Differential | Every 700 hrs */*** | wheel and pinion and/or self- locking differential gear | |
| Adjustment | Negative brake | Every 1000 hours* | Only for mineral oil use e.g. | |
| Adjustment | Service brake | Every 500 hours | ATF Dexron II. Make sure that master cylinder seals are suitable | |
| Tightening | Wheel nuts | Every 200 hours** | for mineral oil. | |
| | King Pin Tapered Bearings | | | |
| Grossing | Seals | Normal work - Weekly | NLGI Z EP OF NLGI S EP """" | |
| Greasing | King Pin Bushings | Severe duty - Daily | NLGI 2 EP or NLGI 3 EP **** | |
| | Trunnion Bushings |] | w/Moly Additive | |
| Note: If working in severe d | uty conditions half intervals shou | ld be used. | | |

- * Initially after 100 working hours
- ** Initially after 10 working hours
- *** When it starts sounding noisy
- **** According to DIN 51825 level KP2K-30 (NLGI #2) or KP3K-20 (NLGI #3); ASTM D4950 NLGI #2 GC-LB

2.5.3 LUBRICANT & SEALANT SPECIFICATIONS

1. Locking, sealing and lubricating materials referred to in this manual are the same used in the shop-floor.

2. The table below gives an account of the typical applications of each single material, in order to facilitate replacement with similar products marketed by different brand names with different trade marks.

| ТҮРЕ | APPLICATION |
|--|---|
| LOCTITE 242 | Anaerobic product apt to prevent the loosening of screws, nuts and plugs. Used for medium-strength locking. Before using it, completely remove any lubricant by using the specific activator. |
| LOCTITE 243 | The oleocompatible alternative to 242. Does not require the activation of lubricated surfaces. |
| LOCTITE 270 | Anaerobic product for very-high strength locking of screws and nuts. Before using it, completely remove any lubricant by using the specific activator. To remove parts, it may be necessary to heat them at 80° C approximately. |
| LOCTITE 275 | Anaerobic product suitable for high-strength locking and sealing of large threaded parts, bolts and stud bolts, for pipe sealing and for protecting parts against tampering; suitable for sealing coupling surfaces with a maximum diametrical clearance of 0.25 mm. |
| LOCTITE 510 | Anaerobic product for the hermetic sealing of flanged units and screw holes communicating with fluids. Can seal clearances between flanges up to 0.2 mm. |
| LOCTITE 577 | Quick anaerobic sealant for sealing threaded portions of conical or cylindrical unions up to M80. Before using it, remove any lubricant with the specific activator. After polymerisation, disassembly may result rather difficult, so heating may be necessary for larger diameters. |
| LOCTITE 638 | Anaerobic adhesive for fast and high-strength gluing of cylindrical metal joints (hub on shaft). Can glue together parts with clearance ranging between 0.1 and 0.25 mm. |
| LOCTITE 648 | Anaerobic adhesive for fast and medium-strength gluing of cylindrical metal joints (hub on shaft). Can glue together parts with radial clearance below 0.1 mm. |
| AREXONS (Repositionable jointing compound for seals) | Solvent-based sealing compound for elastic seals, drying through evaporation. Used for sealing the outer diameter of sealing rings for rotating shafts with outer metal reinforcement. |
| CAT RTV Silicone Adhesive Sealant | Semi-fluid adhesive material used for sealing and filling and to protect components from environmental and physical elements. Polymerises with non-corrosive dampness. |
| CAT Multi Purpose Grease | Highly adhesive synthetic grease, with silicone compounds added. Applied to adjustment screws with hole communicating with oil-type fluids. Used when frequent adjusting is required. |
| CAT Molybdenum Paste | Lubricating compound containing molybdenum disulphide, used to lubricate articulation pins and to prevent sticking and oxidation of parts that are not lubricated on a regular basis. |
| CAT White Assembly Grease | Applied to bearings, sliding parts and used to lubricate seals or parts during assembly. |

2.6 SAFETY PRECAUTIONS

- 1. During all operations described in this manual, the axle should be fastened onto a trestle, while the other parts mentioned should rest on supporting benches.
- 2. When removing one of the arms, an anti-tilting safety trestle should be placed under the other arm.
- 3. When working on an arm that is fitted on the machine, make sure that the supporting trestles are correctly positioned and that the machine is locked lengthways.
- 4. Do not admit any other person inside the work area; mark off the area, hang warning signs and remove the ignition key from the machine.
- 5. Use only clean, quality tools; discard all worn, damaged, low quality or improvised wrenches and tools. Ensure that all torque wrenches have been checked and calibrated.
- 6. Always wear gloves and non-slip rubber shoes when performing repair work.
- 7. Should you stain a surface with oil, remove marks straight away.
- 8. Dispose of all lubricants, seals, rags and solvents once work has been completed. Treat them as special waste and dispose of them according to the relative law provisions obtaining in the country where the axles are being overhauled.
- Make sure that only weak solvents are used for cleaning purposes; avoid using turpentine, dilutants and toluol, xylolbased or similar solvents; use light solvents such as Kerosene, mineral spirits or water-based, environment friendly solvents.
- 10. For the sake of clarity, the parts that do not normally need to be removed have not been reproduced in some of the diagrams.
- 11. For agricultural axles, the terms RIGHT and LEFT refer to the position from operator's seat. For construcition axle, the terms RIGHT and LEFT refer to the position outside facing the machine (with the input drive facing forward).
- 12. After repair work has been completed, accurately touch up any coated part that may have been damaged.
- 13. Follow all safety instructions in the Original Equipment Manufacturer (OEM) manual that came with the vehicle.

This Page Intentionally Left Blank

Section 3 Planetary Reduction 1:6 and Steering Case

3.1 EXPLODED VIEW



MAP11200

3.2 PLANETARY REDUCTION - 1.6 AND STEERING CASE - DISASSEMBLY



MAP11210

- 1. Remove the cap screws (23) from the planetary carrier cover (25).
- Disconnect the steering bars from the steering case (14).



3. Disjoint the planetary carrier cover (**25**) from the steering case by alternatively forcing a screwdriver into the appropriate slots.



MAP11230

4. Remove the complete planetary carrier cover (25).



MAP11240

5. Remove the snap ring (28) of the planetary gears (27).



MAP11250

6. Remove the planetary gears (27).



7. Write down direction of assembly of planetary gears.



- MAP11290
- 10. Remove the shim washer (31).



8. Remove the snap ring (**30**).



11. Remove the safety flange (33).



9. Loosen and remove the nuts (**32**) from the crown flange (**35**).



12. Using a puller, remove the complete crown flange (**35**) by acting on the stud bolts.



MAP11320

13. Partially extract the hub (41) using a plastic hammer. Note: Alternately hammer on several equidistant points.



16. Remove the bearing external thrust blocks, using a pin driver.

Note: Hammer in an alternate sequence to prevent clamping and deformation of the thrust blocks.







18. Pay attention not to damage the seat of bearing.



15. Remove the complete hub (**41**).

14. Remove the external bearing (38).





19. Write down the steering case screw length measurement.



22. Disconnect the tapered pins of the articulation from the steering case (**14**) using a puller.



20. Loosen the lockscrew and insert it to allow the passage of tool.



23. Loosen and remove the cap screws (**19**) from the bottom articulation pin (**20**).

Note: Screws cannot be re-used.



24. Remove the bottom articulation pin (**18**) complete with front sealing ring (**20**).



21. Remove the nuts that lock the articulation pins.



25. Loosen and remove the cap screws (13) from the top articulation pin (10).



29. Use a puller to remove the sealing ring from the steering case (**14**).

Note: Write down the orientation of sealing ring (5).



- 26. Using two levers, remove the top articulation pin (**10**) complete with front seal (**8**).
- 27. Pay attention not to damage the surfaces.



30. Remove the bushing (6) from the steering case (14).*Note:* Write down the orientation of bushing.



28. Remove the complete steering case (14).



MAP11480

31. Remove the u-joint (4).

Note: To remove the u-joint use, if necessary, a plastic hammer or a lever.



- MAP11490
- 32. Using a puller for inner parts, remove the top bushing(7) and the bottom ball-bushing (17).



33. Remove the articulation pins (**10**) and (**20**) and the front sealing rings (**8**) and (**18**).

Note: Write down the side for assembly.



34. If the ball cover (**17**) needs replacing, remove it from the bottom articulation pin (**20**).



MAP11520

35. Remove seal ring (**3**) and the bushing (**2**) from the arm (**1**).

3.3 PLANETARY REDUCTION - 1.6 AND STEERING CASE - ASSEMBLY



MAP11530

- 1. Lubricate the bushing (6) and the seat of the steering case (14)
- 2. Install the bushing (6), using tool (T1).





3. Lubricate the outer surface of the sealing ring (**5**); fit them into their seat using tool (**T2**).



MAP11550

- 4. Using special tool (**T3**) apply a repositionable jointing compound for seals to the outer surface of the sealing ring (**44**).
- 5. Position the sealing ring (44) in the steering case (14).

Note: Check that the ring (44) is correctly oriented.



MAP11560

6. If the bottom articulation pin (**17**) has been extracted, position the pin under a press and fit the ball cover (**20**).



7. Fit the front sealing rings (18) and (8) onto the articulation pins (10) and (20).





- 9. Lubricate the bushing (2) and the seat of the steering case (1).
- 10. Install the bushing (2), using special tool (T1).



MAP11580

8. Lubricate the top bushing (7) or the bottom ball bushing (17) and fit them into the fulcrum holes of the arm.



- 11. Lubricate and fit the sealing ring (3) onto tool (T4).
- 12. Install the rings into the arm.

CAUTION

Pay particular attention to the direction of assembly of the rings.



13. Insert the u-joint (4).



- 17. Lubricate and install the unit in the steering case.
- Grease 4
 - MAP11620
- 14. Lubricate the terminal of the u-joint (**4**) and install the steering case (**14**).
- 15. Pay attention not to damage the dust cover rings and sealing rings.



16. Prepare a series of shims (9) of 0.4 up to 0.7 mm to be assembled under the upper pin (10).



18. Lubricate the steering case.



- 19. Fit the unit (**20**) in the steering case (**14**).
- 20. Position the screws (19) and tighten.





21. Tighten the new cap screws (13) of top articulation pins in sequence using the criss-cross method. Torque wrench setting: 128 - 142 Nm (94 - 104 ft.lb.)



MAP11680

22. Tighten the new cap screws (19) of bottom articulation pins in sequence using the criss-cross method. Torque wrench setting: 128 - 142 Nm (94 - 104 ft.lb.)



MAP11690

- 23. Check by means of a lever that there is no vertical gap.
- 24. In case there is any gap, determine the width and reduce it by removing shims.



MAP11700

- 25. Check the torque of the pins, which has to be between 40 - 80 Nm (29 - 59 ft.lb.).
- 26. If the preliminary measurement value is too high, the shims have to be increased.



27. Look for the position of the notch regarding the safety cotter pin hole when the nut is locked to a maximum 300 Nm (221 ft.lb.).



MAP11740

30. Lubricate the seats of the bearings and position the hub (41) on tool (T5) position the thrust block of the internal bearing (43).

Note: Check that the thrust block is correctly oriented.



28. Bring the lockscrew to the value previously measured.



31. Install the external bearing (38).

Note: Move the bearing to the limit stop by hammering lightly all around the edge.



MAP11730

29. Position the lower part of tool (T5) and the thrust block of the external bearing (38).


32. Install the wheel hub (41).



33. Install the ring gear (**36**).



35. Install the security flange (**33**). Using Techno Lube/101, grease the surface of the safety flange (**33**) that touches the ring gear.



MAP11800





34. Install the complete ring crown flange (**36**).

Note: In order to fasten the flange (**36**), use a plastic hammer and alternately hammer on several equidistant points.

36. Coat the nuts (23) with Loctite 242 and tighten them.



37. Tighten nuts (**32**) in two stages, using the criss-cross

Initial torque wrench setting: 90 Nm (66 ft.lb.) Final torque wrench setting: 100 Nm (73 ft.lb.)

method.



MAP11820



MAP11850

41. Check the condition and position of the o-ring (**37**).



MAP11830

39. Fit the NEW safety snap ring (31).

38. Install the spacer (15).

Note: Check that the snap ring is fitted correctly and safely in its seat.



MAP11840

40. Check the continuous rolling torque on the hub. Torque 7 - 20 Nm (5 - 14 ft.lb.)



MAP11860

42. Fit the planetary gear (27) onto the planetary gear cover (25).



The jointed portion of the internal ring of the bearings must face the bottom of the pin.



43. Lock into position the planetary gears (**16**) with the snap rings (**15**).



44. Fit the planetary gear cover (18) onto the wheel hub (4).



45. Tighten with a torque wrench to 40 - 50 Nm (29 - 36 ft.lb.).

This Page Intentionally Left Blank

Section 4 Steering Cylinder

4.1 EXPLODED VIEW



4.2 STEERING CYLINDER - DISASSEMBLY



1. Remove the steering piston sensor (21).



MAP11970

2. Remove the nuts (18) that lock the articulation pins (14).



MAP11980

3. Disconnect the tapered pins of the articulation (14) from the steering case using a puller.



MAP11990

4. If the connection of the steering bars includes a safety collar, raise the border.



MAP12000

5. Disconnect left and right steering bars from the piston.



MAP12010

6. Remove the securing screws (19) from the steering cylinder (16).



MAP12020

7. Extract the cylinder (16) using a plastic hammer.

CAUTION Before attempting to disassemble the unit, drain the oil in the cylinder chambers completely.



MAP12030

8. Using a snap ring plier, remove the snap ring (1) of the cylinder head.



9. Lightly tap the cylinder head (2) with a plastic hammer so as to push it inside the cylinder (3).

Note: Insert the cylinder head so it is flush with the cylinder.



MAP12050

10. Using a punch, force the stop ring (4) located inside the cylinder (3) and extract ring using a screwdriver.

Steering Cylinder



11. Take the cylinder unit a part by extracting the head first, followed by the piston.



- MAP12070
- 12. Write down the direction of the piston seal ring that is towards cylinder head.



MAP12080

13. Remove all seals, anti-extrusion rings and scraper rings from head (2), cylinder (3), and piston (5).

Note: All seals must be replaced every time the unit is disassembled.

Note: Particular attention must be paid not to damage the seats of both seals and piston slide.

4.3 STEERING CYLINDER - ASSEMBLY



MAP12090

Grease and install the piston rod seal ring (6), rod wiper
 (8) and back up washer (7) into cylinder (3).



Grease and install the piston rod seal ring (6), rod wiper
 (8) and anti-extrusion ring (7) into the head (2).



3. Fit seal (9) on the outside of the head (2).

To ease installation, grease the outer surface of the piston.

Do not roll the seal (9).



MAP12120

4. Prepare piston (5) by fitting it with magnetic ring (11), anti-extrusion ring (10) and piston seal (13).





5. Center the shaft on the cylinder (**3**) so that it fits into the piston (**5**).





6. Push the piston (**5**) into the cylinder for 100 mm using a plastic hammer.



- 7. Apply grease to head (2) seals, fit the head onto the piston and push it into the cylinder (3) using a plastic hammer.
- 8. Insert the head to line it up with the edge of the cylinder.



MAP12160

9. Install the stop ring (4) and ensure that it sets in the seat of cylinder (3).



10. Do not go beyond the ring of gasket the hole of feeding because it could be cut.



12. Replace at each reassembly.



MAP12180

11. Using two screwdrivers or levers, force the head until it is seated against the stop ring (4). Fit the snap ring (1) on the head (2).

Make sure that the snap ring (1) is securely fastened in its seat. If necessary, force it into its seat using a drift and a hammer.



13. Check that the o-rings (17) and (15) of the axle unit are in good condition; lubricate the seats of the seals and fit the steering cylinder (3).





14. Lock the cylinder by criss-cross method the screws (**3**). Torque wrench setting: 90 - 100 Nm (66 - 73 ft.lb.)



MAP12210

15. Apply Loctite 242 to the thread and connect the steering bars by tightening the terminals onto the piston stem.

Torque wrench setting: 240 - 270 Nm (177 - 199 ft.lb.)

Note: Versions with coupling require that the rim of the articulation is riveted onto the surfaces of the piston stem.



16. Insert the pins (**18**) in the steering case and lock into position using a torque wrench setting of 270 - 300 Nm (199 - 221 ft.lb.).



MAP12230

Install the steering piston sensor (21) for checking piston centering - if applicable - and tighten the screws (20).

Torque wrench setting: 5 - 8 Nm (3 - 5 ft.lb.)

CAUTION

Eliminate the action of the negative brake, if fitted.



18. Apply tools (**T6**) to the hubs and lock them. Using a level "B", check that tools are perfectly flat and parallel to each other.



MAP12260

20. Center the piston by slowly moving it first in one direction then in the other and position it half way on the stroke, which is determined by the switching on and off the signal lamp of the inspection device in the reversal stage.



MAP12250

19. Connect the sensor (**21**) to the inspection device according to either diagram.



MAP12270

21. Inspect distance "C" on one side of the piston and write down the size for checking later adjustments.

Note: If cylinders come without a sensor, the centering of the piston must be carried out on the basis of the maximum stroke.



22. Without moving the piston, check front and rear size at the edge of tools (**T6**). Maximum difference: 0.6 - 0.7 mm.





23. If necessary, adjust convergency without moving the centering of the piston and adjust the length of the steering bars (**14**).

Note: With a half turn of screw, the front size is reduced by about 3 mm, whereas the rear one is increased by about 3 mm.



- MAP12300
- 24. Loosen the nuts and tighten them onto the ball and socket joints.



- 25. Hold the articulations still and rotate the ball and socket joints.
- 26. Once the convergency has been adjusted, lock the nuts. Torque wrench setting for nuts: 240 - 270 Nm (177 - 199 ft.lb.).



MAP12320

27. ADJUSTING THE STEERING ANGLE -

Perform the same operations on both sides (see diagram). Loosen the nut of one of the adjusting screws on the cylinder side.



28. Adjust the distance portion of the screw according to data shown in the table. Lock into the position with nut tightened to maximum 148 Nm (109 ft.lb.).



MAP12340

29. Perform one full steering operation until the adjusted screw leans against the arm stop.



30. As you hold the adjusted screw in position against the arm stop, adjust the screw opposite, on noncylinder side, until it leans against the arm stop.

The screws must lean against the respective arm stops all at the same time.

This Page Intentionally Left Blank

5.1 EXPLODED VIEW



5.2 BRAKE WORKING CONDITIONS

5.2.1 SAHR BRAKE APPLIED



NO PRESSURE IN ANY PORT

5.2.2 SAHR BRAKE RELEASED



5.2.3 SERVICE BRAKE APPLIED



5.2.4 DIFFERENTIAL LOCK APPLIED



5.3 EMERGENCY RELEASE INSTRUCTIONS

DANGER

Before working on brakes, when the axle is installed on the vehicle, follow all safety instructions in the Original Equipment Manufacturer (OEM) manual that came with the vehicle.

Note: The below procedure is recommended only for emergency but never for moving the vehicle during the assembly phase, where hydraulic release must be applied.

CAUTION

Refer to the blocking modes, in an emergency to the instruction handbook.

This procedure is needed only for emergency purposes if the engine fails and safety brake is applied in order to move the vehicle.



- Disconnect the pipe of the hydraulic connection from axle port of negative brake (Stamped P1)
- To release the negative brake, loosen the two screws (**30**) on the axle cover and remove the spacer (**32**).
- Tighten both screws (**30**) by hand until both are in contact the internal pusher plate. After tightening both screws, alternatively, for ¼ of turn on each side, with a wrench until they are completely tightened.

5.4 RESET OF FAILS SAFE BRAKE FUNCTION

- Loosen again the screws (**30**) alternatively for ¹/₄ of turn on each side and fit in the spacer (**32**) between the screw head and the axle cover.
- Tighten the screws (**30**) completely against the spacer with torque of 95 115 Nm (70.0 84.8 ft.lb).

5.5 BRAKE: SERVICE BRAKE, NEGATIVE BRAKE, 45% LOCKED & 100% LOCKED-DISASSEMBLY



1. Connect an external pump to the union piece "P1" of the negative brake and introduce a pressure of 15 ± 30 bar to eliminate the pressure of the Belleville washers.



2. Loosen the unlocking screws (**30**) and remove both stop washers (**32**).



- MAP12450
- 3. Insert block screws to end stroke and release pressure.



MAP12460

- 4. Remove the screws of the planetary gearbox cover on the brake side.
- 5. Remove the planetary gearbox cover.



6. Remove the axle half shaft.



7. Sling the arm to be removed and connect it to a hoist. Remove screws.



10. Remove the negative brake locking screws (**30**). Always replace the o-ring (**31**).



8. Take off the arm and lay it down vertically.



11. Loosen the before installed provisional screws in the same sequence and same measure.



12. Insert the screws of the puller (**M12**) into the tap holes of the negative brake and remove the pistons of the brake.



9. In order to keep the disc springs of the negative brake preloaded, tighten the screws with washers to the end stop.



13. Pull out brake piston assembly module.



14. Check locking screw (33) of the brake piston module.



16. Applying pressure to the first hole, remove the service brake piston (**7**).



17. Applying pressure to the second hole, remove the hydraulic block piston (**12**).



MAP12560

15. Remove intermediate disc (2). *Note: Mark the assembly position.*



18. Applying pressure to the third hole, remove the three bolts (**24**).



21. Unscrew the slotted nut (**29**).



19. Turn upside down the brake module and with a pin driver remove the locking pin of the slotted nut.



20. Mark the position of the slotted nut.



22. Remove the disc springs (28).



MAP12640

23. Applying pressure, remove the piston (**27**) of the negative brake.



24. Check the position of the anti-extrusion (8), (10), (14) and (5) and o-rings (9), (10), (13) and (6).



25. Check the position of the o-rings (25) and (26).



26. Remove the snap ring (4) from the intermediate disc (2).



27. Remove coupling (40) and washers (45).Note: Build a stack of washers and check the measurement.



28. Using a puller, preload the spring (42).



29. Remove the snap ring (44).



Spring preloaded.



30. Remove the fixing ball (**41**).



31. Remove the spring (42) and washer (43).



MAP12730

32. Remove the snap ring of the brake stack.



Remove the brake discs one after the other (39) and (38).

Note: If they are not to being replaced, do not mix up the sequence.

5.6 BRAKE: SERVICE BRAKE, NEGATIVE BRAKE, 45% LOCKED & 100% LOCKED -ASSEMBLY



MAP12750

1. Insert spring (**43**) and washer (**42**) onto the hydraulic block coupling.



MAP12760

- 2. Preload the spring (**42**) by using a puller acting on the washer (**43**).
- 3. Insert the snap ring (44) and the fixing ball (41).



MAP12770

Shift the cut of the snap ring (15) according to the ball (41).



5. Complete installing the o-rings and anti-extrusion rings on all pistons.



The o-rings always have to be assembled from the pressure facing side.



MAP12790



9. Insert the intermediate disc (**2**) observing the previously signed position.



MAP12800

7. Insert the hydraulic block piston (12).

6. Insert the bolts (24).



Turn upside down and insert the negative brake piston (27).



11. Tighten the slotted nut (29) for about 5 turns.



8. Insert the service brake piston (**7**) hammering alternately with a plastic hammer.





12. Find out the height of the brake discs "D". E.g. D=44.7 mm Add to D the value G = brake clearance (e.g. 1.4 mm). D + G = 44.7 + 1.4 = 46.1



13. Determine the level "A" between external plane and the brake plate by the adjustment of the slotted nut. A = 141 - (D+G) = 141 - 46,1 = 94,9 mm X = constant value 141 mm

Note: To define the level A adjust the slotted nut always to the smaller value by driving to the closer notch.



MAP12870

14. To determine the level A the slotted nut has to be operated without spring mounted.



15. Before removing the slotted nut in order to insert the springs, write down the distance Z from the plane to the tooth near the pin.

Note: Write down measurement.



MAP12890

16. Turn upside down and fit on the intermediate disc (2).



17. Select a pack of washers (20) of 1.5 mm S4=1.5 mm.



MAP12930

20. Insert the brake discs (38) in the right sequence.

Note: The first brake disc to be inserted must be of friction material.



18. Insert and bring into position washers (45) and coupling (40) into the brake module (22).







19. With the positioned pack determine the distance L between coupling and brake disc surface. E.g. L=37.5 mm

21. Insert the brake discs (**39**) in the right sequence. Note: The last brake disc must be of metal material.





22. Zero the depth gage from the plane of the splined coupling to the surface of the brake discs.

Note: Press the brake disc pack before zeroing, execute the measurement in some points and take an average.



- MAP12960
- 23. Check the clearance "r" between coupling and thrust bearing.
- 24. Find out the distance "M" between the brake discs surface and thrust bearing.
 E.g. M=36.4mm Brake discs clearance G = 1.4 R = (M+G)-L=(36.4+1.4)-37.5=0.3mm



MAP12970

25. Correction of the shims s4 depending on the calculation of the value "R".

Note: The value of "R" has always to result in 0.1 mm. in case it is not so, the shims **S4** (**45**) under the coupling (**40**) have to be modified.



- 26. Depending on the calculation assemble the exact shims to arrive at R=0.1 mm.
- 27. Assemble all with safety ring. Shims S4 z.B.: S4= 1.5+(0.3-0.1)= 1.5+0.2= 1.7mm where 1.5 const.
 0.3mm = R calculated clearance
 0.1mm = R wanted clearance



28. Insert the complete intermediate disc (2).



29. Turn upside down and unscrew the slotted nut (29).



30. Insert the disc springs in the right position (28).



MAP13020

Insert at the bottom the piston of the negative brake (27) and tighten the slotted nut (29).



32. Tighten the slotted nut to the earlier determined position.



33. Check the earlier measured distance Z from the plane to the tooth next to the pin.





34. Put the pin in locking (**21**) position.



MAP13060

35. Insert two screws of M12 to fix the break arm.



36. Position the groove of the brake module in line with the lock screw in the arm.



37. Check locking screw (33) of the brake piston module.



38. Insert the brake module facing the input holes to the top.



39. Insert the piston to the end stop by alternating light strokes and remove the screws.









MAP13140

43. Remove the two auxiliary screws.



MAP13120

41. Alternately tighten with a torque wrench setting of maximum 45 Nm (33 ft. lb).



42. Insert the negative brake unlocking screw (30) up to the end stop.



44. Replace and lubricate the o-ring and insert the arm to the box.



45. Insert the screws and tighten them alternately.


46. Introduce a pressure of maximum 25 bar and loosen the unlocking screws.



MAP13180

 Insert the two "U"-shaped shims and tighten the screws with a torque wrench setting of 95-115 Nm (70 - 84 ft.lb).

Note: The position of the negative brake is unlocked.

5.7 BRAKE PISTON GAP CHECK



MAP13190

 Remove the negative brake locking screws (30).Fit the special tool (T7) into the seat of the manual release of the screws. Insert a depth gauge and pre-load it with 1 mm.



- 2. Introduce a pressure of maximum 25 bar.
 - P1 = SAHR brake port
 - P2 = Service brake port

For drawings, see Brake Working Conditions.



3. Once the pressure is inserted into the circuit the depth gauge must give a measurement equal to $G \pm 0.1$ mm.

Section 6 Brake: Negative Brake 4 Cup Springs Version

6.1 EXPLODED VIEW



MAP13230

6.2 BRAKE: NEGATIVE BRAKE 4 CUP SPRINGS VERSION - DISASSEMBLY

DANGER

Before working on brakes, when the axle is installed on the vehicle, follow all safety instructions in the Original Equipment Manufacturer (OEM) manual that came with the vehicle.



MAP13240

 For details, see Brake: Service Brake, Negative Brake, 45% Locked & 100% Locked. Turn upside down the brake module and with a pin driver remove the locking pin of the slotted nut. Write down the position of the slotted nut.



MAP13260

3. Remove the disc springs (28).



- 4. For details, see Brake: Service Brake, Negative Brake, 45% Locked & 100% Locked.
- 5. Inspect the o-rings and anti-extrusion rings on all pistons.

The o-rings always have to be assembled from the pressure facing side.



2. Unscrew the slotted nut (26).

6.3 BRAKE: NEGATIVE BRAKE 4 CUP SPRINGS VERSION - ASSEMBLY



MAP13280

6. Determine the level "A" between external plane and the brake plate by the adjustment of the slotted nut.
A = 131.5 - (D+G) = 131.5 - (44.95 + 1.25) = 85.3 mm X = constant value 131.5 mm

Note: To define the level A adjust the slotted nut always to the smaller value by driving to the closer notch.



MAP13290

- Find out the level of the brake discs "D".
 E.g. D=44.7 mm
- 8. Add to D the value G = brake clearance (e.g. 1.25 mm). D + G = 44.9 + 1.25 = 46.2 mm



MAP13300

9. Before removing the slotted nut in order to insert the springs, write down the distance Z from the plane to the tooth near the pin.

Note: Sign.



10. Insert the disc springs in the right position.



11. Tighten the slotted nut.



12. Check the earlier measured distance Z from the plane to the tooth next to the pin.



13. Put the pin (**21**) in locking position.



Check brake piston gap, see Brake Piston Gap Check.

Section 7 Normal Preloaded Differential Unit (Old Version)

7.1 EXPLODED VIEW



MAP13350

7.2 NORMAL PRELOADED DIFFERENTIAL **UNIT (OLD VERSION) - DISASSEMBLY**



MAP13360

1. Remove the brake side arm and the brake discs pack. Sling the arm to be removed and connect it to a hoist. Remove screws of the ring gear side arm.



MAP13370

2. Place the arm on a bench.



3. Position the differential gear sideways into the recess in order to be able to pull it out.



4. Pull out the differential.



5. Remove the snap ring (22) that secures the thrust bearing (23).



6. Remove the snap ring (22) and thrust bearing (23).



7. Remove the hydraulic block discs (20) and (24) one after the other.



- MAP13440
- 9. Remove the brake side planetary gear.



10. Remove the snap ring (**33**) out of its seat by moving it sideways.



8. Remove the snap ring (**19**) that secures the planetary gear.



11. Using a puller, extract the bearing (**35**) and the washer (**34**).



12. Remove the bearing (**35**), washer (**34**) and snap ring (**33**).



MAP13500

15. Remove the tapered roller bearing (**2**) of the ring gear side, using two levers.



13. Remove cap screws (**32**) of the ring gear (**31**); exchange each time when removed.



16. Remove the three spider blocking pins (10), (13) and (26) using a pin driver.



17. Move the two opposite mounted short bolts (9) and (28) to the outside of the box using the same pin driver.



14. Extract the ring gear (4).



18. Drive out the long bolt (14) and pull out the spider (16) from the center.



21. Remove the planetary gear (6).



19. Remove the two half bolts (9) and (28), spherical washers (8) and (28) and satellite gears (27) and (7).



20. Remove long bolt (14), spherical washers (12) and (29) and satellite gears (30) and (11).

7.3 NORMAL PRELOADED DIFFERENTIAL UNIT (OLD VERSION) - ASSEMBLY





MAP13590

Insert the two half bolts (28) and (9), spherical washers
 (8) and (28) and satellite gears (7) and (27).

1. Differential module assembled.



MAP13580

2. Lubricate and insert washer and planetary gear.



 Partially insert the long bolt (14), satellite gears (11) and (30) and spherical washers (29) and (12).



5. Insert spider (16) and completely insert the long bolt (14).





6. Insert completely the half bolts (9) and (28).



- MAP13630
- Center the pin holes and insert the 3 pins (10), (13) and (26).



9. Insert snap ring (22) of the planetary wheel.



10. Insert and substitute, if necessary, the discs (**20**) and (**24**) of the differential lock.



8. Insert the planetary wheel together (**17**) with the centering sleeve (**25**).

Note: The centering sleeve must have the fixing ball (**18**) assembled.

First and last disc have to be of steel material.



11. Insert thrust bearing (23) and snap ring (22).



12. Insert ring gear (31).



MAP13690

- 13. Insert the screws (32).
- 14. Tighten screws with a torque wrench setting of 78-86 Nm (57 63 ft.lb).

Note: Always use new screws to fix the ring gear. In case the screws are not thread locking pretreated, use Loctite 270.



MAP13700

15. Assemble the bearing (2).

Note: Heat the bearing to 100 °C before assembling.



16. Assemble the snap ring (33) in its seat.



MAP13720

17. Assemble shim (34) and bearing (35).

Note: Heat the bearing as well as the shim to 100 °C before assembling.

This Page Intentionally Left Blank

8.1 EXPLODED VIEW



MAP13730

8.2 NORMAL PRELOADED DIFFERENTIAL UNIT (INTERMEDIATE VERSION) -DISASSEMBLY



 Remove the brake side arm and the brake discs pack. Sling the arm to be removed and connect it to a hoist. Remove screws of the ring gear side arm.



2. Place the arm on a bench.



3. Position the differential gear sideways into the recess in order to be able to pull it out.



4. Pull out the differential.



5. Remove the snap ring (**33**) out of its seat by moving it sideways.



6. Using a puller, extract the bearing (**35**) and the washer (**34**).



7. Remove completely bearing (**35**), washer (**34**) and snap ring (**33**).



MAP13820

9. Extract the ring gear (**34**).



10. Remove the tapered roller bearing (1) of the ring gear side, using two levers.



- 11. Remove the snap ring (23) that secures the thrust bearing.
- Переод
 Энание

 МАР1310
- Remove the cap screws (3) of crown. Renew the screws
 (3) at each reassembly.







15. Remove the hydraulic block discs (**21**) and (**25**) one after the other.



- MAP1
- 13. Remove the thrust bearing (22).



16. Remove the snap ring (**20**) that secures the planetary gear.



17. Remove the brake side planetary gear (18).



MAP13870

14. Remove the thrust block (22).



Remove the three spider blocking pins (13), (16) and (27) by using a pin driver.



Remove long bolt (17) and spherical washers (11) and (29).



Move the two opposite mounted short bolts (12) and
 (30) to the outside of the box using the same pin driver.



22. Remove the planetary gear (9).



20. Drive out the long bolt (**17**) and pull out the spider (**33**) from the center.

8.3 NORMAL PRELOADED DIFFERENTIAL UNIT (INTERMEDIATE VERSION) -ASSEMBLY



- MAP13960
- 1. Install the planetary gear (9).



2. Install the planetary gears (10) and (28), spherical washers (11) and (29) onto the shafts (12) and (30).



3. Insert spider (33) and partially insert the long bolt (17).



 Install satellite gears (32) and (14), spherical washers (15) and (31) and completely insert the long bolt (17).



MAP14000

5. Insert completely the half bolts (30) and (12).



MAP14010

Center the pin holes and insert the 3 pins (13), (16) and (27).

Note: Check the free rotation of the satellite gears on the bolts.



7. Insert the planetary wheel (**18**) together with the centering sleeve (**26**).

Note: The centering sleeve must have the fixing ball (**19**) assembled.



8. Insert snap ring (**20**) of the planetary wheel (**18**).



9. Insert and replace, if necessary, the discs of the differential lock.





10. Install the thrust block with maximum internal diameter.



13. Install the snap ring (23).Note: Make sure that the ring is properly set in its seat.



11. Position the bearing (**22**) in the differential unit.



12. Install the thrust block with minimum internal diameter.

9.1 EXPLODED VIEW



MAP14090

9.2 NORMAL PRELOADED DIFFERENTIAL **UNIT (LAST VERSION) - DISASSEMBLY**



MAP14100

1. If the bearing (12) has to be replaced, remove two retaining screws (10) from the crown and, using an extractor, remove the crown bearing (9).



2. If the bearing need replacing, extract the bearing (28) from the differential carrier.



MAP14120

3. Remove the snap ring (27).



- 4. Remove the thrust block (26).
- 5. Remove the thrust bearing (26).
- 6. Remove the thrust block (26).



MAP14140

7. Remove the hydraulic block discs (24 and 25) one after the other.



8. Remove fixing screws (10) of the ring gear (9); exchange

each time when removed.





12. Remove the three spider blocking pins (**19**) by using a pin driver. Move the two opposite mounted short bolts (**18**) to the outside of the box using the same pin driver.



MAP14160

- 10. Remove the shim washer (14).
- 11. Remove the planetary gear (**15**).



MAP14180

13. Remove the bolts with the help of a drift (20).



MAP14190

14. Remove the two half bolts (18), spherical washers (17) and satellite gears (16).



15. Remove the cross bolts (21).



16. Remove the planetary gear (22) with washer (23).

9.3 NORMAL PRELOADED DIFFERENTIAL UNIT (LAST VERSION) - ASSEMBLY



MAP14210

1. Lubricate and insert washer (23) and planetary gear (22).



- MAP14220
- 2. Insert the two half bolts (18), spherical washers (17) and satellite gears (16).



3. Partially insert the long bolt (20), satellite gears (16) and spherical washers (17).



 Place the satellite gear (16) and the spherical washer (17) in the box and fix with a fake pin of suitable diameter.



5. Insert the cross bolt (21) in the correct position.



MAP14260

6. Secure the satellite gears (16) and spherical washers (17) by completely inserting the long bolt (20).



- 7. Bring the pin holes in line with the help of a pin driver.
- 8. Insert pins (19) to end of stroke.



MAP14280

9. Insert and substitute, if necessary, the discs of the differential lock (24 and 25).

CAUTION $\mathbf{\hat{N}}$

First and last disc have to be of steel material (25).



MAP14290

- 10. Install the thrust block with maximum internal diameter.
- 11. Position the bearing (26) in the differential unit.
- 12. Install the thrust block with minimum internal diameter.



13. Insert the snap ring (27).



14. Insert planetary gear wheel (15).



17. Mount the gear ring (**9**) and fasten it to the differential box with screws (**10**).



- 15. Position the shim washer (14) on the crown (9).
- 16. Install the ring gear (**9**).

Note: In order to hold the shim washer (14) in position, apply grease to it.



MAP14350

18. Heat the bearings (**12** and **28**) at 100° and insert them on the differential.

This Page Intentionally Left Blank

10.1 EXPLODED VIEW



MAP14360

10.2 FLANGED REDUCTION GEAR 603 TYPE: INTEGRAL 603 INPUT GEAR -DISASSEMBLY



- MAP14370
- 1. Remove screws (14) and (20) of the drive side flange cover.



- MAP14380
- 2. Remove the drive side flange cover (**21**).



3. Place two levers into the appropriate slots. *Note: Be careful not to damage the surfaces.*



4. Remove the cover (21).



To remove the drive side shaft (1), remove the snap ring (2).





6. Using two levers, remove the drive side shaft (1).



7. Using a screwdriver, remove the flange sealing ring (**6**). *Note: Be careful not to damage the surfaces.*



8. Remove the snap ring (4).



MAF 14450

9. With a puller, remove the bearing (3) from the input shaft (1).



10. With a puller, remove the bearing (7) from the lower shaft (8).



11. Remove the secondary gear wheel (8), if necessary use two levers.









15. Remove the sealing ring cup (**11**) by using a drift.



MAP14490

13. Remove the flange (18) using a plastic hammer.



14. Remove the internal bearing (**10**).
10.3 FLANGED REDUCTION GEAR 603 TYPE: INTEGRAL 603 INPUT GEAR - ASSEMBLY



MAP14520

1. Insert the sealing ring (6) with special tool **(T8)**.

Note: Bring the sealing ring just to the end stop. Apply grease to the sealing lips.



2. Insert the sealing ring (11) with special tool (T9)

Note: Bring the sealing ring just to the end stop. Apply grease to the sealing lips.



- 3. Fit the flange (18) and fasten it.
- 4. For keying the flange (**18**), use a plastic hammer if necessary.



MAP14550

5. Insert the bearing (10).



6. Using a driver insert the bearing (10) and snap ring (9).



7. Install the secondary gear wheel (8) with a plastic hammer.



10. Fix the bearing with the snap ring (4).





11. Install the drive side shaft (1) with a plastic hammer.



8. Using a driver insert the bearing (7).

MAP14590

9. Insert the snap ring (2) and using a driver insert the bearing (3).



MAP14620

12. Install drive side flange cover. Apply Loctite 510 to the short screws.



13. Tighten screws with a torque wrench setting of 82-91 Nm (60 - 67 ft.lb).

This Page Intentionally Left Blank

11.1 EXPLODED VIEW



11.2 BEVEL PINION: NORMAL FLANGE AND NUT REVOLUTION COUNTER VERSION-DISASSEMBLY



1. Make marks across nut (1) and pinion (11) tang; If disassembly is difficult, heat the check nut (1) of the flange (2) at 80C°.

Note: Heating is meant to loosen the setting of Loctite on the nut (1).



4. Remove the flange (2) complete with guard (7) using a puller.



5. Loosen the sealing ring (3).



6. Remove the sealing ring (**3**) and spacer (**8A**).

Note: Sealing rings (3) must be replaced each time the unit is disassembled.



- 2. Position tool (**T10**), so as to avoid pinion rotation.
- Loosen and remove the nut (1); also remove the o-ring (6).



7. Remove the pinion (11), shims and spacer.



- MAP14750
- 10. Remove the thrust block of the external bearing (14).



MAP14730

8. Refer and keep to the positions marked during disassembly.



9. Using a puller and a press, remove the inner bearing (4) from the pinion (11).



11. Insert a drift in the appropriate holes.



12. Remove the thrust block of the internal bearing (**4**) as well as the shim washers (**10**) and (**S**).



13. Remove the snap ring (15)

14. Remove the cap (**14**).

11.3 BEVEL PINION: NORMAL FLANGE AND NUT REVOLUTION COUNTER VERSION -ASSEMBLY



MAP14790

1. CALCULATING PINION CENTER DISTANCE: Using a faceplate, reset a dial indicator "DG" on a calibrated block (whose known thickness is 30 mm.). Preload the depth gauge by about 3 mm.



MAP14800

 Bring inner bearing (4), complete with thrust block, under depth gauge "DG".
 EXAMPLE: 30 - 0.55 = 29.45 = "D".

Press the thrust block centrally and carry out several measurements by rotating the thrust block.



 Check nominal dimension "I" as marked on the pinion. Add or subtract from "I" the variation indicated as "Y" to obtain the actual center distance "I". EXAMPLE: I = INT ± Y = 98-0.1=97.9mm C61 = Match part number



MAP14820

4. Calculate shims "S" for insertion under the thrust block of the inner bearing using the following formula:
S = X - (I + D) where: X = fixed dimension
I = actual pinion center distance
D = Total bearing thickness;
EXAMPLE: S = 128 - (97.9+29.45) = 0.65 mm



5. Using special tool (**T11**) partially insert the thrust block of the bearings (**4**) and shims (**10**).



 CALCULATING PINION BEARINGS ROLLING TORQUE: Introduce tool (T12) complete with bearings (4) and (14) into the main body (12); tighten by hand until a rolling torque is definitely obtained.



- 6. Connect the tension rod to the press and move the thrust block of bearings (4) and (14) into the seats.
- 7. Disconnect the press and remove the tension rod.

Note: Before starting the next stage, make sure that the thrust block has been completely inserted into its seat.



9. Introduce the tracer of a depth gauge "DDG" into either side hole of tool (**T12**). Reset the dial indicator with a preload of about 3 mm.



- 10. Remove the depth gauge and take out tool and bearing kits from the main body.
- 11. Reinstall every part, also introduce a spacer between bearings (4) and (14). Tighten the entire pack by hand.



MAP14880

12. Assemble on top of the tool (T12) and between the two bearings the shim (5) and the largest calibrated shim (**9**).



13. Measure the difference H using a dial indicator DDG. E.g. H = A - B = 2.93 mm



14. Calculate the shim S2 to be inserted. E.g. S2 = H + X = 3.01 mmwhere X = fixed value to obtain = $0.07 \div 0.08$ mm



15. Measure the difference H using a dial indicator DDG. E.g. H = A - B = 2.93 mm



16. Fit the pinion (**11**), shim "S1" (**10**) and spacer (**5**) and (**9**) in the main body (**12**)

Note: The thin shims must be placed in- between the thick ones.).

11.3.1 NORMAL FLANGE VERSION



Insert the spacer (8A).
 Note: Verify the use of the friction washers.



MAP14930

17. Heat the external bearing (14) to a temperature of about 100 C° and fit it on to the pinion (11) so as to complete the pack as shown in the figure.

Note: Lightly lubricate bearing with SAE85W90 oil.



2. Install the flange (2) onto the pinion (11) without sealing ring.



- MAP14960
- 3. Install the nut (1) without LOCTITE 270.



4. Lock the wrench (**T13**), rotate the pinion using a torque wrench, up to a minimum required torque setting of 260 Nm (191.8 ft.lb.).



6. Make marks across nut (1) and pinion (11) tang; then remove nut and flange (2)



MAP14980

5. Apply onto the pinion (1) the bar-hold and with the help of a torque meter, check the torque of the pinion (1). Torque: 80-120 Nm (59.0 - 88.5 ft.lb.).

If torque exceeds the maximum value, then the size of shim "S1" f (4) between the bearing (9) and the spacer (3) needs to be increased.

If torque does not reach the set value, increase the torque setting of the ring nut (**10**) in different stages to obtain a maximum value of 300 Nm (221.2 ft.lb.).

If torque does not reach the minimum value, then the size of shim "S1" (4) needs to be reduced.

When calculating the increase or decrease in size of shim "S1", bear in mind that a variation of shim of 0.01 mm corresponds to a variation of 60 Nm (44.2 ft. lb.) in the torque of the pinion (1).



7. Apply Arexons rubber cement to the outer surface of the new seal ring (3) and fit ring in the main body (12) using driver (T14).





- 8. Oil seal ring lips and install flange (2).
- 9. Mount o-ring (6) and apply Loctite 270 to pinion tang; tighten nut (1).



- MAP15020
- 10. Tighten the nut until the match marks made at Figure 33 line up.

11.3.2 REVOLUTION COUNTER VERSION



1. Apply Loctite 270 to the thread of the ring nut (**8**) and screw the nut onto the pinion.



2. Apply onto the pinion (**11**) the bar-hold and with the help of a torque wrench, check the torque of the pinion (**11**). Torque: 400 Nm (295.0 ft.lb.).

If torque exceeds the maximum value, then the size of shim "S1" (4) between the bearing (9) and the spacer (3) needs to be increased.

If torque does not reach the set value, increase the torque setting of the ring nut (**10**) in different stages to obtain a maximum value of 500 Nm (368.8 ft.lb.).

If torque does not reach the minimum value, then the size of shim "S1" ($\mathbf{4}$) needs to be reduced.

When calculating the increase or decrease in size of shim "S1", bear in mind that a variation of shim of 0.01 mm corresponds to a variation of 60 Nm (44.2 ft. lb.) in the torque of the pinion (1).



MAP15050

3. Using a torque meter, verify rolling torque.



 Apply Arexons rubber cement to the outer surface of the new seal ring (3) and fit ring in the main body (12) using driver (T14).



- 5. Oil seal ring lips and install flange (2).
- 6. Mount o-ring (**6**) and apply Loctite 270 to pinion tang; tighten nut (**1**).



7. Lock the wrench (**T10**), rotate the pinion using a torque wrench, up to a minimum required torque setting of 260-300 Nm (191- 221 ft.lb.)

This Page Intentionally Left Blank

12.1 EXPLODED VIEW



MAP15140

12.2 RING AND PINION ADJUSTING: STEP FOR PRELOADED DIFFERENTIAL -INSTALL AND ADJUST



1. Choose a pack of shims (**Sb**) with an initial value of about 0.37mm to place under the brake side bearings cup.



2. Assemble the shims (**Sb**), the cup (**1**) and level.



MAP15170

3. Remove the snap ring.



4. Remove cap.





MAP15190

5. Insert the complete differential.

Note: Attention do not damage the sealing surface of the oring.



6. Choose a pack of shims (**Sc**) with an initial value of about 0.84 mm to place under the ring gear side bearings cup.



- MAP15210
- 8. Always replace the o-ring of the arm.



9. Assemble the arm and tighten temporarily with a torque wrench setting of 128 Nm (94 ft.lb) at least 6 screws equally distributed.



7. Assemble the shims (**Sc**), the (**1**) cup and level.



 Apply torque meter (TM) to pinion nut and check that torque will increase by 40-60 Ncm (2.9 - 4.4 ft. lb) as a result of differential bearing preload. Example: pinion torque: 80-120 Ncm (5.9 - 8.8 ft.lb) Pinion + differential torque: 120-180 Ncm (8.8-4.4 - 132.7 ft.lb)



MAP15250

11. Introduce a depth gauge with rotary key through the rear cap hole. Position depth gauge on the center of one of the crown teeth, preset it to 1 mm and reset it to zero. Manually move the crown in both directions to check the existing clearance between pinion and crown. Gap= 0.13-0.20 mm

In order to increase the gap while keeping the load on the bearing unchanged, take off shims from the ring gear side and insert them on the opposite side. In order to decrease the gap, do the opposite.



MAP15260

12. Assemble rubber cap and snap ring.

13.1 EXPLODED VIEW



MAP15270

13.2 SWINGING SUPPORT - DISASSEMBLY



MAP15280

1. Make marks across nut and pinion tang; If disassembly is difficult, heat the check nut of the flange at 80C°.

Note: Heating is meant to loosen the setting of Loctite on the nut.



2. Loosen the nut.







4. Remove the flange complete with guard using a puller.



MAP15320

5. Remove the swinging support (4).



6. Remove the swinging support (**4**) on the side opposite the drive.



7. Position the swinging support (**4**) under a press and remove the complete bushing (**3**).

13.3 SWINGING SUPPORT - ASSEMBLY



- MAP15350
- 8. If the bushing (3) is worn and needs replacing, write down the assembly side of the connection notch "A".





9. Position the swinging support (**4**) under a press and insert the complete bushing (**3**).



11. Install the swinging support (4) on the side opposite the drive.



- 12. Fit the flange and fasten it.
- 13. For keying the flange, use a plastic hammer if necessary.





- 14. Install flange.
- 15. Mount o-ring and apply Loctite 270 to pinion tang; tighten nut.



- 10. Install the swinging support (4).
- **Note:** Check that it is properly oriented.



1. Tighten the nut until the marks line up.

This Page Intentionally Left Blank

14.1 EXPLODED VIEW



MAP15420

14.2 PLANETARY REDUCTION: 1:4, 23 -DISASSEMBLY



1. Remove snap ring (1).



3. Positioning the planetary wheel gear (**3**) in center of the spider cover and remove, complete with outer shim washer (**6**).



MAP15440

2. Using a screw M6 remove all bolts (2).



4. Remove the inner shim washer (6).

14.3 PLANETARY REDUCTION: 1:4, 23 -ASSEMBLY



5. Install the shim washer (**6**).



- MAP15480
- 6. Install planetary gears complete with roller bearing (3).



 Check the concentricity of the planetary gear, the seat and friction washers. Using a screw M6 install the pin (2).



9. Carefully check that pin is completely inserted and install the snap rings (1).



Install the others friction washers.
 Note: Two friction washers for every planetary gear.

31200451

This Page Intentionally Left Blank

Section 15 Brake: Incoming Disc Brake

15.1 EXPLODED VIEW



MAP15520

15.2 BRAKE: INCOMING DISC BRAKE -DISASSEMBLY

DANGER

Before working on brakes, when the axle is installed on the vehicle, follow all safety instructions in the Original Equipment Manufacturer (OEM) manual that came with the vehicle.



MAP15530

1. Remove nuts (**2**) and washers (**3**).



MAP15550

3. Remove the disc (5).



4. Loosen and remove the nut (1) and the o-ring (4).

Note: If necessary, apply a lever to the flange (**6**), so as to prevent pinion rotation.



5. Remove the flange (6) complete with dust seal ring (10).



MAP15540

2. Remove screws (14) and caliper unit (13).

Note: Access to screws (**14**) is gained through the holes on the disc (**5**).



6. Remove the securing screws (9) from brake support (11).



8. Remove the seal ring (12).



- MAP15590
- 7. Remove brake support (**11**).



- 9. Remove the snap ring (8) from its seat around the screws (7).
- 10. Remove the screws (7).



MAP15620

11. Remove the dust seal ring (10) by means of a puller.

15.3 BRAKE: INCOMING DISC BRAKE -ASSEMBLY



MAP15630

1. Lubricate the outer part of the seal (12) and insert it into the brake support (11) using tool (T15).

Note: Carefully check assembly direction.



2. Insert the screws (**7**) and hold them in position with the snap ring (**8**).

Note: Make sure that the ring is properly set in its seat.



3. Lubricate the coupling surfaces and position brake support (11).



 Apply Loctite 270 to the screws (9) and tighten using the criss-cross method. Torque wrench setting: 49 - 51 Nm (36-38 ft.lb.)



- Install parts in the following sequence: flange (6), o-ring (4) and nut (1).
- 6. Spread Loctite 242 on the threaded portion of the pinion.



7. Engage the stop rod and tighten the nut (**9**). Torque wrench setting: 260 - 300 Nm (192-221 ft.lb.)



MAP15690

8. Install disc (5) and keep it into position with screws (7).



Install the caliper unit (13) and block with screws (14) coated with Loctite 242.
 Tighten using a torque wrench to a tightening torque of 120 -123 Nm (88-90 ft.lb.)



10. Tighten using a torque wrench to a tightening torque of 40 Nm (29 ft.lb.).

15.4 CHECKING WEAR AND REPLACING THE BRAKING PADS





MAP15740

13. Remove the brake pads.

.

11. Remove the safety cotter pin.





MAP15730

12. Using a pin driver remove the guide pin.
Section 16 Brake: Service and Mechanical Parking Brake

16.1 EXPLODED VIEW



MAP15750

16.2 BRAKE: INCOMING DISC BRAKE -DISASSEMBLY

DANGER

Before working on brakes, when the axle is installed on the vehicle, follow all safety instructions in the Original Equipment Manufacturer (OEM) manual that came with the vehicle



MAP15760

1. Sling the arm to be removed and connect it to a hoist. Remove screws.



3. Remove the snap ring of the brake stack.



4. Remove the brake discs (1) and (2) one after the other.

Note: If they are not going to be replaced, do not mix up the sequence.



5. Mark the assembly position.



2. Remove the arm and lay it down vertically.



MAP15810

6. Remove intermediate disc (7).



7. Mark the assembly position.



- 8. Remove the springs (**21**).



9. Insert the screws of the puller (M12) into the tap holes of the negative brake (**22**) and remove the pistons of the brake.



MAP15850

10. Pull out brake piston assembly module.



11. Remove the breather (**47**).



12. Remove the locking screw of the lever brake.



- MAP15900
- 15. Remove the screw (39) of the thrust bushing (40).



MAP15880

13. Remove the locking screw (**38**) lever brake complete with conical washer (**37**).



16. Remove the thrust bushing (**40**) complete with the o-rings.



14. Mark the lever (36) position.



- MAP15920
- 17. Remove the screw (23) of the thrust bushing.



18. With a plastic hammer, hammer on the internal lever (27).



19. Remove the thrust bushing (24) complete the o-rings (25).



20. Remove the internal lever complete with bearings.



21. Place the lever (27) under a press and remove the bearings (43).



22. Place the lever under a press and remove the bearing (26).



MAP15980

23. Applying pressure to the hole, remove the hydraulic piston (**9**).



24. Remove the snap ring (14) from the intermediate disc (7).



25. Remove coupling (3) and washers (6).

Note: Build a stack of washers and check the measure.



26. Using a puller, preload the spring (16).



- MAP160.
- 27. Remove the snap ring (15).





MAP16030

28. Remove the fixing ball (4).



29. Remove washer (5) and spring (16).

16.3 **BRAKE: INCOMING DISC BRAKE -**ASSEMBLY



30. Insert spring (16) and washer (5) onto the hydraulic block coupling (3).



32. Shift the cut of the snap ring (15) according to the ball (4). The o-rings always have to be assembled from the pressure facing side.





31. Preload the spring by using a puller acting on the washer. Insert the snap ring (15) and the fixing ball (4).



33. Using a surface plate, positioning disc (7), the coupling (3) and brake discs.



34. Measure distance B between the sleeve and first disk brake. Es: 8.6mm



35. Zero the depth gage from the plane of the splined coupling to the surface of the brake discs.



36. Measure distance A between the spline and bearing.



- 37. Calculation of shims S to be inserted. S = (B+G)-(A+R)G= brake disc gap= 0.1mm R = fi x gap = 1.4mm
 - S = (8.6+1.4) (8+0.1) = 1.9mm





- 38. Insert and bring into position shims S (6) and coupling into the brake module.
- 39. Install the intermediary disk (7) on sleeve (3) starting with the snap ring (15).





MAP16170

43. Insert the service brake piston (**9**) hammering alternately with a plastic hammer.



- MAP16150
- 41. Install last disk brake of metallic material.

40. Install the first friction disc.



44. Insert the lever brake (27).



45. Install the thrust bushing (24) complete with new o-ring (25).



42. Install the snap ring of brake discs.



46. Insert screws (23).



47. Tighten the screws to 23.8 - 26.2 Nm (18-19 ft.lb.).



49. Insert screws (**39**). Tighten the screws to 23.8 - 26.2 Nm (18-19 ft.lb)



- MAP16240
- 50. Insert the springs (21) in the piston.



48. Insert the thrust bushing (**24**).



- 51. Install the intermediate brake disk (7) on the piston.
- 52. Verify assembly is in the correct position.



MAP16260





- 56. Install the brake lever (36).
- 57. Note the position previously marked.



- MAP16270
- 54. Exchange and lubricate the o-ring and insert the arm to the box.



58. Lock the lever (36) with the screw (37) and washer (38).



55. Insert the screws and tighten them alternately.



MAP16310

59. Tighten screws to a torque wrench setting: 10 Nm (7.3 ft.lb.).



MAP16320

60. Applying light pressure to bring the lever brake to the piston, without preloading the inside spring. With the register screw (**33**) to draw near to the lever (**36**) leaving a gap of 0.1 - 0.2 mm.



MANDATORY PROCEDURE:

Check brake piston gap, see Brake Piston Gap Check.

This Page Intentionally Left Blank

Section 17 Brake: Parking Brake and Differential Hydraulic 100%

17.1 EXPLODED VIEW



MAP16330

17.2 BRAKE: INCOMING DISC BRAKE-DISASSEMBLY

DANGER

Before working on brakes, when the axle is installed on the vehicle, follow all safety instructions in the Original Equipment Manufacturer (OEM) manual that came with the vehicle.



MAP16340

1. Remove the spacer (1).



3. Mark before disassembly the brake lever, and remove.



4. Remove the cap screw of the thrust bushing.



MAP16380

5. Remove the thrust bushing complete with the o-rings.



MAP16350

2. Remove the brake lever locking screw complete with the conical washer.





6. Remove the cap screw of the thrust bushing.



MAP16400

7. With a plastic hammer, hammer on the internal lever (10).



MAP16420

9. Remove the internal lever complete with bearings.



10. Applying pressure to the hole and remove the piston differential block.



8. Remove the thrust bushing complete with the o-rings.



MAP16440

11. Piston differential block.



12. Remove the plug.



MAP16460

13. Using an extractor, remove the plug (4).



14. Remove o-ring (**18**) from the plug (**4**).

Note: The o-ring (**18**) must be replaced each time the unit is disassembled.

17.3 **BRAKE: INCOMING DISC BRAKE-**ASSEMBLY



MAP16480

- 1. Fit o-rings (18) and onto the plug (4).
- 2. Lubricate the plug and the o-rings and install the unit into the arm.



3. Using a plastic hammer, press the plug (18) into the arm.



- 4. Fit o-rings (3) and (20) onto the piston (21).
- 5. Lubricate the piston and the o-rings and install the unit into the cylinder.



6. Before installing, lubricate the piston and o-ring.



7. Using a plastic hammer, press the piston into the arm.



MAP16530

8. Install the lever (10) complete with bearings (11) and (12).



MAP16540

9. Insert the spacer (1).



MANDATORY PROCEDURE: Check brake piston gap, see Brake Piston Gap Check.

Section 18 Differential With Block to Spheres 100% (Old Version)

18.1 EXPLODED VIEW



MAP16550

18.2 **DIFFERENTIAL WITH BLOCK TO SPHERES** 100% (OLD VERSION) - DISASSEMBLY



MAP16560

1. Sling the arm to be removed and connect it to a hoist. Loosen and remove screws and nuts.



MAP16570

2. Remove arm together with brakes and axle shafts; lay down the arm vertically.



- MAP16580
- 3. Extract the whole differential unit.



4. Extract the bearing (24) from the differential carrier.



MAP16600

5. Remove 4 cap screws of the coupling of the cover. *Note: Mark the position of the coupling.*



MAP16610

6. Hold down the spring to avoid the coupling from jumping off, then remove the remaining two screws.



7. Remove the coupling (17) and the spring (16).



8. Remove the cover (**18**) from the blocking side of the differential unit.



MAP 10040

9. Remove the cover (**18**) from the blocking side of the differential unit.



10. Remove the shim washer (**15**) and the planetary gear (**14**).



MAP16660

11. Remove the blocking balls (3).



12. Remove the fixing ball (4) from the differential box by using a magnetic tool.



15. Separate the ring gear (**33**) from the differential box (**2**).



MAP16680

13. Extract the bearing (1) partially and using a puller, remove the bearing (1) of the ring gear side (33).



14. Remove the ring gear fixing screws (34).



16. Replace the cap screws every disassembly.



MAP16720

17. Use a correctly sized pin driver to remove the pins.



18. Remove the fixing pins (10) and (29) of the differential cross bolts.



21. Remove the two halves of the cross bolts (9) and (28) with the help of a drift.



- MAP16740
- 19. With a pin driver push the two bolts (9) and (28) to the outside.



20. Remove the bolts with the help of a drift (12).



22. Remove the cross bolts (32).



23. Remove the satellite gears and the spherical washers.



24. Remove the planetary gear (8) with washer.



27. With pressurized air push out the piston (1) together until the head of caps crews (2).



- MAP16800
- 25. Remove the circuit breaker of the hydraulic block.



28. Remove piston.



26. Loosen the two caps crews (2) with 4 turns.

18.3 DIFFERENTIAL WITH BLOCK TO SPHERES 100% (OLD VERSION) - ASSEMBLY



MAP16840

1. Insert the washer (**5**) and the planetary gear (**6**) on the ring gear side.



2. Insert the satellite gears (27) and (8) with the spherical washers (26) and (7) and the bolts (28) and (9) to keep them in position.



3. Insert the satellite gears (31) and (35) with the spherical washers (30) and (11) and the bolt (12).



4. Insert the cross bolt (**32**) in the correct position.



5. Insert the bolts in their position.



6. Bring the pin holes in line with the help of a pin driver.



MAP16920

9. Tighten the cap screws (34) of the ring gear.



7. Insert pins to end of stroke.



MAP16930

 Tighten the cap screws of the ring gear using the crisscross method. Torque wrench setting: 78 - 86 Nm (57-63 ft.lb.)



11. Insert planetary gear (**14**) (together with washer). Insert the fixing ball (**15**) of the coupling.



MAP16910

8. Install the ring gear (**33**).



- 12. Grease and insert balls (3).
- 13. Install the cover (18) of the blocking side.



14. Load the spring and the coupling and insert screws.



MAP16980

16. Heat up the roller bearings to 100° C and insert onto the differential.



17. Press on the roller bearing.



 Place the piston (1) in position inside the box and tighten screw (2) partially. Pay attention to the correct position.



15. Tighten to torque wrench setting of 26.2 Nm (19 ft.lb.).



19. Hammering lightly on alterning points bring the piston to the end of stroke. Tighten with a torque wrench setting of 30 Nm

(22 ft.lb.).

Section 19 Differential With Block to Spheres 100% (Last Version)

19.1 EXPLODED VIEW



MAP17020

19.2 **DIFFERENTIAL WITH BLOCK TO SPHERES** 100% (LAST VERSION)- DISASSEMBLY



MAP17030

1. If the bearing has to be replaced, remove two retaining screws (24) from the crown and, using an extractor, remove the crown bearing (1).



2. If the bearing needs replacing, extract the bearing (1) from the differential carrier (2).



MAP17050

- 3. Remove 3 cap screws (18) of the coupling (16) of the cover.
- 4. Verify for the position of the slot that fits the coupling (16) to the fixing ball (4).



5. Pull off the coupling (16) and the spring (15).



MAP17070

6. Remove the blocking balls (3).



MAP17080

- 7. Remove cap screws (24) of the ring gear (13); replace each time when removed.
- 8. Extract the ring gear (13).



MAP17090

9. Remove the shim washer (5) and the planetary gear (6).



11. Remove the bolts (10) with the help of a drift.



12. Remove the two half bolts (9), spherical washers (7), and satellite gears (8).



10. Remove the three spider blocking pins (11) by using a pin driver. Move the two opposite mounted short bolts (9) to the outside of the box using the same pin driver.



MAP17130

13. Remove the cross bolts (14).



- 14. Remove the planetary gear (**12**).
- 15. Remove the shim washer (5).

19.3 DIFFERENTIAL WITH BLOCK TO SPHERES 100% (LAST VERSION)- ASSEMBLY



MAP17150

1. Lubricate and insert washer (5) and planetary gear (12).



MAP17160

2. Partially insert the long bolt (10), satellite gears (8) and spherical washers (7).



MAP17170

3. Place the satellite gear (8) and the spherical washer (7) in the box and fix with a fake pin of suitable diameter.



4. Insert the two half bolts (9), spherical washers (7) and satellite gears (8).



5. Insert the cross bolt (**14**) in the correct position.



6. Satellite gears (8), spherical washers (7) and completely insert the long bolt (10).



MAP17220

- 8. Insert planetary gear wheel (6).
- 9. Position the shim washer (5) on the crown (13).

Note: In order to hold the shim washer (5) in position, apply grease to it.



MAP17210

7. Bring the pin holes in line with the help of a pin-driver. Insert pins (**11**) to end of stroke.



MAP17230

10. Install the ring gear (13).


MAP17240

11. Tighten the cap screws of the ring gear using the crisscross method.

Torque wrench setting: 78 - 86 Nm (58-63 ft.lb.).



- 14. Place the differential carrier under a press.
- 15. Load the spring (15) and the coupling (16) and insert screws (18).



- 12. Grease and insert balls (3).



16. Mount the ring gear (13) and fasten it to the differential box with screws (24).



13. Verify the position of the slot that fits the coupling (16) to the fixing ball (4).





17. Heat the bearings (1) at 100° and insert them on the differential.

Section 20 Normal Differential (Old Version)

20.1 EXPLODED VIEW



MAP17300

20.2 NORMAL DIFFERENTIAL (OLD VERSION) - DISASSEMBLY



MAP17310

1. Extract the bearing (35) from the differential carrier (14).



MAP17320

2. Remove the ring gear cap screws (13).



3. Separate the ring gear (10) from the differential box (14).



MAP17340

4. Extract the bearing (12) partially and using a puller, remove the bearing (12) of the ring gear side (10).



5. Remove the cover (34) from the blocking side of the differential unit.



MAP17360

6. Remove the shim washer (**33**) and the planetary gear (**32**).



7. Remove the fixing pins (**20**), (**24**) and (**31**) of the differential cross bolts (**25**).



8. With a pin driver push the two bolts (**19**) and (**26**) to the outside.



9. Remove the bolts with the help of a drift (23).



MAP17400

10. Remove the two halves of the cross bolts (19) and (26) with the help of a drift.



11. Remove the cross bolts (25).



12. Remove the gear wheels (28), (21), (29) and (18) and the spherical washers (17), (30), (22) and (27).



13. Remove the shim washer (**15**) and the planetary gear (**16**).

20.3 NORMAL DIFFERENTIAL (OLD VERSION) - ASSEMBLY



MAP17440

1. Insert the washer (**15**) and the planetary gear (**16**) on the ring gear side.



2. Insert the satellite gear (**18**) with the spherical washer (**17**) and the bolt (**19**) to keep them in position.



- Insert the satellite gear (29) with the spherical washer
 (30) and the bolt (26) to keep them in position.



4. Insert the satellite gears (28) and (21) with the spherical washers (27) and (22) and the bolt (26) and (19).



5. Insert the cross bolt (25) in the correct position.



- MAP17510
- 8. Insert pins (20), (24) and (31) to end of stroke.





6. Insert the bolts in their position.



9. Insert planetary gear (32) together with washer (33).





7. Bring the pin holes in line with the help of a pin driver.



MAP17530

10. Coat the nuts (37) with Loctite 270 and tighten.



MAP17540

11. Torque wrench setting: 58 Nm (42 ft.lb.).



MAP17550

- 12. Install the ring gear (**10**).
- 13. Tighten the cap screws (13).

Note: Use LOCTITE 270 on screws not treated with DRILOC.



MAP17560

14. Tighten the screws of the ring gear using the criss-cross method 76-86 N-m (56-63 ft.lb.)



15. Heat up the roll bearings (**12**) and (**35**) to 100°C and insert it onto the differential.

This Page Intentionally Left Blank

Section 21 Normal Differential (Last Version)

21.1 EXPLODED VIEW



MAP17580

21.2 NORMAL DIFFERENTIAL (LAST VERSION) - DISASSEMBLY



MAP17590

1. Connect an external pump to the union piece "P1" of the negative brake and introduce a pressure of 15 ± 30 bar to eliminate the pressure of the Belleville washers.



2. Loosen the unlocking screws (**30**) and remove both U-shaped spacers (**32**).



MAP17610

3. Insert block screws to end stroke and release pressure.



- 4. Remove the brake side arm and the brake discs pack.
- 5. Sling the arm to be removed and connect it to a hoist. Remove screws of the ring gear side arm.
- 6. Remove the arm together with the pack of the braking disks. Place the arm on a bench.



- MAP17630
- 7. Remove the screws from the middle cover.
- 31200451



MAP17640

8. Insert a screwdriver in the opposing slots then force and remove the middle cover.



11. If the bearing needs replacing, extract the bearing (13) from the differential carrier.



9. If the bearings need replacing (13), extract the external thrust blocks of the bearings (13) from middle cover and central body.



12. Remove cap screws (**24**) of the ring gear (**11**); exchange each time when removed. with the help of a drift.



MAP17660



MAP17690

13. Extract the ring gear (**11**).

10. Pull out the differential (14).







17. Move the two opposite mounted short bolts (19) to the outside of the box using the same pin driver.



- 15. Remove the planetary gear (16).



18. Drive out the long bolt (21) and pull out the spider (22) from the center.



MAP17740

19. Remove the two half bolts (19), spherical washers and satellite gears.



16. Remove the three spider blocking pins (20) by using a pin driver



20. Remove long bolt, spherical washers (18) and satellite gears (17).



23. Remove the shim washer (15)



MAP17760

21. Remove the spider (22) from the center.



22. Remove the planetary gear (16).

21.3 NORMAL DIFFERENTIAL (LAST VERSION) - ASSEMBLY



1. Lubricate and insert washer (**15**) and planetary gear (**16**).



2. Partially insert the long bolt (21), satellite gears (17) and spherical washers (21).



3. Insert the two half bolts (19), spherical washers (18) and satellite gears (17).



 Insert spider (22) and completely insert the long bolt (21).



MAP17830

5. Insert completely the bolts (19).



- 6. Center the pin holes and insert the 3V pins (20).
- **Note:** Check the free rotation of the satellite wheels on the bolts.



-
- 7. Lubricate planetary gear (16).





10. Position the crown (**11**) on the differential carrier and tighten cap screws (**24**) applied with Loctite 270.



MAP17860



11. Tighten screws with a torque wrench: see table

Note: Always use new screws to attach the ring gear. In case the screws are not thread locking pretreated, use Loctite **270**.

8. Insert planetary gear (16).



MAP17890

- 12. Assemble the bearing (13).
- *Note:* Heat the bearing to 100 °C before assembling.

Note: Thoroughly check the state of the o-ring and make sure that the cover is fitted with the oil discharge in the lower position.



MAP17920





13. If the bearings are replaced, insert the external thrust blocks in the middle cover and in the central body.



14. Position the differential unit in the central body with the help of a bar and fit the middle cover.



MAP17930

- 16. Check that the positioning of the sealing ring on the arm is intact; install the complete arm.
- 17. Lock it into position using two facing screws and washers.

Section 22 Limited Slip Differential Unit 45% (Old Version)

22.1 EXPLODED VIEW



MAP17940

22.2 **LIMITED SLIP DIFFERENTIAL UNIT 45%** (OLD VERSION) - DISASSEMBLY



MAP17950

1. Extract the bearing (25) from the differential carrier.



MAP17960

2. Remove the ring gear cap screws (2).



3. Separate the ring gear (1) from the differential (4).



MAP17980

4. Extract the bearing (3) partially and using a puller, remove the bearing (3) of the ring gear side (1).



5. Remove the screws (26) jointing the differential unit.



6. Remove the differential cover (24).





7. Remove the bushing (22).



8. Remove the planetary gear (**19**) and the whole friction unit (**20**), (**27**) and (**21**).



9. Replace the whole pack to 17.10 mm.



10. Remove the fixing pins (14), (17) and (28) of the differential cross bolts (10).



11. With a pin driver push the two bolts (**31**) and (**13**) to the outside.



12. Remove the bolts with the help of a drift (18).



13. Remove the two halves of the cross bolts (13) and (31) with the help of a drift.



 Remove the planetary gear (9) and limited slip package (8), (7) and (34).



14. Remove the cross bolts (10).



17. Remove the bushing (6).



15. Remove the satellite gears (11), (29), (15) and (33) and the spherical washers (32), (16), (30) and (12).

22.3 LIMITED SLIP DIFFERENTIAL UNIT 45% (OLD VERSION) - ASSEMBLY



MAP18120

1. L.S. differential components.



MAP18130

2. Align disks (8), (7) and (34) and bushing (6) on the planetary gear (9) in the correct position.



MAP18140

3. Insert the planetary gear (9) into the differential housing (4).



4. Check for correct position.



5. Insert the satellite gears (11) and (29) with the spherical washers (12) and (30) and the bolts (13) and (31) to keep them in position.



6. Insert the satellite gears (11) and (29) with the spherical washers (12) and (30) and the bolts (13) and (31) to keep them in position.



9. Insert the bolts in their position (17), (13) and (31).





7. Insert the satellite gears (33) and (15) with the spherical washers (32) and (16) and the bolt (17).



10. Bring the pin holes in line with the help of a pin driver.





11. Insert pins to end of stroke (14), (17) and (28).



8. Insert the cross bolt (10) in the correct position.



12. Insert the planetary gear (19) and the whole friction unit (20), (27) and (21).



13. Install the bushing (22).



14. Install the differential cover (24)



15. Apply Loctite 270 to the cap screws (26).



16. Torque wrench setting: 52 - 58 Nm (38-42 ft.lb)



17. Tighten the cap screws (**2**) of the ring gear using the criss-cross method 78-86 Nm. (57-63 ft.lb.).

Note: Use LOCTITE 270 on screws not treated with DRILOC.



18. Heat up the roller bearings (25) and (3) to 100°C and insert onto the differential.

Section 23 Limited Slip Differential Unit 45% (Last Version)

23.1 EXPLODED VIEW



MAP18300

23.2 **LIMITED SLIP DIFFERENTIAL UNIT 45%** (LAST VERSION) - DISASSEMBLY



MAP18310

1. If the bearing (12) has to be replaced, remove two retaining screws (10) from the crown and, using an extractor, remove the crown bearing (9).



MAP18320

2. If the bearing need replacing, extract the bearing (13) from the differential carrier.



MAP18330

- 3. Remove cap screws (14) of the ring gear (11); replace each time when removed.
- 4. Extract the ring gear (11).
- 5. Remove the shim washer (16).



MAP18340

6. Remove the planetary gear (17) and the whole friction assembly.





Remove the three spider blocking pins (21) by using a pin driver. Move the two opposite mounted short bolts (18) to the outside of the box using the same pin driver.



9. Remove the two half bolts (18), spherical washers (19) and satellite gears (20).



MAP18360

8. Remove the bolts (22) with the help of a drift.



10. Remove the cross bolts (23).



MAP18390

11. Remove the planetary gear (**17**) and the whole friction assembly.

23.3 **LIMITED SLIP DIFFERENTIAL UNIT 45%** (LAST VERSION) - ASSEMBLY



MAP18460

1. As to ring (24), the side without notches must face outwards.



2. 35% FRICTION UNIT COMPOSITION: Friction discs with increased shim (24), steel discs (25) and friction discs (26) alternated, and end disc (25).



MAP18480

3. Place a friction unit and planetary gear (17) into the half-box (15).



4. Partially insert the long bolt (22), satellite wheels (20) and spherical washers (19).



MAP18500

 Place the satellite gear (20) and the spherical washer (19) in the box and fix with a fake pin of suitable diameter.



8. Satellite gears (**20**), spherical washers (**19**) and completely insert the long bolt (**22**).



MAP18510

6. Insert the two half bolts (18), spherical washers (19) and satellite gears (20).



- 9. Bring the pin holes in line with the help of a pin driver.
- 10. Insert pins (**21**) to end of stroke.



MAP18400

7. Insert the cross bolt (23) in the correct position.



MAP18430

11. As to ring (**24**), the side without notches must face outwards.



12. 35% FRICTION UNIT COMPOSITION: Friction discs with increased shim (24), steel discs (25) and friction discs (26) alternated, and end disc (25).



- MAP18520
- 14. Position the shim washer (16) on the crown (11).
- 15. Install the ring gear (**11**).

Note: In order to hold the shim washer (**16**) in position, apply grease to it.



MAP18450

13. Place a friction unit and planetary gear (17) into the half-box (15).



16. Mount the gear ring (11) and fasten it to the differential box with screws (14).





17. Heat the bearings (**13**) at 100° and insert them on the differential.

This Page Intentionally Left Blank

Section 24 Preloaded Limited Slip Differential Unit 45% Unit (Old Version)

24.1 EXPLODED VIEW



MAP18550

24.2 PRELOADED LIMITED SLIP **DIFFERENTIAL UNIT 45% UNIT (OLD VERSION) - DISASSEMBLY**





- 1. Remove the brake side arm and the brake discs pack.
- 2. Sling the arm to be removed and connect it to a hoist. Remove screws of the ring gear side arm.



3. Place the arm on a bench.



4. Position the differential gear sideways into the recess in order to be able to pull it out.



5. Pull out the differential.



6. Remove the snap ring (23) that secures the thrust bearing.


7. Remove the snap ring (23) and thrust bearing (24).



- MAP 1004
- 10. Remove the brake side planetary gear (18)



8. Remove the hydraulic block discs (21) and (25) one after the other.



11. Remove the snap ring (**33**) out of its seat by moving it sideways.



9. Remove the snap ring (20) that secures the planetary gear.



12. Using a puller, extract the bearing (**35**) and the washer (**34**).



13. Remove completely the bearing (**35**), washer (**34**) and snap ring (**33**).



16. Remove the tapered roller bearing (1) of the ring gear side, using two levers.



- MAP18680
- 14. Remove the cap screws (**3**) of crown. Replace the screws (**3**) at each reassembly.



- MAP18710
- 17. Remove the three spider blocking pins (13), (16) and a (27) using a pin driver.



Move the two opposite mounted short bolts (12) and
 (30) to the outside of the box using the same pin driver.



15. Extract the ring gear (34)



19. Drive out the long bolt (**17**) and pull out the spider (**33**) from the center.



Do not change the position of the friction disks.



22. Remove the half shaft bushing (5).



20. Remove the planetary gear (9).



21. Remove the limited slip discs friction (6)(7)(8).

24.3 PRELOADED LIMITED SLIP DIFFERENTIAL UNIT 45% UNIT (OLD VERSION) - DISASSEMBLY



- MAP18770
- 1. Install the half shaft bushing (**5**).



2. Insert in the body of the differential unit any required shims and the friction disks (6), (7) and (8)





4. Install the planetary gears (10), (28) and spherical washers (11) and (29) onto the shafts (12) and (30).



5. Insert spider (**33**) and partially insert the long bolt (**17**).



 Satellite gears (32) and (14), spherical washers (15) and (31) and completely insert the long bolt (17).

3. Install the planetary gear (9).



7. Insert completely the half bolts (**30**) and (**12**).



8. Center the pin holes and insert the 3 pins (13), (16) and (27).

Note: Check the free rotation of the satellite wheels on the bolts.



9. Insert the planetary wheel (18) together with the centering sleeve (26).

Note: The centering sleeve must have the fixing ball (19) assembled.



- 10. Insert snap ring (20) of the planetary wheel (18).



MAP18870

11. Insert and substitute, if necessary, the discs of the differential lock.



12. .Insert thrust (24) bearing and snap ring (23).



13. Insert ring gear (34).



14. Insert the screws (**3**) and tighten to a torque wrench setting of 78-86 Nm (57-63 ft.lb.).

Note: Always use new screws to fix the ring gear. In case the screws are not thread locking pretreated, use Loctite 270.



15. Assemble the bearing (1)*Note:* Heat the bearing to 100 °C before assembling.



16. Assemble the snap ring (33) in its seat.



MAP18930

17. Assemble shim (34) and bearing (35).

Note: Heat the bearing as well as the shim to 100 °C before assembling.

This Page Intentionally Left Blank

Section 25 Preloaded Limited Slip Differential Unit 45%(Intermediate Version)

25.1 EXPLODED VIEW



MAP18940

25.2 PRELOADED LIMITED SLIP **DIFFERENTIAL UNIT45%** (INTERMEDIATE VERSION) -DISASSEMBLY



MAP

1. Remove the brake side arm and the brake discs pack. Sling the arm to be removed and connect it to a hoist. Remove screws of the ring gear side arm



MAP18960

2. Place the arm on a bench.



3. Position the differential gear sideways into the recess in order to be able to pull it out.



4. Pull out the differential.



MAP18990

5. Remove the snap ring (33) out of its seat by moving it sideways.



Using a puller, extract the bearing (35) and the washer (34).



7. Remove completely bearing (**35**), washer (**34**) and snap ring (**33**).



MAP19030

9. Extract the ring gear (**34**).



10. Remove the tapered roller bearing (1) of the ring gear side, using two levers.



- 11. Remove the snap ring (23) that secures the thrust bearing.
- Переод
 Энание

 МАР19020
- Remove the cap screws (3) of crown. Renew the screws
 (3) at each reassembly.



12. Remove the thrust block (22).



13. Remove the thrust bearing (22).

14. Remove the thrust block (22).



15. Remove the hydraulic block discs (21) and (25) one after the other.



16. Remove the snap ring (20) that secures the planetary gear.



- 17. Remove the brake side planetary gear (18).





Remove the three spider blocking pins (13), (16) and (27) using a pin driver.



19. Move the two opposite mounted short bolts (12) and (30) to the outside of the box using the same pin driver.



20. Drive out the long bolt (17) and pull out the spider (33) from the center.



21. Remove long bolt (17), spherical washers (11) and (29).



22. Remove the planetary gear (9).



23. Remove the limited slip friction disks (6), (7) and (8).



MAP19180

24. Remove the half shaft bushing (5).

25.3 PRELOADED LIMITED SLIP **DIFFERENTIAL UNIT** 45% (INTERMEDIATE VERSION) -ASSEMBLY



MAP19190

1. Install the half shaft bushing (5).



2. Insert in the body of the differential unit any required shims and the friction disks (6), (7) and (8).



3. Install the planetary gear (9).



4. Install the planetary gears (10) and (28) and spherical washers (11) and (29) onto the shafts (12) and (30).



MAP19230

5. Insert spider (33) and partially insert the long bolt (17).



 Satellite gears (32) and (14), spherical washers (15) and (31) and completely insert the long bolt (17).



7. Insert completely the half bolts (30) and (12).



Center the pin holes and insert the **3** pins (**13**), (**16**) and (**27**).

Note: Check the free rotation of the satellite wheels on the bolts.



9. Insert the planetary wheel (**18**) together with the centering sleeve (**26**).

Note: The centering sleeve must have the fixing ball (**19**) assembled.



10. Insert snap ring (20) of the planetary wheel (18).

First and last disc have to be of steel material.



MAP19290

11. Insert and substitute, if necessary, the discs of the differential lock.



MAP19300

12. Install the thrust block with maximum internal diameter.



MAP19310

13. Position the bearing (**22**) in the differential unit.



14. Install the thrust block with minimum internal diameter.



15. Positioning the snap ring (23).

Note: Make sure that the ring is properly set in its seat.

This Page Intentionally Left Blank

Section 26 Preloaded Limited Slip Differential Unit 45%(Last Version)

26.1 EXPLODED VIEW



MAP19340

26.2 PRELOADED LIMITED SLIP DIFFERENTIAL UNIT 45%(LAST VERSION) - DISASSEMBLY



 If the bearing (12) has to be replaced, remove two retaining screws (10) from the crown and, using an extractor, remove the crown bearing (9).



2. If the bearing needs replacing, extract the bearing (**28**) from the differential carrier.



MAP19370

3. Remove the snap ring (27).



- 4. Remove the thrust block (**26**).
- 5. Remove the thrust bearing (**26**).
- 6. Remove the thrust block (**26**).



MAP19390

7. Remove the hydraulic block discs (**24** and **25**) one after the other.



- 8. Remove cap screws (**10**) of the ring gear (**9**); Replace each time when removed.
- 9. Extract the ring gear (**9**).
- 10. Remove the shim washer (14).



MAP19410

11. Remove the planetary gear (**15**) and the whole friction assembly concerned.



MAP19420

12. Remove the three spider blocking pins (19) by using a pin driver. Move the two opposite mounted short bolts (18) to the outside of the box using the same pin driver.



MAP19430

13. Remove the bolts with the help of a drift (20).



MAP19440

14. Remove the two half bolts (18), spherical washers (17) and satellite gears (16).



15. Remove the cross bolts (21)



16. Remove the planetary gear (22) with washer (23).

26.3 PRELOADED LIMITED SLIP **DIFFERENTIAL UNIT 45%(LAST VERSION) - ASSEMBLY**



MAP19470

1. Lubricate and insert washer (23) and planetary gear (22).



2. Insert the two half bolts (18), spherical washers (17) and

satellite gears (16).

MAP19480



MAP19490

3. Partially insert the long bolt (20), satellite gears (16) and spherical washers (17).



MAP19500

4. Place the planetary gear (16) and the spherical washer (17) in the box and fix with a fake pin of suitable diameter.



MAP19510

5. Insert the cross bolt (21) in the correct position.



6. Satellite wheels (**16**), spherical washers (**17**) and completely insert the long bolt (**20**).



MAP19540

8. Insert and replace, if necessary, the discs of the differential lock (**24** and **25**).



7. Bring the pin holes in line with the help of a pin driver. Insert pins (**19**) to end of stroke. First and last disc have to be of steel (25).



MAP19550

- 9. Install the thrust block with maximum internal diameter.
- 10. Position the bearing (**26**) in the differential unit.
- 11. Install the thrust block with minimum internal diameter.



MAP19560

12. Insert the snap ring (27).



MAP19570

13. As to ring (**33**), the side without notches must face outwards.



14. 35% FRICTION UNIT COMPOSITION:

Friction discs with increased shim (**33**), steel discs (**32**) and friction discs (**31**) alternated, and end disc (**32**).



MAP19590

15. Place a friction unit and planetary gear (**22**) into the half-box (**13**).



MAP19600

16. Position the shim washer (14) on the crown (9). Install the ring gear (9).

Note: In order to hold the shim washer (**14**) in position, apply grease to it.



17. Mount the gear ring (**9**) and fasten it to the differential box with screws (**10**).





18. Heat the bearings (**12** and **28**) at 100° and insert them on differential.

Section 27 Bevel Pinion: Flanged to Reduction Gear 603

27.1 EXPLODED VIEW



27.2 BEVEL PINION: FLANGED TO REDUCTION GEAR 603 - DISASSEMBLY



MAP19640

- 1. Position tool (**T16**), to avoid pinion rotation.
- 2. Loosen and remove the nut (1) and o-ring (6).





3. Remove the pinion (11), shims, and spacer.



MAP19660

4. Refer and keep to the positions marked during disassembly



5. Using a puller and a press, remove the inner bearing (4) from the pinion (11).



MAP19680

6. Remove the thrust block of the external bearing (14).



MAP19690

7. Insert a drift in the appropriate holes.



10. Remove the cap (**14**).



8. Remove the thrust block of the internal bearing (4) as well as the shims (10)(S).



9. Remove the snap ring (15).

27.3 BEVEL PINION: FLANGED TO REDUCTION GEAR 603 - ASSEMBLY



MAP19730

- 1. CALCULATING PINION CENTER DISTANCE: Using a faceplate, reset a dial indicator "DG" on a calibrated block (whose known thickness is 30 mm.
- 2. Preload the depth gauge by about 3 mm.



MAP19740

 Bring inner bearing (4), complete with thrust block, under depth gauge "DG".
 EXAMPLE: 30 - 0.55 = 29.45 = "D".

CAUTION

Press the thrust block centrally and carry out several measurements by rotating the thrust block.



MAP19750

 Check nominal dimension "I" as marked on the pinion. Add up to or subtract from "I" the variation indicated as "Y " to obtain the actual center distance "I". EXAMPLE: I=INT ± Y ==98-0.1=97.9mm.



MAP19760

5. Calculate shims "S" for insertion under the thrust block of the inner bearing using the following formula:
S = X - (I + D) where: X = fixed dimension
I = actual pinion center distance
D = Total bearing thickness;
EXAMPLE: S = 128 - (97.9+29.45) = 0.65 mm.



MAP19770

6. Using special tool (**T17**) insert the thrust block of the bearings (**4**) and shims (**10**).



 CALCULATING PINION BEARINGS ROLLING TORQUE: Introduce tool (T18) complete with bearings (4) and (14) into the main body (12); tighten by hand until a rolling torque is definitely obtained.



7. Before starting the next step, make sure that the thrust block has been completely inserted into its seat.



MAP19790

8. Using special tool (**T17**) insert the thrust block of the bearings (**4**)and shims (**10**).



10. Introduce the tracer of a depth gauge "DDG" into either side hole of tool (**T18**) Reset the dial indicator with a preload of about 3 mm.



 Remove the depth gauge and take out tool (**T18**) and bearing kits from the main body. Reinstall every part, also introducing a spacer between bearings (**4**) and (**14**), tighten the entire pack by hand.



 Assemble on top of the tool (T18) and between the two bearings the shim (5) and the largest calibrated shim (9).



MAP19840

13. Measure the difference H using a dial gauge DDG E.g. H = A - B = 2.93 mm.



14. Calculate the shim S2 to be inserted.
E.g. S2 = H + X = 3.01 mm where X = fixed value to obtain = 0.07÷0.08 mm.



15. Heat the bearing to 100°C and assemble it to the pinion shaft.



16. Fit the pinion (**11**), shim "S1" (**10**) and spacer (**5**) and (**9**) in the main body (**12**).

Note: The thin shims must be placed in- between the thick ones.



 Apply onto the pinion (11) the bar-hold and with the help of a torque wrench, check the torque of the pinion (11).

Tightening torque: 500 Nm (369 ft.lb.) Rolling torque: 8 - 12 Nm (5.9-8.9 ft.lb.)



MAP19880

17. Heat the external bearing (**14**) to a temperature of about 100 C° and fit it on to the pinion (**11**) so as to complete the pack as shown in the figure.

Note: Lightly lubricate bearing with SAE85W90 oil.

If torque exceeds the maximum value, then the size of shim "S1" (4) between the bearing (9) and the spacer (3) needs to be increased. If torque does not reach the set value, increase the torque setting of the ring nut (10) in different stages to obtain a maximum value of 700 Nm (516 ft.lb.) If torque does not reach the minimum value, then the size of shim "S1" (4) needs to be reduced.

This Page Intentionally Left Blank

Section 28 Ring and Pinion Adjusting: Version Pinion Cover and Single Arm

28.1 EXPLODED VIEW



MAP19930

28.2 RING AND PINION ADJUSTING: VERSION PINION COVER AND SINGLE ARM -INSTALL AND ADJUST



1. Remove the snap ring.



3. Insert shim washers (**S**) as calculated and insert the pinion.

Note: Position pinion support respecting assembly direction.



2. Remove cap.



4. Insert the pinion cover screws.



MAP19980

5. Tighten using the criss-cross method and a torque wrench setting of 68 - 75 Nm (50 - 55 ft.lb.).




SETTING OF THE RING GEAR AND PINION
 Insert the thrust block of the bearing (6) opposite side of the crown wheel shims (Sb) and (7) of an initial thickness of about 0.55 mm.



8. SETTING OF THE RING GEAR AND PINION Insert thrust block (4) of the bearing shims (Sc) and (3) to an initial thickness of about 0.75 mm.



MAP20000

7. Insert the thrust block (6) and the shims (Sb) and (7) into the arm.

Note: Verify at end of stroke.



MAP20020

9. Insert the thrust block and the shims into the arm. *Note: Verify at end of stroke.*



MAP20030

10. Insert complete differential (5).



Do not damage the seat of the o-ring with the planetary gear.



11. Inspect the o-ring (2) and grease.



12. Install the ring gear side arm (1) without the half axle.

Note: To check the torque of the differential, neither half-axles should be installed.



MAP20060

13. Temporarily insert all screws of the arm (18).



14. Apply torque meter (**TM**) to pinion nut and check that torque will increase by 40-60 Ncm (3-4 ft.lb.) as a result of differential bearing preload.

Pinion + differential torque: 120-180 Ncm (8.8-13.2 ft.lb.)



MAP20080

15. Introduce a depth gauge with rotary key through the rear cap hole. Position depth gauge on the center of one of the crown teeth, preset it to 1 mm and reset it to zero. Manually move the crown in both directions to check the existing clearance between pinion and crown. Gap= 0,13-0,20mm

In order to increase the gap while keeping the load on the bearing unchanged, take off shims from the ring gear side and insert them on the opposite side. In order to decrease the gap, do the opposite.



16. Check that the arms are level; then lock the arms into their final position, using screws adequately coated with Loctite 242.



17. Torque wrench setting: 116 - 128 Nm (86-94 ft.lb.) *Note: Tighten using the criss-cross method.*



18. Using a driver, fit the cap and secure with the snap ring.

This Page Intentionally Left Blank

Section 29 Ring and Pinion Adjusting: Version Pinion Integral and Double Arm

29.1 EXPLODED VIEW



29.2 **RING AND PINION ADJUSTING: VERSION PINION INTEGRAL AND DOUBLE ARM -INSTALL AND ADJUST**





3. Check the o-ring (2) and grease.

1. SETTING OF THE RING GEAR AND PINION: Insert the thrust block of the bearing (6) opposite side of the ring gear shims (Sb) and (7) of an initial thickness of about 0.55mm.



MAP20140

2. Insert the thrust block (6) and the shims (Sb) and (7) into the arm.

Note: Verify at end of stroke.



4. Temporarily insert all screws of the arm (18).



MAP20170

5. Insert complete differential (5).



Do not damage the seat of the o-ring with the planetary gear.





MAP20200

8. Install the ring gear side arm (1) without half-axle.

Note: To check the torque of the differential, neither of both half-axles should be installed.

MAP20180

6. SETTING OF THE RING GEAR AND PINION: Insert thrust block (4) of the bearing shims (Sc) and (3) an initial thickness of about 0.75mm.



7. Insert the thrust block and the shims into the arm.

Note: Verify at end of stroke.



9. Temporarily insert all screws of the arm (18).



MAP20220

 Apply torque meter (**TM**) to pinion nut and check that torque will increase by 40-60 Ncm (2.9 - 4.4 ft.lb.) as a result of differential bearing preload.
 Example: pinion torque: 80-120 Ncm (5.9 - 8.8 ft.lb.)
 Pinion +differential torque:120-180 Ncm (8.8 - 13.2 ft.lb.)







12. Torque wrench setting: 130 Nm (96 ft.lb.)

Note: Tighten using the criss-cross method.

- 13. Using a driver, fit the cap and secure with the snap ring.
- Introduce a depth gauge with rotary key through the rear cap hole. Position depth gauge on the center of one of the crown teeth, preset it to 1 mm and reset it to zero. Manually move the crown in both directions to check the existing clearance between pinion and crown. Gap = 0.13 - 0.20 mm

In order to increase the gap while keeping the load on the bearing unchanged, take off shims from the ring gear side and insert them on the opposite side. In order to decrease the gap, do the opposite.

Note: Verify at end of stroke.

31200451

Section 30 Special Tools

30.1 T1

910.06.4209



30.2 T2

910.06.4207



30.3 T3

910.06.4203



30.4 T4

910.06.4210



30.5 T5

910.06.2385





30.6 T6

910.24.2367



30.7 T7

660.18.1469



30.8 T8

910.04.0608



30.9 T9

910.04.0599



30.10 T10

910.99.0002



30.11 T11

910.06.4069



30.12 T12

910.04.2389



30.13 T13



30.14 T14



30.15 T16



30.16 T17

910.06.4069



Write code 910.06.4069

30.17 T18



This Page Intentionally Left Blank



CATERPILLAR®