M0107105 (en-us) September 2021



# **Disassembly and Assembly**

## TH408D Telehandler Power Train

TH9 1-UP (Machine)



Scan to access the latest service information, purchase additional media, and buy genuine Cat<sup>®</sup> parts.



## Important Safety Information

Most accidents that involve product operation, maintenance and repair are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. A person must be alert to potential hazards, including human factors that can affect safety. This person should also have the necessary training, skills and tools to perform these functions properly.

## Improper operation, lubrication, maintenance or repair of this product can be dangerous and could result in injury or death.

## Do not operate or perform any lubrication, maintenance or repair on this product, until you verify that you are authorized to perform this work, and have read and understood the operation, lubrication, maintenance and repair information.

Safety precautions and warnings are provided in this manual and on the product. If these hazard warnings are not heeded, bodily injury or death could occur to you or to other persons.

The hazards are identified by the "Safety Alert Symbol" and followed by a "Signal Word" such as "DANGER", "WARNING" or "CAUTION". The Safety Alert "WARNING" label is shown below.

🛕 WARNING

The meaning of this safety alert symbol is as follows:

### Attention! Become Alert! Your Safety is Involved.

The message that appears under the warning explains the hazard and can be either written or pictorially presented.

A non-exhaustive list of operations that may cause product damage are identified by "NOTICE" labels on the product and in this publication.

Caterpillar cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this publication and on the product are, therefore, not all inclusive. You must not use this product in any manner different from that considered by this manual without first satisfying yourself that you have considered all safety rules and precautions applicable to the operation of the product in the location of use, including site-specific rules and precautions applicable to the worksite. If a tool, procedure, work method or operating technique that is not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and for others. You should also ensure that you are authorized to perform this work, and that the product will not be damaged or become unsafe by the operation, lubrication, maintenance or repair procedures that you intend to use.

The information, specifications, and illustrations in this publication are on the basis of information that was available at the time that the publication was written. The specifications, torques, pressures, measurements, adjustments, illustrations, and other items can change at any time. These changes can affect the service that is given to the product. Obtain the complete and most current information before you start any job. Cat dealers have the most current information available.

#### NOTICE

When replacement parts are required for this product Caterpillar recommends using original Caterpillar® replacement parts.

Other parts may not meet certain original equipment specifications.

When replacement parts are installed, the machine owner/user should ensure that the machine remains in compliance with all applicable requirements.

In the United States, the maintenance, replacement, or repair of the emission control devices and systems may be performed by any repair establishment or individual of the owner's choosing.

## **Table of Contents**

### **Disassembly and Assembly Section**

### **Index Section**

Index......94

### 

Accidental machine starting can cause injury or death to personnel working on the machine.

To avoid accidental machine starting, turn the battery disconnect switch to the OFF position and remove the key. If the machine is not equipped with a battery disconnect switch, disconnect the battery cables from the battery and tape the battery clamps.

Place a do not operate tag at the battery disconnect switch location to inform personnel that the machine is being worked on.

## Disassembly and Assembly Section

i08228057

## **Transmission - Disassemble**

SMCS Code: 3030-015

### References



Illustration 1

g06471531

**Reference:** For more information, refer to supplemental video "TH408D AG Telehandler Transmission - Disassemble" on Caterpillar Channel1 (A CWS login is required to access Caterpillar Channel1).

**Note:** Click or copy the following link into a web browser (A CWS login is required to access Caterpillar Channel1), or scan the following QR code using a QR enabled device.

https://channel1.mediaspace.kaltura.com/media/ 1\_56h4b9ui



Illustration 2

g06722223

## **Disassembly Procedure**

Table 1

Required Tools				
Tool	Part Number	Part Description	Qty	
А	439-3938	Link Bracket	3	
В	422-5474	Lifting Eye Assembly	2	
С	422-5473	Lifting Eye Assembly	1	
D	1P-2420	Transmission Repair Stand	1	
E	6V-5230	Bolt	4	
	6V-5839	Washer	8	
	2Y-5829	Nut	4	
F	4C-8359	Eyebolt	1	
G	156-7100	Slide Hammer Puller Gp	1	
Н	2P-8312	Retaining Ring Pliers	1	
J	5P-5197	Retaining Ring Pliers As	1	
К	1P-0510	Driver Gp	1	
L	-	Guide stud (M10x1.5x145mm)	2	
М	8H-0663	Bearing Puller As	1	
Ν	1U-6400	Three Jaw Puller	1	
Р	4C-3652	Compressor As	1	
R	8B-7554	Bearing Cup Puller Gp	1	
S	6V-3009	Crossbar	1	

(Table 1, contd)

Required Tools				
Tool	Part Number	Part Description	Qty	
	8S-6470	Pressure Screw	1	
	126-7179	Puller Leg	1	
	5P-8245	Hard Washer	1	
	6B-6684	Full Nut	1	

### Start By:

### a. Remove the transmission.



Illustration 3

g06693862

 Attach a suitable lifting device to pump (1). The weight of pump (1) is approximately 41 kg (90 lb). Remove bolts (2), pump (1), and the O-ring seal.



Illustration 4

g06693879



Illustration 5

g06693882

- **2.** Attach Tooling (A) and a suitable lifting device to transmission assembly (3). The weight of transmission assembly (3) is approximately 338 kg (745 lb).
- **3.** Position transmission assembly (3) and place on suitable cribbing as shown in Illustration 5.
- 4. Attach a suitable lifting device to transfer case (4). The weight of transfer case (4) is approximately 73 kg (161 lb). Remove six bolts (5) and transfer case (4) from transmission assembly (3).



Illustration 6

**5.** Attach Tooling (A) and a suitable lifting device to torque converter (6). The weight of torque converter (6) is approximately 20 kg (44 lb). Cut the cable straps (not shown) and remove torque converter (6).



Illustration 7

g06693887

- **6.** Attach Tooling (A) and a suitable lifting device to transmission (7). The weight of transmission (7) is approximately 245 kg (540 lb).
- **7.** Position transmission (7) onto suitable cribbing. Remove Tooling (A) and the suitable lifting device from transmission (7).



Illustration 8

g06693890



Illustration 9

g06693893

- **8.** Attach Tooling (B), Tooling (C), and a suitable lifting device to transmission (7).
- **9.** Position transmission (7) onto Tooling (D) as shown in Illustration 9 . Install Tooling (E) (not shown) to secure transmission (7).



Illustration 10

**10.** Remove the bolt, speed sensor (10), and the O-ring seal. Remove hose (9), adapter (8), and the O-ring seal.



Illustration 12

g06693899

F

7

12. Remove O-ring seals (13).



Illustration 13 Output shaft

g06693901

- **13.** Attach Tooling (F) and a suitable lifting device to output shaft (14). Remove output shaft (14).
- A (1) (2) (2)

Illustration 11

g06693897

**11.** Attach Tooling (A), Tooling (B), and a suitable lifting device to rear case (11). The weight of rear case (11) is approximately 50 kg (110 lb). Remove bolts (12) and rear case (11).



Illustration 14 Forward high/third clutch assembly

**14.** Remove the bolt and the washer (not shown). Attach Tooling (F) and a suitable lifting device onto clutch assembly (15). The weight of clutch assembly is approximately 23 kg (51 lb). Remove clutch assembly (15).



Illustration 15 Forward low/reverse clutch assembly

**Note:** Be aware of potential pinch points during removal.

**15.** Remove clutch assembly (16).



Illustration 16 First/second clutch assembly g06693906

 Remove the bolt and the washer (not shown). Attach Tooling (F) and a suitable lifting device onto clutch assembly (17). Remove clutch assembly (17).



Illustration 17

g06693909

**17.** Remove four bearing cups (18).



Illustration 18

**18.** Remove gage assembly (21) and tube assembly (19). Remove the three bolts and suction strainer assembly (20).



Illustration 19

g06693918

**19.** Remove O-ring seal (22) from tube assembly (19).



Illustration 20

g06693919

**20.** Remove O-ring seals (23) from suction strainer assembly (20).



Illustration 21

g06693922

- **21.** Remove four bolts (26) and solenoid valve assembly (27).
- **22.** Remove two screws (25) and solenoid valves (24).



g06693995

- 23. Remove four bolts (28) and pump housing (29).
- **24.** Remove relief valves (30) and (31).



Illustration 23

g06693998

- 25. Remove O-ring seal (34).
- **26.** Remove four bolts (32) and pump (33).



Illustration 24

g06693999

- **27.** Attach Tooling (A) and a suitable lifting device to transmission intermediate case (35). The weight of transmission intermediate case (35) is approximately 108 kg (238 lb).
- **28.** Remove Tooling (E) and transmission intermediate case (35) from Tooling (D).



g06694001



Illustration 26

g06694002

- 29. Position transmission intermediate case (35) on suitable cribbing. Attach Tooling (A) and a suitable lifting device to transmission intermediate case (35) and position transmission intermediate case (35) as shown in Illustration 26.
- **30.** Remove four bolts (36) and solenoid valve assembly (37). Remove screw (38) and solenoid valve (39).



Illustration 27

g06694006



Illustration 28

g06694009

31. Attach Tooling (A) and a suitable lifting device to torque converter housing (41). The weight of torque converter housing (41) is approximately 29 kg (64 lb). Remove 15 bolts (40) and torque converter housing (41).



g06694011

Note: Discard seal (42).

32. Remove seal (42).



Illustration 30

g06694012

Note: Discard bushing (43) and needle bearing (44).

**33.** Position torque converter housing (41). Use Tooling (G) (not shown) to remove bushing (43) and needle bearing (44). Remove bushing (43) and needle bearing (44).



### Illustration 31

g06694014

- **34.** Remove sensor assembly (46), the O-ring seal, adapter (45), and the O-ring seal.
- 35. Remove transmission filter (47).



Illustration 32

g06694018

Note: Discard lip seal (48).

**36.** Mark the orientation of lip seal (48) for assembly purposes.

Remove lip seal (48) and four O-ring seals (49).



Illustration 33

**Note:** Note the orientation of thrust washers (50) for assembly purposes.

- **37.** Remove thrust washers (50) and gear assembly (53).
- **38.** Remove the spacer and gear assembly (51).
- **39.** Remove gear assembly (52).



Illustration 34

g06694021

**40.** Remove O-ring seal (54) from gear assembly (53).



Illustration 35

g06694022

Note: Discard bushing (55).

41. Remove bushing (55) from gear assembly (53).



Illustration 36

g06694023

**42.** Use Tooling (J) (not shown) to remove retaining ring (56) from gear assembly (51). Remove retaining ring (56).



Illustration 37

**43.** Use Tooling (K) and a suitable press to remove bearing (57). Remove bearing (57) from gear assembly (51).



Illustration 38

g06694027

**44.** Use Tooling (H) (not shown) to remove retaining ring (58). Remove retaining ring (58) and thrust washer (59) from gear assembly (52). Repeat for the other side.



Illustration 39

g06694031

- **45.** Remove five bolts (63) and stator support hub (60).
- 46. Remove support shaft assembly (61).

Note: Discard needle bearing (62).

**47.** Use Tooling (G) (not shown) to remove needle bearing (62). Remove needle bearing (62).



Illustration 40

g06694033

**48.** Remove O-ring seal (64) from support shaft assembly (61).



Illustration 41

- **49.** Use a suitable press to remove support shaft
  - (65). Remove support shaft (65) from bearing race (66).



Illustration 42

g06694039

**50.** Attach Tooling (A) and a suitable lifting device to transmission intermediate case (35). The weight of transmission intermediate case (35) is approximately 68 kg (150 lb). Place transmission intermediate case (35) in VERTICAL position.



Illustration 43

g06694042



Illustration 44

g06694045

- **51.** Use Tooling (L) and a suitable pry bar to hold the reverse idler gear.
- 52. Remove bolt (67), washers (68), and (69).





16

g06694048



Illustration 46

g06694051

- 53. Remove reverse idler gear (70) and the spacer from rear of the case.
- 54. Remove bearing (71) from front of the case.



### Illustration 47

g06694054

Note: Discard bearing cup (72).

55. Use Tooling (G) (not shown) to remove bearing cups (72). Remove bearing cups (72).

### **Output shaft disassembly**



Illustration 48

g06694061

1. Use a suitable press to remove bearing cone (73) and gear (74). Remove bearing cone (73) and gear (74) from the output shaft.

Ν



Illustration 49

g06694063

 Use Tooling (M) and a suitable press to remove bearing cone (75). Remove bearing cone (75) from the output shaft.

## Forward high/third clutch disassembly



Illustration 50

g06694071

1. Remove three ring seals (76).



 Use Tooling (K) and Tooling (N) to remove bearing cone (77) and gear (78). Remove bearing cone (77) and gear (78).



Illustration 52

g06694077

**3.** Remove spacer (79), thrust washer (80), thrust bearing (81), and gear (82).



g06694081

- 4. Remove needle bearings (83) and (84).
- **5.** Remove thrust bearing (85) and thrust washer (86).



Illustration 54

g06694086

**6.** Use a suitable flat blade screw driver to remove retaining ring (87). Remove retaining ring (87) and retainer plate (88).



Illustration 55

g06694088

**Note:** Note the quantity and the location of friction discs (89) and clutch discs (90) for assembly purposes.

7. Remove friction discs (89) and clutch discs (90).



g06694091



Illustration 57

g06694095

### 

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

**8.** Use Tooling (P) and a suitable press to compress spring assembly (91). Use Tooling (J) (not shown) to remove retaining ring (92).

**9.** Remove retaining ring (92), spring assembly (91), and the spring retainer.



Illustration 58

g06694097

### 🏠 WARNING

Personal injury can result from air pressure against the piston.

The piston can come out of the housing assembly with force when air pressure is applied.

To prevent possible personal injury, the piston must be retained in the housing assembly when applying air pressure.

**10.** Using an air line with a low-pressure supply, pressurize the forward high clutch to remove piston (93). Remove piston (93).



g06694099



Illustration 60

g06694102

**11.** Use a suitable press to remove bearing cones (94), (95), and gear (96). Remove bearing cones (94), (95), and gear (96).

Note: Discard the bearing cups.

**12.** Use Tooling (G) (not shown) to remove the bearing cups. Remove the bearings cups from gear (96).



Illustration 61

g06694105

**13.** Use a suitable flat blade screw driver to remove retaining ring (97). Remove retaining ring (97) and retainer plate (98).



Illustration 62

g06694108

**Note:** Note the quantity and the location of clutch discs (100) and friction discs (101) for assembly purposes.

**14.** Remove spacer (99), clutch discs (100), and friction discs (101).



g06694112

Note: Discard bearing cone (102).

**15.** Use Tooling (R) to remove bearing cone (102). Remove bearing cone (102).



Illustration 64

g06694113



Illustration 65

g06694117

### 🛕 WARNING

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

**16.** Use Tooling (P) and a suitable press to compress spring assembly (103). Use Tooling (J) (not shown) to remove retaining ring (104).

17. Remove retaining ring (104), spring assembly (103), and the spring retainer.



Illustration 66

g06694126

#### WARNING Λ

Personal injury can result from air pressure against the piston.

The piston can come out of the housing assembly with force when air pressure is applied.

To prevent possible personal injury, the piston must be retained in the housing assembly when applying air pressure.

18. Using an air line with a low-pressure supply, pressurize the forward high clutch to remove piston (105). Remove piston (105).

### Forward low/reverse clutch disassembly



Illustration 67

1. Remove ring seal (106).







Illustration 69

g06694134

- Use Tooling (M) and Tooling (S) to remove bearing cone (107), thrust washer (108), thrust bearing (109), and gear (110).
- **3.** Remove bearing cone (107), thrust washer (108), thrust bearing (109), and gear (110).



Illustration 70

g06694135

**4.** Remove needle bearings (111), (112), thrust bearing (113), and thrust washer (114).



Illustration 71

g06694136

**5.** Use a suitable flat blade screw driver to remove the retaining ring (115). Remove retaining ring (115) and retainer plate (116).



Illustration 72

**Note:** Note the quantity and the location of friction discs (117) and clutch discs (118) for assembly purposes.

6. Remove friction discs (117) and clutch discs (118).



Illustration 73

g06694159



Illustration 74

g06694160

### WARNING

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

**7.** Use Tooling (P) and a suitable press to compress spring assembly (119). Use Tooling (J) (not shown) to remove retaining ring (120).

8. Remove retaining ring (120), spring assembly (119), and the spring retainer.



Illustration 75

g06694161



Illustration 76

g06694163

### 

Personal injury can result from air pressure against the piston.

The piston can come out of the housing assembly with force when air pressure is applied.

To prevent possible personal injury, the piston must be retained in the housing assembly when applying air pressure.

9. Using an air line with a low-pressure supply, pressurize the forward high clutch to remove piston (121). Remove piston (121).



Illustration 77

10. Remove three ring seals (122).







Illustration 80

g06694172





Illustration 81

g06694174

**14.** Use a suitable flat blade screw driver to remove the retaining ring (131). Remove retaining ring (131) and retainer plate (132).



Illustration 79

```
g06694170
```

- **11.** Use Tooling (K) and Tooling (N) to remove bearing cone (123), thrust washer (124), thrust bearing (125), and gear (126).
- **12.** Remove bearing cone (123), thrust washer (124), thrust bearing (125), and gear (126).

M0107105



g06694175

**Note:** Note the quantity and the location of friction discs (133) and clutch discs (134) for assembly purposes.

**15.** Remove friction discs (133) and clutch discs (134).



Illustration 83

g06694176



Illustration 84

g06694179

## 

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

**16.** Use Tooling (P) and a suitable press to compress spring assembly (135). Use Tooling (J) (not shown) to remove retaining ring (136).

**17.** Remove retaining ring (136), spring assembly (135), and the spring retainer.



Illustration 85

g06694180

### 

Personal injury can result from air pressure against the piston.

The piston can come out of the housing assembly with force when air pressure is applied.

To prevent possible personal injury, the piston must be retained in the housing assembly when applying air pressure.

**18.** Using an air line with a low-pressure supply, pressurize the forward high clutch to remove piston (137). Remove piston (137).



Illustration 86

g06694182

19. Remove spacer (138).

### First/second clutch disassembly



Illustration 87

g06694183

1. Use Tooling (K) and Tooling (N) to remove bearing cone (139) and gear (140). Remove bearing cone (139) and gear (140).

### M0107105



Illustration 88

g06694185

g06694187

**2.** Remove spacer (141), thrust washer (142), and thrust bearing (143).



Illustration 90

g06694188

**4.** Remove needle bearings (145), (146), thrust bearing (147), and thrust washer (148).



Illustration 91

g06694190

**5.** Use a suitable flat blade screw driver to remove the retaining ring (149). Remove retaining ring (149) and retainer plate (150).

Illustration 89

3. Remove gear assembly (144).



g06694191

**Note:** Note the quantity and the location of friction discs (151) and clutch discs (152) for assembly purposes.

6. Remove friction discs (151) and clutch discs (152).



Illustration 93

g06694192



Illustration 94

g06694193

### 🛕 WARNING

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

**7.** Use Tooling (P) and a suitable press to compress spring assembly (153). Use Tooling (J) (not shown) to remove retaining ring (154).

**8.** Remove retaining ring (154), spring assembly (153), and the spring retainer.



Illustration 95

g06694196



Illustration 96

g06694198

## A WARNING

Personal injury can result from air pressure against the piston.

The piston can come out of the housing assembly with force when air pressure is applied.

To prevent possible personal injury, the piston must be retained in the housing assembly when applying air pressure. **9.** Using an air line with a low-pressure supply, pressurize the forward high clutch to remove piston (155). Remove piston (155).



Illustration 97

**10.** Remove three seal rings (156).



Illustration 98

g06694200

g06694199

- **11.** Use a suitable press to remove bearing cone (157), thrust washer (158), thrust bearing (159), and gear (160).
- **12.** Remove bearing cone (157), thrust washer (158), thrust bearing (159), and gear (160).



g06694201

**13.** Remove needle bearings (161), (162), thrust bearing (163), and thrust washer (164).



Illustration 100

g06694202

**14.** Use a suitable flat blade screw driver to remove the retaining ring (165). Remove retaining ring (165) and retainer plate (166).



Illustration 101

g06694203

**Note:** Note the quantity and the location of clutch discs (167) and friction discs (168) for assembly purposes.

**15.** Remove clutch discs (167) and friction discs (168).



g06694205



Illustration 103

g06694207

### 

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

**16.** Use Tooling (P) and a suitable press to compress spring assembly (169). Use Tooling (J) (not shown) to remove retaining ring (170).

**17.** Remove retaining ring (170), spring assembly (169), and the spring retainer.



Illustration 104

g06694208

### 🏠 WARNING

Personal injury can result from air pressure against the piston.

The piston can come out of the housing assembly with force when air pressure is applied.

To prevent possible personal injury, the piston must be retained in the housing assembly when applying air pressure.

**18.** Using an air line with a low-pressure supply, pressurize the forward high clutch to remove piston (171). Remove piston (171).

### Transfer case disassembly





Illustration 107

g06694212

Illustration 105 Transfer case g06694209

1. Remove vent (172) from transfer case (4).



Illustration 106

g06694211

2. Remove bolt (173) and washer (174).

**3.** Remove O-ring seal (177), yoke assembly (176), and spacer (175). Repeat for the other side.



Illustration 108

g06694213

- **4.** Place transfer case (4) onto suitable cribbing. Use two people to remove the front case assembly of transfer case (4). The weight of the front case assembly is approximately 25 kg (55 lb).
- **5.** Remove bolts (178) and the front case assembly from transfer case (4).



Illustration 109

**Note:** Note the quantity of the shims for assembly purposes.

6. Remove four bearing cups (179) and the shims



### Illustration 110

g06694215

Note: Discard lip seal (180) and plugs (181).

**Note:** Mark the orientation of lip seal (180) for assembly purposes.

**7.** Use Tooling (K) (not shown) to remove lip seal (180). Remove lip seal (180) and plugs (181).



Illustration 111

g06694216

**8.** Remove the output gear assembly (182), idler gear assemblies (183), (184), and input gear assembly (185).



Illustration 112

### g06694217

Note: Discard lip seals (187).

**Note:** Mark the orientation of lip seal (187) for assembly purposes.

**9.** Remove bearing cups (186). Use Tooling (K) (not shown) to remove lip seal (187). Remove two lip seals (187).



Illustration 113

**10.** Use Tooling (K) and Tooling (N) to remove bearing cone (188). Remove bearing cone (188) from idler gear assembly (183). Repeat for the other side.



Illustration 114

g06694219

**11.** Use Tooling (K) and Tooling (N) to remove bearing cone (189). Remove bearing cone (189) from idler gear assembly (184). Repeat for the other side.



Illustration 115

g06694220

**12.** Use Tooling (K) and Tooling (N) to remove bearing cone (190). Remove bearing cone (190) from input gear assembly (185).



Illustration 116

g06694221

**13.** Use Tooling (K) and Tooling (N) to remove bearing cone (191). Remove bearing cone (191) from input gear assembly (185).


Illustration 117

**14.** Use Tooling (K) and Tooling (N) to remove bearing cone (192). Remove bearing cone (192) from output gear assembly (182).



Illustration 118

g06694223

**15.** Use Tooling (K) and Tooling (N) to remove bearing cone (193). Remove bearing cone (193) from output gear assembly (182).



Illustration 119

g06694224

 Use Tooling (J) (not shown) to remove retaining ring (194) from output gear assembly (182). Repeat for the other side.



Illustration 120

g06694225

**17.** Use a suitable press to remove output shaft (195). Remove output shaft (195).

# Modulating solenoid valve disassembly



Illustration 121 Modulating solenoid valve assembly

**1.** Remove four O-ring seals (196) from solenoid valve assembly (37).



Illustration 122

g06694227

2. Remove locknut (198), O-ring seal (199), and coil assembly (197).



Illustration 123

g06694228

# 

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

**3.** Remove solenoid tube assembly (201), O-ring seals (203), (200), and spring (202).



g06694229

**4.** Use a suitable magnet to remove central washer (205) and spool (204). Remove central washer (205) and spool (204).



Illustration 125

g06694230

### 

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

**5.** Remove plug (207), O-ring seal (208), and spring (206).



Illustration 126

g06694231

**6.** Use a suitable magnet to remove poppet (209). Remove poppet (209).



g06694232

Illustration 128

# A WARNING

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

7. Remove plug (212), O-ring seal (213), spring (211), and spring carrier (210).



Follow the recommended procedure and use all recommended tooling to release the spring force.

8. Use a suitable magnet to remove spring (215) and piston (214). Remove spring (215) and piston (214).

# 

Personal injury can result from being struck by parts propelled by a released spring force.

norrann

M0107105

g06694233



g06694234

# 

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

**9.** Remove plug (217), O-ring seal (218), and spring (216).



Illustration 130

#### g06694235

**10.** Use a suitable magnet to remove washer (219). Remove washer (219).

# Dual modulating valve disassembly



Illustration 131

g06694236

**1.** Remove four O-ring seals (220) from solenoid valve assembly (27).



g06694238

2. Remove locknut (222), O-ring seal (223), and coil assembly (221).



Illustration 133

g06694239

## 

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

**3.** Remove solenoid tube (225), O-ring seals (227), (224), and spring (226).



Illustration 134

g06694240

**4.** Use a suitable magnet to remove washer (229) and spool (228). Remove washer (229) and spool (228).



g06694241

# 

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

**5.** Remove plug (231), O-ring seal (232), and spring (230).



Illustration 136

g06694242

**6.** Use a suitable magnet to remove poppet (233). Remove poppet (233).



Illustration 137

g06694243

# 

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

**7.** Remove plug (236), O-ring seal (237), spring (235), and spring carrier (234).



Illustration 138

g06694244

#### 

Personal injury can result from being struck by parts propelled by a released spring force.

Make sure to wear all necessary protective equipment.

Follow the recommended procedure and use all recommended tooling to release the spring force.

- **8.** Use a suitable magnet to remove spring (239) and piston (238). Remove spring (239) and piston (238).
- 9. Repeat Step 2 through Step 8 for the other side.

## Relief valve disassembly



Illustration 139

g06694312

**1.** Remove three O-ring seals (240) from relief valve (31).



g06694313

 Remove two O-ring seals (241) from relief valve (30).

i08238485

# **Transmission - Assemble**

SMCS Code: 3030-016

## **Assembly Procedure**

Table 2

Required Tools					
Tool	Part Number	Part Description	Qty		
А	439-3938	Link Bracket	3		
В	422-5474	Lifting Eye Assembly	2		
С	422-5473	Lifting Eye Assembly	1		
D	1P-2420	Transmission Repair Stand	1		
E	6V-5230	Bolt	4		
	6V-5839	Washer	8		
	2Y-5829	Nut	4		
F	4C-8359	Eyebolt	1		
Н	2P-8312	Retaining Ring Pliers	1		
J	5P-5197	Retaining Ring Pliers As	1		
К	1P-0510	Driver Gp	1		
L	-	Guide stud (M10x1.5x145mm)	2		

· <u> </u>	-	
(Tabl	е2,	contd)

Required Tools					
Tool	Part Number	Part Description	Qty		
Р	4C-3652	Compressor As	1		
Т	-	Loctite 648	-		
U	-	Petro gel grease	-		
V	8T-5096	Tool Gp	1		
W	-	Loctite 5188	-		

### NOTICE

Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.

**Note:** Apply a light film of clean transmission oil to all components before assembly.

## **Dual Modulating Valve Assembly**



Illustration 141

g06697215

## A WARNING

Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.

1. Install piston (238) and spring (239).



g06697218

# 

Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.

2. Install spring carrier (234), spring (235), O-ring seal (237), and plug (236). Tighten plug (236) to a torque of 25 to 35 N·m (18 to 26 lb ft).



Illustration 143

g06697221

 $\begin{array}{c}
 230 \\
 232
\end{array}$ 

Illustration 144

g06697223

# 

Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.

**4.** Install spring (230), O-ring seal (232), and plug (231). Tighten plug (231) to a torque of 10 to 20 N⋅m (89 to 177 lb in).



Illustration 145

g06697226

5. Install spool (228) and washer (229).

3. Install poppet (233).



g06697575

# 

Improper assembly of parts that are spring loaded can cause bodily injury.

# To prevent possible injury, follow the established assembly procedure and wear protective equipment.

6. Install spring (226), O-ring seals (224), (227), and solenoid tube (225). Tighten solenoid tube (225) to a torque of 25 to 35 N⋅m (18 to 26 lb ft).



Illustration 147

g06697237

- Install coil assembly (221), O-ring seal (223), and locknut (222). Tighten locknut (222) to a torque of 2.5 to 3.5 N⋅m (22 to 31 lb in).
- 8. Repeat Step 1 through Step 7 for the other side.



Illustration 148

g06694236

**9.** Install four O-ring seals (220) onto solenoid valve assembly (27).

# Modulating Solenoid Valve Assembly



Illustration 149 Modulating solenoid valve assembly

g06694235

1. Install washer (219).



Illustration 150

g06694234

# 

Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.

**2.** Install spring (216), O-ring seal (218), and plug (217).



g06694233

## 

Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.

3. Install piston (214) and spring (215).



Illustration 152

g06694232

# 

Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.

**4.** Install spring carrier (210), spring (211), O-ring seal (213), and plug (212). Tighten plug (212) to a torque of 25 to 35 N·m (18 to 26 lb ft).



Illustration 153

g06694231

5. Install poppet (209).





g06694230

## 

Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.

 Install spring (206), O-ring seal (208), and plug (207). Tighten plug (207) to a torque of 10 to 20 N⋅m (89 to 177 lb in).



Illustration 155

g06694229

7. Install spool (204) and washer (205).



Illustration 156

g06694228

# 

Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.

 Install spring (202), O-ring seals (200), (203), and solenoid tube assembly (201). Tighten solenoid tube assembly (201) to a torque of 25 to 35 N⋅m (18 to 26 lb ft).



Illustration 157

 Install coil assembly (197), O-ring seal (199), and locknut (198). Tighten locknut (198) to a torque of 2.5 to 3.5 N⋅m (22 to 31 lb in).



Illustration 158

g06694226

**10.** Install four O-ring seals (196) onto solenoid valve assembly (37).

## **Transfer Case Assembly**



Illustration 159

g06695843

**1.** Use Tooling (J) to install retaining ring (194). Install retaining ring (194) onto output shaft (195).



#### Illustration 160

g06695848

- **2.** Raise the temperature of gear (182) and position gear (182) onto suitable cribbing.
- **3.** Apply Tooling (T) to the splines of output shaft (195). Install output shaft (195) into gear (182).



g06695855

**4.** Raise the temperature of bearing (193). Install bearing (193).



Illustration 162

g06695859

**5.** Use Tooling (J) to install retaining ring (194). Install retaining ring (194) onto output shaft (195).



Illustration 163

g06695861

**6.** Raise the temperature of bearing (192). Install bearing (192).



Illustration 164

g06695862

7. Raise the temperature of bearing (191). Install bearing (191) onto input gear assembly (185).



Illustration 165

g06695869

88

**8.** Raise the temperature of bearing (190). Install bearing (190) onto input gear assembly (185).



Illustration 166

g06695867

**9.** Raise the temperature of bearing (189). Install bearing (189) onto idler gear assembly (184). Repeat for the other side.

 Raise the temperature of bearing (188). Install bearing (188) onto idler gear assembly (183). Repat for the other side.



Illustration 168

(183)

Illustration 167

g06695871

**Note:** Ensure the correct orientation of lip seals (187) from disassembly procedure.

**11.** Use Tooling (K) (not shown) to install lip seals (187). Install lip seals (187).





Illustration 169

**12.** Use two people to position the case assembly onto suitable cribbing. The weight of the case assembly is approximately 25 kg (55 lb). Lower the temperature of bearing cups (186). Install bearing cups (186).



Illustration 171

g06695874

**Note:** Ensure the correct orientation of lip seal (180) from disassembly procedure.

**14.** Use Tooling (K) (not shown) to install lip seal (180). Install lip seal (180).



Illustration 172

g06695876

- **15.** Use two people to remove the front case assembly onto suitable cribbing (not shown). The weight of the front case assembly is approximately 25 kg (55 lb).
- **16.** Apply Tooling (U) to hold bearing cups (179) during installation of case assembly.

182 183 184 185 184 185

Illustration 170

g06694216

**Note:** Ensure that the threaded holes are facing upwards.

**13.** Install input gear assembly (185), idler gear assemblies (184), (183), and output gear assembly (182).

**17.** Lower the temperature of the bearing cups (179). Install bearing cups (179).



Illustration 173

g06695900

**18.** Use two people to install the front case assembly. Install the front case assembly and six bolts (178) evenly spaced. Tighten bolts (178) in a star pattern to a torque of 45 to 64 N⋅m (33 to 47 lb ft).



Illustration 174

g06695902

19. Install Tooling (V) with the head machined to a flat surface into the input gear. Set up Tooling (V) as shown in Illustration 174 and set zero. Use a suitable pry bar to check the input gear end float. Repeat for the other gear assemblies.



Illustration 175

g06695900



#### Illustration 176

g06695903

- 20. Remove six bolts (178).
- **21.** Use two people to position the front case assembly. The weight of the front case assembly is approximately 25 kg (55 lb). Calculate the required shim size to give the correct end float for each gear assembly.
- **22.** Install the shims behind each bearing cups (179). Use Tooling (U) to hold the bearing cups in place during installation of the front case assembly.



Illustration 177

- **23.** Use two people to install the front case assembly. The weight of the front case assembly is approximately 25 kg (55 lb).
- 24. Install the front case assembly and six bolts (178). Tighten bolts (178) in a star pattern to a torque of 45 to 64 N·m (33 to 47 lb ft).



Illustration 178

g06695902

**25.** Reinstall Tooling (V) with the head machined to a flat surface into the input gear. Set up Tooling (V) as shown in Illustration 178 and set to zero. Use a suitable pry bar to recheck the input gear assembly end float. Repeat for the other gear assemblies.

**26.** Repeat Step 12 through Step 25 until the correct end float of 0.025 to 0.076 mm (0.0009 to 0.0029 inch) is achieved.



Illustration 179

g06695907

27. Remove the front case assembly (not shown). Apply a thin layer of Tooling (W) to the rear case assembly.



Illustration 180

g06695910

28. Install the front case assembly and bolts (178). Tighten bolts (178) in star pattern to a torque of 45 to 64 N·m (33 to 47 lb ft).

### M0107105



Illustration 181

g06695913

**29.** Use Tooling (K) to install plugs (181). Install three plugs (181).



Illustration 182

g06696405



Illustration 183

g06694212

- 30. Attach a suitable lifting device to transfer case (4). The weight of transfer case (4) is approximately 73 kg (161 lb). Position transfer case (4) as shown in Illustration 183.
- **31.** Install spacer (175), yoke assembly (176), and O-ring (177).



Illustration 184

- **32.** Install washer (174) and bolt (173). Tighten bolt (173) to a torque of 68 to 88 N·m (50 to 65 lb ft).
- **33.** Repeat Step 31 and Step 32 for the other side.



Illustration 185

g06694209

34. Install vent (172) onto transfer case (4).

# First / Second clutch Assembly



Illustration 186

g06696408



Illustration 187

g06697697

- **1.** Lubricate the piston seals with new transmission oil.
- 2. Install piston (171).



g06694205



Illustration 189

g06694207

## \Lambda WARNING

Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.

**Note:** Ensure that the flat surface of the retaining ring is facing up.

 Install the spring retainer and spring assembly (169). Use Tooling (P) and a suitable press to compress spring assembly (169). Use Tooling (J) to install retaining ring (170). Compress spring assembly (169) and install retaining ring (170).



Illustration 190

g06694203

**4.** Lubricate friction discs (168) and clutch discs (167) with new transmission oil. Install friction discs (168) and clutch discs (167) alternately.



Illustration 191

#### g06694202

5. Install retainer plate (166) and retaining ring (165).



g06694201

**Note:** Ensure the groove of thrust bearing (163) is facing thrust washer (164).

- **6.** Install thrust washer (164) and thrust bearing (163).
- 7. Install bearings (162) and (161).



Illustration 193

g06697780

8. Install gear assembly (160).



Illustration 194

g06697777

**Note:** Ensure the groove of thrust bearing (159) is facing thrust washer (158).

- **9.** Install thrust bearing (159) and thrust washer (158).
- **10.** Raise the temperature of bearing cone (157). Install bearing cone (157).



Illustration 195

g06694199

**11.** Install three O-ring seals (156).



g06697791



Illustration 197

g06694198

- **12.** Lubricate the piston seals with new transmission oil.
- 13. Install piston (155).



Illustration 198

g06694192



Illustration 199

g06694193

# \Lambda WARNING

Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.

**Note:** Ensure that the flat surface of retaining ring (154) is facing up.

14. Install the spring retainer and spring assembly (153). Use Tooling (P) and a suitable press to compress spring assembly (153). Use Tooling (J) to install retaining ring (154). Compress spring assembly (153) and install retaining ring (154).



Illustration 200

g06694191

**15.** Lubricate friction discs (151) and clutch discs (152) with new transmission oil. Install friction discs (151) and clutch discs (152) alternately.



Illustration 201

g06694190

**16.** Install retainer plate (150) and retaining ring (149).



Illustration 202

g06697800

**Note:** Ensure the groove of thrust bearing (147) is facing thrust washer (148).

**17.** Install thrust washer (148) and thrust bearing (147).



Illustration 203

g06697802

**18.** Install bearings (146) and (145).



Illustration 204

g06694185

**19.** Install gear (144).



Illustration 206

g06697811

**21.** Apply Tooling (T) to the splines of the shaft. Raise the temperature of gear (140). Install gear (140).



Illustration 207

g06697812

**22.** Raise the temperature of bearing cone (139). Install bearing cone (139).

Illustration 205

**Note:** Ensure the groove of thrust bearing (143) is facing thrust washer (142).

**20.** Install thrust bearing (143), thrust washer (142), and spacer (141).



Illustration 208 Input shaft assembly

23. Install spacer (138).

# Forward low / Reverse clutch Assembly



Illustration 209

g06697861



Illustration 210

g06697867

- **1.** Lubricate the piston seals with new transmission oil.
- 2. Install piston (137).



g06694176



Illustration 212

g06694179

**Note:** Ensure that the flat surface of retaining ring (136) is facing up.

 Install the spring retainer and spring assembly (135). Use Tooling (P) and a suitable press to compress spring assembly (135). Use Tooling (J) to install retaining ring (136). Compress spring assembly (135) and install retaining ring (136).



Illustration 213

g06694175

**4.** Lubricate friction discs (133) and clutch discs (134) with new transmission oil. Install friction discs (133) and clutch discs (134) alternately.



Illustration 214

g06694174

5. Install retainer plate (132) and retaining ring (131).



g06694172

**Note:** Ensure the groove of thrust bearing (129) is facing thrust washer (130).

- **6.** Install thrust washer (130) and thrust bearing (129).
- 7. Install bearing (128) and (127).



Illustration 216

g06698079

8. Install gear assembly (126).



Illustration 217

g06698080

**Note:** Ensure the groove of thrust bearing (125) is facing thrust washer (124).

- **9.** Install thrust bearing (125) and thrust washer (124).
- **10.** Raise the temperature of bearing cone (123). Install bearing cone (123).



Illustration 218

g06694165

11. Install three ring seals (122).



g06698088



### Illustration 220

g06694163

- **12.** Lubricate the piston seals with new transmission oil.
- 13. Install piston (121).



Illustration 221

g06694159



Illustration 222

g06694160

# 

Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.

**Note:** Ensure that the flat surface of retaining ring (120) is facing up.

14. Install the spring retainer and spring assembly (119). Use Tooling (P) and a suitable press to compress spring assembly (119). Use Tooling (J) to install retaining ring (120). Compress spring assembly (119) and install retaining ring (120).



Illustration 223

g06694158

**15.** Lubricate friction discs (117) and clutch discs (118) with new transmission oil. Install friction discs (117) and clutch discs (118) alternately.



Illustration 224

g06694136

**16.** Install retainer plate (116) and retaining ring (115).



Illustration 225

g06694135

**Note:** Ensure the groove of thrust bearing (113) is facing thrust washer (114).

- **17.** Install thrust washer (114) and thrust bearing (113).
- **18.** Install bearings (112) and (111).



Illustration 226

g06698098

**19.** Install gear assembly (110).



Illustration 227

**Note:** Ensure the groove of thrust bearing (109) is facing thrust washer (108).

- **20.** Install thrust bearing (109) and thrust washer (108).
- **21.** Raise the temperature of bearing cone (107). Install bearing cone (107).



Illustration 229

g06698104

# 

To avoid personal injury, always wear eye and face protection when using pressurized air.

**23.** Use an air line with a low pressure supply as shown in Illustration 229 . Pressurize the forward low and reverse clutches to check operation of the clutches.



Illustration 228

g06694131

22. Install ring seal (106).

# Forward high / Third clutch Assembly





Illustration 232

g06694113



Illustration 233

g06694117

# 

Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.

Note: Ensure that the flat surface of retaining ring (104) is facing up.

Illustration 230

g06698105



### Illustration 231

Forward high/third clutch shaft assembly

- 1. Lubricate the piston seals with new transmission oil.
- 2. Install piston (105).

 Install the spring retainer and spring assembly (103). Use Tooling (P) and a suitable press to compress spring assembly (103). Use Tooling (J) to install retaining ring (104). Compress spring assembly (103) and install retaining ring (104).



Illustration 234

g06698110

**4.** Raise the temperature of the bearing cone (102). Install bearing cone (102).



Illustration 235

g06694108

**5.** Lubricate clutch discs (100) and friction discs (101) with new transmission oil. Install clutch discs (100) and friction discs (101) alternately.



Illustration 236

g06694105

7. Install retainer plate (98) and retaining ring (97).



Illustration 237

g06694102

**8.** Lower the temperature of the bearing cups. Install the bearing cups.

6. Install spacer (99).



Illustration 238

9. Install gear assembly (96).



Illustration 239

g06698120



Illustration 240

g06698121

**10.** Raise the temperature of bearing cones (95) and (94). Install bearing cones (95) and (94).


g06698123



Illustration 242

g06698124

- **11.** Lubricate the piston seals with new transmission oil.
- **12.** Install piston (93).



Illustration 243

g06694091



Illustration 244

g06694095

## 🏠 WARNING

Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.

**Note:** Ensure that the flat surface of retaining ring (92) is facing up.

**13.** Install the spring retainer and spring assembly (91). Use Tooling (P) and a suitable press to compress spring assembly (91). Use Tooling (J) to install retaining ring (92). Compress spring assembly (91) and install retaining ring (92).



Illustration 245

g06694088

**14.** Lubricate friction discs (89) and clutch discs (90) with new transmission oil. Install friction discs (89) and clutch discs (90) alternately.



Illustration 246

g06694086

15. Install retainer plate (88) and retaining ring (87).



Illustration 247

g06694081

**Note:** Ensure the groove of thrust bearing (85) is facing thrust washer (86).

- 16. Install thrust washer (86) and thrust bearing (85).
- 17. Install bearings (84) and (83).



Illustration 248

g06698127

18. Install gear (82).



g06698128



Illustration 250

g06698129

**Note:** Ensure the groove of thrust bearing (81) is facing thrust washer (80).

**19.** Install thrust bearing (81) and thrust washer (80).



Illustration 251

g06698130

**20.** Install spacer (79). Apply Tooling (T) to the splines of the shaft. Raise the temperature of gear (78). Install gear (78).



Illustration 252

g06698131

**21.** Raise the temperature of bearing cone (77). Install bearing cone (77).



Illustration 253

22. Install three ring seals (76).



Illustration 254

g06698133



Illustration 255

g06698134

# 

To avoid personal injury, always wear eye and face protection when using pressurized air.

**23.** Use air line with a low pressure as shown in Illustration 254 and Illustration 255. Pressurize the forward high and third clutch to check operation of the clutches.

## **Output shaft Assembly**





Illustration 258

g06698161

Illustration 256 Output shaft

g06698156

**1.** Apply Tooling (T) to the splines of the output shaft. Raise the temperature of the gear (74). Install gear (74) onto the output shaft.



Illustration 257

g06698159

**2.** Raise the temperature of bearing cone (73). Install bearing cone (73) onto the output shaft.

**3.** Raise the temperature of bearing cone (75). Install bearing cone (75) onto the output shaft.



Illustration 259

g06694054

**Note:** Prepare the transmission intermediate case assembly and the rear case assembly for assembly by removing all sealant from the matting surfaces.

**4.** Lower the temperature of bearing cups (72). Install bearing cups (72).



g06694051



Illustration 261

g06694048

**5.** Install idler gear (70) and the spacer into the rear of the intermediate case assembly. Install bearing cone (71) into the front of the intermediate case assembly.



Illustration 262

g06694042



Illustration 263

g06694045

6. Use Tooling (L) and a suitable pry bar to hold the reverse idler gear. Install washers (69), (68), and bolt (67). Tighten bolt (67) to a torque of 68 to 88 N⋅m (50 to 65 lb ft).

M0107105



g06694039



Illustration 265

g06698169

 Attach Tooling (A) and a suitable lifting device to intermediate case assembly (35). The weight of intermediate case assembly (35) is approximately 108 kg (238 lb). Position intermediate case assembly (35) as shown in Illustration 264.



Illustration 266

g06698171

8. Use Tooling (V) to check the reverse idler gear end float. Spacer installed in Step 5 may need swapped with a different spacer to achieve the proper end float of 0.025 to 0.076 mm (0.001 to 0.003 inch).



Illustration 267

g06698180

- **9.** Raise the temperature of bearing race (66). Install bearing race (66).
- 10. Install O-ring seal (64) onto support shaft (65).



Illustration 268

g06694027

- 11. Use Tooling (K) (not shown) to install needle bearing (62). Install needle bearing (62).
- 12. Install support shaft assembly (61).

Note: Ensure proper orientation of oil passages while installation of stator support hub (60).

13. Install stator support hub (60) and five bolts (63). Tighten five bolts (63) to a torque of 18 to 31 N·m (159 to 274 lb in).



14. Install thrust washer (59) onto gear assembly (52). Use Tooling (H) (not shown) to install retaining ring (58). Install retaining ring (58).

15. Repeat Step 14 for the opposite side of gear assembly (52).



Illustration 270

g06698185

16. Raise the temperature of idler gear (51) and install bearing (57). Use Tooling (J) (not shown) to install retaining ring (56). Install retaining ring (56).



Illustration 271

**17.** Use Tooling (K) (not shown) to install bushing (55). Install bushing (55) into gear assembly (53).



Illustration 272

g06694021

18. Install O-ring seal (54) onto gear assembly (53).



Illustration 273

#### g06694020

19. Install gear assembly (52).

20. Install gear assembly (51) and the spacer.

**Note:** Ensure correct orientation of thrust washer (50).

21. Install gear assembly (53) and thrust washer (50).



Illustration 274

g06694018

**Note:** Ensure the correct orientation of lip seal (48) from disassembly procedure.

**22.** Install four O-ring seals (49). Use Tooling (K) (not shown) to install lip seal (48). Install lip seal (48).



g06694014

- 23. Install transmission filter (47).
- **24.** Install the O-ring seals, adapter (45), and sensor (46).



Illustration 276

g06694012



Illustration 277

g06694011

- **25.** Use Tooling (K) (not shown) to install needle bearing (44) and bushing (43). Install needle bearing (44) and bushing (43) onto torque converter housing (41).
- **26.** Use two people to position torque converter housing (41). The weight of torque converter housing (41) is approximately 25 kg (55 lb). Use Tooling (K) (not shown) to install seal (42). Install seal (42).



g06698206



Illustration 279

g06694009

- **27.** Apply a thin layer of Tooling (W) to intermediate case assembly (35).
- 28. Attach Tooling (A) and a suitable lifting device to torque converter housing (41). The weight of torque converter housing (41) is approximately 25 kg (55 lb). Install torque converter housing (41).



Illustration 280

g06694006

29. Install 15 bolts (40) onto torque converter housing (41). Tighten 15 bolts (40) to a torque of 40 to 64 N·m (30 to 47 lb ft).



Illustration 281

g06694002

- 30. Install solenoid valve (39) and screw (38). Tighten screw (38) to a torque of 18 to 31 N⋅m (159 to 274 lb in).
- 31. Install solenoid valve assembly (37) and four bolts (36). Tighten four bolts (36) to a torque of 7 to 10 N⋅m (70 to 89 lb in).





g06694001



Illustration 283

g06693999

- **32.** Attach Tooling (A) and a suitable lifting device to intermediate case assembly (35). The weight of intermediate case assembly (35) is approximately 108 kg (238 lb). Position intermediate case assembly (35) onto suitable cribbing. Remove Tooling (A) and a suitable lifting device.
- **33.** Attach Tooling (A) and a suitable lifting device onto intermediate case assembly (35) as shown in Illustration 283 . Position intermediate case assembly (35) onto Tooling (D). Use Tooling (E) to secure intermediate case assembly (35).



Illustration 284

g06693998

**Note:** Keep checking the gear rotate freely during tightening procedure.

34. Install pump (33) and four bolts (32). Tighten four bolts (32) to a torque of 18 to 21 N⋅m (159 to 186 lb in).

35. Install O-ring seal (34).

## **Relief Valve Assembly**



Illustration 285 Relief valve g06694313

1. Install O-ring seals (241) onto relief valve (30).



Illustration 286 Relief valve g06694312

2. Install O-ring seals (240) onto relief valve (31).



Illustration 287

q06693995

- 3. Install relief valve (31). Tighten relief valve (31) to a torque of 46 to 60 N·m (34 to 44 lb ft).
- 4. Install relief valve (30). Tighten relief valve (30) to a torque of 23 to 30 N·m (204 to 266 lb in).
- 5. Install pump housing (29) and four bolts (28). Tighten four bolts (28) to a torque of 68 to 88 N·m (50 to 65 lb ft).



Illustration 288

g06693922

- 6. Install solenoid valve (24) and screw (25). Tighten screw (25) to a torque of 18 to 31 N·m (159 to 274 lb in). Repeat for the other solenoid valve.
- 7. Install solenoid valve assembly (27) and four bolts (26). Tighten four bolts (26) to a torque of 7 to 10 N·m (62 to 89 lb in).



Illustration 289

g06693919

8. Install O-ring seals (23) onto suction strainer assembly (20).



Illustration 290



**12.** Lower the temperature of bearing cups (18). Install bearing cups (18).



Illustration 293 First/second clutch assembly

13. Attach Tooling (F) and a suitable lifting device to clutch assembly (17). The weight of clutch assembly (17) is approximately 20 kg (44 lb). Install clutch assembly (17).



Illustration 291

g06693915

- 10. Install suction strainer assembly (20) and the three bolts. Tighten the three bolts to a torque of 18 to 31 N·m (159 to 274 lb in).
- 11. Install tube assembly (19) and gauge assembly (21).

M0107105



Illustration 292

9. Install O-ring seal (22) onto tube assembly (19).



Illustration 294 Input shaft assembly g06693905

Note: Be aware of possible pinch points during installation.

14. Install input shaft (16).



Illustration 295

g06693902

- Forward high/third clutch assembly
- 15. Attach Tooling (F) and suitable lifting device to clutch assembly (15). The weight clutch assembly (15) is approximately 23 kg (51 lb). Install clutch assembly (15).



Illustration 296 Output shaft assembly g06693901

16. Attach Tooling (F) and a suitable lifting device to output shaft assembly (14). Install output shaft assembly (14).



Illustration 297

g06698236

17. Use Tooling (K) to remove the three bearing cup plugs. Apply Tooling (U) onto rear case assembly (11) where the three bearing cups are installed. Lower the temperature of the three bearing cups and install the three bearing cups without the shims.



g06698244

**18.** Attach Tooling (A) and a suitable lifting device to rear case assembly (11). Position rear case assembly (11) onto suitable cribbing.



Illustration 299

g06698246



Illustration 300

g06698251

- **19.** Attach Tooling (A), Tooling (B), and a suitable lifting device to rear case assembly (11).
- 20. Install rear case assembly (11) onto the intermediate case assembly. Install 6 bolts (12) evenly spaced. Tighten six bolts (12) to a torque of 45 to 64 N·m (33 to 47 lb ft).



Illustration 301

- **21.** Install Tooling (V) with the head machined to a flat surface on the clutch assembly. Set up Tooling (V) as shown in Illustration 301.
- **22.** Check the bearing end float using a suitable pry bar. Repeat this step for the other clutch assemblies and output shaft assembly. Calculate the shim thickness needed to achieve 0.025 to 0.076 mm (0.0010 to 0.0030 inch) of end float for each of the clutch assemblies and the output shaft assembly.
- **23.** Remove Tooling (V).



Illustration 302

g06698268



Illustration 303

g06698273

24. Attach a suitable lifting device to rear case assembly (11). Remove 6 bolts (12) and rear case assembly (11). Position rear case assembly (11) onto suitable cribbing.





Illustration 304

- **25.** Remove the three bearing cups and install the shims calculated from Step21. Apply Tooling (U) to rear case assembly (11) where the bearing cups are installed. Install the bearing cups.
- **26.** Repeat Step 17 through Step 25 until the desired 0.025 to 0.076 mm (0.0010 to 0.0030 inch) end float is achieved on the 2 clutch assemblies and the output shaft assembly.



Illustration 306

g06698279

- 28. Install the two washers and the two bolts. Tighten the two bolts to a torque of 68 to 88 N⋅m (50 to 65 lb ft).
- **29.** Apply a thin coating of Tooling (W) to the intermediate case assembly as shown in Illustration 306.
- 30. Install three O-ring seals (13).



Illustration 305

g06698275

**27.** Use Tooling (K) to install three plugs. Install three plugs.



Illustration 307

**31.** Attach suitable lifting device to rear case assembly (11). The weight of rear case assembly (11) is approximately 50 kg (110 lb). Install rear case assembly (11), the ladder clips, and bolts (12). Tighten bolts (12) to a torque of 45 to 64 N·m (33 to 47 lb ft).



Illustration 308

g06693895

- **32.** Install the O-ring seal, adapter (8), and hose assembly (9).
- **33.** Install speed sensor (10) and the bolt. Tighten the bolt to a torque of 18 to 31 N⋅m (159 to 274 lb in).



Illustration 309

g06698311

- **34.** Attach Tooling (C), Tooling (B), and a suitable lifting device to transmission (7). The weight of transmission (7) is approximately 154 kg (340 lb).
- **35.** Remove Tooling (E) from the transmission stand.
- **36.** Rotate the transmission (7) 90 degrees to a VERTICAL position. Position transmission (7) onto suitable cribbing.



Illustration 310

g06693887

**37.** Remove Tooling (B) (not shown) and Tooling (C) (not shown). Attach Tooling (A) and a suitable lifting device to transmission (7).

**38.** Lift transmission (7) using suitable lifting device attached to the top of the torque converter housing. Use two lifting device attached near bottom of the torque converter housing to rotate transmission (7) 90 degree. Rotate transmission (7) 90 degree and position transmission (7) onto suitable bench or cribbing.



Illustration 311

g06693883

**39.** Attach Tooling (A) and a suitable lifting device to torque converter (6). The weight of torque converter (6) is approximately 20 kg (44 lb). Install torque converter (6).



Illustration 312

g06698337

**40.** Install the two cable straps to keep torque converter (6) stable during the installation of the transmission.



Illustration 313

g06698350

**41.** Apply a thin layer of Tooling (W) to the mating surface of the transfer case.







Illustration 315

g06693879

- **42.** Attach a suitable lifting device to transfer case (4). The weight of transfer case (4) is approximately 73 kg (161 lb). Install transfer case (4) and six bolts (5).
- **43.** Attach Tooling (A) and a suitable lifting device to transmission assembly (3). The weight of transmission assembly (3) is approximately 247 kg (545 lb). Position transmission assembly (3) 90 degree and place onto suitable jack stands.



Illustration 316

g06698364

**44.** Tighten six bolts (5) to a torque of 200 to 280 N⋅m (148 to 207 lb ft).



Illustration 317

g06693862

- **45.** Attach a suitable lifting device to pump (1). The weight of pump (1) is approximately 41 kg (90 lb). Install the O-ring seal onto pump (1).
- 46. Install pump (1) and two bolts (2). Tighten bolts (2) to a torque of 68 to 88 N⋅m (50 to 65 lb ft).

#### End By:

a. Install the transmission.

#### M0107105

# Index

## D

Disassembly and Assembly Section4
5

## I

Important Safety Information	2
------------------------------	---

#### т

Table of Contents Transmission - Assemble Assembly Procedure	3 45 45
First / Second clutch Assembly	45
Forward high / Third clutch Assembly	70
Forward low / Reverse clutch Assembly	64
Modulating Solenoid Valve Assembly	48
Output shaft Assembly	77
Relief Valve Assembly	84
Transfer Case Assembly	51
Transmission - Disassemble	4
Disassembly Procedure	4
Dual modulating valve disassembly	41
First/second clutch disassembly	28
Forward high/third clutch disassembly	17
Forward low/reverse clutch disassembly	22
Modulating solenoid valve disassembly	38
Output shaft disassembly	16
References	4
Relief valve disassembly	44
Transfer case disassembly	34

M0107105 ©2021 Caterpillar All Rights Reserved CAT, CATERPILLAR, LET'S DO THE WORK, their respective logos, "Caterpillar Corporate Yellow", the "Power Edge" and Cat "Modern Hex" trade dress as well as corporate and product identity used herein, are trademarks of Caterpillar and may not be used without permission.

