M0108394-08 (en-us) July 2022



# Operation and Maintenance Manual

## **C3.6 and C2.8 Industrial Engines**

J37 1-UP (Engine) J29 1-UP (Engine)



Scan to find and purchase genuine Cat<sup>®</sup> parts and related service information.



#### Important Safety Information

Most accidents that involve product operation, maintenance and repair are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. A person must be alert to potential hazards, including human factors that can affect safety. This person should also have the necessary training, skills and tools to perform these functions properly.

## Improper operation, lubrication, maintenance or repair of this product can be dangerous and could result in injury or death.

## Do not operate or perform any lubrication, maintenance or repair on this product, until you verify that you are authorized to perform this work, and have read and understood the operation, lubrication, maintenance and repair information.

Safety precautions and warnings are provided in this manual and on the product. If these hazard warnings are not heeded, bodily injury or death could occur to you or to other persons.

The hazards are identified by the "Safety Alert Symbol" and followed by a "Signal Word" such as "DANGER", "WARNING" or "CAUTION". The Safety Alert "WARNING" label is shown below.

The meaning of this safety alert symbol is as follows:

#### Attention! Become Alert! Your Safety is Involved.

The message that appears under the warning explains the hazard and can be either written or pictorially presented.

A non-exhaustive list of operations that may cause product damage are identified by "NOTICE" labels on the product and in this publication.

Caterpillar cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this publication and on the product are, therefore, not all inclusive. You must not use this product in any manner different from that considered by this manual without first satisfying yourself that you have considered all safety rules and precautions applicable to the operation of the product in the location of use, including site-specific rules and precautions applicable to the worksite. If a tool, procedure, work method or operating technique that is not specifically recommended by Caterpillar is used, you must satisfy yourself that it is safe for you and for others. You should also ensure that you are authorized to perform this work, and that the product will not be damaged or become unsafe by the operation, lubrication, maintenance or repair procedures that you intend to use.

The information, specifications, and illustrations in this publication are on the basis of information that was available at the time that the publication was written. The specifications, torques, pressures, measurements, adjustments, illustrations, and other items can change at any time. These changes can affect the service that is given to the product. Obtain the complete and most current information before you start any job. Cat dealers have the most current information available.

#### NOTICE

When replacement parts are required for this product Caterpillar recommends using original Caterpillar® replacement parts.

Other parts may not meet certain original equipment specifications.

When replacement parts are installed, the machine owner/user should ensure that the machine remains in compliance with all applicable requirements.

In the United States, the maintenance, replacement, or repair of the emission control devices and systems may be performed by any repair establishment or individual of the owner's choosing.

## **Table of Contents**

Foreword	4
Safety Section	
Safety Messages	6
Safety Messages	10
Safety Messages	13
Additional Messages	16
General Hazard Information	17
Burn Prevention	21
Fire Prevention and Explosion Prevention	23
Crushing Prevention and Cutting Prevention.	25
Mounting and Dismounting	25
High Pressure Fuel Lines	25
Before Starting Engine	27
Engine Starting	27
Engine Stopping	28
Electrical System	28
Engine Electronics	29
Product Information Section	
General Information	31
Product Identification Information	47
Operation Section	
Lifting and Storage	49
Features and Controls	53
Engine Diagnostics	67
Engine Starting	69

Engine Operation73	3
Aftertreatment Operation76	6
Cold Weather Operation83	3
Engine Stopping 88	8
Maintenance Section	
Maintenance Recommendations	C
Refill Capacities93	3
Maintenance Interval Schedule	2
Warranty Section	
Warranty Information 150	0
Reference Information Section	
Engine Ratings 15 <sup>2</sup>	1
Customer Service 152	2
Reference Materials 153	3
Index Section	

## Foreword

#### California Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.



WARNING – This product can expose you to chemicals including ethylene glycol, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to:

www.P65Warnings.ca.gov

Do not ingest this chemical. Wash hands after handling to avoid incidental ingestion.



WARNING – This product can expose you to chemicals including lead and lead

compounds, which are known to the State of California to cause cancer, birth defects, or other reproductive harm. For more information go to:

www.P65Warnings.ca.gov

Wash hands after handling components that may contain lead.

#### Literature Information

This manual contains safety, operation instructions, lubrication, and maintenance information. This manual should be stored in or near the engine area in a literature holder or literature storage area. Read, study, and keep it with the literature and engine information.

English is the primary language for all Cat publications. The English used facilitates translation and consistency in electronic media delivery.

Some photographs or illustrations in this manual show details or attachments that may be different from your engine. Guards and covers may have been removed for illustrative purposes. Continuing improvement and advancement of product design may have caused changes to your engine which are not included in this manual Whenever a question arises regarding your engine, or this manual, please consult with your Cat dealer for the latest available information.

#### Safety

This safety section lists basic safety precautions. In addition, this section identifies hazardous, warning situations. Read and understand the basic precautions listed in the safety section before operating or performing lubrication, maintenance, and repair on this product.

#### Operation

Operating techniques outlined in this manual are basic. They assist with developing the skills and techniques required to operate the engine more efficiently and economically. Skill and techniques develop as the operator gains knowledge of the engine and its capabilities.

The operation section is a reference for operators. Photographs and illustrations guide the operator through procedures of inspecting, starting, operating, and stopping the engine. This section also includes a discussion of electronic diagnostic information.

#### Maintenance

The maintenance section is a guide to engine care. The illustrated, step-by-step instructions are grouped by fuel consumption, service hours and/or calendar time maintenance intervals. Items in the maintenance schedule are referenced to detailed instructions that follow.

Use fuel consumption or service hours to determine intervals. Calendar intervals shown (daily, annually, etc.) may be used instead of service meter intervals if they provide more convenient schedules and approximate the indicated service meter reading.

Recommended service should be performed at the appropriate intervals as indicated in the Maintenance Interval Schedule. The actual operating environment of the engine also governs the Maintenance Interval Schedule. Therefore, under severe, dusty, wet, or freezing cold operating conditions, more frequent lubrication, and maintenance than is specified in the Maintenance Interval Schedule may be necessary.

The maintenance schedule items are organized for a preventive maintenance management program. If the preventive maintenance program is followed, a periodic tune-up is not required. The implementation of a preventive maintenance management program should minimize operating costs through cost avoidances resulting from reductions in unscheduled downtime and failures.

#### **Maintenance Intervals**

Perform maintenance on items at multiples of the original requirement. Each level and/or individual items in each level should be shifted ahead or back depending upon your specific maintenance practices, operation, and application. We recommend that the maintenance schedules be reproduced and displayed near the engine as a convenient reminder. We also recommend that a maintenance record be maintained as part of the engine's permanent record.

See the section in the Operation and Maintenance Manual, "Maintenance Records" for information regarding documents that are accepted as proof of maintenance or repair. Your authorized Cat dealer can assist you in adjusting your maintenance schedule to meet the needs of your operating environment.

#### Overhaul

Major engine overhaul details are not covered in the Operation and Maintenance Manual except for the interval and the maintenance items in that interval. Major repairs are best left to trained personnel or an authorized Cat dealer. Your Cat dealer offers various options regarding overhaul programs. If you experience a major engine failure, there are also numerous after failure overhaul options available from your Cat dealer. Consult with your dealer for information regarding these options. i07853993

## **Safety Messages**

SMCS Code: 1000; 7405

There may be several specific warning signs on your engine. The exact location and a description of the warning signs are reviewed in this section. Ensure that you are familiar with all warning signs.

Ensure that all the warning signs are legible. Clean the warning signs or replace the warning signs if the words cannot be read or if the illustrations are not visible. Use a cloth, water, and soap to clean the warning signs. Do not use solvents, gasoline, or other harsh chemicals. Solvents, gasoline, or harsh chemicals could loosen the adhesive that secures the warning signs. The warning signs that are loosened could drop off the engine.

Replace any warning sign that is damaged or missing. If a warning sign is attached to a part of the engine that is replaced, install a new warning sign on the replacement part. Your Caterpillar dealer can provide new warning signs.

## C3.6 Industrial Engine




Illustration 1 Typical example

(1) Universal Warning label

(2) Hand (High Pressure) Warning label

#### **C2.8 Industrial Engine**




Illustration 2 Typical example

(1) Universal Warning label

#### **Universal Warning**

#### A WARNING

Do not operate or work on this equipment unless you have read and understand the instructions and warnings in the Operation and Maintenance Manuals. Failure to follow the instructions or heed the warnings could result in serious injury or death.




Illustration 3 Typical example g01154807

The universal warning labels are located in two positions. One label is on the front over the engine, the other label is on the right side of the engine.

#### Hand (High Pressure)

## 

Contact with high pressure fuel may cause fluid penetration and burn hazards. High pressure fuel spray may cause a fire hazard. Failure to follow these inspection, maintenance and service instructions may cause personal injury or death.




Illustration 4 Typical example

The hand high-pressure label is on the high-pressure fuel line between pump and manifold, on the right side of the engine.

#### **Ether Warning**

#### 

Do not use aerosol types of starting aids such as ether. Such use could result in an explosion and personal injury. A WARNING

Illustration 5
Typical example

g01154809

g02382677

The ether warning label is installed on the air cleaner close to the intake. The location will depend on the application. In some applications, the ether label will be supplied loose for fitting by the engine installer.

i08067908

## **Safety Messages**

SMCS Code: 1000; 7405

There may be several specific warning signs on your engine. The exact location and a description of the warning signs are reviewed in this section. Ensure that you are familiar with all warning signs.

Ensure that all the warning signs are legible. Clean the warning signs or replace the warning signs if the words cannot be read or if the illustrations are not visible. Use a cloth, water, and soap to clean the warning signs. Do not use solvents, gasoline, or other harsh chemicals. Solvents, gasoline, or harsh chemicals could loosen the adhesive that secures the warning signs. The warning signs that are loosened could drop off the engine.

Replace any warning sign that is damaged or missing. If a warning sign is attached to a part of the engine that is replaced, install a new warning sign on the replacement part. Your Caterpillar dealer can provide new warning signs.

#### C3.6 Industrial Engine With A **Balancer**




Illustration 6

Typical example


(1) Universal Warning label

(2) Hand (High Pressure) Warning label

## **Universal Warning 1**

#### 

Do not operate or work on this equipment unless you have read and understand the instructions and warnings in the Operation and Maintenance Manuals. Failure to follow the instructions or heed the warnings could result in serious injury or death.



The universal warning labels are located in two positions. One label is on the front over the engine, the other label is on the right side of the engine.

### Hand (High Pressure) 2

## 

Contact with high pressure fuel may cause fluid penetration and burn hazards. High pressure fuel spray may cause a fire hazard. Failure to follow these inspection, maintenance and service instructions may cause personal injury or death.




Illustration 8 Typical example

The hand high-pressure label is on the high-pressure fuel line between pump and manifold, on the right side of the engine.

#### **Ether Warning**

#### 

Do not use aerosol types of starting aids such as ether. Such use could result in an explosion and personal injury.



Illustration 9 Typical example g01154809

g02382677

The ether warning label is installed on the air cleaner close to the intake. The location will depend on the application. In some applications, the ether label will be supplied loose for fitting by the engine installer.

i09430650

#### **Safety Messages**

SMCS Code: 1000; 7405

There may be several specific warning signs on your engine. The exact location and a description of the warning signs are reviewed in this section. Ensure that you are familiar with all warning signs.

Ensure that all the warning signs are legible. Clean the warning signs or replace the warning signs if the words cannot be read or if the illustrations are not visible. Use a cloth, water, and soap to clean the warning signs. Do not use solvents, gasoline, or other harsh chemicals. Solvents, gasoline, or harsh chemicals could loosen the adhesive that secures the warning signs. The warning signs that are loosened could drop off the engine.

Replace any warning sign that is damaged or missing. If a warning sign is attached to a part of the engine that is replaced, install a new warning sign on the replacement part. Your Caterpillar dealer can provide new warning signs.

#### C3.6 Open Power Unit (OPU)




Illustration 10
Typical example

g06737415

### **Universal Warning 1**

#### 

Do not operate or work on this equipment unless you have read and understand the instructions and warnings in the Operation and Maintenance Manuals. Failure to follow the instructions or heed the warnings could result in serious injury or death.



Illustration 11 Typical example g01154807

The universal warning labels are located in two positions. One label is on the front over the engine, the other label is on the right side of the engine.

#### **Hot Fluid Under Pressure 2**



Illustration 12

g01371640

#### 

Pressurized system! Hot coolant can cause serious burns, injury or death. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure. Read and understand the Operation and Maintenance Manual before performing any cooling system maintenance.

The hot fluids under pressure label is installed on the radiator cover next to the coolant filler cap.

#### Hand (High Pressure) 3

#### 

Contact with high pressure fuel may cause fluid penetration and burn hazards. High pressure fuel spray may cause a fire hazard. Failure to follow these inspection, maintenance and service instructions may cause personal injury or death.



Illustration 13

Typical example

The hand high-pressure label is on the high-pressure fuel line between pump and manifold, on the right side of the engine.

#### **Ether Warning**



Do not use aerosol types of starting aids such as ether. Such use could result in an explosion and personal injury.



Illustration 14 Typical example g01154809

The ether warning label is installed on the air cleaner close to the intake. The location will depend on the application. In some applications, the ether label will be supplied loose for fitting by the engine installer.

i07672517

g02382677

## **Additional Messages**

SMCS Code: 1000; 7405

There are several specific messages on this engine. The exact location of the messages and the description of the information are reviewed in this section. Become familiar with all messages.

Make sure that all the messages are legible. Clean the messages or replace the messages if you cannot read the words. Replace the illustrations if the illustrations are not legible. When you clean the messages, use a cloth, water, and soap. Do not use solvent, gasoline, or other harsh chemicals to clean the messages. Solvents, gasoline, or harsh chemicals could loosen the adhesive that secures the messages. Loose adhesive will allow the messages to fall.

Replace any message that is damaged, or missing. If a message is attached to a part that is replaced, install a message on the replacement part. Any Caterpillar dealer can provide new messages.




Illustration 15

g03422039

Purge notice message

This notice should be located next to the battery disconnect switch.

NOTICE Do not turn the battery power disconnect switch off until indicator lamp has turned off. If the switch is turned off when the light is illuminated then the DEF system will not purge and DEF could freeze and cause damage to the pump and lines.

i08461421

## **General Hazard Information**

SMCS Code: 1000; 4450; 7405




Illustration 16

g00104545

Attach a "Do Not Operate" warning tag or a similar warning tag to the start switch or to the controls before the engine is serviced or before the engine is repaired. These warning tags (Special Instruction, SEHS7332) are available from your Caterpillar dealer. Attach the warning tags to the engine and to each operator control station. When appropriate, disconnect the starting controls. Excessive idling of the engine in cold ambient temperatures could result in the breather freezing. The breather freezing can cause leaks & component failure, which can be harmful to the engine.

Do not allow unauthorized personnel on the engine, or around the engine when the engine is being serviced.

- Tampering with the engine installation or tampering with the OEM supplied wiring can be dangerous. Personal injury, death and/or engine damage could result.
- Vent the engine exhaust to the outside when the engine is operated in an enclosed area.
- If the engine is not running, do not release the secondary brake or the parking brake systems unless the vehicle is blocked or unless the vehicle is restrained.
- Wear a hard hat, protective glasses, and other protective equipment, as required.
- When working around an engine, the engine must not be in operation. You may only be near a running engine to carry out maintenance procedures that require the engine to be in operation. When work is performed around an engine that is operating, wear protective devices for ears to help prevent damage to hearing.
- Do not wear loose clothing or jewelry that can snag on controls or on other parts of the engine.
- Ensure that all protective guards and all covers are secured in place on the engine.
- Never put maintenance fluids into glass containers. Glass containers can break.
- Use all cleaning solutions with care.
- · Report all necessary repairs.

Unless other instructions are provided, perform the maintenance under the following conditions:

- The engine is stopped. Ensure that the engine cannot be started.
- The protective locks or the controls are in the applied position.
- Engage the secondary brakes or parking brakes.
- Block the vehicle or restrain the vehicle before maintenance or repairs are performed.

- Disconnect the batteries when maintenance is performed or when the electrical system is serviced. Disconnect the battery ground leads.
   Tape the leads to help prevent sparks. If equipped, allow the diesel exhaust fluid to be purged before disconnecting the battery.
- If equipped, disconnect the connectors for the unit injectors that are on the valve cover base. This action will help prevent personal injury from the high voltage to the unit injectors. Do not come in contact with the unit injector terminals while the engine is operating.
- Do not attempt any repairs or any adjustments to the engine while the engine is operating.
- Do not attempt any repairs that are not understood. Use the proper tools. Replace any equipment that is damaged or repair the equipment.
- For initial start-up of a new engine or for starting an engine that has been serviced, make provisions to stop the engine if an overspeed occurs. The stopping of the engine may be accomplished by shutting off the fuel supply and/ or the air supply to the engine. Ensure that only the fuel supply line is shut off. Ensure that the fuel return line is open.
- Start the engine from the operators station (cab). Never short across the starting motor terminals or the batteries. This action could bypass the engine neutral start system and/or the electrical system could be damaged.

Engine exhaust contains products of combustion which may be harmful to your health. Always start the engine and operate the engine in a well-ventilated area. If the engine is in an enclosed area, vent the engine exhaust to the outside.

Cautiously remove the following parts. To help prevent spraying or splashing of pressurized fluids, hold a rag over the part that is being removed.

- Filler caps
- Grease fittings
- Pressure taps
- Breathers
- Drain plugs

Use caution when cover plates are removed. Gradually loosen, but do not remove the last two bolts or nuts that are at opposite ends of the cover plate or the device. Before removing the last two bolts or nuts, pry the cover loose to relieve any spring pressure or other pressure.




Illustration 17

g00702020

- Wear a hard hat, protective glasses, and other protective equipment, as required.
- Caterpillar recommends that you do not stand next to an exposed running engine unless it is necessary when carrying out daily checks or maintenance procedures. When work is performed around an engine that is operating, wear protective devices for ears to help prevent damage to hearing.
- Do not wear loose clothing or jewelry that can snag on controls or on other parts of the engine.
- Ensure that all protective guards and all covers are secured in place on the engine.
- Never put maintenance fluids into glass containers. Glass containers can break.
- · Use all cleaning solutions with care.
- Report all necessary repairs.

## Unless other instructions are provided, perform the maintenance under the following conditions:

- The engine is stopped. Ensure that the engine cannot be started.
- Disconnect the batteries when maintenance is performed or when the electrical system is serviced. Disconnect the battery ground leads. Tape the leads to help prevent sparks.
- Do not attempt any repairs that are not understood. Use the proper tools. Replace any equipment that is damaged or repair the equipment.

#### **Pressurized Air and Water**

Pressurized air and/or water can cause debris and/or hot water to be blown out. This action could result in personal injury. When pressurized air and/or pressurized water is used for cleaning, wear protective clothing, protective shoes, and eye protection. Eye protection includes goggles or a protective face shield.

The maximum air pressure for cleaning purposes must be below 205 kPa (30 psi). The maximum water pressure for cleaning purposes must be below 275 kPa (40 psi).

#### **Fluid Penetration**

Pressure can be trapped in the hydraulic circuit long after the engine has been stopped. The pressure can cause hydraulic fluid or items such as pipe plugs to escape rapidly if the pressure is not relieved correctly.

Do not remove any hydraulic components or parts until pressure has been relieved or personal injury may occur. Do not disassemble any hydraulic components or parts until pressure has been relieved or personal injury may occur. Refer to the OEM information for any procedures that are required to relieve the hydraulic pressure. Dispose of all fluids according to local regulations and mandates.

#### Static Electricity Hazard when Fueling with Ultra-low Sulfur Diesel Fuel

The removal of sulfur and other compounds in ultralow sulfur diesel fuel (ULSD fuel) decreases the conductivity of ULSD and increases the ability of ULSD to store static charge. Refineries may have treated the fuel with a static dissipating additive. Many factors can reduce the effectiveness of the additive over time. Static charges can build up in ULSD fuel while the fuel is flowing through fuel delivery systems. Static electricity discharge when combustible vapors are present could result in a fire or explosion. Ensure that the entire system used to refuel your machine (fuel supply tank, transfer pump, transfer hose, nozzle, and others) is properly grounded and bonded. Consult with your fuel or fuel system supplier to ensure that the delivery system complies with fueling standards for proper grounding and bonding.




Illustration 18

g00687600

Always use a board or cardboard when you check for a leak. Leaking fluid that is under pressure can penetrate body tissue. Fluid penetration can cause serious injury and possible death. A pin hole leak can cause severe injury. If fluid is injected into your skin, you must get treatment immediately. Seek treatment from a doctor that is familiar with this type of injury.

#### **Containing Fluid Spillage**

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting, and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Cat Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Cat products.

#### 

Avoid static electricity risk when fueling. Ultralow sulfur diesel fuel (ULSD fuel) poses a greater static ignition hazard than earlier diesel formulations with a higher sulfur contents. Avoid death or serious injury from fire or explosion. Consult with your fuel or fuel system supplier to ensure the delivery system is in compliance with fueling standards for proper grounding and bonding practices.

#### Inhalation




Illustration 19

g00702022

#### Exhaust

Use caution. Exhaust fumes can be hazardous to health. If you operate the equipment in an enclosed area, adequate ventilation is necessary.

#### **Hexavalent Chromium**

Caterpillar equipment and replacement parts comply with applicable regulations and requirements where originally sold. Caterpillar recommends the use of only genuine Caterpillar replacement parts.

Hexavalent chromium has occasionally been detected on exhaust and heat shield systems on Caterpillar engines. Although laboratory testing is the only accurate way to know if hexavalent chromium is, in fact, present, the presence of a yellow deposit in areas of high heat (for example, exhaust system components or exhaust insulation) may be an indication of the presence of hexavalent chromium.

Use caution if you suspect the presence of hexavalent chromium. Avoid skin contact when handling items that you suspect may contain hexavalent chromium, and avoid inhalation of any dust in the suspect area. Inhalation of, or skin contact with, hexavalent chromium dust may be hazardous to your health. If such yellow deposits are found on the engine, engine component parts, or associated equipment or packages, Caterpillar recommends following local health and safety regulations and guidelines, utilizing good hygiene, and adhering to safe work practices when handling the equipment or parts. Caterpillar also recommends the following:

- Wear appropriate Personal Protective Equipment (PPE)
- Wash your hands and face with soap and water prior to eating, drinking, or smoking, and also during rest room breaks, to prevent ingestion of any yellow powder
- Never use compressed air for cleaning areas suspected of containing hexavalent chromium
- Avoid brushing, grinding, or cutting materials suspected of containing hexavalent chromium
- Obey environmental regulations for the disposal of all materials that may contain or have come into contact with hexavalent chromium
- Stay away from areas that might have hexavalent chromium particles in the air.

#### Asbestos Information

Cat equipment and replacement parts that are shipped from Caterpillar are asbestos free. Caterpillar recommends the use of only genuine Cat replacement parts. Use the following guidelines when you handle any replacement parts that contain asbestos or when you handle asbestos debris.

Use caution. Avoid inhaling dust that might be generated when you handle components that contain asbestos fibers. Inhaling this dust can be hazardous to your health. The components that may contain asbestos fibers are brake pads, brake bands, lining material, clutch plates, and some gaskets. The asbestos that is used in these components is usually bound in a resin or sealed in some way. Normal handling is not hazardous unless airborne dust that contains asbestos is generated.

If dust that may contain asbestos is present, there are several guidelines that should be followed:

- · Never use compressed air for cleaning.
- · Avoid brushing materials that contain asbestos.
- Avoid grinding materials that contain asbestos.
- Use a wet method to clean up asbestos materials.
- A vacuum cleaner that is equipped with a high efficiency particulate air filter (HEPA) can also be used.

- Use exhaust ventilation on permanent machining jobs.
- Wear an approved respirator if there is no other way to control the dust.
- Comply with applicable rules and regulations for the work place. In the United States, use Occupational Safety and Health Administration (OSHA) requirements. These OSHA requirements can be found in "29 CFR 1910.1001".
- Obey environmental regulations for the disposal of asbestos.
- Stay away from areas that might have asbestos particles in the air.

#### **Dispose of Waste Properly**




Illustration 20

g00706404

Improperly disposing of waste can threaten the environment. Potentially harmful fluids should be disposed of in accordance with local regulations. Always use leakproof containers when you drain fluids. Do not pour waste onto the ground, down a drain, or into any source of water.

#### **Diesel Exhaust Fluid**

#### \Lambda WARNING

DEF is an aqueous solution of urea which can release ammonia vapors. Always wear the appropriate Personal Protective Equipment (PPE) that is noted on a material safety data sheet (MSDS) for Diesel Exhaust Fluid (DEF).

- · Do not inhale ammonia vapor or mist
- Do not eat, drink, or smoke in presence of DEF
- Avoid DEF contact with eyes, skin, and clothing
- Wash thoroughly after handling DEF

Always follow the directions for first aid that are noted on a material safety data sheet (MSDS) for Diesel Exhaust Fluid (DEF).

DEF is not expected to produce significant adverse health effects when the recommended instructions for use are followed.

- Draining DEF must be carried out in a wellventilated area.
- Do not allow the DEF to be spilled onto hot surfaces.

i07277507

## **Burn Prevention**

**SMCS Code:** 1000; 4450; 7405

Do not touch any part of an operating engine system. The engine, the exhaust, and the engine aftertreatment system can exceed 650° C (1202° F) under normal operating conditions.

Allow the engine system to cool before any maintenance is performed. Relieve all pressure in the air system, hydraulic system, lubrication system, fuel system, and the cooling system before the related items are disconnected.

#### 🏠 WARNING

Contact with high pressure fuel may cause fluid penetration and burn hazards. High pressure fuel spray may cause a fire hazard. Failure to follow these inspection, maintenance and service instructions may cause personal injury or death. After the engine has stopped, wait for 10 minutes to allow the fuel pressure to be purged from the highpressure fuel lines before any service or repair is performed on the engine fuel lines. The 10 minute wait will also allow static charge to dissipate from the low-pressure fuel system.

Allow the pressure to be purged in the air system, in the hydraulic system, in the lubrication system, or in the cooling system before any lines, fittings, or related items are disconnected.

#### **Induction System**

#### 

Sulfuric Acid Burn Hazard may cause serious personal injury or death.

The exhaust gas cooler may contain a small amount of sulfuric acid. The use of fuel with sulfur levels greater than 15 ppm may increase the amount of sulfuric acid formed. The sulfuric acid may spill from the cooler during service of the engine. The sulfuric acid will burn the eyes, skin and clothing on contact. Always wear the appropriate personal protective equipment (PPE) that is noted on a material safety data sheet (MSDS) for sulfuric acid. Always follow the directions for first aid that are noted on a material safety data sheet (MSDS) for sulfuric acid.

#### Coolant

When the engine is at operating temperature, the engine coolant is hot. The coolant is also under pressure. The radiator and all lines to the heaters, aftertreatment system or to the engine contain hot coolant.

Any contact with hot coolant or with steam can cause severe burns. Allow cooling system components to cool before the cooling system is drained.

Check the coolant level after the engine has stopped and the engine has been allowed to cool.

Ensure that the filler cap is cool before removing the filler cap. The filler cap must be cool enough to touch with a bare hand. Remove the filler cap slowly to relieve pressure.

Cooling system conditioner contains alkali. Alkali can cause personal injury. Do not allow alkali to contact the skin, the eyes, or the mouth.

#### Oils

Skin may be irritated following repeated or prolonged exposure to mineral and synthetic base oils. Refer to your suppliers Material Safety Data Sheets for detailed information. Hot oil and lubricating components can cause personal injury. Do not allow hot oil to contact the skin. Appropriate personal protective equipment should be used.

#### **Diesel Fuel**

Diesel engines have high-pressure fuel systems and the fuel can reach temperatures of over 100° C (212° F). Ensure that the fuel has cooled before any service or repairs are performed.

Diesel may be irritating to the eyes, respiratory system, and skin. Prolonged exposure to diesel may cause various skin conditions. Appropriate personal protective equipment should be used. Refer to supplier Material safety Data sheets for detailed information.

#### **Batteries**

Electrolyte is an acid. Electrolyte can cause personal injury. Do not allow electrolyte to contact the skin or the eyes. Always wear protective glasses for servicing batteries. Wash hands after touching the batteries and connectors. Use of gloves is recommended.

#### Engine and Aftertreatment System

Do not touch any part of an operating engine or engine aftertreatment system. Allow the engine or the engine aftertreatment system to cool before any maintenance is performed on the engine or the engine aftertreatment system. Relieve all pressure in the appropriate system before any lines, fittings, or related items are disconnected.

## Aftertreatment System and Diesel Exhaust Fluid

Diesel Exhaust Fluid (DEF) temperatures can reach 65° to 70°C (149.° to 126°F) during normal engine operation. Stop the engine. Wait for 15 minutes to allow the DEF system to be purged and the DEF to cool before service or repair is performed.

i07676034

## Fire Prevention and Explosion Prevention

**SMCS Code:** 1000; 4450; 7405




Illustration 21

g00704000

All fuels, most lubricants, and some coolant mixtures are flammable.

Flammable fluids that are leaking or spilled onto hot surfaces or onto electrical components can cause a fire. Fire may cause personal injury and property damage.

A flash fire may result if the covers for the engine crankcase are removed within 15 minutes after an emergency shutdown.

Determine whether the engine will be operated in an environment that allows combustible gases to be drawn into the air inlet system. These gases could cause the engine to overspeed. Personal injury, property damage, or engine damage could result.

If the application involves the presence of combustible gases, consult your Caterpillar dealer for additional information about suitable protection devices.

Remove all flammable combustible materials or conductive materials such as fuel, oil, and debris from the engine. Do not allow any flammable combustible materials or conductive materials to accumulate on the engine. Store fuels and lubricants in properly marked containers away from unauthorized persons. Store oily rags and any flammable materials in protective containers. Do not smoke in areas that are used for storing flammable materials.

Do not expose the engine to any flame.

Exhaust shields (if equipped) protect hot exhaust components from oil or fuel spray in a case of a line, a tube, or a seal failure. Exhaust shields must be installed correctly.

Do not weld on lines or tanks that contain flammable fluids. Do not flame cut lines or tanks that contain flammable fluid. Clean any such lines or tanks thoroughly with a nonflammable solvent prior to welding or flame cutting.

Wiring must be kept in good condition. Ensure that all electrical wires are properly routed and securely attached. Check all electrical wires daily. Repair any wires that are loose or frayed before you operate the engine. Clean all electrical connections and tighten all electrical connections.

Eliminate all wiring that is unattached or unnecessary. Do not use any wires or cables that are smaller than the recommended gauge. Do not bypass any fuses and/or circuit breakers.

Arcing or sparking could cause a fire. Secure connections, recommended wiring, and properly maintained battery cables will help to prevent arcing or sparking.

#### 

Contact with high pressure fuel may cause fluid penetration and burn hazards. High pressure fuel spray may cause a fire hazard. Failure to follow these inspection, maintenance and service instructions may cause personal injury or death.

After the engine has stopped, you must wait for 10 minutes to allow the fuel pressure to be purged from the high-pressure fuel lines before any service or repair is performed on the engine fuel lines. The 10 minute wait will also allow static charge to dissipate from the low-pressure fuel system.

Ensure that the engine is stopped. Inspect all lines and hoses for wear or for deterioration. Ensure that the hoses are correctly routed. The lines and hoses must have adequate support and secure clamps.

Oil filters and fuel filters must be correctly installed. The filter housings must be tightened to the correct torque. Refer to the Disassembly and Assembly for more information.



Illustration 22

g00704059

Use caution when you are refueling an engine. Do not smoke while you are refueling an engine. Do not refuel an engine near open flames or sparks. Always stop the engine before refueling.

Avoid static electricity risk when fueling. Ultra-low Sulfur Diesel fuel (ULSD fuel) poses a greater static ignition hazard than earlier diesel formulations with a higher sulfur content. Avoid death or serious injury from fire or explosion. Consult your fuel or fuel system supplier to ensure that the delivery system is in compliance with fueling standards for proper grounding and bonding practices.



Illustration 23

g00704135

Gases from a battery can explode. Keep any open flames or sparks away from the top of a battery. Do not smoke in battery charging areas.

Never check the battery charge by placing a metal object across the terminal posts. Use a voltmeter or a hydrometer.

Improper jumper cable connections can cause an explosion that can result in injury. Refer to the Operation Section of this manual for specific instructions.

Do not charge a frozen battery. A frozen battery may cause an explosion.

The batteries must be kept clean. The covers (if equipped) must be kept on the cells. Use the recommended cables, connections, and battery box covers when the engine is operated.

#### **Fire Extinguisher**

Make sure that a fire extinguisher is available. Be familiar with the operation of the fire extinguisher. Inspect the fire extinguisher and service the fire extinguisher regularly. Obey the recommendations on the instruction plate.

#### Ether

Ether is flammable and poisonous.

Do not smoke while you are replacing an ether cylinder.

Do not store ether cylinders in living areas or in the engine compartment. Do not store ether cylinders in direct sunlight or in temperatures above 49 °C (120 °F). Keep ether cylinders away from open flames or sparks.

#### Lines, Tubes, and Hoses

Do not bend high-pressure lines. Do not strike highpressure lines. Do not install any lines that are bent or damaged.

Leaks can cause fires. Consult your Caterpillar dealer for repair or for replacement parts.

Replace the parts if any of the following conditions are present:

- · High-pressure fuel line or lines are removed.
- End fittings are damaged or leaking.
- · Outer coverings are chafed or cut.
- · Wires are exposed.
- · Outer coverings are ballooning.
- · Flexible parts of the hoses are kinked.
- Outer covers have embedded armoring.
- · End fittings are displaced.

Make sure that all clamps, guards, and heat shields are installed correctly. During engine operation, correct installation will help to prevent vibration, rubbing against other parts, and excessive heat.

i08162291

#### **Crushing Prevention and Cutting Prevention**

SMCS Code: 1000; 4450; 7405

Support the component properly when work beneath the component is performed.

Unless other maintenance instructions are provided, never attempt adjustments while the engine is running.

Stay clear of all rotating parts and of all moving parts. Leave the guards in place until maintenance is performed. After the maintenance is performed, reinstall the guards.

Keep objects away from moving fan blades. The fan blades will throw objects or cut objects.

When objects are struck, wear protective glasses to avoid injury to the eyes.

Chips or other debris may fly off objects when objects are struck. Before objects are struck, ensure that no one will be injured by flying debris.

i05768982

### **Mounting and Dismounting**

**SMCS Code:** 1000; 4450; 7405

Do not climb on the engine or the engine aftertreatment system. The engine and aftertreatment system have not been designed with mounting or dismounting locations.

Refer to the OEM for the location of foot and hand holds for your specific application.


i07366423

### **High Pressure Fuel Lines**

SMCS Code: 1274

WARNING

Contact with high pressure fuel may cause fluid penetration and burn hazards. High pressure fuel spray may cause a fire hazard. Failure to follow these inspection, maintenance and service instructions may cause personal injury or death.



#### Illustration 24

- (1) High-pressure line
- (2) High-pressure line
- (3) High-pressure line

(4) High-pressure line(5) Fuel transfer line that is high pressure(6) High-pressure pump

(7) High-pressure line(8) High-pressure fuel manifold (rail)

g06334696

The high-pressure fuel lines are the fuel lines that are between the high-pressure fuel pump and the highpressure fuel manifold and the fuel lines that are between the fuel manifold and electronic unit injectors. These fuel lines are different from fuel lines on other fuel systems.

The fuel lines are different because of the following items:

- The high-pressure fuel lines are constantly charged with high pressure.
- The internal pressures of the high-pressure fuel lines are higher than other types of fuel system.
- The high-pressure fuel lines are formed to shape and then strengthened by a special process.

Do not step on the high-pressure fuel lines. Do not deflect the high-pressure fuel lines. Do not bend or strike the high-pressure fuel lines. Deformation or damage of the high-pressure fuel lines may cause a point of weakness and potential failure. Do not check the high-pressure fuel lines with the engine or the starting motor in operation. After the engine has stopped, you must wait for 10 minutes to allow the fuel pressure to be purged from the highpressure fuel lines before any service or repair is performed on the engine fuel lines. The 10 minute wait will also allow static charge to dissipate from the low-pressure fuel system.

Do not loosen the high-pressure fuel lines to remove air from the fuel system. This procedure is not required.

Visually inspect the high-pressure fuel lines before the engine is started. This inspection should be each day.

If you inspect the engine in operation, always use the proper inspection procedure to avoid a fluid penetration hazard. Refer to Operation and Maintenance Manual, "General hazard Information".

 Inspect the high-pressure fuel lines for damage, deformation, a nick, a cut, a crease, or a dent.

- Do not operate the engine with a fuel leak. If there is a leak, do not tighten the connection, to stop the leak. The connection must only be tightened to the recommended torque. Refer to Disassembly and Assembly, "Fuel injection lines - Remove and Fuel injection lines - Install".
- If the high-pressure fuel lines are torqued correctly and the high-pressure fuel lines are leaking, the high-pressure fuel lines must be replaced.
- Ensure that all clips on the high-pressure fuel lines are in place. Do not operate the engine with clips that are damaged, missing, or loose.
- Do not attach any other item to the high-pressure fuel lines.
- Loosened high-pressure fuel lines must be replaced. Also removed high-pressure fuel lines must be replaced. Refer to Disassembly and assembly manual, "Fuel Injection Lines - Install".

i07728672

## **Before Starting Engine**

SMCS Code: 1000

#### NOTICE

For initial start-up of a new or rebuilt engine, and for start-up of an engine that has been serviced, make provision to shut the engine off should an overspeed occur. This may be accomplished by shutting off the air and/or fuel supply to the engine.

#### 🏠 WARNING

Engine exhaust contains products of combustion which may be harmful to your health. Always start and operate the engine in a well ventilated area and, if in an enclosed area, vent the exhaust to the outside.

Inspect the engine for potential hazards.

Do not start the engine or move any of the controls if there is a "DO NOT OPERATE" warning tag or similar warning tag attached to the start switch or to the controls.

Before starting the engine, ensure that no one is on, underneath, or close to the engine. Ensure that the area is free of personnel.

If equipped, ensure that the lighting system for the engine is suitable for the conditions. Ensure that all lights work properly, if equipped. All protective guards and all protective covers must be installed if the engine must be started to perform service procedures. To help prevent an accident that is caused by parts in rotation, work around the parts carefully.

Do not bypass the automatic shutoff circuits. Do not disable the automatic shutoff circuits. The circuits are provided to help prevent personal injury. The circuits are also provided to help prevent engine damage.

Before starting the engine, ensure that the drive belt is securely in place. The coolant pump is operated by the drive belt.

See the Service Manual for repairs and for adjustments.

i08219601

## **Engine Starting**

SMCS Code: 1000

Do not use aerosol types of starting aids such as ether. Such use could result in an explosion and personal injury.

If a warning tag is attached to the engine start switch or to the controls DO NOT start the engine or move the controls. Consult with the person that attached the warning tag before the engine is started.

All protective guards and all protective covers must be installed if the engine must be started to perform service procedures. To help prevent an accident that is caused by parts in rotation, work around the parts carefully.

Start the engine from the operator's compartment or from the engine start switch.

Always start the engine according to the procedure that is described in the Operation and Maintenance Manual, "Engine Starting" topic in the Operation Section. Knowing the correct procedure will help to prevent major damage to the engine components. Knowing the procedure will also help to prevent personal injury.

To ensure that the jacket water heater (if equipped) and/or the lube oil heater (if equipped) is working correctly, check the water temperature gauge. Also, check the oil temperature gauge during the heater operation.

g06296580

#### 

Engine exhaust contains products of combustion which may be harmful to your health. Always start and operate the engine in a well ventilated area and, if in an enclosed area, vent the exhaust to the outside.

**Note:** The engine is equipped with a device for cold starting. If the engine will be operated in very cold conditions, an extra cold starting aid may be required. Normally, the engine will be equipped with the correct type of starting aid for the region of operation.

These engines are equipped with a glow plug starting aid in each individual cylinder that heats the intake air to improve starting. Some Caterpillar engines may have a cold starting system that is controlled by the ECM that allows a controlled flow of ether into the engine. The ECM will disconnect the glow plugs before the ether is introduced. This system would be installed at the factory.

i02234873

## **Engine Stopping**

#### SMCS Code: 1000

Stop the engine according to the procedure in the Operation and Maintenance Manual, "Engine Stopping (Operation Section)" in order to avoid overheating of the engine and accelerated wear of the engine components.

Use the Emergency Stop Button (if equipped) ONLY in an emergency situation. Do not use the Emergency Stop Button for normal engine stopping. After an emergency stop, DO NOT start the engine until the problem that caused the emergency stop has been corrected.

Stop the engine if an overspeed condition occurs during the initial start-up of a new engine or an engine that has been overhauled.

To stop an electronically controlled engine, cut the power to the engine and/or shutting off the air supply to the engine.

i08154895


## **Electrical System**

SMCS Code: 1000; 1400

Never disconnect any charging unit circuit or battery circuit cable from the battery when the charging unit is operating. A spark can cause the combustible gases that are produced by some batteries to ignite. To help prevent sparks from igniting combustible gases that are produced by some batteries, the negative "–" cable should be connected last from the external power source to the primary position for grounding.

Check the electrical wires daily for wires that are loose or frayed. Tighten all loose electrical connections before the engine is started. Repair all frayed electrical wires before the engine is started. See the Operation and Maintenance Manual for specific starting instructions.

#### **Grounding Practices**



#### Illustration 25

- Typical example
- (1) Ground to battery
- (2) Ground to starting motor
- (3) Starting motor to engine block




Illustration 26

g06296637

#### Typical example

- (4) Ground to the battery(5) Ground to the engine block
- (6) Primary position for grounding

#### NOTICE

For C3.6 industrial engines, ensure that a 12 VDC or 24 VDC battery source is used to start the engine. For C2.8 industrial engines, use a 12 VDC battery source to start the engine. Never attempt to start an engine from an external power source such as electric welding equipment, which has a voltage that is unsuitable for engine starting and will damage the electrical system.

Correct grounding for the engine electrical system is necessary for optimum engine performance and reliability. Incorrect grounding will result in uncontrolled electrical circuit paths and in unreliable electrical circuit paths.

Uncontrolled electrical circuit paths can result in damage to the crankshaft bearing journal surfaces and to aluminum components.

Engines that are installed without engine-to-frame ground straps can be damaged by electrical discharge.

To ensure that the engine and the engine electrical systems function correctly, an engine-to-frame ground strap with a direct path to the battery must be used. This path may be provided by way of a direct engine ground to the frame.

The connections for the grounds should be tight and free of corrosion. The engine alternator must be grounded to the negative "-" battery terminal. The wire used must be adequate to handle the full charging current of the alternator.

The power supply connection for the engine electronics should always be from the isolator to the battery. It is the decision of the OEM which polarity the isolator is connected to.

i07925886

## **Engine Electronics**

SMCS Code: 1000; 1900

#### 

Tampering with the electronic system installation or the OEM wiring installation can be dangerous and could result in personal injury or death and/ or engine damage.

#### 

Electrical Shock Hazard. The electronic unit injectors use DC voltage. The ECM sends this voltage to the electronic unit injectors. Do not come in contact with the harness connector for the electronic unit injectors while the engine is operating. Failure to follow this instruction could result in personal injury or death.

This engine has a comprehensive, programmable Engine Monitoring System. The Electronic Control Module (ECM) has the ability to monitor the engine operating conditions. If any of the engine parameters extend outside an allowable range, the ECM will initiate an immediate action.

The following actions are available for engine monitoring control:

- Warning: A warning light could be illuminated or a sound warning could be activated (horn)
- Derate: The engine power could be reduced by 50
   percent
- Shutdown: The engine could be shut down or only operate at low idle

The following monitored engine operating conditions and components can limit engine speed and/or the engine power:

- Engine Coolant Temperature
- Engine Oil Pressure
- Engine Speed
- Intake Manifold Air Temperature
- Intake Manifold Pressure
- Wastegate Regulator
- Supply Voltage to Sensors
- Fuel Temperature
- Fuel Pressure in Manifold (Rail)
- NOx Reduction System temperature
- Engine Aftertreatment System

The Engine Monitoring package can vary for different engine models and different engine applications. However, the monitoring system and the engine monitoring control will be similar for all engines.

**Note:** Many of the engine control systems and display modules that are available for Caterpillar engines will work in unison with the Engine Monitoring System. Together, the two controls will provide the engine monitoring function for the specific engine application. Refer to Troubleshooting for more information on the Engine Monitoring System.

## **Product Information Section**

## **General Information**


i07853978

## **Model View Illustrations**

SMCS Code: 1000

The following model views show typical features of the engine. Due to individual applications, your engine may appear different from the illustrations.

#### **C3.6 Industrial Engine Views**



#### Illustration 27


#### Typical example


- (1) Selective Catalytic Reduction (SCR)
- (2) Diesel Exhaust Fluid (DEF) injector
- (3) Engine harness interface
- (4) Throttle control valve (5) NOx Reduction System (NRS) valve
- (7) Alternator (8) Oil gauge (Dipstick)

(6) Air intake from air charge cooler

- (9) Oil filler (lower)
- (10) Oil filter assembly

- (11) Starting motor
- (12) Oil drain plug
- (13) High-pressure fuel pump
- (14) Diesel Particulate Filter (DPF)





#### Illustration 28

#### Typical example

- (15) Front lifting eye
  (16) Rear lifting eyes
  (17) Actuator for turbocharger
  (18) Turbocharger
  (19) Air intake from air cleaner

(20) Electronic Control Module (ECM), location for transportation only


- (21) Idler for drive belt
- (22) Adjuster for drive belt(23) Coolant pump pulley

- (24) Coolant intake(25) Drive belt(26) Coolant outlet(27) Top oil filler

#### g06297569

M0108394-08

#### **C2.8 Industrial Engine Views**




#### Illustration 29

#### Typical example

- (1) Diesel Particulate Filter (DPF) and Diesel Oxidation Catalyst (DOC) combined
   (2) Engine harness interface
   (3) NOx Reduction System (NRS) valve

- (4) Throttle control valve(5) Alternator(6) Oil filter assembly(7) Oil filler (lower)

- (8) Oil gauge (Dipstick)(9) Oil drain plug(10) Starting motor
- (11) High-pressure fuel pump



#### Illustration 30

#### Typical example


- (12) Oil filler (upper)
  (13) Front lifting eye
  (14) Rear lifting eyes
  (15) Actuator for turbocharger
  (16) Turbocharger

- (17) Air intake from air cleaner
  (18) Electronic Control Module (ECM), location for transportation only
  (19) Adjuster for drive belt
  (20) Coolant pump pulley

g06481335

- (21) Coolant intake(22) Drive belt(23) Coolant outlet

#### Loose or Off Engine Components



#### Illustration 31

#### Typical example

- (1) Primary fuel filter, combined with electric fuel priming pump and Water-In-Fuel (WIF) sensor
- (2) If equipped, secondary fuel filter
- (3) Primary fuel filter, combined with manual fuel priming pump and Water-In-Fuel (WIF) sensor
- (4) Coolant diverter valve(5) Diesel Exhaust Fluid (DEF) pump with DEF pump filter
- (6) DEF tank with DEF header installed (7) DEF heated lines
- (8) Link harness
- (9) Electric control module

- (10) Inlet temperature sensor
- (11) Exhaust assembly
- (12) NOx sensors
- (13) Low-pressure fuel line


i08067930

## **Model View Illustrations**

#### SMCS Code: 1000

The following model views show typical features of the engine. Due to individual applications, your engine may appear different from the illustrations.

#### **C3.6 Industrial Engine Views For Engines Equipped With A Balancer**




#### Illustration 32

#### Typical example

- (1) Selective Catalytic Reduction (SCR)
- (2) Diesel Exhaust Fluid (DEF) injector (3) Diesel Particulate Filter (DPF)
- (4) NOx Reduction System (NRS) valve
- (5) Air intake from air charge cooler
- (6) Alternator
- (7) Oil filter assembly
- (8) Starting motor

(9) Oil drain plug (1 of 2) (10) High-pressure fuel pump (11) Throttle control valve (12) Engine harness interface



### Typical example

- (13) Rear lifting eyes(14) Actuator for turbocharger
- (15) Turbocharger
  (16) Electronic Control Module (ECM), location for transportation only
  (17) Oil gauge (Dipstick)


- (18) Oil filler
  (19) Oil drain plug (2 of 2)
  (20) Automatic adjuster for drive belt
  (21) Coolant pump pulley
  (22) Coolant intake

- (23) Drive belt

g06511390

- (24) Fan Pulley(25) Coolant outlet(26) Air intake from air cleaner(27) Front lifting eye

# Loose or Off Engine Components



### Illustration 34

- (1) Primary fuel filter, combined with electric fuel priming pump and Water-In-Fuel (WIF) sensor
- (2) If equipped, secondary fuel filter
- (3) Primary fuel filter, combined with manual fuel priming pump and Water-In-Fuel (WIF) sensor
- (4) Coolant diverter valve(5) Diesel Exhaust Fluid (DEF) pump with DEF pump filter
- (6) DEF tank with DEF header installed (7) DEF heated lines
- (8) Link harness
- (9) Electric control module

- (10) Inlet temperature sensor
- (11) Exhaust assembly
- (12) NOx sensors
- (13) Low-pressure fuel line


i09430651

# **Model View Illustrations**

### SMCS Code: 1000

The following model views show typical features of the engine. Due to individual applications, your engine may appear different from the illustrations.


## C3.6 Open Power Unit (OPU)



### Illustration 35

- (1) Selective Catalytic Reduction (SCR)
- (2) NOx Reduction System (NRS) valve
- (3) Electronic Control Module (ECM)
- (4) Radiator filler cap
- (5) Radiator lifting point (1 of 2)
- (6) Radiator
- (7) Radiator lifting point (2 of 2)
- (8) Radiator drain plug
- (9) Alternator
- (10) Oil gauge (Dipstick) (11) Oil drain tap
- (12) Lower Oil filler
- (13) Oil filter assembly
- (14) Starting motor

- (15) High-pressure fuel pump
- (16) Throttle control valve
- (17) Engine harness interface
- (18) Diesel Particulate Filter (DPF)
- (19) Diesel Exhaust Fluid (DÈF) injector
- (20) Engine Rear lifting eyes




### Typical example

- (3) Electronic Control Module (ECM)(5) Radiator lifting point (1 of 2)(21) Actuator for turbocharger

(22) Turbocharger (23) Fan guard (24) Air intake from air cleaner

(25) Engine Front lifting eye (26) Upper Oil filler

### Loose or Off Engine Components for C3.6 OPU




### Illustration 37

- (1) Primary fuel filter, combined with electric fuel priming pump and Water-In-Fuel (WIF) sensor
- (2) If equipped, secondary fuel filter
- (3) Primary fuel filter, combined with manual fuel priming pump and Water-In-Fuel (WIF) sensor
- (4) Coolant diverter valve
  (5) Diesel Exhaust Fluid (DEF) pump with DEF pump filter

- (6) DEF heated lines
  (7) NOx sensors
  (8) DEF tank with DEF header installed
- (9) line
- (10) Inlet temperature sensor(11) Engine air cleaner

# **C2.8 OPU**




### Illustration 38

- (1) Diesel Particulate Filter (DPF) and Diesel Oxidation Catalyst (DOC) combined
   (2) Engine Rear lifting eye
   (3) NOx Reduction System (NRS) valve
   (4) Radiator filler cap
   (5) Radiator lifting point (1 of 2)

- (6) Throttle control valve
- (7) Alternator(8) Oil filter assembly
- (9) Lower Oil filler(10) Oil gauge (Dipstick)(11) Starting motor

- (12) Oil drain plug(13) Primary fuel filter(14) Engine harness interface(15) High-pressure fuel pump




- (16) Actuator for turbocharger(17) Turbocharger(18) Fan guard

- (19) Air intake from air cleaner(20) Engine Front lifting eye(21) Upper Oil filler

- (22) Electronic Control Module (ECM)(23) Radiator lifting point (2 of 2)

# Loose or Off Engine Components for C2.8 OPU



#### Illustration 40

g06740514

#### Typical example

- (1) Primary fuel filter, combined with electric fuel priming pump and Water-In-Fuel (WIF) sensor
- (2) If equipped, secondary fuel filter
- (3) Primary fuel filter, combined with manual fuel priming pump and Water-In-Fuel (WIF) sensor
- (4) Inlet temperature sensor
- (5) Engine air cleaner

i07853928

# **Product Description** ((Engine and Aftertreatment))

SMCS Code: 1000; 4450; 4491

# **C3.6 Industrial Engine**

The Caterpillar C3.6 industrial engine is a single turbocharged, air to air charge cooled engine. There are two variants of the C3.6 industrial engines. Engines with a power rating of 56 kW (75.1 hp) and below or engines with a power rating of 70 kW (93.9 hp) and above.

The engine aftertreatment system for engines with a power ratings of 56 kW (75.1 hp) and below, is configured as follows:

- Diesel Oxidation Catalyst (DOC)
- Diesel Particulate Filter (DPF)

The engine aftertreatment system for engines with a power ratings of 70 kW (93.9 hp) and above, is configured as follows:

- Diesel Oxidation Catalyst (DOC)
- Diesel Particulate Filter (DPF)
- Selective Catalytic Reduction (SCR)

# **C2.8 Industrial Engine**


The Caterpillar C2.8 industrial engine is a single turbocharged engine. The engine may be turbocharged or turbocharged with an air charge cooler.

The engine aftertreatment system is configured as follows:

- Diesel Oxidation Catalyst (DOC)
- Diesel Particulate Filter (DPF)

## **Engine Specifications**

**Note:** The front end of the engine is opposite the flywheel end of the engine. The left and the right sides of the engine are determined from the flywheel end. The number 1 cylinder is the front cylinder.



# Illustration 41

(A) Inlet valves

(B) Exhaust valves

Table 1

C3.6 Engine Specifications			
Operating Range (rpm)	800 to 2400 (1)		
Number of Cylinders	4 In-Line		
Bore	98 mm (3.86 inch)		
Stroke	120 mm (4.72 inch)		
Power rating (engines with DOC and DPF)	55.4 kW(74.29 hp)		

g06297997

(Table 1, contd)

()	
Power rating (engines with DOC, DPF, and SCR)	70 to 100 kW (93.87 to 134.1 hp)
Aspiration	Turbocharged charge cooled
Compression Ratio	17:1
Displacement	3.621 L (220.966 cubic inch)
Firing Order	1-3 -4-2
Valves per cylinder	4
Rotation (flywheel end)	Counterclockwise

<sup>(1)</sup> The operating rpm depends on the engine rating, the application, and the configuration of the throttle.

Table 2

C2.8 Engine Specifications		
Operating Range (rpm)	800 to 2400 (1)	
Number of Cylinders	4 In-Line	
Bore	90 mm (3.54 inch)	
Stroke	110 mm (4.33 inch)	
Power rating	50 kW to 55.4 kW (67.05 hp to 74.29 hp)	
Aspiration	Turbocharged and Turbo- charged charge cooled	
Compression Ratio	17:1	
Displacement	2.8 L (170.87 cubic inch)	
Firing Order	1-3 -4-2	
Valves per cylinder	4	
Rotation (flywheel end)	Counterclockwise	

<sup>(1)</sup> The operating rpm depends on the engine rating, the application, and the configuration of the throttle.

# **Electronic Engine Features**

The engine and aftertreatment operating conditions are monitored. The Electronic Control Module (ECM) controls the response of the engine to these conditions and to the demands of the operator. These conditions and operator demands determine the precise control of fuel injection by the ECM. The electronic engine control system provides the following features:

- Engine monitoring
- · Engine speed governing
- Control of the injection pressure
- Cold start strategy
- · Automatic air/fuel ratio control

- · Torque rise shaping
- · Injection timing control
- System diagnostics
- NOx reduction system control
- Aftertreatment system control

The ECM provides an electronic governor that controls the injector output to maintain the desired engine speed.

For more information on electronic engine features, refer to the Operation and Maintenance Manual, "Features and Controls" topic (Operation Section).

# **Engine Diagnostics**

The engine has built-in diagnostics to ensure that the engine systems are functioning correctly. The operator will be alerted to the condition by a "Stop or Warning" lamp. Under certain conditions, the engine horsepower and the vehicle speed may be limited. The electronic service tool may be used to display the diagnostic codes.

There are three types of diagnostic codes: active, logged, and event.

Most of the diagnostic codes are logged and stored in the ECM. For additional information, refer to the Operation and Maintenance Manual, "Engine Diagnostics" topic (Operation Section).

### **Engine Cooling and Lubrication**

The cooling system and lubrication system consists of the following components:

- Belt driven water pump
- Water temperature regulator which regulates the engine coolant temperature
- · Gear-driven gerotor type oil pump
- Oil cooler

The engine lubricating oil is supplied by a gerotor type oil pump. The engine lubricating oil is cooled and the engine lubricating oil is filtered. The bypass valve can provide unrestricted flow of lubrication oil to the engine if the oil filter element should become plugged. Engine efficiency, efficiency of emission controls, and engine performance depend on adherence to proper operation and maintenance recommendations. Engine performance and efficiency also depend on the use of recommended fuels, lubrication oils, and coolants. Refer to this Operation and Maintenance Manual, "Maintenance Interval Schedule" for more information on maintenance items.

# **Engine Service Life**

Engine efficiency and maximum utilization of engine performance depend on the adherence to proper operation and maintenance recommendations. In addition, use recommended fuels, coolants, and lubricants. Use the Operation and Maintenance Manual as a guide for required engine maintenance.

Expected engine life is generally predicted by the average power that is demanded. The average power that is demanded is based on fuel consumption of the engine over time. Reduced hours of operation at full throttle and/or operating at reduced throttle settings result in a lower average power demand. Reduced hours of operation will increase the length of operating time before an engine overhaul is required. For more information, refer to the Operation and Maintenance Manual, "Overhaul Considerations" topic (Maintenance Section).

# Aftermarket Products and Caterpillar Engines

Caterpillar does not warrant the quality or performance of non-Caterpillar fluids and filters.

When auxiliary devices, accessories, or consumables (filters, additives, catalysts), which are made by other manufacturers are used on Caterpillar products, the Caterpillar warranty is not affected simply because of such use.

However, failures that result from the installation or use of other manufacturers devices, accessories, or consumables are NOT Caterpillar defects. Therefore, the defects are NOT covered under the Caterpillar warranty.

# Aftertreatment System

The aftertreatment system is approved for use by Caterpillar. To be emissions-compliant, only the approved Caterpillar aftertreatment system must be used on a Caterpillar engine.

# **Product Identification** Information

i07816292

g06298126

### **Plate Locations and Film** Locations

SMCS Code: 1000; 4450




Illustration 42

#### Typical example

(1) Engine serial number plate location

# **Serial Number Plate**

The engine serial number plate (1) is on the right side of the cylinder block to the rear of the front engine mounting.

Caterpillar dealers need all these numbers to determine the components that were included with the engine. This information permits accurate identification of replacement part numbers.

GATERPILLAR®	GAT®
ARRANGEMENT NUMBER	SALES MODEL
0	0
SERIAL NUMBER	
MADE IN U.K. (ALWAYS GIVE ALL NUM	/BERS) #####


Illustration 43	
Typical example of serial number plate	

i08043623

g03047463

# **Emissions Certification Film**

SMCS Code: 1000; 7405



#### Illustration 44

g06522161

Typical location of the engine emission label

The engine emission label is typically installed on the flywheel housing at Position (X). An extra engine emission label may be supplied loose.

i07925928

# **Reference Information**

### SMCS Code: 1000; 4450

Information for the following items may be needed to order parts. Locate the information for your engine. Record the information in the appropriate space. Make a copy of this list for a record. Keep the information for future reference.

## **Record for Reference**

Engine Model
Engine Serial number
Engine Low Idle rpm
Engine Full Load rpm
In Line Fuel Filter
Primary Fuel Filter
Secondary Fuel Filter Element
Lubrication Oil Filter Element
Auxiliary Oil Filter Element (if equipped)
Total Lubrication System Capacity
Total Cooling System Capacity
Air Cleaner Element
Drive Belt
Clean Emissions Module
Part Number
Serial Number
Diesel Exhaust Fluid (DEF) Pump

Part Number \_\_\_\_\_\_ Serial Number \_\_\_\_\_\_

# **Operation Section**

# Lifting and Storage

i09512670

# **Product Lifting**

SMCS Code: 7000; 7002

#### NOTICE

Always inspect lifting eyebolts and all other lifting equipment for damage before performing any lifting. Never bend the eyebolts and the brackets. Never perform product lifting if components are damaged. Only load the eyebolts and the brackets under tension. Remember that the capacity of an eyebolt is less as the angle between the supporting members and the object becomes less than 90 degrees.

When it is necessary to remove a component at an angle, only use a link bracket that is properly rated for the weight.

Read all the information within product lifting before any lifting is attempted. Ensure that the correct set of lifting eyes for the assembly to be lifted have been selected.

Use a hoist to remove heavy components. Use an adjustable lifting beam to lift the engine. All supporting members (chains and cables) should be parallel to each other. The chains and cables should be perpendicular to the top of the object that is being lifted.

To obtain the correct balance for lifting an application, adjust the chain lengths.

Lifting eyes are designed and installed for the specific engine arrangement. Alterations to the lifting eyes and/or the engine, make the lifting eyes and the lifting fixtures obsolete. If alterations are made, ensure that proper lifting devices are provided.

There are several different designs of lifting eyes. The following sections give examples of lifting eyes on the engine and engine with aftertreatment.

Consult your Caterpillar dealer for information regarding fixtures for proper engine lifting.

### C3.6 Industrial Engine




Illustration 45 Typical example (1) Rear lifting eyes

q06298473

(2) Front lifting eye

Use all 3 lifting eyes when lifting engine assembly.

Caterpillar recommends that model-specific cradles are used to store and transport engines. Supporting engines on the sump/oil pan is not recommended under any circumstances. This action is for both safety and quality reasons.

## C3.6 Industrial Engine Equipped With A Balancer




Illustration 46


Typical example

- (1) Rear lifting eyes
- (2) Front lifting eye

Use both lifting eyes when lifting engine assembly.

Caterpillar recommends that model-specific cradles are used to store and transport engines. Supporting engines on the sump/oil pan is not recommended under any circumstances. This action is for both safety and quality reasons.

# C3.6 Open Power Unit (OPU)



### Illustration 47

q06742363

Typical example

- (1) Radiator lifting eye (1 of 2) (2) Radiator lifting eye (2 of 2)
- (3) Front lifting eye
- (4) Rear lifting eye
- (5) Rear lifting eye

Use all 3 lifting eyes when lifting engine assembly.

Use both lifting eyes when lifting radiator assembly.

Use all the lifting eyes when lifting OPU.

## **C2.8 Industrial Engine**




Illustration 48 Typical example

- (1) Rear lifting eye(2) Front lifting eye

Use both lifting eyes when lifting engine assembly.

Caterpillar recommends that model-specific cradles are used to store and transport engines. Supporting engines on the sump/oil pan is not recommended under any circumstances. This action is for both safety and quality reasons.

# C2.8 Open Power Unit (OPU)




Illustration 49 Typical example

(1) Radiator lifting eye (1 of 2) (2) Radiator lifting eye (2 of 2) (3) Front lifting eye

(4) Rear lifting eye

Use both lifting eyes when lifting engine assembly.

Use both lifting eyes when lifting radiator assembly.

Use all the lifting eyes when lifting the OPU.

i07676027

# **Product Storage**

SMCS Code: 7002

If the engine will not be started for several weeks, the lubricating oil will drain from the cylinder walls and from the piston rings. Rust can form on the cylinder liner surface. Rust on the cylinder liner surface will cause increased engine wear and a reduction in engine service life.

To help prevent excessive engine wear, use the following guidelines:

- Complete all the lubrication recommendations that are listed in the Operation and Maintenance Manual, "Maintenance Interval Schedule".
- If freezing temperatures are expected, check the cooling system for adequate protection against freezing. Refer to Operation and Maintenance Manual, "Fluid Recommendations" for more information.

If an engine is out of operation and if use of the engine is not planned, special precautions should be made. If the engine will be stored for more than 1 month, a complete protection procedure is recommended.

Ensure that the outlets on the Clean Emission Module (CEM) are capped. Ensure that the Diesel Exhaust Fluid (DEF) connections are capped.

To prevent damage to the exhaust outlet connection during storage, the weight of the CEM must not act on the exhaust outlet.

For more detailed information on engine storage, refer to Special Instruction, SEHS9031, "Storage Procedure For Caterpillar Products".

Your Caterpillar dealer can help in preparing the engine for extended storage periods.

### Aftertreatment

The engine must be allowed to perform a DEF purge before the battery disconnect switch is turned off. Allow 2 minutes after the engine has stopped before disconnecting the battery disconnect switch.

The exhaust outlet of the aftertreatment must be capped. To prevent damage to the exhaust outlet connection during storage, the weight of the CEM must not act on the exhaust outlet.

### **DEF Tank Storage**

- 1. Ensure normal engine shutdown, allow the DEF to be purged. Do not disconnect the battery disconnect switch, allow 2 minutes after key off before disconnection.
- **2.** Fill the tank with DEF that meets all the requirement defined in ISO 22241-1.
- **3.** Ensure that all DEF lines and electrical connection are connected prior to prevent crystal from forming.
- 4. Ensure that the DEF filler cap is correctly installed.

### **Removal from Storage**

DEF has a limited life, refer to table 3 for the time and temperature range. DEF that is outside this range MUST be replaced.

On removal from storage the DEF quality in the tank must be tested with a refractometer. The DEF in the tank must meet the requirements defined in ISO 22241-1 and comply with table 3.

- **1.** If necessary, drain the tank and fill with DEF that meets ISO 22241-1.
- 2. Replace the DEF filter. Refer to Operation and Maintenance Manual, "Diesel Exhaust Fluid Filter (Emission Related Component) - Replace" for the correct procedure.
- **3.** Ensure that the drive belt is correctly installed. Ensure that all engine coolant and engine oil has the correct specification and grade. Ensure that the coolant and the engine oil are at the correct level. Start the engine. If a fault becomes active turn off the engine, allow 2 minutes for the DEF system to purge, then restart the engine.
- **4.** If the fault continues to stay active, refer to Troubleshooting for more information.

Tabl	e (	3
------	-----	---

Temperature	Duration
10° C (50° F)	36 months
25° C (77° F)	18 months
30° C (86° F)	12 months
35° C (95° F) <sup>(1)</sup>	6 months

 $^{(1)}\,$  At 35° C, significant degradation can occur. Check every batch before use.

# **Features and Controls**

i07925952

# **Alarms and Shutoffs**

SMCS Code: 7400

### Shutoffs

The shutoffs are electrically operated or mechanically operated. The electrically operated shutoffs are controlled by the ECM.

Shutoffs are set at critical levels for the following items:

- · Operating temperature
- · Operating pressure
- Operating level
- Operating rpm

The particular shutoff may need to be reset before the engine will start.

#### NOTICE

Always determine the cause of the engine shutdown. Make necessary repairs before attempting to restart the engine.

Be familiar with the following items:

- Types and locations of shutoff
- Conditions which cause each shutoff to function
- The resetting procedure that is required to restart the engine

### Alarms

The alarms are electrically operated. The operations of the alarms are controlled by the ECM.

The alarm is operated by a sensor or by a switch. When the sensor or the switch is activated, a signal is sent to the ECM. An event code is created by the ECM. The ECM will send a signal to illuminate the lamp.

Your engine may be equipped with the following sensors or switches:

**Coolant temperature** – The coolant temperature sensor indicates high jacket water coolant temperature.

**Intake manifold air temperature** – The intake manifold air temperature sensor indicates high intake air temperature.

**Intake manifold pressure** – The intake manifold pressure sensor checks the rated pressure in the engine manifold.

**Fuel rail pressure** – The fuel rail pressure sensor measures the high pressure or low pressure in the fuel rail. The ECM will Check the pressure.

**Engine oil pressure** – The engine oil pressure switch indicates when oil pressure drops below rated system pressure, at a set engine speed.

**Engine overspeed** – If the engine rpm exceeds the overspeed setting, the alarm will be activated.

**Air filter restriction** – The switch checks the air filter when the engine is operating.

**User-defined switch** – This switch can shut down the engine remotely.

Water in fuel switch – This switch checks for water in the primary fuel filter when the engine is operating.

**Fuel temperature** – The fuel temperature sensor monitors the pressurized fuel in the high-pressure fuel pump.

NRS absolute pressure and NRS delta pressure – A combined pressure sensor across the NRS valve.

**Note:** The sensing element of the coolant temperature sensor must be submerged in coolant to operate.

Engines may be equipped with alarms to alert the operator when undesirable operating conditions occur.

#### NOTICE

When an alarm is activated, corrective measures must be taken before the situation becomes an emergency in order to avoid possible engine damage.

If corrective measures are not taken within a reasonable time, engine damage could result. The alarm will continue until the condition is corrected. The alarm may need to be reset.

**Note:** If installed, the coolant level switch and the oil level switch are indicators. Both switches operate when the application is on level ground and the engine RPM at zero.

### Aftertreatment System

- Diesel Oxidation Catalyst \_\_\_\_\_(DOC)
- Selective Catalyst Reduction \_\_\_\_\_(SCR)
- Diesel Particulate Filter \_\_\_\_\_(DPF)

**Soot Sensors** – The soot sensor monitor the soot level within the DPF.

**NOx Sensors** – Two NOx sensors monitor the NOx concentration within the exhaust gas before and after the selective catalyst reduction module.

**Temperature Sensor** – A temperature sensor after the engine exhaust gas exit, after the DOC and before the SCR module monitor the temperatures within the system.

**DEF Tank Header Unit** – The DEF level sensor monitors the volume of fluid in the tank and signals the ECM if the level drops below a given point.

### Testing

Turning the keyswitch to the ON position will check the indicator lights on the control panel. All the indicator lights will be illuminated for 2 seconds after the keyswitch is operated. Replace suspect bulbs immediately.

Refer to Troubleshooting for more information.

i05408886

# Battery Disconnect Switch (If Equipped)

SMCS Code: 1411

Allow at least 2 minutes after the engine has stopped before you turn the battery disconnect switch to OFF. Disconnecting the battery power too soon will prevent purging of the Diesel Exhaust Fluid (DEF) lines after the engine is shut down. Also, during the 2 minutes the engine Electronic Control Module (ECM) is active storing information from the engine and aftertreatment sensors.

Not allowing the DEF purge to be performed can damage the DEF system. Not allowing the engine ECM time to store the information from the sensors can damage to emission control system.

Some applications, the engine can be equipped with a wait to disconnect lamp. The wait to disconnect lamp will be illuminated during engine operation and will be extinguished approximately 2 minutes after the engine has stopped.




Illustration 50

g03265058

Battery disconnect switch label

90020000

NOTICE

Do not turn off the battery disconnect switch until the indicator lamp has turned off. If the switch is turned off when the indicator lamp is illuminated the Diesel Exhaust Fluid (DEF) system will not purge the DEF. If the DEF does not purge, DEF could freeze and damage the pump and lines.

#### NOTICE

Never move the battery disconnect switch to the OFF position while the engine is operating. Serious damage to the electrical system could result.

i08773514

# **Gauges and Indicators**

SMCS Code: 7450

Your engine may not have the same gauges or all the gauges that are described. For more information about the gauge package, see the OEM information.

Gauges provide indications of engine performance. Ensure that the gauges are in good working order. Determine the normal operating range by observing the gauges over a period.

Noticeable changes in gauge readings indicate potential gauge or engine problems. Problems may also be indicated by gauge readings that change even if the readings are within specifications. Determine and correct the cause of any significant change in the readings. Consult your Caterpillar dealer for assistance.

Some engine applications are equipped with Indicator Lamps. Indicator lamps can be used as a diagnostic aid. There are two lamps. One lamp has an orange lens and the other lamp has a red lens.

These indicator lamps can be used in two ways:

- The indicator lamps can be used to identify the current operational status of the engine. The indicator lamps can also indicate that the engine has a fault. This system is automatically operated via the ignition switch.
- The indicator lamps can be used to identify active diagnostic codes. This system is activated by pressing the Flash Code button.

Refer to the Troubleshooting Guide, "Indicator Lamps" for further information.

#### NOTICE

If no oil pressure is indicated, STOP the engine. If maximum coolant temperature is exceeded, STOP the engine. Engine damage can result.



#### Engine Oil Pressure – The oil pressure should be greatest after a cold engine is started. The typical engine oil pressure with SAE10W40 is 350 to 450 kPa (50 to 65 psi) at rated rpm.

A lower oil pressure is normal at low idle. If the engine speed and load are stable and the gauge reading changes, perform the following procedure:

- 1. Remove the load.
- 2. Stop the engine.
- 3. Check and maintain the oil level.



#### Jacket Water Coolant Temperature -Typical temperature range is 82° to 94°C (179.6° to 169.2°F). This temperature range will vary according to engine load and the ambient temperature.

A 100 kPa (14.5 psi) radiator cap must be installed on the cooling system. The maximum temperature for the cooling system is 108° C (226.4° F). This temperature is measured at the outlet for the water temperature regulator. The engine coolant temperature is monitored by the engine sensors and the engine ECM. This programming cannot be altered. Derates can occur if the maximum engine coolant temperature is exceeded.

If the engine is operating above the normal range, reduce the engine load. If high coolant temperatures are a frequent event, perform the following procedures:

- 1. Reduce the load on the engine.
- 2. Determine if the engine must be shut down immediately or if the engine can be cooled by reducing the load.
- **3.** Inspect the cooling system for leaks. If necessary, consult your Caterpillar dealer for assistance.



Tachometer – This gauge indicates engine speed (rpm). When the throttle control lever is moved to the full throttle position without load, the engine is running at

high idle. The engine is running at the full load rpm when the throttle control lever is at the full throttle position with maximum rated load.

#### NOTICE

To help prevent engine damage, never exceed the high idle rpm. Overspeeding can result in serious damage to the engine. Operation at speeds exceeding high idle rpm should be kept to a minimum.

1	T	
Ċ	7	)

Ammeter – This gauge indicates the amount of charge or discharge in the battery charging circuit. Operation of the indicator should be to the "+" side of "0" (zero).



Engine - Electrical Preheat – This indicator comes "ON" to show that the glow plug preheat is active. The engine should be set to "RUN" only after indicator lamp on the display turns "OFF".



Fuel Level – This gauge indicates the fuel level in the fuel tank. The fuel level gauge operates when the "START/STOP" switch is in the "on" position.



Service Hour Meter – The gauge indicates total operating hours of the engine.

### Indicator Lamps

- Shutdown lamp
- Warning lamp
- Low oil pressure lamp
- Wait to start lamp (Glow plug warning lamp)

For information, refer to this manual, "Monitoring System (Table for the Indicator Lamps)" for the sequence of operation of the shutdown lamp and the warning lamp.

The function of the wait to start lamp is automatically controlled at engine start-up.

The function of the low oil pressure lamp is controlled by the engine ECM. If low oil pressure is detected, the lamp will be illuminated. The reason for the illumination of the low-pressure lamp should be investigated immediately.

The glow plug warning lamp will flash to show that the engine is being held at low speed. This function will be performed at engine starting and the duration will depend on ambient temperature and engine temperature.

The lamps will illuminate for 2 seconds to check that the lamps are functioning when the keyswitch is turned to the ON position. If any of the lamps stay illuminated, or a lamp fails to be illuminated the reason should be investigated immediately.

## Aftertreatment Lamps and gauges

All applications will require the following lamps and gauges:

- Emission malfunction lamp
- · Action indicator lamp
- Gauge for Diesel Exhaust Fluid (DEF)
- Low warning lamp for DEF
- Wait to disconnect lamp (optional)

The wait to disconnect lamp will be illuminated during engine operation and will be extinguished approximately 2 minutes after the engine has stopped. Do not disconnect the battery disconnect switch during the period the lamp is illuminated. The diesel exhaust fluid system will be purged during this time. Also, during the 2 minutes the engine electronic control module is active storing information from the engine and aftertreatment sensors.

**Note:** The wait to disconnect lamp will not be checked at key on.

i07682718

# **Monitoring System** (Engine Indicators and Aftertreatment Indicators)

SMCS Code: 1900; 7400; 7450; 7451

### **Engine Indicator Lamps**

**Note:** When in operation the amber warning lamp has three states, solid, flashing, and fast flashing. The sequence is to give a visual indication of the importance of the warning. Some application can have an audible warning installed.

Ensure that the engine maintenance is carried out at the correct intervals. A lack of maintenance can result in illumination of the warning lamp. For the correct intervals of maintenance, refer to the Operation and Maintenance Manual, "Maintenance Interval Schedule". Table 4

	Indicator Lamp Table			
Warning Lamp	Shutdown Action Indi- cator Lamp	Lamp State	Description of the Indication	Engine Status
On	On	Lamp Check	When the keyswitch is moved to the ON po- sition, the lamps come on for 2 seconds and the lamps will then go off.	The keyswitch is in the ON position but the en- gine has not yet been cranked.
			lluminate during indicator check, the fault mus y illuminated or flash, the fault must be investig	
Off	Off	No Faults	With the engine in operation, there are no active warnings, diagnostic codes, or event codes.	The engine is operating with no detected faults.
On Solid	Off	Warning	Level 1 warning	The engine is operating normally but there is one or more faults with the electronic management system for the engine.
		As s	soon as possible the fault should be investigate	ed.
Flashing	Off	Warning	Level 2 warning	The engine continues to be operated, but the level of importance of the warning has increased. Depending on the particular fault and the se- verity the engine may be de-rated. The engine could be damaged if continued to be operated.
			Stop the engine. Investigate the code.	
Flashing	On	Engine Shutdown	Level 3 warning If both the warning lamp and the shutdown lamp are in operation, this issue indicates one of the following conditions. 1. One or more of the shutdown values for the engine protection strategy has been exceeded. 2. A serious active diagnostic code has	The engine is either shutdown or an engine shutdown is imminent. One or more monitored engine parameters have exceeded the limit for an engine shutdown. This pattern of lamps can be caused by the detection of a serious active diagnostic code. Contact your Caterpillar dealer.
			been detected. If installed, the audible warning will sound. After a short time period, the engine may shut down.	

### **Flash Codes**

Some applications may support flash codes. A flash code can be viewed by an indicator lamp that when asked will flash in a particular sequence. The indicator lamp used to view the codes is the warning lamp, the lamp can then be referred to as a diagnostic lamp. For more information refer to this Operation and Maintenance Manual, "Diagnostic Lamp".

### Aftertreatment System

The aftertreatment indicators should illuminate at key on for 2 seconds to test the system. If any of the indicators do not illuminate, the fault must be investigated immediately. For more information on the illumination of the aftertreatment indicators refer to this Operation and Maintenance Manual, "Selective Catalytic Reduction Warning System".

i08068136


# Sensors and Electrical Components

SMCS Code: 1900; 7400

The illustrations within the following sections are typical location of the sensors or electrical components for an industrial engine. Specific engines may appear different due to differences in applications.


- NRS NOx Reduction System
- **DEF** Diesel Exhaust Fluid
- DOC Diesel Oxidation Catalyst
- **DPF** Diesel Particulate Filter
- SCR Selective Catalytic Reduction
- **ECM** Electronic Control Module
- NOx Nitrogen Oxides

### **C3.6 Industrial Engines**



#### Illustration 51

- (1) Engine 47-pin interface connector
- (2) Inlet throttle valve
- (3) Inlet manifold combined pressure and temperature sensor
- (4) Temperature sensor pre-NRS valve
- (5) Coolant temperature sensor
- (6) Alternator
- (7) Starting motor
- (8) Camshaft speed/timing sensor
- (9) Fuel temperature sensor
- (10) Control valve for high-pressure fuel
- (11) Temperature sensor post NRS valve




### Typical example


- (12) NRS Differential pressure sensor(13) NRS valve(14) Injector 1 and injector 2

- (15) Injector 3 and injector 4(16) Actuator for turbocharger(17) Crankshaft speed/timing sensor

(18) Engine oil pressure switch(19) Fuel rail pressure sensor



- Typical example
- (20) DEF Injector(21) DPF Differential pressure sensor
- (22) Temperature sensor controller with 3 probes across aftertreatment (in transport position)
- (A) DPF temperature probe (B) DOC temperature probe (C) SCR temperature probe




Industrial engine equipped with a balancer

(23) DPF Differential pressure sensor(24) DEF Injector

(25) Temperature sensor controller connection with 3 probes across aftertreatment (A) DOC temperature probe(B) DPF temperature probe(C) SCR temperature probe

g06511813

# **Off Engine Sensors and Electrical** Components




### Illustration 55

- (1) ECM(2) If equipped, Air intake temperature sensor (Air Cleaner)(3) Priming pump

- (4) Water in fuel switch
- (5) Coolant diverter valve
  (6) DEF tank level, temperature sensor, and DEF quality sensor
- (7) DEF pump (8) NOx sensors(9) DEF heated lines


## **C2.8 Industrial Engine**



#### Illustration 56

- (1) Engine 47-pin interface connector(2) Inlet throttle valve
- (3) Temperature sensor pre-NRS valve
- (4) Coolant temperature sensor
- (5) Alternator

- (6) Starting motor(7) Camshaft speed/timing sensor(8) Fuel temperature sensor
- (9) Control valve for high-pressure fuel pump
- (10) Inlet Manifold Temperature Sensor (11) Inlet Manifold Pressure Sensor
- (12) Temperature sensor post NRS valve




### Typical example

(13) NRS Differential pressure sensor (14) NRS valve (15) Injector 1 and injector 2 (Injector 3 and injector 4 not shown)(16) Crankshaft speed/timing sensor

(17) Engine oil pressure switch(18) Fuel rail pressure sensor

g06481410




### Typical example

(19) Temperature sensor controller with 2 probes across aftertreatment (in transport position)

(20) Tube assembly for Differential pressure(21) DPF Differential pressure sensor(22) Tube assembly for Differential pressure

(A) DPF temperature probe (B) DOC temperature probe

## **C2.8 Off Engine Sensors and Electrical Components**



(1) ECM

(2) If equipped, Air intake temperature sensor (Air Cleaner)

(3) Priming pump(4) Water in fuel switch

# **Engine Diagnostics**

i01796959

# Self-Diagnostics

SMCS Code: 1000; 1900; 1901; 1902

Caterpillar Electronic Engines have the capability to perform a self-diagnostics test. When the system detects an active problem, a diagnostic lamp is activated. Diagnostic codes will be stored in permanent memory in the Electronic Control Module (ECM). The diagnostic codes can be retrieved by using Caterpillar electronic service tools.

Some installations have electronic displays that provide direct readouts of the engine diagnostic codes. Refer to the manual that is provided by the OEM for more information on retrieving engine diagnostic codes.

Active codes represent problems that currently exist. These problems should be investigated first.

Logged codes represent the following items:

- Intermittent problems
- · Recorded events
- · Performance history

The problems may have been repaired since the logging of the code. These codes do not indicate that a repair is needed. The codes are guides or signals when a situation exists. Codes may be helpful to troubleshoot problems.

When the problems have been corrected, the corresponding logged fault codes should be cleared.

i03554520

# **Diagnostic Lamp**

SMCS Code: 1000; 1900; 1901; 1902; 7451

A diagnostic lamp is used to indicate the existence of an active fault. A fault diagnostic code will remain active until the problem is repaired. The diagnostic code may be retrieved by using the electronic service tool.

i04907245

# Diagnostic Flash Code Retrieval

SMCS Code: 1000; 1900; 1901; 1902

Use the following procedure to retrieve the flash codes if the engine is equipped with a "DIAGNOSTIC" lamp:

- 1. Move the keyswitch from the on/off two times within 3 seconds.
- 2. The shutdown warning lamp will flash once.
- **3.** A flashing YELLOW lamp indicates a 3-digit diagnostic code for the engine. The sequence of flashes represents the system diagnostic message. Count the first sequence of flashes in order to determine the first digit of the flash code. After a two second pause, the second sequence of flashes will identify the second digit of the flash code. After the second pause, the third sequence of flashes will identify the flash code.
- **4.** After the diagnostic codes have been displayed, the shutdown lamp will flash twice and the indicator lamp will start to flash the logged diagnostic codes.
- **5.** After the logged diagnostic codes have been displayed, the shutdown lamp will flash three times in order to indication that the code sequences have finished.

**Note:** If there are no diagnostic codes or logged diagnostic codes, the system will flash the code 551.

i05406659

# **Fault Logging**

SMCS Code: 1000; 1900; 1901; 1902

The system provides the capability of Fault Logging. When the Electronic Control Module (ECM) generates an active diagnostic code, the code will be logged in the memory of the ECM. The codes that have been logged by the ECM can be identified by the electronic service tool. The active codes that have been logged will be cleared when the fault has been rectified or the fault is no longer active. The following logged faults cannot be cleared from the memory of the ECM without using a factory password: Overspeed, low engine oil pressure, high engine coolant temperature, and aftertreatment codes.

i03554534

# Engine Operation with Active Diagnostic Codes

SMCS Code: 1000; 1900; 1901; 1902

If a diagnostic lamp illuminates during normal engine operation, the system has identified a situation that is not within the specification. Use electronic service tools to check the active diagnostic codes. **Note:** If the customer has selected "DERATE" and if there is a low oil pressure condition, the Electronic Control Module (ECM) will limit the engine power until the problem is corrected. If the oil pressure is within the normal range, the engine may be operated at the rated speed and load. However, maintenance should be performed as soon as possible.

The active diagnostic code should be investigated. The cause of the problem should be corrected as soon as possible. If the cause of the active diagnostic code is repaired and there is only one active diagnostic code, the diagnostic lamp will turn off.

Operation of the engine and performance of the engine can be limited as a result of the active diagnostic code that is generated. Acceleration rates may be significantly slower. Refer to the Troubleshooting Guide for more information on the relationship between these active diagnostic codes and engine performance.

i01797063

# Engine Operation with Intermittent Diagnostic Codes

### **SMCS Code:** 1000; 1900; 1901; 1902

If a diagnostic lamp illuminates during normal engine operation and the diagnostic lamp shuts off, an intermittent fault may have occurred. If a fault has occurred, the fault will be logged into the memory of the Electronic Control Module (ECM).

In most cases, it is not necessary to stop the engine because of an intermittent code. However, the operator should retrieve the logged fault codes and the operator should reference the appropriate information in order to identify the nature of the event. The operator should log any observation that could have caused the lamp to light.

- · Low power
- · Limits of the engine speed
- Excessive smoke, etc

This information can be useful to help troubleshoot the situation. The information can also be used for future reference. For more information on diagnostic codes, refer to the Troubleshooting Guide for this engine.

i08165229

# **Engine Starting**

i08171598

# **Before Starting Engine**

SMCS Code: 1000; 1400; 1450

Perform the required daily maintenance and other periodic maintenance before the engine is started. Inspect the engine compartment. This inspection can help prevent major repairs later. Refer to the Operation and Maintenance Manual, "Maintenance Interval Schedule" for more information.

- Ensure that the engine has an adequate fuel supply.
- Ensure that the engine has an adequate diesel exhaust fluid supply
- Open the fuel supply valve (if equipped).
- Drain the water separators.

#### NOTICE

All valves in the fuel return line must be open and fuel supply lines must be open. Damage to the fuel system can occur if fuel lines are closed with the engine in operation.

If the engine has not been started for several weeks, fuel may have drained from the fuel system. Air may have entered the filter housing. Also, when fuel filters have been changed, some air pockets will be trapped in the engine. In these instances, prime the fuel system. Refer to the Operation and Maintenance Manual, "Fuel System - Prime" for more information on priming the fuel system. Also, check that the fuel specification is correct and that the fuel condition is correct. Refer to the Operation and Maintenance Manual, "Fuel Recommendations".

### 

Engine exhaust contains products of combustion which may be harmful to your health. Always start and operate the engine in a well ventilated area and, if in an enclosed area, vent the exhaust to the outside.

- Do not start the engine or move any of the controls if there is a "DO NOT OPERATE" warning tag or similar warning tag attached to the start switch or to the controls.
- · Reset all the shutoffs or alarm components.
- Ensure that any driven equipment has been disengaged. Minimize electrical loads or remove any electrical loads.

# **Cold Weather Starting**

SMCS Code: 1000; 1250; 1450; 1453; 1456; 1900

### WARNING

Do not use aerosol types of starting aids such as ether. Such use could result in an explosion and personal injury.

The ability to start the engine will be improved at temperatures below -18 °C (0 °F) from the use of a jacket water heater or extra battery capacity.

The following items provide a means of minimizing starting problems and fuel problems in cold weather: Engine oil pan heaters, jacket water heaters, fuel heaters, and fuel line insulation.

Use the procedure that follows for cold weather starting.

**Note:** Do not adjust the engine speed control during start-up. The electronic control module (ECM) will control the engine speed during start-up.

1. Disengage any driven equipment.

**Note:** During key ON, the indicator lamps will be illuminated for 2 seconds to check the lamp operation. If any of the indicator lamps do not illuminate check the bulb. If any indicator lamps stay illuminated or flash, refer to Troubleshooting, "Indicator Lamp Circuit - Test".

- 2. Turn the keyswitch to the RUN position. Leave the keyswitch in the RUN position until the warning light for the glow plugs is extinguished.
- **3.** When the warning light for the glow plugs is extinguished, turn the keyswitch to the START position to engage the electric starting motor and crank the engine.

**Note:** The operating period of the warning light for the glow plugs will change due to the ambient air temperature.

### NOTICE

Do not engage the starting motor when flywheel is turning. Do not start the engine under load.

If the engine fails to start within 30 seconds, release the starter switch or button and wait two minutes to allow the starting motor to cool before attempting to start the engine again.

**4.** Allow the keyswitch to return to the RUN position after the engine starts.

**5.** Repeat step 2 through step 4 if the engine fails to start.

**Note:** After starting, the engine may be held at low speed for a duration between 1 and 60 seconds to allow engine systems to stabilize. The duration will depend on ambient temperature, time since last run and other factors. The glow plug warning lamp will flash to indicate that the engine has been held at low speed.

- 6. The engine should not be raced to speed up the warm-up process. Allow the engine to idle for 3 to 5 minutes, or allow the engine to idle until the water temperature indicator begins to rise. When idling after the engine has started in cold weather, increase the engine rpm from low idle to 1200 rpm. This operation will warm up the engine more quickly.
- **7.** Operate the engine at low load until all systems reach operating temperature. Check the gauges during the warm-up period.

Following a cold start, white vapor can be seen from the tailpipe. This vapor is normal and caused by condensation leaving the exhaust system after warming up. The white vapor should clear following working of the engine.

i08165241

# **Starting the Engine**

SMCS Code: 1000; 1450

**Note:** Do not adjust the engine speed control during start-up. The electronic control module (ECM) will control the engine speed during start-up.

# **Starting the Engine**

- **1.** Disengage any equipment that is driven by the engine.
- **2.** Turn the keyswitch to the RUN position. Leave the keyswitch in the RUN position until the warning light for the glow plugs is extinguished.

**Note:** If the keyswitch has been left in the RUN position for a long period of time without engaging the electric starting motor, turn the keyswitch from the RUN position to the OFF position and then back to the RUN position to reactivate the glow plug preheat stage.

**Note:** During the key on, the indicator lamps will be illuminated for 2 seconds to check lamp operation. If any of the lamps do not illuminate, check the bulb. If any indicator lamps stay illuminated or flash, refer to Troubleshooting, "Indicator Lamp Circuit - Test".

**3.** When the warning light for the glow plugs is extinguished, turn the keyswitch to the START position to engage the electric starting motor and crank the engine.

**Note:** The operating period of the warning light for the glow plugs will change due to the temperature of the engine.

NOTICE Do not engage the starting motor when flywheel is turning. Do not start the engine under load.

If the engine fails to start within 30 seconds, release the starter switch or button and wait two minutes to allow the starting motor to cool before attempting to start the engine again.

- **4.** Allow the keyswitch to return to the RUN position after the engine starts.
- **5.** Repeat step 2 through step 4 if the engine fails to start.
- **6.** After starting, the engine may be held at low speed for a duration between 1 and 60 seconds to allow engine systems to stabilize. The duration will depend on ambient temperature, time since last run and other factors. The glow plug warning light will flash to indicate that the engine is being held at low speed in some applications.

i07926219

# Starting with Jump Start Cables

(Do Not Use This Procedure in Hazardous Locations that have Explosive Atmospheres)

**SMCS Code:** 1000; 1401; 1402; 1900

# 

The connection of battery cables to a battery and the disconnection of battery cables from a battery may cause an explosion which may result in injury or death. The connection and the disconnection of other electrical equipment may also cause an explosion which may result in injury or death. The procedures for the connection and the disconnection of battery cables and other electrical equipment should only be performed in a nonexplosive atmosphere.

## 

Improper jump start cable connections can cause an explosion resulting in personal injury.

Prevent sparks near the batteries. Sparks could cause vapors to explode. Do not allow jump start cable ends to contact each other or the engine.

**Note:** If possible, first diagnose the reason for the starting failure. Refer to Troubleshooting, "Engine Will Not Crank and Engine Cranks But Will Not Start" for further information. Make any necessary repairs. If the engine will not start only due to the condition of the battery, either charge the battery, or start the engine by using another battery with jump-start cables. The condition of the battery can be rechecked after the engine has been switched OFF.

#### NOTICE

For C3.6 industrial engines, ensure that a 12 VDC or 24 VDC battery source is used to start the engine. For C2.8 industrial engines, use a 12 VDC battery source to start the engine. Never attempt to start an engine from an external power source such as electric welding equipment, which has a voltage that is unsuitable for engine starting and will damage the electrical system.

### NOTICE

Using a battery source with the same voltage as the electric starting motor. Use ONLY equal voltage for jump starting. The use of higher voltage will damage the electrical system.

Do not reverse the battery cables. The alternator can be damaged. Attach ground cable last and remove first.

Turn all electrical accessories OFF before attaching the jump start cables.

Ensure that the main power switch is in the OFF position before attaching the jump start cables to the engine being started.

- **1.** Turn the start switch on the stalled engine to the OFF position. Turn off all the engines accessories.
- 2. Connect one positive end of the jump-start cable to the positive cable terminal of the discharged battery. Connect the other positive end of the jump-start cable to the positive cable terminal of the electrical source.

3. Connect one negative end of the jump-start cable to the negative cable terminal of the electrical source. Connect the other negative end of the jump-start cable to the engine block or to the chassis ground. This procedure helps to prevent potential sparks from igniting the combustible gases that are produced by some batteries.

**Note:** The engine ECM must be powered before the starting motor is operated or damage can occur.

- Start the engine in the normal operating procedure. Refer to this Operation and Maintenance Manual, "Starting the Engine".
- **5.** Immediately after the engine is started, disconnect the jump-start cables in reverse order.

After jump starting, the alternator may not be able to recharge fully batteries that are severely discharged. The batteries must be replaced or charged to the proper voltage with a battery charger after the engine is stopped. Many batteries which are considered unusable are still rechargeable. Refer to Operation and Maintenance Manual, "Battery - Replace" and Testing and Adjusting Manual, "Battery - Test".

i08165244

# **After Starting Engine**

### SMCS Code: 1000

After starting, the engine may be held at low speed for a duration between 1 and 60 seconds to allow engine systems to stabilize. Holding the engine speed low is controlled by the Electronic Control Module (ECM). The duration will depend on ambient temperature, time since last run and other factors.

**Note:** In ambient temperatures from 15° to 20°C (59° to 68°F), the warm-up time is approximately 20 to 30 minutes. In temperatures below 15°C (59°F), additional warm-up time may be required. In temperatures greater than 20° C (68° F), warm-up time may be less.

When the engine idles during warm-up, observe the following conditions:

Do not check the high-pressure fuel lines with the engine or the starting motor in operation. If you inspect the engine in operation, always use the correct inspection procedure to avoid a fluid penetration hazard. Refer to Operation and Maintenance Manual, "General hazard Information".

 Check for any fluid or air leaks at idle rpm and at one-half full rpm (no load on the engine), before operating the engine under load. This check may not be possible in some applications. • Allow the engine to idle for 3 to 5 minutes, or allow the engine to idle until the water temperature indicator begins to rise. Check all gauges during the warm-up period.

Constant speed engines should be allowed to operate at low idle for 3 minutes before used at operational speed. If the low idle option is not available, then operate the engine at operational speed with no load for 2 minutes.

**Note:** Gauge readings should be observed and the data should be recorded frequently while the engine is operating. Comparing the data over time will help to determine normal readings for each gauge. Comparing data over time will also help detect abnormal operating developments. Significant changes in the readings should be investigated.

# **Engine Operation**

i07853963

# **Engine Operation**

SMCS Code: 1000

Correct operation and maintenance are key factors in obtaining the maximum life and economy of the engine. If the directions in the Operation and Maintenance Manual are followed, costs can be minimized and engine service life can be maximized.

The time that is needed for the engine to reach normal operating temperature can be less than the time taken for a walk-around inspection of the engine.

The engine can be operated at the rated rpm after the engine is started and after the engine reaches operating temperature. The engine will reach normal operating temperature sooner during a low engine speed (rpm) and during a low-power demand. This procedure is more effective than idling the engine at no load. The engine should reach operating temperature in a few minutes.

Avoid excess idling. Excessive idling causes carbon buildup, engine slobber, and soot loading of the Diesel Particulate Filter (DPF). These issues are harmful to the engine.

Gauge readings should be observed and the data should be recorded frequently while the engine is operating. Comparing the data over time will help to determine normal readings for each gauge. Comparing data over time will also help detect abnormal operating developments. Significant changes in the readings should be investigated.

# Engine Operation and the Aftertreatment System

The exhaust gases and hydrocarbon particles from the engine first pass through Diesel Oxidation Catalyst (DOC). Some of the gasses and matter are oxidized as the gasses pass through the DOC. The gasses then pass through the Diesel Particulate Filter (DPF). The DPF collects the soot and any ash that is produced by the combustion in the engine. During regeneration, the soot is converted into a gas and the ash remains in the DPF. The gasses finally pass through the Selective Catalytic Reduction (SCR). Before the gasses pass through the SCR, Diesel Exhaust Fluid (DEF) is injected into the gas stream.

The DEF is stored in the DEF tank and is pumped to the DEF injector. The DEF injector is controlled by the ECM. The mixtures of DEF and the exhaust gas pass through the SCR reducing the NOx in the exhaust emissions. The DPF may require the exhaust gas temperature to rise to remove the soot. If necessary, the throttle valve is operated to help in rising the exhaust temperature.

The engine software will control the amount of DEF that will be required to keep the exhaust emission compliant.

This design of DPF will not require a service maintenance interval. The DPF can be expected to function properly for the useful life of the engine (emissions durability period), as defined by regulation, subject to prescribed maintenance requirements being followed.

A fault code will be active for any DPF system-related issue. Follow the troubleshooting guide to rectify the issue.

If the DPF loses function, or is tampered with in any way, the check engine lamp, and an amber action (if equipped) will illuminate. A fault code will also annunciate. The lamps and fault code will remain active until the problem is rectified.

#### NOTICE

The engine and emissions control system shall be operated, used, and maintained in accordance with the instructions provided. Failure to follow the instructions could result in emissions performance that does not meet the requirements applicable to the category of the engine. No deliberate tampering with, or misuse of the engine emissions control system should take place. Prompt action is critical to rectify any incorrect operation, use, or maintenance of the emissions control system.

## Carbon Dioxide (CO<sub>2</sub>) Emissions Statement

Emissions regulations require that the value of the  $CO_2$  emissions be reported to the end user.

## C3.6 Industrial Engine

For engines with a power rating of 56 kW (75.1 hp) and below, 903.75 g/kWh was determined to be the  $CO_2$  value during the EU type approval process. For engines with a power rating of 70 kW (93.9 hp) and above, 733.73 g/kWh was determined to be the  $CO_2$ value during the EU type approval process. This value was recorded in EU type approval certificate. This  $CO_2$  measurement results from testing over a fixed test cycle, under laboratory conditions, with a parent engine representative of the engine family. This value shall not imply or express any guarantee of the performance of a particular engine.

## **C2.8 Industrial Engine**

856.35 g/kWh was determined to be the  $CO_2$  value during the EU type approval process. This value was recorded in EU type approval certificate. This  $CO_2$ measurement results from testing over a fixed test cycle, under laboratory conditions, with a parent engine representative of the engine family. This value shall not imply or express any guarantee of the performance of a particular engine.

i01646335

# Engaging the Driven Equipment

#### SMCS Code: 1000

- **1.** Operate the engine at one-half of the rated rpm, when possible.
- **2.** Engage the driven equipment without a load on the equipment, when possible.

Interrupted starts put excessive stress on the drive train. Interrupted starts also waste fuel. To get the driven equipment in motion, engage the clutch smoothly with no load on the equipment. This method should produce a start that is smooth and easy. The engine rpm should not increase and the clutch should not slip.

- **3.** Ensure that the ranges of the gauges are normal when the engine is operating at one-half of the rated rpm. Ensure that all gauges operate properly.
- **4.** Increase the engine rpm to the rated rpm. Always increase the engine rpm to the rated rpm before the load is applied.
- **5.** Apply the load. Begin operating the engine at low load. Check the gauges and equipment for proper operation. After normal oil pressure is reached and the temperature gauge begins to move, the engine may be operated at full load. Check the gauges and equipment frequently when the engine is operated under load.

Extended operation at low idle or at reduced load may cause increased oil consumption and carbon buildup in the cylinders. This carbon buildup results in a loss of power and/or poor performance.

i04018250

# **Fuel Conservation Practices**

#### SMCS Code: 1000; 1250

The efficiency of the engine can affect the fuel economy. Caterpillar's design and technology in manufacturing provides maximum fuel efficiency in all applications. Follow the recommended procedures in order to attain optimum performance for the life of the engine.

• Avoid spilling fuel.

Fuel expands when the fuel is warmed up. The fuel may overflow from the fuel tank. Inspect fuel lines for leaks. Repair the fuel lines, as needed.

- Be aware of the properties of the different fuels. Use only the recommended fuels. Refer to the Operations and Maintenance Manual, "Fuel Recommendations" for further information.
- · Avoid unnecessary idling.

Shut off the engine rather than idle for long periods of time.

• Observe the service indicator frequently. Keep the air cleaner elements clean.

- Ensure that the turbocharger is operating correctly. For more information refer to this Operation and Maintenance Manual, "Turbocharger - Inspect".
- Maintain a good electrical system.

One faulty battery cell will overwork the alternator. This fault will consume excess power and excess fuel.

- The belt should be in good condition. Refer to the Systems Operation, Testing and Adjusting, "V -Belt Test" for further information.
- Ensure that all of the connections of the hoses are tight. The connections should not leak.
- Ensure that the driven equipment is in good working order.
- Cold engines consume excess fuel. Utilize heat from the jacket water system and the exhaust system, when possible. Keep cooling system components clean and keep cooling system components in good repair. Never operate the engine without water temperature regulators. All of these items will help maintain operating temperatures.

# **Aftertreatment Operation**

i07682723

## Selective Catalytic Reduction Warning System

SMCS Code: 1091-WXX; 7400

The Selective Catalytic Reduction (SCR) system is a system used to reduce Nitrogen Oxide (NOx) emissions from the engine. Diesel Exhaust Fluid (DEF) is pumped from the DEF tank and is sprayed into the exhaust stream. The DEF reacts with the SCR catalyst to reduce NOx and leaves a nitrogen and water vapor.

The engine and emissions control system shall be operated, used, and maintained in accordance with the instructions provided to the end user to maintain the emissions performance of the engine within the requirements applicable to the category of the engine. No deliberate tampering with, or misuse of the engine emissions control system should take place. In particular regarding deactivating, or not maintaining the SCR system.

#### NOTICE

Stopping the engine immediately after the engine has been working under load can result in overheating of SCR components.

Refer to the Operation and Maintenance Manual, "Engine Stopping" procedure to allow the engine to cool and to prevent excessive temperatures in the turbocharger housing and the DEF injector.

#### NOTICE

Allow at least 2 minutes after shutting down the engine before you turn the battery disconnect switch to OFF. Disconnecting the battery power too soon will prevent purging of the DEF lines after the engine is shutdown.

**Note:** For information on DEF, refer to this Operation and Maintenance Manual, "Fluid Recommendations".

## Warning Strategy

The Electronic Control Module (ECM) will be enabled with a world-wide warning strategy.

## Warning Indicators

The warning indicators consist of a level gauge for the DEF, a low-level lamp for the DEF, an emission malfunction lamp, and the application stop lamp.




Illustration 60

(1) DEF gauge

À Low-level warning lamp

=13

Illustration 61 Emission malfunction lamp g02852336

g03069862

## Warning Levels

The SCR has three levels of warning. The time that the system will stay at each warning level depends on the fault detected and the type of software enabled.

Any warning should be investigated immediately. Contact your Caterpillar dealer if further assistance is required. The system is equipped with an override option. If the override option has been used and the fault still exists, the engine will be locked in de-rate or shutdown mode.

#### Definitions

- **Self-correct** Fault condition no longer exists. An active fault code will no longer be active.
- **Notification** Action taken by the system to alert the operator of pending Inducement.
- **Inducement** Engine derates, vehicle speed limits, or other actions intended to prompt the operator to repair or maintain the emission control system.

Inducement Categories The Inducements are separated into categories. DEF Levels have inducement fault codes separate from the other inducement categories. DEF level inducements are based on the DEF level, the other inducement categories are based on escalating time. The escalating time inducements will always have an associated fault code along with the inducement fault code. The associated fault is the root cause. The escalating time inducement fault code is just an indicator of what level of inducement the engine is in. The escalating time inducement fault code also indicates how much time remains until the next level of inducement. There are three inducement categories that will trigger an escalating time inducement fault code.

**Note:** The associated codes for each of the escalating time categories can be found in Troubleshooting, SCR Warning System Problem.

- **First Time** When an escalating time inducement fault code becomes active for the first time.
- **Repeat occurrence** When any escalating time inducement fault code becomes active again within 40 hours of the first occurrence. Engine must run for 40 hours without tripping any escalating time inducement fault before returning back to first occurrence times.
- Safe Harbor Mode (Worldwide) Safe Harbor Mode is a 20 minute engine run time period. Once in level 3 inducement, the operator can perform a key cycle and the engine will enter Safe Harbor Mode. Safe Harbor Mode can only be implemented once. Safe Harbor Mode is not allowed for DEF level inducements with Worldwide configuration.

#### NOTICE

It is essential to take prompt action to rectify any incorrect operation, use, or maintenance of the emissions SCR control system in accordance with the rectification measures indicated by the warnings listed on the following pages.

#### World-Wide SCR Warnings

- At Level 1 the emission malfunction lamp will be on solid.
- At Level 2 the emission malfunction lamp will flash.
- At Level 3 the emission malfunction lamp will flash and the stop lamp will activate.
- At Level 3 the engine may shut down, or operate at 1000 Revolutions Per Minute (RPM).

 At Level 3 cycling the keyswitch will give 20 minutes override at full power, before the shutdown or idle is triggered. The emission malfunction lamp will continue to flash.

## World-Wide Reduced Performance Setting

Тэ	h	ما	5
Ia	D	ie	Э

	World-Wide Reduced Performance Setting					
	Category	1 Fault (Tampering Do	osing Interruption and	Quality)		
-	Normal operation	Level 1	Level 2	Level 3	Override	
Inducement Time First Occurrence	None	2.5 Hours	70 minutes	50 Percent torque Shut down or idle Until fault heals	Cycling the keyswitch will give 20 minutes of full power	
the repeat occurrence i	The system must be fault free for 40 hours before the system will reset to zero. If the fault is intermittent, and returns within the 40 hours, then the repeat occurrence inducement time will be triggered. The override can only be used once					
Inducement Time Repeat Occurrence	None	5 minutes	75 Percent torque	50 Percent torque Shut down or idle	Cycling the keyswitch will give 20 minutes of full power	
Inducement	None	None	None	Until fault heals		
Notification	None	Emission malfunction lamp will be on solid	Emission malfunction lamp will flash	Emission malfunction lamp will flash The stop lamp will be on solid	Emission malfunction lamp will flash	
Contact your Caterpilla	r dealer at level 1 warning	J, do not let the fault dev	elop.			
Table 6						
		World-Wide Reduced	Performance Setting			

world-wide Reduced Performance Setting						
	Category 2 Fault (Non-Tampering Dosing and Interruption)					
-	Normal operation	Level 1	Level 2	Level 3	Override	
Inducement Time First Occurrence	None	10 Hours	10 Hours	50 Percent torque Shut down or idle Until fault heals	Cycling the keyswitch will give 20 minutes of full power	
The system must be fault free for 40 hours before the system will reset to zero. If the fault is intermittent, and returns within the 40 hours, then the repeat occurrence inducement time will be triggered. The override can only be used once						
Inducement Time Repeat Occurrence	None	None	2 Hours	Shut down or idle	Cycling the keyswitch will give 20 minutes	
Inducement	None	None	75 Percent of torque	Until fault heals	of full power	
Notification	None	Emission malfunction lamp will be on solid	Emission malfunction lamp will flash	Emission malfunction lamp will flash The stop lamp will be on solid	Emission malfunction lamp will flash	
Contact your Caterpillar dealer at level 1 warning, do not let the fault develop.						

Table 7

World-Wide Reduced Performance Setting					
Category 3 Fault (Non-Tampering NOx Control Monitoring and Impeded EGR)					
-	Normal operation	Level 1	Level 2	Level 3	Override

(Table 7, contd)

Inducement Time First Occurrence	None	36 Hours	64 Hours	50 Percent torque Shut down or idle Until fault heals	Cycling the keyswitch will give 20 minutes of full power
The system must be fault free for 40 hours before the system will reset to zero. If the fault is intermittent, and returns within the 40 hours, then the repeat occurrence inducement time will be triggered. The override can only be used once					
Inducement Time Repeat Occurrence	None	None	5 Hours	50 Percent torque Shut down or idle	Cycling the keyswitch will give 20 minutes
Inducement	None	None	75 Percent of torque	Until fault heals	of full power
Notification	None	Emission malfunction lamp will be on solid	Emission malfunction lamp will flash	Emission malfunction lamp will flash The stop lamp will be on solid	Emission malfunction lamp will flash
Contact your Caterpillar dealer at level 1 warning, do not let the fault develop.					

## World-Wide Reduce Time Setting

#### Table 8

World-Wide Reduced Time Setting						
	Category 1 Fault (Tampering Dosing Interruption and Quality)					
-	Normal operation	Level 1	Level 2	Level 3	Override	
Inducement Time First Occurrence	None	2.5 Hours	70 minutes	50 Percent torque Shut down or idle Until fault heals	Cycling the keyswitch will give 20 minutes of full power	
The system must be fault free for 40 hours before the system will reset to zero. If the fault is intermittent, and returns within the 40 hours, then the repeat inducement time will be triggered. The override can only be used once.						
Inducement Time Repeat Occurrence	None	5 minutes	5 minutes	Shut down or idle will give	Cycling the keyswitch will give 20 minutes	
Inducement	None	None	None	Until fault heals	of full power	
Notification	None	Emission malfunction lamp will be on solid	Emission malfunction lamp will flash	Emission malfunction lamp will flash The stop lamp will activate	Emission malfunction lamp will flash	
Contact your Caterpillar dealer at level 1 warning, do not let the fault develop.						
Table 9						

	World-Wide Reduced Time Setting					
	Cat	tegory 2 Fault (Non-Tamp	pering Dosing Interrup	tion)		
-	Normal operation	Level 1	Level 2	Level 3	Override	
Inducement Time First Occurrence	None	5 Hours	5 Hours	50 Percent torque Shut down or idle Until fault heals	Cycling the keyswitch will give 20 minutes of full power	
The system must be fault free for 40 hours before the system will reset to zero. If the fault is intermittent, and returns within the 40 hours, then the repeat inducement time will be triggered. The override can only be used once.						
Inducement Time Repeat Occurrence	None	None	1 Hour	50 Percent torque Shut down or idle	Cycling the keyswitch will give 20 minutes	
Inducement	None	None	None	Until fault heals	of full power	
Notification	None	Emission malfunction lamp will be on solid	Emission malfunction lamp will flash	Emission malfunction lamp will flash The stop lamp will activate	Emission malfunction lamp will flash	
Contact your Caterpill	Contact your Caterpillar dealer at level 1 warning, do not let the fault develop.					

#### Table 10

World-Wide Reduced Time Setting					
Category 3 Fault (Non-Tampering NOx Control Monitoring and Impeded EGR)					
-	Normal operation	Level 1	Level 2	Level 3	Override

(Table 10, contd)

Inducement Time First Occurrence	None	18 Hours	18 Hours	50 Percent torque Shut down or idle Until fault heals	Cycling the keyswitch will give 20 minutes of full power
The system must be fault free for 40 hours before the system will reset to zero. If the fault is intermittent, and returns within the 40 hours, then the repeat inducement time will be triggered. The override can only be used once.					
Inducement Time Repeat Occurrence	None	None	108 Minutes	Shut down or idle w	Cycling the keyswitch will give 20 minutes of full power
Inducement	None	None	None		
Notification	None	Emission malfunction lamp will be on solid	Emission malfunction lamp will flash	Emission malfunction lamp will flash The stop lamp will activate	Emission malfunction lamp will flash
Contact your Caterpillar dealer at level 1 warning, do not let the fault develop.					

#### World-Wide DEF Level Warnings

Two options are available but only one option will be enabled.

- The low-level warning lamp will operate when DEF • level reaches the trigger point of below 20 percent.
- At Level 1 the low-level warning lamp in the DEF gauge will illuminate and the emission malfunction lamp will be on solid.
- At Level 2 the low-level warning lamp for the DEF is active and the emission malfunction lamp will flash.
- · At Level 3 all level 2 warning lamps are active, plus the stop lamp will become active. The engine will shut down or will only operate at 1000 RPM.

Filling the DEF tank will remove the warning from the system.

	World-Wide DEF Level Option 1					
-	Normal operation	Initial indication	Level 1	Level 2	Level 3	
Inducement Trigger	Above 19 percent	Below 19 percent	Below 12.5 percent	0 Percent reading	Empty tank	
Inducement	None	None	None	Engine may be de- rated by 25 percent torque	The engine may be derated by 50 percent torque. A shutdown or low idle only will be en- forced after 5 minutes.	
Notification	None	Low-level lamp illuminated	Low-level lamp illuminated Emission malfunction lamp on solid	Low-level lamp illuminated Emission malfunction lamp flashing	Low-level lamp illuminated Emission malfunction lamp flashing Stop lamp on solid	

Table '	12
---------	----

	World-Wide DEF Level Option 2				
-	Normal operation	Initial indication	Level 1	Level 2	Level 3
Inducement Trigger	Above 19 percent	Below 19 percent	Below 12.5 percent	6 Percent reading	0 Percent reading
Inducement	None	None	None	None	The engine may be derated by 50 percent torque A shutdown or low idle only will be en- forced after 5 minutes.
Notification	None	Low-level lamp illuminated	Low-level lamp illuminated Emission malfunction lamp on solid	Low-level lamp illuminated Emission malfunction lamp flashing	Low-level lamp illuminated Emission malfunction lamp flashing Stop lamp on solid

# **Cold Weather Operation**

i08185453

# **Cold Weather Operation**

SMCS Code: 1000; 1250

Caterpillar Diesel Engines can operate effectively in cold weather. During cold weather, the starting and the operation of the diesel engine depends on the following items:

- · The type of fuel that is used
- The viscosity of the engine oil
- · The operation of the glow plugs
- · Optional Cold starting aid
- · Battery condition
- Ambient air temperature and altitude
- · Parasitic load of the application
- Application hydraulic and transmission oil viscosities

Refer to Special Publication, SEBU5898, "Cold-Weather Recommendations for Caterpillar Machines".

This section will cover the following information:

- Potential problems that are caused by coldweather operation
- Suggested steps which can be taken to minimize starting problems and operating problems when the ambient air temperature is between 0° to-40 °C (32° to 40 °F).

The operation and maintenance of an engine in freezing temperatures is complex . This complexity is because of the following conditions:

- · Weather conditions
- · Engine applications

Recommendations from your Caterpillar dealer are based on past proven practices. The information that is contained in this section provides guidelines for cold-weather operation.

## **Hints for Cold-Weather Operation**

 After starting the engine, the engine speed will be governed for up to a maximum of 60 seconds.
 After this period, the engine should be operated at low loads until a minimum operating temperature of 80° C (176° F) is achieved.

- Achieving operating temperature will help prevent the intake valves and exhaust valves from sticking.
- The cooling system and the lubrication system for the engine do not lose heat immediately upon shutdown. Therefore an engine can be shut down for a period of time and the retained heat within the engine will allow the engine to start readily.
- Install the correct specification of engine lubricant before the beginning of cold weather. Refer to this Operation and Maintenance Manual, "Fluid Recommendations" for the recommended viscosity of oil.
- Check all rubber parts (hoses, fan drive belts) weekly.
- Check all electrical wiring and connections for any fraying or damaged insulation.
- Keep all batteries fully charged and warm by ensuring that the engine is allowed to operate at normal operating temperature.
- · Fill the fuel tank at the end of each shift.
- Check the air cleaners and the air intake daily. Check the air intake more often when you operate in snow.
- Ensure that the glow plugs are in working order. Refer to Troubleshooting, "Glow Plug Starting Aid-Test".

## 

Personal injury or property damage can result from alcohol or starting fluids.

Alcohol or starting fluids are highly flammable and toxic and if improperly stored could result in injury or property damage.

## \Lambda WARNING

Do not use aerosol types of starting aids such as ether. Such use could result in an explosion and personal injury.  For jump starting with cables in cold weather, refer to the Operation and Maintenance Manual, "Starting with Jump-Start Cables." for instructions.

# Viscosity of the Engine Lubrication Oil

Correct engine oil viscosity is essential. Oil viscosity affects lubrication properties and wear protection that the oil provides for the engine. Refer to this Operation and Maintenance Manual, "Fluid Recommendations" for the recommended viscosity of oil.

At temperatures below  $-10^{\circ}$  C (14° F) damage to engine components can occur if the engine is allowed to operate at high load and speed immediately after starting.

## **Recommendations for the Coolant**

Provide cooling system protection for the lowest expected outside temperature. Refer to this Operation and Maintenance Manual, "Fluid Recommendations" for the recommended coolant mixture.

In cold weather, check the coolant often for the correct glycol concentration to ensure adequate freeze protection.

#### **Engine Block Heaters**

Engine block heaters (if equipped) heat the engine jacket water that surrounds the combustion chambers. This heat provides the following functions:

- · Startability is improved.
- · Warm up time is reduced.

An electric block heater can be activated once the engine is stopped. A block heater can be 120 V ac 600W or 220 V ac 550W. Consult your Caterpillar dealer for more information.

## **Idling the Engine**

After starting the engine, the engine speed will be governed for a maximum period of 60 seconds. When idling after the engine is started in cold weather, increase the engine rpm from 1000 to 1200 rpm. This idling will warm up the engine more quickly. Maintaining an elevated low idle speed for extended periods will be easier with the installation of a hand throttle. The engine should not be "raced" to speed up the warm-up process. While the engine is idling, the application of a light load (parasitic load) will help in achieving the minimum operating temperature. The minimum operating temperature is  $80^{\circ}$  C (176° F).

## Recommendations for Coolant Warm Up

Warm up an engine that has cooled below normal operating temperatures due to inactivity. This warm -up should be performed before the engine is returned to full operation. During operation in very cold temperature conditions, damage to engine valve mechanisms can result from engine operation for short intervals. This damage can happen if the engine is started and the engine is stopped many times without being operated to warm up completely.

When the engine is operated below normal operating temperatures, fuel and oil are not burned completely in the combustion chamber. This fuel and oil causes soft carbon deposits to form on the valve stems. Generally, the deposits do not cause problems and the deposits are burned off during operation at normal engine operating temperatures.

When starting and stopping an engine many times without being operated to warm up completely, the carbon deposits become thicker. This starting and stopping can cause the following problems:

- · Free operation of the valves is prevented.
- Valves become stuck.
- · Pushrods may become bent.
- Other damage to valve train components can result.

For these reasons, when the engine is started, the engine must be operated until the coolant temperature is 80° C (176° F) minimum. Carbon deposit on the valve stems will be kept at a minimum. The free operation of the valves and the valve components will be maintained.

The engine must be warmed thoroughly to keep other engine parts in better condition. The service life of the engine will generally be extended. Lubrication will be improved. There will be less acid and less sludge in the oil. This condition will provide longer service life for the engine bearings, the piston rings, and other parts. However, limit unnecessary idle time to 10 minutes to reduce wear and unnecessary fuel consumption.

# The Water Temperature Regulator and Insulated Heater Lines

The engine is equipped with a water temperature regulator. When the engine coolant is below the correct operating temperature, jacket water circulates through the engine cylinder block and into the engine cylinder head. The coolant then returns to the cylinder block via an internal passage that bypasses the valve of the coolant temperature regulator. This return ensures that coolant flows around the engine under cold operating conditions. The water temperature regulator begins to open when the engine jacket water has reached the correct minimum operating temperature. As the jacket water coolant temperature rises above the minimum operating temperature, the water temperature regulator opens further allowing more coolant through the radiator to dissipate excess heat.

The progressive opening of the water temperature regulator operates the progressive closing of the bypass passage between the cylinder block and head. This action ensures maximum coolant flow to the radiator to achieve maximum heat dissipation.

**Note:** Do not restrict the air flow. Restriction of the air flow can damage the fuel system. Caterpillar discourages the use of all air flow restriction devices such as radiator shutters. Restriction of the air flow can result in the following: high exhaust temperatures, power loss, excessive fan usage, and reduction in fuel economy.

A cab heater is beneficial in very cold weather. The feed from the engine and the return lines from the cab should be insulated to reduce heat loss to the outside air.

i07940051

# **Radiator Restrictions**

SMCS Code: 1353; 1396

Caterpillar discourages the use of airflow restriction devices that are mounted in front of radiators. Airflow restriction can cause the following conditions:

- · High exhaust temperatures
- Power loss
- Excessive fan usage
- Reduction in fuel economy

Reducing air flow over components will also affect under hood temperatures. Reducing air flow can increase surface temperatures during an aftertreatment regeneration and could affect component reliability. If an airflow restriction device must be used, the device should have a permanent opening directly in line with the fan hub. The device must have a minimum opening dimension of at least 770 cm<sup>2</sup> (120 in<sup>2</sup>).

A centered opening that is directly in line with the fan hub is specified to prevent an interrupted airflow on the fan blades. Interrupted airflow on the fan blades could cause a fan failure.

Caterpillar recommends a warning device for the inlet manifold temperature and/or the installation of an inlet air temperature gauge.

- For turbocharged, air to air charge cooled engines, the warning device for the inlet manifold temperature should be set at 75 °C (167 °F). The inlet manifold air temperature should not exceed 75 °C (167 °F).
- For turbocharged engines, the warning device for the inlet manifold temperature should be set at 180 °C (356 °F). The inlet manifold air temperature should not exceed 180 °C (356 °F).

Temperatures that exceed these limits can cause power loss and potential engine damage.

i05385898

# Fuel and the Effect from Cold Weather

SMCS Code: 1000; 1250; 1280

The following fuels are the grades that are available for Cat engines:

- NO. 1 is ASTM D975 grade 1D S15
- NO. 2 is ASTM D975 grade 2D S15

No. 2 diesel fuel is the most commonly used fuel. Either No. 1 diesel fuel or a blend of No. 1 and No. 2 is best suited for cold-weather operation.

Quantities of No. 1 diesel fuel are limited. No. 1 diesel fuels are usually available during the months of the winter in the colder climates. During cold-weather operation, if No. 1 diesel fuel is not available, use No. 2 diesel fuel, if necessary.

There are three major differences between No. 1 and No. 2 diesel fuel. No. 1 diesel fuel has the following properties:

- · Lower cloud point
- · Lower pour point
- Lower rating of kJ (BTU) per unit volume of fuel

When No. 1 diesel fuel is used, a decrease in power and in fuel efficiency may be noticed. Other operating effects should not be experienced.

The cloud point is the temperature when a cloud of wax crystals begins to form in the fuel. These crystals can cause the fuel filters to plug. The pour point is the temperature when diesel fuel will thicken. The diesel fuel becomes more resistant to flow through fuel pumps and through fuel lines.

Be aware of these values when diesel fuel is purchased. Anticipate the average ambient temperature of the area. Engines that are fueled in one climate may not operate well if the engines are moved to another climate. Problems can result due to changes in temperature.

Before troubleshooting for low power or for poor performance in the winter, check the type of fuel that is being used.

When No. 2 diesel fuel is used, the following components provide a means of minimizing problems in cold weather:

- Starting aids
- · Engine oil pan heaters
- Engine coolant heaters
- Fuel heaters
- Fuel line insulation

For more information on cold-weather operation, see Special Publication, SEBU5898, "Cold Weather Recommendations".

i08298402

# Fuel Related Components in Cold Weather

SMCS Code: 1000; 1250; 1280

## **Fuel Tanks**

Condensation can form in partially filled fuel tanks. Top off the fuel tanks after you operate the engine.

Fuel tanks should contain some provision for draining water and sediment from the bottom of the tanks. Some fuel tanks use supply pipes that allow water and sediment to settle below the end of the fuel supply pipe.

Some fuel tanks use supply lines that take fuel directly from the bottom of the tank. If the engine is equipped with this system, regular maintenance of the fuel system filter is important. Drain the water and sediment from any fuel storage tank at the following intervals: weekly, service intervals and refueling of the fuel tank. This procedure will help prevent water and/or sediment from being pumped from the fuel storage tank and into the engine fuel tank.

## **Fuel Filters**

After you change the fuel filter, always prime the fuel system to remove air bubbles from the fuel system. Refer to the Operation and Maintenance Manual in the Maintenance Section for more information on priming the fuel system.

The micron rating and the location of a primary fuel filter is important in cold-weather operation. The Inline filter, primary fuel filter, and the fuel supply line are the most common components that are affected by cold fuel.

#### NOTICE

To maximize fuel system life and prevent premature wear out from abrasive particles in the fuel, a four micron [c] absolute high efficiency fuel filter is required for all Caterpillar Electronic Unit Injectors. Caterpillar High Efficiency Fuel Filters meet these requirements. Consult your Caterpillar dealer for the correct part numbers.

## **Fuel Heaters**

Fuel heaters help to prevent fuel filters from plugging in cold weather due to waxing. A fuel heater should be installed in the fuel system before the electric fuel pump.

**Note:** If so, the temperature of the fuel must not exceed 75° C ( $167^{\circ}$  F) at the electric fuel pump.

For further information on fuel heaters, consult your Caterpillar dealer.

i08811356

## Diesel Exhaust Fluid in Cold Weather

SMCS Code: 108K

Due to the freezing point of Diesel Exhaust Fluid (DEF) the aftertreatment system is equipped with electrically heated DEF lines. The system also has a coolant heated element in the DEF tank and the DEF pump.

During periods of weather in which DEF can freeze the application should be stood on level ground when not in use. DEF can start to freeze at  $-11^{\circ}$  C (12.2° F). **Note:** At certain angles DEF can cover the DEF filler cap. If the DEF freezes, the DEF tank vent could block. A blocked vent in the DEF tank assembly will cause operational difficulties.

For information on DEF refer to this Operation and Maintenance Manual, "Fluid Recommendations".

# **Engine Stopping**

i07693085

# **Stopping the Engine**

SMCS Code: 1000

#### NOTICE

Stopping the engine immediately after the engine has been working under load, can result in overheating and accelerated wear of the engine components.

Avoid accelerating the engine prior to shutting down the engine.

Avoiding hot engine shutdowns will maximize turbocharger shaft and bearing life. Also, selective catalytic reduction component life.

**Note:** Individual applications will have different control systems. Ensure that the shutoff procedures are understood. Use the following general guidelines to stop the engine.

- 1. Remove the load from the engine. Reduce the engine speed to low idle. Allow the engine to idle for 5 minutes to cool the engine.
- Stop the engine after the cool down period according to the shutoff system on the engine and turn the ignition keyswitch to the OFF position. If necessary, refer to the instructions that are provided by the OEM.

**Note:** In some applications the engine will continue to operate after the keyswitch is turned to the OFF position. The engine will operate for a short time to allow engine components to cool.

**3.** Allow at least 2 minutes after the engine has stopped before you turn the battery disconnect switch to OFF. Disconnecting the battery power too soon will prevent purging of the DEF fluid lines after the engine is shut down. Also, during the 2 minutes the engine electronic control module is active, storing information from the engine and aftertreatment sensors.

# Delayed Engine Shutdown (if Equipped)

The delayed engine shutdown allows the engine to run for a time after the engine start switch is turned to the OFF position to cool the system components. The engine start switch key may be removed. **Note:** There may be regulations that define the requirements for the operator and/or support personnel to be present when the engine is running.

## 🔒 WARNING

Leaving the machine unattended when the engine is running may result in personal injury or death. Before leaving the machine operator station, neutralize the travel controls, lower the work tools to the ground and deactivate all work tools, and place the lever for the hydraulic lockout control in the LOCKED position.

Leaving the engine unattended while running may result in property damage in the event of a malfunction.

**Note:** An authorized dealer can change the maximum run time value up to 30 minutes but the default setting is 10 minutes.

An override can be enabled so that the delayed engine shutdown will not operate. Overriding delayed engine shutdown may reduce engine and system component life. The override is operated by the keyswitch.

At any time during a delayed engine shutdown, the engine start switch may be turned to the ON position. The engine may be placed back into service.

i05195199

# **Emergency Stopping**

SMCS Code: 1000; 7418

#### NOTICE

Emergency shutoff controls are for EMERGENCY use ONLY. DO NOT use emergency shutoff devices or controls for normal stopping procedure.

The OEM may have equipped the application with an emergency stop button. For more information about the emergency stop button, refer to the OEM information.

Ensure that any components for the external system that support the engine operation are secured after the engine is stopped.

i07486528

# **After Stopping Engine**

#### SMCS Code: 1000

**Note:** Before you check the engine oil, do not operate the engine. Wait for at least 30 minutes after the engine has stopped to allow the engine oil to return to the oil pan.

## 

Contact with high pressure fuel may cause fluid penetration and burn hazards. High pressure fuel spray may cause a fire hazard. Failure to follow these inspection, maintenance and service instructions may cause personal injury or death.

- Diesel Exhaust Fluid (DEF) purge, do not disconnect the battery disconnect switch until the DEF purge has been completed. The procedure is automatically controlled and will take approximately 2 minutes.
- After the engine has stopped, you must wait for 10 minutes to allow the fuel pressure to be purged from the high-pressure fuel lines before any service or repair is performed on the engine fuel lines. If necessary, perform minor adjustments. Repair any leaks from the low-pressure fuel system and from the cooling, lubrication, or air systems. Replace any high-pressure fuel line that has leaked. Refer to Disassembly and Assembly Manual, "Fuel Injection Lines Install".
- Check the crankcase oil level. Maintain the oil level between the "MIN" mark and the "MAX" mark on the engine oil level gauge.
- If the engine is equipped with a service hour meter, note the reading. Perform the maintenance that is in the Operation and Maintenance Manual, "Maintenance Interval Schedule".
- Fill the fuel tank, to help prevent accumulation of moisture in the fuel. Do not overfill the fuel tank.
- Fill the DEF tank, a low level of DEF in the tank can result in engine de-rate.

#### NOTICE

Only use antifreeze/coolant mixtures recommended in this Operation and Maintenance Manual, "Refill Capacities and Recommendations" topic or in this Operation and Maintenance Manual, "Fluid Recommendations" topic. Failure to do so can cause engine damage.

## 

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

• Allow the engine to cool. Check the coolant level.

- Check the coolant for correct antifreeze protection and the correct corrosion protection. Add the correct coolant/water mixture, if necessary.
- Perform all required periodic maintenance on all driven equipment. This maintenance is outlined in the instructions from the OEM.

# **Maintenance Section**

# Maintenance Recommendations

i07819420

# System Pressure Release

SMCS Code: 1250; 1300; 1350; 5050

## **Coolant System**

## 

Pressurized system: Hot coolant can cause serious burn. To open cap, stop engine, wait until radiator is cool. Then loosen cap slowly to relieve the pressure.

## 

When the engine is in the AUTOMATIC mode, the engine can start at any moment. To avoid personal injury, always remain clear of the the engine when the engine is in the AUTOMATIC mode.

The engine can have the ability to auto start. Ensure that the power supply is isolated before any service or repair is performed.

To relieve the pressure from the coolant system, turn off the engine. Allow the cooling system pressure cap to cool. Remove the cooling system pressure cap slowly to relieve pressure.

## **Fuel System**

To relieve the pressure from the fuel system, turn off the engine.

### **High-Pressure Fuel Lines**

## 

Contact with high pressure fuel may cause fluid penetration and burn hazards. High pressure fuel spray may cause a fire hazard. Failure to follow these inspection, maintenance and service instructions may cause personal injury or death.

The high-pressure fuel lines are the fuel lines that are between the high-pressure fuel pump and the highpressure fuel manifold and the fuel lines that are between the fuel manifold and the fuel injectors. The high-pressure fuel lines are different from fuel lines on other fuel systems, the differences are as follows:

- The high-pressure fuel lines are constantly charged with high pressure.
- The internal pressures of the high-pressure fuel lines are higher than other types of fuel system.

Before any service or repair is performed on the engine fuel lines, perform the following tasks:

- 1. Stop the engine.
- 2. Wait for 10 minutes.

Do not loosen the high-pressure fuel lines to remove air from the fuel system.

## **Engine Oil**

To relieve pressure from the lubricating system, turn off the engine.

i07703516

## Welding on Engines with Electronic Controls

SMCS Code: 1000

NOTICE

Because the strength of the frame may decrease, some manufacturers do not recommend welding onto a chassis frame or rail. Consult the OEM of the equipment or your Caterpillar dealer regarding welding on a chassis frame or rail.

Correct welding procedures are necessary to avoid damage to the engines ECM, sensors, and associated components. When possible, remove the component from the unit and then weld the component. If removal of the component is not possible, the following procedure must be followed when you weld on a unit equipped with an Electronic Engine. The following procedure is considered to be the safest procedure to weld on a component. This procedure should provide a minimum risk of damage to electronic components.

#### NOTICE

Do not ground the welder to electrical components such as the ECM or sensors. Improper grounding can cause damage to the drive train bearings, hydraulic components, electrical components, and other components.

Clamp the ground cable from the welder to the component that will be welded. Place the clamp as close as possible to the weld. This will help reduce the possibility of damage. Note: Perform the welding in areas that are free from explosive hazards.

- 1. Stop the engine. Turn the switched power to the OFF position.
- 2. Ensure that the fuel supply to the engine is turned off.
- 3. Disconnect the negative battery cable from the battery. If a battery disconnect switch is provided, open the switch.
- 4. Disconnect all electronic components from the wiring harnesses. Include the following components:
  - Electronic components for the driven equipment
  - ECM •
  - Sensors
  - Electric operated fuel pump
  - Electronically controlled valves
  - Relays
  - Aftertreatment ID module

#### NOTICE

Do not use electrical components (ECM or ECM sensors) or electronic component grounding points for grounding the welder.




Illustration 62

q06392357

Use the example above. The current flow from the welder to the ground clamp of the welder will not damage any associated components.

(1) Engine

- (2) Welding electrode
- (3) Keyswitch in the OFF position
- (4) Battery disconnect switch in the open position (5) Disconnected battery cables
- (6) Battery
- (7) Electrical/Electronic component
- (8) The component that is being welded
- (9) Current path of the welder (10) Ground clamp for the welder
- 5. Connect the welding ground cable directly to the part that will be welded. Place the ground cable as close as possible to the weld to reduce the possibility of welding current damage to the following components. Bearings, hydraulic components, electrical components, and ground straps.

**Note:** If electrical/electronic components are used as a ground for the welder, or electrical/electronic components are located between the welder ground and the weld, current flow from the welder could severely damage the component.

- 6. Protect the wiring harness from welding debris and spatter.
- 7. Use standard welding practices to weld the materials.

i04807435

# Severe Service Application

#### SMCS Code: 1000

An engine which operates outside of normal conditions is operating in a severe service application.

An engine that operates in a severe service application may need more frequent maintenance intervals in order to maximize the following conditions:

- · Reliability
- Service life

The number of individual applications cause the impossibility of identifying all of the factors which may contribute to severe service operation. Consult your Caterpillar dealer for the unique maintenance that may be necessary for your engine.

An application is a severe service application if any of the following conditions apply:

## **Severe Environmental Factors**

- · Frequent operation in dirty air
- Frequent operation at an altitude which is above 1525 m (5000 ft)
- Frequent operation in ambient temperatures which are above 32° C (90° F)
- Frequent operation in ambient temperatures which are below 0° C (32° F)

## **Severe Operating Conditions**

- Frequent operation with inlet air which has a corrosive content
- Operation with inlet air which has a combustible content
- Operation which is outside of the intended application
- · Operation with a plugged fuel filter
- Extended operation at low idle (more than 20% of hours)
- Frequent cold starts at temperatures below 0° C (32° F)
- Frequent dry starts (starting after more than 72 hours of shutdown)

- Frequent hot shutdowns (shutting down the engine without the minimum of 2 minutes to 5 minutes of cool down time)
- · Operation above the engine rated speed
- · Operation below the peak torque speed
- Operating with fuel which does not meet the standards for distillate diesel fuel as stated in Special Publication, SEBU6250, "Caterpillar Machine Fluids Recommendations" "Distillate Diesel Fuel"
- Operating with a blend of distillate fuel which contains more than 20 percent biodiesel

## Improper Maintenance Procedures (Maintenance Procedures Which May Contribute to a Severe Service Application)

- Inadequate maintenance of fuel storage tanks from causes such as excessive water, sediment, and microorganism growth.
- Extending maintenance intervals beyond the recommended intervals
- Using fluids which are not recommended in Special Publication, SEBU6250, "Caterpillar Machine Fluids Recommendations"
- Extending maintenance intervals for changing the engine oil and engine coolant without S·O·S validation
- Extending maintenance intervals for changing air filters, oil filters, and fuel filters
- · Failure to use a water separator
- Using filters which are not recommended by Special Publication, PEWJ0074, "2008 Cat Filter and Fluid Application Guide"
- Storing the engine for more than 3 months but less than 1 yr (For information about engine storage, refer to Special Publication, SEHS9031, "Storage Procedure for Caterpillar Products")

# **Refill Capacities**

i09512674

# **Refill Capacities**

SMCS Code: 1000; 1348; 1395; 7560

## Lubrication System for Engines Equipped With a Standard Oil Pan




Illustration 63 Typical example g06511838

(1) Standard Oil Pan

**OEM** – Original Equipment Manufacturer

The refill capacities for the engine crankcase reflect the approximate capacity of the crankcase or sump plus standard oil filters. Auxiliary oil filter systems will require extra oil. Refer to the OEM specifications for the capacity of the auxiliary oil filter. Refer to the Operation and Maintenance Manual, "Maintenance Section" for more information on Lubricant Specifications.

Table 13

C3.6 Industrial Engine Refill Capacities	
Compartment or System	Capacity
Crankcase Oil Sump <sup>(1)</sup>	9.1 to 10.6 L (2.40422 to 2.80052 US gal)

(1) These values are the approximate capacities for the crankcase oil sump which includes the standard factory installed oil filters. Engines with auxiliary oil filters will require extra oil. Refer to the OEM specifications for the capacity of the auxiliary oil filter. The design of the oil pan can change the oil capacity of the oil pan. Table 14

C2.8 Industrial Engine Refill Capacities		
Compartment or System	Capacity	
Crankcase Oil Sump <sup>(1)</sup>	7.5 to 8.8 L (1.98150 to 2.32496 US gal)	

(1) These values are the approximate capacities for the crankcase oil sump which includes the standard factory installed oil filters. Engines with auxiliary oil filters will require extra oil. Refer to the OEM specifications for the capacity of the auxiliary oil filter. The design of the oil pan can change the oil capacity of the oil pan.

## Lubrication System for Engines Equipped With a Balancer Oil Pan




Illustration 64
Typical example

(2) Oil Pan with a balancer

#### **OEM** – Original Equipment Manufacturer

The refill capacities for the engine crankcase reflect the approximate capacity of the crankcase or sump plus standard oil filters. Auxiliary oil filter systems will require extra oil. Refer to the OEM specifications for the capacity of the auxiliary oil filter. Refer to the Operation and Maintenance Manual, "Maintenance Section" for more information on Lubricant Specifications.

g06511850

**Note:** During engine oil changes both sides of the engine oil pan must be drained of lubricant.

Table 15

C3.6 Industrial Engine With a Balancer Oil Pan Refill Capacities		
Compartment or System	Capacity	
Crankcase Oil Sump (1)	8.5 to 10 L (2.246 to 2.642 US gal)	

## **Cooling System**

Refer to the OEM specifications for the External System capacity. This capacity information will be needed to determine the amount of coolant/ antifreeze that is required for the Total Cooling System.

Table 16

C3.6 Industrial Engine Refill Capacities	
Compartment or System	Capacity
Engine Only	4.3 L (1.136 US gal)
External System Per OEM <sup>(1)</sup>	

(1) The External System includes a radiator or an expansion tank with the following components: heat exchanger and piping. Refer to the OEM specifications. Enter the value for the capacity of the External System in this row.

Table 17

C2.8 Industrial Engine Refill Capacities		
Compartment or System	Capacity	
Engine Only	3.9 L (1.03038 US gal)	
External System Per OEM <sup>(1)</sup>		

(1) The External System includes a radiator or an expansion tank with the following components: heat exchanger and piping. Refer to the OEM specifications. Enter the value for the capacity of the External System in this row.

## **Open Power Unit (OPU)**

Table 18

C3.6 OPU Refill Capacities		
Compartment or System	Capacity	
Engine Only	4.3 L(1.136 US gal)	
Radiator	8.7 L (2.3 US gal)	
Total coolant capacity	11.5 to 13.2 L (3.04 to 3.49 US gal)	

Table 19

C2.8 OPU Refill Capacities		
Compartment or System	Capacity	
Engine Only	3.9 L (1.03 US gal)	
Radiator	8.9 L (2.35 US gal)	
Total coolant capacity	10.6 to 12.2 L (2.80 to 3.22 US gal)	

## **DEF System**

DEF - Diesel Exhaust Fluid

Table 20

	DEF Tank Capacity
19 L (5 US gal) <sup>(1)</sup>	

<sup>(1)</sup> OEM tank size shape, and capacities could be different.

i08811382

# **Fluid Recommendations**

SMCS Code: 1280; 1348; 1395; 7560

## **Engine Lubrication Oil**

NOTICE These recommendations are subject to change without notice. Contact your local Cat dealer for the most up-to-date fluids recommendations.

- EMA\_\_\_\_Engine Manufacturers Association
- API\_\_\_\_\_American Petroleum Institute
- SAE\_\_\_\_Society Of Automotive Engineers Inc.
- DEO-ULS \_\_\_\_\_Diesel Engine Oil-Ultra Low Sulfur

#### Cat DEO-ULS

Cat DEO-ULS is developed and tested to provide superior protection and life for your Caterpillar engines.

- Better Detergents
- Advanced Additive Package
- · Enhanced Dispersants
- Improved Protection from Thermal breakdown and Oxidation Breakdown

Due to significant variations in the quality and in the performance of commercially available oils, Caterpillar makes the following recommendations:

- Cat DEO-ULS (SAE 10W-30)
- Cat DEO-ULS (SAE 15W-40)

Cat DEO-ULS Multigrade oil is available in various viscosity grades that include SAE 10W-30 and SAE 15W-40. To choose the correct viscosity grade for the ambient temperature, see illustration 65 . Multigrade oils provide the correct viscosity for a broad range of operating temperatures. Multigrade oils are also effective in maintaining low oil consumption and low levels of piston deposits.

Consult your Cat dealer for part numbers and for available sizes of containers.

Note: Cat DEO-ULS in SAE 15W-40 passes the following proprietary tests: sticking of the piston ring, oil control tests, wear tests, and soot tests. Proprietary tests help ensure that Caterpillar multigrade oil provides superior performance in Caterpillar Diesel Engines. In addition, Cat DEO-ULS Multigrade oil exceeds many of the performance requirements of other manufacturers of diesel engines. Therefore, this oil is an excellent choice for many mixed fleets. True high-performance oil is produced with a combination of the following factors: industry standard tests, proprietary tests, field tests, and prior experience with similar formulations. The design and the development of Caterpillar lubricants that are both high performance and high quality are based on these factors.

#### **Commercial Oils**

**Note:** Non-Caterpillar commercial oils are second choice oils.

#### NOTICE

Caterpillar require the use of the following specification of engine oil. Failure to use the appropriate specification of engine oil will reduce the life of your engine. Failure to use the correct specification of engine will also reduce the life and the effectiveness of your aftertreatment system.

Table 21

able 2 I	
	API Classifications for the Industrial Engine
	Oil Specification
ECF-3 CK-4 AECA E	9

NOTICE

Failure to follow these oil recommendations can cause shortened engine service life due to deposits and/or excessive wear.

**Note:** API FA-4 oil is designed for use in selected onhighway applications and is NOT designed to support off-road applications, including Caterpillar Engines. DO NOT use API FA-4 oil for Caterpillar engines.

Refer to Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" for additional information that relates to lubrication for your engine.

#### Lubricant Viscosity Recommendations

The proper SAE viscosity grade of oil is determined by the minimum ambient temperature during cold engine start-up, and the maximum ambient temperature during engine operation.

Refer to illustration 65 (minimum temperature) to determine the required oil viscosity for starting a cold engine.

Refer to illustration 65 (maximum temperature) to select the oil viscosity for engine operation at the highest ambient temperature that is anticipated.

**Note:** Generally, use the highest oil viscosity that is available to meet the requirement for the temperature at start-up.

If ambient temperature conditions at engine start-up require the use of multigrade SAE 0W oil, SAE 0W-40 viscosity grade is preferred.




Illustration 65

g03329687

Supplemental heat is recommended for cold soaked starts below the minimum ambient temperature. Supplemental heat may be required for cold soaked starts that are above the minimum temperature that is stated, depending on the parasitic load and other factors. Cold soaked starts occur when the engine has not been operated for time. This time period will allow the oil to become more viscous due to cooler ambient temperatures.

#### S·O·S Oil Analysis

Caterpillar has developed a tool for maintenance management that evaluates oil degradation and the tool also detects the early signs of wear on internal components. The Caterpillar tool for oil analysis is called  $S \cdot O \cdot S$  Oil Analysis and the tool is part of the  $S \cdot O \cdot S$  Services program.  $S \cdot O \cdot S$  Oil Analysis divides oil analysis into three categories:

- · Wear Analysis
- Oil condition
- Extra tests

The wear analysis monitors metal particles, some oil additives, and some contaminants.

Oil condition uses infrared (IR) analysis to evaluate the chemistry of the oil. Infrared analysis is also used to detect certain types of contamination.

Extra tests are used to measure contamination levels from water, fuel, or coolant. Oil viscosity and corrosion protection can be evaluated, as needed. Refer to Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" or contact your local Cat dealer for additional information concerning the  $S \cdot O \cdot S$  Oil Analysis program.

## Lubricating Grease

Caterpillar provides a range of moderate greases to high performance greases to service the entire line of Caterpillar products that operate throughout the wide variety of climates. You will always be able to find a grease that will meet your machines requirements for a certain application. Caterpillar grease products often exceed Caterpillar specifications.

Before selecting a grease products for any application, the performance requirements must be determined. Consult the grease recommendations that are made by the OEM for the equipment when the equipment is operated in the expected conditions. Then, consult with your Cat dealer for a list of greases and the following related characteristics.

- Performance specifications
- Available sizes of containers
- Part numbers

Always choose a grease that meets the recommendations that are specified by the equipment manufacturer for the application, or choose a grease that exceeds the recommendations that are specified by the equipment manufacturer for the application.

Always choose a grease that meets the requirements of the most demanding application. A product that barely meets the minimum performance requirements will shorten the life of the part. Use the grease that yields the least total operating cost. Base this cost on an analysis that includes the costs of the parts, the labor, the downtime, and the cost of the grease that is used.

Some greases are not chemically compatible. Consult your supplier to determine if two or more greases are compatible.

Purge the grease from a joint at the following times:

- Switching from one grease to another grease
- Switching from one supplier to another supplier

Note: All Caterpillar brand name greases are compatible with each other.

**Note:** Refer to Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" for additional information that relates to lubrication for your engine.

## Fuel

Refer to Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" for the Caterpillar Specification for distillate fuel and for additional information that

for distillate fuel and for additional information that relates to fuel for your engine.

#### Ultra low Sulfur Diesel (ULSD)

Your Caterpillar Diesel Engine must use ultra low sulfur diesel fuel. This fuel complies with the emissions regulations that are prescribed by the European Union and the Environmental Protection Agency of the United States.

Engines that are manufactured by Caterpillar are certified with the fuel that is prescribed by the United States Environmental Protection Agency. Engines that are manufactured by Caterpillar are certified with the fuel that is prescribed by the European Certification. Caterpillar does not certify diesel engines on any other fuel.

**Note:** The owner and the operator of the engine has the responsibility of using the fuel that is prescribed by the United States Environmental Protection Agency and other appropriate regulatory agencies.

Fuel tank inlet labels are installed to ensure that the correct fuels are used. Illustration 66 is an example of one of the labels designs that will be installed.




Illustration 66 Typical example g02157153

### **Fuel Additives**

Many types of fuel additives are available. Caterpillar does not generally recommend the use of fuel additives.

In special circumstances, Caterpillar recognizes the need for fuel additives. Use caution if using fuel additives. The additive may not be compatible with the fuel. Some additives may precipitate. This action causes deposits in the fuel system. The deposits may cause seizure. Some additives may be corrosive and some additives may be harmful to the elastomers in the fuel system.

Some additives may damage emission control systems. Some additives may cause the amount of sulfur in the fuel to be greater than 15 ppm.

Contact your fuel supplier for those circumstances when fuel additives are required. Your fuel supplier can recommend the best additives for your application and for the proper level of treatment.

**Note:** For the best results, your fuel supplier should treat the fuel when additives are necessary.

## **Diesel Exhaust Fluid**

#### **General Information**

Diesel Exhaust Fluid (DEF) is a liquid that is injected into the exhaust system of engines equipped with Selective Catalytic Reduction (SCR) systems. SCR reduces emissions of nitrogen oxides (NOx) in diesel engine exhaust.

In engines equipped with SCR emissions reduction system, DEF is injected in controlled amounts into the engine exhaust stream. At the elevated exhaust temperature, urea in DEF is converted to ammonia. The ammonia chemically reacts with NOx in diesel exhaust in the presence of the SCR catalyst. The reaction converts NOx into nitrogen (N2) and water (H2O).

DEF is known by many brands including AdBlue or API certification.

Refer to Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" for more information.

#### **DEF Recommendations**

For use in Caterpillar engines, DEF must meet all the requirements defined by "ISO 22241-1" Requirements.

Caterpillar recommends the use of DEF available through the Cat parts ordering system for use in Caterpillar engines equipped with SCR systems. Refer to Table 22 for part number information:

Table 22

Cat Part Number	Container Size
350-8733	2.5 gal bottle
350-8734	1000-L totes

In North America, commercial DEF that is API approved and meets all the requirements defined in "ISO 22241-1" may be used in Cat engines that are equipped with SCR systems.

Outside of North America, commercial DEF that meets all requirements defined in "ISO 22241-1" may be used in Cat engines that are equipped with SCR systems.

The supplier should provide documentation to prove that the DEF is compliant with the requirements of "ISO 22241-1".

#### NOTICE

Cat <sup>®</sup> does not warrant the quality or performance of non-Cat fluids.

#### NOTICE

**Do not use agriculture grade urea solutions.** Do not use any fluids that do not meet "ISO 22241-1" Requirements in SCR emissions reduction systems. Use of these fluids can result in numerous problems including damage to SCR equipment and a reduction in NOx conversion efficiency.

DEF is a solution of solid urea that is dissolved in demineralized water to produce a final concentration of 32.5% urea. DEF concentration of 32.5% is optimal for use in SCR systems. DEF solution of 32.5% urea has the lowest attainable freeze point of  $-11.5^{\circ}$  C ( $11.3^{\circ}$  F). DEF concentrations that are higher or lower than 32.5% have higher freeze points. DEF dosing systems and "ISO 22241-1" specifications are designed for a solution that is approximately 32.5%.

Caterpillar offers a refractometer, Cat part number 360-0774, that can be used to measure DEF concentration. Follow the instructions provided with the instrument. Appropriate commercial portable refractometers can be used to determine urea concentration. Follow the instructions from the manufacturer.

#### **DEF Guidelines**

DEF solution is typically colorless and clear. Changes to color or clarity are indicators of quality issues. Quality of DEF can degrade when stored and handled inappropriately or if DEF is not protected from contamination. Details are provided below.

If quality issues are suspected, testing of DEF should focus on urea percentage, alkalinity as NH3 and biuret content. DEF that does not pass all these tests or that is no longer clear should not be used.

#### Materials compatibility

DEF is corrosive. Due to the corrosion caused, DEF must be stored in tanks constructed of approved materials. Recommended storage materials:

Stainless Steels:

- 304 (S30400)
- 304L (S30403)
- 316 (S31600)
- 316L (S31603)

Alloys and metals:

- Chromium Nickel (CrNi)
- Chromium Nickel Molybdenum (CrNiMo)
- Titanium

Non-metallic materials:

- Polyethylene
- Polypropylene
- · Polyisobutylene
- Teflon (PFA)
- · Polyfluoroethylene (PFE)
- Polyvinylidene fluoride (PVDF)
- Polytetrafluoroethylene (PTFE)

Materials NOT compatible with DEF solutions include Aluminum, Magnesium, Zinc, Nickel coatings, Silver, and Carbon steel and Solders containing any of the above. Unexpected reactions may occur if DEF solutions come in contact with any non-compatible material or unknown materials.

#### Bulk storage

Follow all local regulations covering bulk storage tanks. Follow proper tank construction guidelines. Tank volume typically should be 110% of planned capacity. Appropriately vent indoor tanks. Plan for control of overflow of the tank. Heat tanks that dispense DEF in cold climates. DEF will start to freeze at  $-9^{\circ}$  C (15.8° F).

Bulk tank breathers should be fitted with filtration to keep airborne debris from entering the tank. Desiccant breathers should not be used because water will be absorbed, which potentially can alter DEF concentration.

#### Handling

Follow all local regulations covering transport and handling. DEF transport temperature is recommended to be  $-5^{\circ}$  C (23° F) to 25° C (77° F). All transfer equipment and intermediate containers should be used exclusively for DEF. Containers should not be reused for any other fluids. Ensure that transfer equipment is made from DEF-compatible materials. Recommended material for hoses and other non-metallic transfer equipment includes:

- Nitrile Rubber (NBR)
- Fluoroelastomer (FKM)
- Ethylene Propylene Diene Monomer (EPDM)

The condition of hoses and other nonmetallic items that are used with DEF should be monitored for signs of degradation. DEF leaks are easily recognizable by white urea crystals that accumulate at the site of the leak. Solid urea can be corrosive to galvanized or unalloyed steel, aluminum, copper, and brass. Leaks should be repaired immediately to avoid damage to surrounding hardware.

#### Cleanliness

Contaminants can degrade the quality and life of DEF. Filtering DEF is recommended when dispensed into the DEF tank. Filters should be compatible with DEF and should be used exclusively with DEF. Check with the filter supplier to confirm compatibility with DEF before using. Mesh-type filters using compatible metals, such as stainless steel, are recommended. Paper (cellulose) media and some synthetic filter media are not recommended because of degradation during use.

Care should be taken when dispensing DEF. Spills should be cleaned immediately. Machine or engine surfaces should be wiped clean and rinsed with water. Caution should be used when dispensing DEF near an engine that has recently been running. Spilling DEF onto hot components will cause harmful vapors.

#### Stability

DEF fluid is stable when stored and handled properly. The quality of DEF rapidly degrades when stored at high temperatures. The ideal storage temperature for DEF is between  $-9^{\circ}$  C (15.8° F) and 25° C (77° F). DEF that is stored above 35° C (95° F) for longer than 1 month must be tested before use. Testing should evaluate Urea Percentage, Alkalinity as NH3 and Biuret content.

The length of storage of DEF is listed in the following table:

Table 23

Storage Temperature	Expected DEF Life
Below 25° C (77° F)	18 months
25° C (77° F) to 30° C (86° F)	12 months
30° C (86° F) to 35° C (95° F)	6 months
Above 35° C (95° F)	test quality before use

Refer to "ISO 22241" document series for more information about DEF quality control.

**Note:** Dispose of all fluids according to applicable regulations and mandates.

#### Filling Tank

The DEF tank filler cap is colored blue. A special nozzle size is required to fill a DEF tank. Ensure that the DEF tank is on level ground before the tank is filled.

#### Spillage

Care should be taken when dispensing DEF. Spills should be cleaned immediately. All surfaces should be wiped clean and rinsed with water.

DEF that has been spilt will crystallize when the water within the liquid evaporates. Spilt DEF will attack paint and metal. If DEF is spilt, wash the area with water.

Caution should be used when dispensing DEF near an engine that has recently been running. Spilling DEF onto hot components may cause the release of ammonia vapors. Do not breathe ammonia vapors. Do not clean up any spills with bleach.

## Coolant

The following two coolants are recommended for use in Caterpillar diesel engines:

**Preferred** – Cat ELC (Extended Life Coolant) or a commercial extended life coolant that meets the Caterpillar EC-1 specification

Acceptable – A Cat DEAC (Diesel Engine Antifreeze/Coolant) or a commercial heavy-duty antifreeze that meets "ASTM D6210" or "ASTM D4985" specifications

#### NOTICE

The Caterpillar industrial engine must be operated with a 1:1 or 50 percent mixture of water and glycol. This concentration allows the NOx reduction system to operate correctly at high ambient temperatures.

#### NOTICE

Do not use a commercial coolant/antifreeze that only meets the ASTM "D3306" or equivalent specification. This type of coolant/antifreeze is made for light duty automotive applications.

Use only the coolant/antifreeze that is recommended.

#### NOTICE

Do NOT mix brands or types of coolant. Do NOT mix brands or types of SCA and/or brands or types of extenders. Different brands or types may use different additive packages to meet the cooling system requirements. Different brands or types may not be compatible.

Failure to follow the recommendations can reduce cooling system component life unless appropriate corrective action is performed.

Caterpillar recommends a 1:1 or 50 percent mixture of water and glycol. This mixture of water and glycol will provide optimum heavy-duty performance as an antifreeze.

**Note:** Cat DEAC does not require a treatment with an SCA at the initial fill. Commercial heavy-duty antifreeze that meets "ASTM D6210" or "ASTM D4985" specifications MAY require a treatment with an SCA at the initial fill. Read the label or the instructions that are provided by the OEM of the product.

NOTICE

Use only Cat products or commercial products that have passed Cat EC-1 specification for pre-mixed or concentrated coolants.

Use only Cat ELC Extender with Cat ELC.

Do NOT use conventional SCA with Cat ELC. Mixing Cat ELC with conventional coolants and/or conventional SCA reduces the Cat ELC service life.

Do NOT mix brands or types of coolant. Do NOT mix brands or types of SCA and/or brands or types of extenders. Different brands or types may use different additive packages to meet the cooling system requirements. Different brands or types may not be compatible.

Failure to follow the recommendations can reduce cooling system component life unless appropriate corrective action is performed.

Table 24

Coolant Service Life	
Coolant Type	Service Life (1)

(Table 24, contd)

Cat ELC	12000 Service Hours or Six Years <sup>(2)</sup>
Commercial coolant that meets the Caterpillar EC-1 Specification	6000 Service Hours or Six Years (3)
Cat DEAC	3000 Service Hours or Three Years
Commercial Heavy-Duty Cool- ant/Antifreeze that meets "ASTM D6210"	3000 Service Hours or Two Years
Commercial Heavy-Duty Cool- ant/Antifreeze that meets "ASTM D4985"	3000 Service Hours or One Year

<sup>(1)</sup> Use the interval that occurs first. The cooling system must also be flushed out now.

- (2) Cat ELC Extender must be added at 6000 service hours or one half of the service life of the Cat ELC. Refer to your machine Operation and Maintenance Manual for exceptions.
- <sup>(3)</sup> An extender must be added at 3000 service hours or one half of the service life of the coolant.

**Note:** Refer to Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" for additional information that relates to coolant for your engine.

## S·O·S Coolant Analysis

#### Table 25

Recommended Interval		
Type of Coolant	Level 1	Level 2
DEAC	Every 250 Hours (1)	Yearly <sup>(1)</sup>
ELC	Optional <sup>(1)</sup>	Yearly

<sup>(1)</sup> The Level 2 Coolant Analysis should be performed sooner if a problem is identified by a Level 1 Coolant Analysis.

#### S·O·S Coolant Analysis (Level 1)

A coolant analysis (Level 1) is a test of the properties of the coolant.

The following properties of the coolant are tested:

- Glycol concentration for freeze protection and boil protection
- Ability to protect from erosion and corrosion
- pH
- · Conductivity
- · Visual analysis
- · Odor analysis

(continued)

The results are reported, and appropriate recommendations are made.

Refer to the Maintenance Interval Schedule in this Operation and Maintenance Manual to find the maintenance interval for collecting the coolant samples.

#### S·O·S Coolant Analysis (Level 2)

A coolant analysis (Level 2) is a comprehensive chemical evaluation of the coolant. This analysis is also a check of the overall condition of the inside cooling system.

The S $\cdot$ O $\cdot$ S Coolant Analysis has the following features:

- Full coolant analysis (Level 1)
- Identification of the source of metal corrosion and of contaminants
- Water hardness
- Identification of buildup of the impurities that cause corrosion
- Identification of buildup of the impurities that cause scaling

The results are reported, and appropriate recommendations are made.

Refer to the Maintenance Interval Schedule in this Operation and Maintenance Manual, "Cooling System Coolant Sample (Level 2) - Obtain" for the maintenance interval for collecting the coolant samples.

Testing the engine coolant is important to ensure that the engine is protected from internal cavitation and from corrosion. The analysis also tests the ability of the coolant to protect the engine from boiling and from freezing. The S $\cdot$ O $\cdot$ S Coolant Analysis can be done at your Caterpillar dealer. Caterpillar S $\cdot$ O $\cdot$ S Coolant Analysis is the best way to monitor the condition of your coolant and your cooling system. S $\cdot$ O $\cdot$ S Coolant Analysis is a program that is based on periodic samples.

Refer to Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" for additional information. i09513135

# Maintenance Interval Schedule

SMCS Code: 1000; 4450; 7500

## When Required

"Battery - Replace" 104
" Battery or Battery Cable - Disconnect" 105
" DEF Filler Screen (Emission Related Component) - Clean"
" Diesel Exhaust Fluid (Emission Related Component) - Fill"
" Diesel Exhaust Fluid Tank - Flush"
" Engine - Clean"
" Engine Air Cleaner Element - Replace" 125
" Engine Oil Sample - Obtain"
" Fuel System - Prime" 135

## Daily

" Driven Equipment - Check"	125
" Engine Air Cleaner Service Indicator - Inspect"	127
" Engine Air Precleaner - Check/Clean"	128
" Engine Oil Level - Check"	128
" Coolant Level - Check"	116

## **Every Week**

"Hoses and Clamps - Inspect/Replace" 14
---

## **Every 50 Service Hours**

## **Every 250 Service Hours**

" Coolant Sample (Level 1) - Obtain"	117
" Engine Oil Sample - Obtain"	129

## Every 500 Service Hours or 1 Year

"Battery Electrolyte Level - Check"	105
" Cooling System Supplemental Coolant Additive (SCA) - Test/Add"	118
" Engine Air Cleaner Element - Replace"	125

" Engine Oil and Filter - Change"	130
" Fan Clearance - Check"	134
" Fuel System Primary Filter (Water Separator) Element - Replace"	136
"Fuel System Secondary Filter - Replace"	139
" Radiator - Clean"	145

## **Every 1000 Service Hours**

"Belt - Inspect"	106
"Belt Tensioner - Check"	107
"Water Pump - Inspect"	148

## **Every 2000 Service Hours**

" Aftercooler Core - Inspect"	104
" Alternator - Inspect"	104
" Engine Mounts - Inspect"	128
" Radiator Mounts - Inspect"	146
" Starting Motor - Inspect"	146

## **Every Year**

" Coolant Sample (Level 2) - Obtain"	
--------------------------------------	--

## **Every 3000 Service Hours**

" Diesel Exh	aust Fluid Filter (Emission Related	
	) - Replace"	21

### Every 3000 Service Hours or 3 Years

" Coolant (DEAC) - Change" ..... 107

## **Every 4000 Service Hours**

```
"Aftercooler Core - Clean/Test" ..... 104
```

## **Every 4500 Service Hours**

## **Every 6000 Service Hours**

### Every 6000 Service Hours or 3 Years

" Coolant Extender (ELC) - Add"	
---------------------------------	--

## **Every 10 000 Service Hours**

" DEF Manifold Filters (Emission Related	
Component) - Replace 120	)

## Every 12 000 Service Hours or 6 Years

" Coolant (ELC) - Change" 112	2
-------------------------------	---

## Overhaul

"Overhaul Considerations	<sup>.</sup>	2
--------------------------	--------------	---

i01807350

## Aftercooler Core - Clean/Test (Air-To-Air Aftercooler)

SMCS Code: 1064-070; 1064-081

The air-to-air aftercooler is OEM installed in many applications. Please refer to the OEM specifications for information that is related to the aftercooler.

i02322295

# **Aftercooler Core - Inspect**

SMCS Code: 1064-040

**Note:** Adjust the frequency of cleaning according to the effects of the operating environment.

Inspect the aftercooler for these items: damaged fins, corrosion, dirt, grease, insects, leaves, oil and other debris. Clean the aftercooler, if necessary.

For air-to-air aftercoolers, use the same methods that are used for cleaning radiators.

## 

Personal injury can result from air pressure.

Personal injury can result without following proper procedure. When using pressure air, wear a protective face shield and protective clothing.

Maximum air pressure at the nozzle must be less than 205 kPa (30 psi) for cleaning purposes.

After cleaning, start the engine and accelerate the engine to high idle rpm. This will help in the removal of debris and drying of the core. Stop the engine. Use a light bulb behind the core in order to inspect the core for cleanliness. Repeat the cleaning, if necessary.

Inspect the fins for damage. Bent fins may be opened with a "comb".

**Note:** If parts of the aftercooler system are repaired or replaced, a leak test is highly recommended.

Inspect these items for good condition: Welds, mounting brackets, air lines, connections, clamps and seals. Make repairs, if necessary.

## **Alternator - Inspect**

#### SMCS Code: 1405-040

Caterpillar recommends a scheduled inspection of the alternator. Inspect the alternator for loose connections and proper battery charging. Inspect the ammeter (if equipped) during engine operation in order to ensure proper battery performance and/or proper performance of the electrical system. Make repairs, as required.

Check the alternator and the battery charger for proper operation. If the batteries are properly charged, the ammeter reading should be very near zero. All batteries should be kept charged. The batteries should be kept warm because temperature affects the cranking power of the battery. If the battery is too cold, the battery will not crank the engine.

When the engine is not run for long periods of time or if the engine is run for short periods, the batteries may not fully charge. A battery with a low charge will freeze more easily than a battery with a full charge.

i02680137

## Alternator and Fan Belts -Replace

SMCS Code: 1357-510

Refer to Disassembly and Assembly Manual , " Alternator Belt - Remove and Install".

i05425759

# **Battery - Replace**

SMCS Code: 1401-510

### 

Batteries give off combustible gases which can explode. A spark can cause the combustible gases to ignite. This can result in severe personal injury or death.

Ensure proper ventilation for batteries that are in an enclosure. Follow the proper procedures in order to help prevent electrical arcs and/or sparks near batteries. Do not smoke when batteries are serviced.

i03641972

## 

The battery cables or the batteries should not be removed with the battery cover in place. The battery cover should be removed before any servicing is attempted.

Removing the battery cables or the batteries with the cover in place may cause a battery explosion resulting in personal injury.

**1.** Switch the engine to the OFF position. Remove all electrical loads.

**Note:** After the engine has stopped, allow 2 minutes in order for the diesel exhaust fluid lines to be purged before disconnecting the power.

- **2.** Turn off any battery chargers. Disconnect any battery chargers.
- **3.** Ensure that the battery disconnect switch is in the OFF position.
- **4.** Disconnect the NEGATIVE "-" cable from the NEGATIVE "-" battery terminal.
- **5.** Disconnect the POSITIVE "+" cable from the POSITIVE "+" battery terminal.

**Note:** Always recycle a battery. Never discard a battery. Dispose of used batteries to an appropriate recycling facility.

- 6. Remove the used battery.
- 7. Install the new battery.

**Note:** Before the cables are connected, ensure that the battery disconnect switch is in the OFF position.

- **8.** Connect the POSITIVE "+" cable to the POSITIVE "+" battery terminal.
- **9.** Connect the NEGATIVE "-" cable to the NEGATIVE "-" battery terminal.
- **10.** Turn the battery disconnect switch to the ON position.

i02724529

# Battery Electrolyte Level - Check

SMCS Code: 1401-535-FLV

When the engine is not run for long periods of time or when the engine is run for short periods, the batteries may not fully recharge. Ensure a full charge in order to help prevent the battery from freezing. If batteries are properly charged, ammeter reading should be very near zero, when the engine is in operation.

## 

All lead-acid batteries contain sulfuric acid which can burn the skin and clothing. Always wear a face shield and protective clothing when working on or near batteries.

**1.** Remove the filler caps. Maintain the electrolyte level to the "FULL" mark on the battery.

If the addition of water is necessary, use distilled water. If distilled water is not available use clean water that is low in minerals. Do not use artificially softened water.

- Check the condition of the electrolyte with the 245-5829 Coolant Battery Tester Refractometer.
- 3. Keep the batteries clean.

Clean the battery case with one of the following cleaning solutions:

- Use a solution of 0.1 kg (0.2 lb) baking soda and 1 L (1 qt) of clean water.
- Use a solution of ammonium hydroxide.

Thoroughly rinse the battery case with clean water.

Use a fine grade of sandpaper to clean the terminals and the cable clamps. Clean the items until the surfaces are bright or shiny. DO NOT remove material excessively. Excessive removal of material can cause the clamps to not fit properly. Coat the clamps and the terminals with 5N-5561 Silicone Lubricant, petroleum jelly or MPGM.

i05424317

## Battery or Battery Cable -Disconnect

SMCS Code: 1401; 1402-029

## \Lambda WARNING

The battery cables or the batteries should not be removed with the battery cover in place. The battery cover should be removed before any servicing is attempted.

Removing the battery cables or the batteries with the cover in place may cause a battery explosion resulting in personal injury. **1.** Turn the start switch to the OFF position. Turn the ignition switch (if equipped) to the OFF position and remove the key and all electrical loads.

**Note:** After the engine has stopped, allow 2 minutes in order for the diesel exhaust fluid lines to be purged before disconnecting the power.

- 2. Disconnect the negative battery terminal. Ensure that the cable cannot contact the terminal. When four 12 V batteries are involved, 2 negative connections must be disconnected.
- 3. Remove the positive connection.
- **4.** Clean all disconnected connection and battery terminals.
- 5. Use a fine grade of sandpaper to clean the terminals and the cable clamps. Clean the items until the surfaces are bright or shiny. DO NOT remove material excessively. Excessive removal of material can cause the clamps to fit incorrectly. Coat the clamps and the terminals with a suitable silicone lubricant or petroleum jelly.
- **6.** Tape the cable connections in order to help prevent accidental starting.
- 7. Proceed with necessary system repairs.
- **8.** In order to connect the battery, connect the positive connection before the negative connector.

## **Belt - Inspect**

SMCS Code: 1357-040; 1357; 1397; 1397-040




Illustration 67 Typical example g06301080

To maximize the engine performance, inspect the belt (1) for wear and for cracking. Replace the belt if the belt is worn or damaged.

 Inspect the belt for cracks, splits, glazing, grease, displacement of the cord and evidence of fluid contamination.

The belt must be replaced if the following conditions are present.

- The belt has a crack in more than one rib.
- More than one section of the belt is displaced in one rib of a maximum length of 50.8 mm (2 inch).

To replace the belt, refer to Disassembly and Assembly, "Alternator Belt - Remove and Install". If necessary, replace the belt tensioner. Refer to Disassembly and Assembly, "Alternator Belt -Remove and Install" for the correct procedure.

i07380538

i07382084

# **Belt Tensioner - Check**

SMCS Code: 1358-535





Illustration 68

g06302365

Typical example

- 1. Remove the belt. Refer to Disassembly and Assembly, "Alternator Belt - Remove and Install".
- 2. Ensure that the belt tensioner (2) is securely installed. Visually inspect the belt tensioner for damage. Check that the pulley on the tensioner rotates freely and that the bearing is not loose.
- 3. Some engines have an idler pulley (2). Ensure that the idler pulley is securely installed. Visually inspect the idler pulley for damage. Ensure that the idler pulley can rotate freely and that the bearing is not loose.



#### Illustration 69

#### Typical example

- (A) Tensioner stop
- (3) Tensioner body stop
- (B) Tensioner stop
- 4. Ensure that the tensioner has full movement of travel from stop (A) the other stop (B). Using a constant force the tensioner should move smoothly between the tensioner stop and the tensioner body stop.
- 5. If necessary, replace damaged components.

Install the belt. Refer to Disassembly and Assembly, "Alternator Belt - Remove and Install".

i09430684

q06302436

# Coolant (DEAC) - Change

SMCS Code: 1350-070; 1395-044

Clean the cooling system and flush the cooling system before the recommended maintenance interval if the following conditions exist:

- The engine overheats frequently.
- Foaming is observed.
- The oil has entered the cooling system and the coolant is contaminated.
- The fuel has entered the cooling system and the coolant is contaminated.

#### NOTICE

Use of commercially available cooling system cleaners may cause damage to cooling system components. Use only cooling system cleaners that are approved for Caterpillar engines.

#### NOTICE

When any servicing or repair of the engine cooling system is performed, the procedure must be performed with the engine on level ground. Level ground will allow you to check accurately the coolant level. This procedure will also help in avoiding the risk of introducing an air lock into the coolant system.

**Note:** Inspect the water pump and the water temperature regulator after the cooling system has been drained. This inspection is a good opportunity to replace the water pump, the water temperature regulator, and the hoses, if necessary.

### Drain

## 

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

1. Stop the engine and allow the engine to cool. Loosen the cooling system filler cap slowly to relieve any pressure. Remove the cooling system filler cap.

**Note:** Refer to Operation and Maintenance Manual, "General Hazard Information" for information on containing a fluid spillage.




Illustration 70 Typical example of an industrial engine




Illustration 71

g06742584

q06302798

Typical example of a C3.6 Open Power Unit (OPU)

**2.** Remove the drain plug (1) on the engine. Remove the drain plug (2) on the radiator.


Allow the coolant to drain into a suitable container.

NOTICE Dispose of used engine coolant properly or recycle. Various methods have been proposed to reclaim used coolant for reuse in engine cooling systems. The full distillation procedure is the only method ac-ceptable by Caterpillar to reclaim the used coolant.

3. Properly dispose of the drained material. Obey local regulations for the disposal of the material.

For information regarding the disposal and the recycling of used coolant, consult your Caterpillar dealer or consult Dealer Service Tools.

#### **Drain Plugs for OPU Radiators**



#### Illustration 72

Typical example

(3) C3.6 OPU radiator drain plug

(4) C2.8 OPU radiator drain plug

- Tighten drain plug (3) to a torque of 4 N·m ٠ (35.4 lb in)
- Tighten drain plug (4) to a torque of 4 N·m (35.4 lb in)

### Flush

- 1. Flush the cooling system with clean water to remove any debris.
- 2. Install connection hose. Clean the drain plugs. Install the drain plugs and tighten securely.

NOTICE Do not fill the cooling system faster than 5 L (1.3 US gal) per minute to avoid air locks.

Cooling system air locks may result in engine damage.

- 3. Fill the cooling system with a mixture of clean water and Caterpillar Fast Acting Cooling System Cleaner. Add 0.5 L (1 pt) of cleaner per 15 L (4 US gal) of the cooling system capacity. Install the cooling system filler cap.
- 4. Start and run the engine at low idle for a minimum of 30 minutes. The coolant temperature should be at least 85° C (185° F).

#### NOTICE

Improper or incomplete rinsing of the cooling system can result in damage to copper and other metal components.

To avoid damage to the cooling system, make sure to completely flush the cooling system with clear water. Continue to flush the system until all signs of the cleaning agent are gone.

- 5. Stop the engine and allow the engine to cool. Loosen the cooling system filler cap slowly to relieve any pressure. Remove the cooling system filler cap. Remove the connection hose or remove the cooling system drain plugs. Allow the water to drain. Flush the cooling system with clean water. Install the connection hose.
- 6. The drain plug O rings on the engine block must be replaced. Clean the drain plugs and install new O ring seal. Install the drain plugs and tighten securely.

### Cooling Systems with Heavy Deposits or Plugging

**Note:** For the following procedure to be effective, there must be some active flow through the cooling system components.

- **1.** Flush the cooling system with clean water to remove any debris.
- **2.** Clean the drain plugs. Install the drain plugs and tighten securely.

NOTICE

Do not fill the cooling system faster than 5 L (1.3 US gal) per minute to avoid air locks.

Cooling system air locks may result in engine damage.

- Fill the cooling system with a mixture of clean water and Caterpillar Fast Acting Cooling System Cleaner. Add 0.5 L (1 pt) of cleaner per 3.8 to 7.6 L (1 to 2 US gal) of the cooling system capacity. Install the cooling system filler cap.
- **4.** Start and run the engine at low idle for a minimum of 90 minutes. The coolant temperature should be at least 85° C (185° F).

#### NOTICE

Improper or incomplete rinsing of the cooling system can result in damage to copper and other metal components.

To avoid damage to the cooling system, make sure to completely flush the cooling system with clear water. Continue to flush the system until all signs of the cleaning agent are gone.

- 5. Stop the engine and allow the engine to cool. Loosen the cooling system filler cap slowly to relieve any pressure. Remove the cooling system filler cap. Open the drain valve (if equipped) or remove the cooling system drain plug. Allow the water to drain. Flush the cooling system with clean water.
- 6. The drain plug O rings on the engine block must be replaced. Clean the drain plugs and install new O ring seal. Install the drain plugs and tighten securely.

#### Fill

NOTICE

Do not fill the cooling system faster than 5 L (1.3 US gal) per minute to avoid air locks.

Cooling system air locks may result in engine damage.

- Fill the cooling system with the coolant/antifreeze. Refer to this Operation and Maintenance Manual, "Fluid Recommendations" for more information on cooling system specifications. Install the cooling system filler cap.
- 2. Start and run the engine at low idle. Increase the engine rpm to high idle. Operate the engine to open the engine thermostat. This operation will allow any air in the system to be purged. Decrease the engine speed to low idle. Stop the engine.
- **3.** Maintain the coolant level at the maximum mark that is correct for your application. Refer to this Operation and Maintenance Manual, "Coolant Level - Check" for more information.
- 4. Clean the cooling system filler cap. Inspect the gasket that is on the cooling system filler cap. If the gasket that is on the cooling system filler cap is damaged, discard the old cooling system filler cap and install a new cooling system filler cap. If the gasket that is on the cooling system filler cap. If the gasket that is on the cooling system filler cap is not damaged, perform a pressure test. A 9S 8140 Pressurizing Pump is used to perform the pressure test. The correct pressure for the cooling system filler cap is stamped on the face of the cooling system filler cap. If the cooling system filler cap. If the cooling system filler cap is stamped on the face of the cooling system filler cap. If the cooling system filler cap does not retain the correct pressure, install a new cooling system filler cap.

**5.** Start the engine. Inspect the cooling system for leaks and for the correct operating temperature.

i09430683

### Coolant (ELC) - Change

SMCS Code: 1350-070; 1395-044

Clean the cooling system and flush the cooling system before the recommended maintenance interval if the following conditions exist:

- · The engine overheats frequently.
- · Foaming is observed.
- The oil has entered the cooling system and the coolant is contaminated.
- The fuel has entered the cooling system and the coolant is contaminated.

**Note:** When the cooling system is cleaned, only clean water is needed when the ELC is drained and replaced.

**Note:** Use non-foaming detergent to clean oil or fuel contamination.

**Note:** Inspect the water pump and the water temperature regulator after the cooling system has been drained. Replace the water pump, the water temperature regulator, and the hoses, if necessary.

#### NOTICE

Service or repair of the engine cooling system must be performed on level ground. The engine must be level to check the coolant level. The engine must be level to avoid the risk of introducing an air lock into the coolant system.

### Drain

#### 🏠 WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

1. Stop the engine and allow the engine to cool. Loosen the cooling system filler cap slowly to relieve any pressure. Remove the cooling system filler cap.





Illustration 73 g06302798 Typical example of an industrial engine



#### Illustration 74

#### g06742584

Typical example of a C3.6 Open Power Unit (OPU)

**2.** Remove the drain plug (1) on the engine. Remove the drain plug (2) on the radiator.


Allow the coolant to drain into a suitable container.

NOTICE Dispose of used engine coolant properly or recycle. Various methods have been proposed to reclaim used coolant for reuse in engine cooling systems. The full distillation procedure is the only method ac-ceptable by Caterpillar to reclaim the used coolant.

3. Properly dispose of the drained material. Obey local regulations for the disposal of the material.

For information regarding the disposal and the recycling of used coolant, consult your Caterpillar dealer or consult Dealer Service Tools.

#### **Drain Plugs for OPU Radiators**



#### Illustration 75

Typical example

(3) C3.6 OPU radiator drain plug

(4) C2.8 OPU radiator drain plug

- Tighten drain plug (3) to a torque of 4 N·m (35.4 lb in)
- Tighten drain plug (4) to a torque of 4 N·m (35.4 lb in)

### Flush

- 1. Flush the cooling system with clean water to remove any debris.
- 2. Install the connection hose. Clean the drain plugs. Install the drain plugs. Refer to Torque Specifications, SENR3130 for more information on the correct torques.

#### NOTICE

Do not fill the cooling system faster than 5 L (1.3 US gal) per minute to avoid air locks.

Cooling system air locks may result in engine damage.

3. Fill the cooling system with clean water. Install the cooling system filler cap.

- 4. Start and run the engine at low idle until the temperature reaches 50° to 70°C (122° to 158°F).
- Stop the engine and allow the engine to cool. Loosen the cooling system filler cap slowly to relieve any pressure. Remove the cooling system filler cap. Remove the cooling system drain plugs. Allow the water to drain. Flush the cooling system with clean water. Install the connection hose. Clean the drain plugs. Install the drain plugs. Refer to Torque Specifications, SENR3130 for more information on the correct torques.

#### Fill

NOTICE Do not fill the cooling system faster than 5 L (1.3 US gal) per minute to avoid air locks.

Cooling system air locks may result in engine damage.

- Fill the cooling system with Extended Life Coolant (ELC). Refer to Operation and Maintenance Manual, "Fluid Recommendations" for more information on cooling system specifications. Install the cooling system filler cap.
- 2. Start and run the engine at low idle. Increase the engine rpm to high idle. Operate the engine to open the engine thermostat. An open thermostat will allow any air in the system to be purged. Decrease the engine speed to low idle. Stop the engine.
- **3.** Maintain the coolant level at the maximum mark that is correct for your application.
- 4. Clean the cooling system filler cap. Inspect the gasket that is on the cooling system filler cap. If the gasket that is on the cooling system filler cap is damaged, discard the old cooling system filler cap and install a new cooling system filler cap. If the gasket that is on the cooling system filler cap. If the gasket that is on the cooling system filler cap is not damaged, use a 9S-8140 Pressurizing Pump to pressure test the cooling system filler cap. The correct pressure for the cooling system filler cap is stamped on the face of the cooling system filler cap is not retain the correct pressure, install a new cooling system filler cap.
- **5.** Start the engine. Inspect the cooling system for leaks and for proper operating temperature.

i04913503

### Coolant Extender (ELC) - Add

SMCS Code: 1352-544-NL

Cat ELC (Extended Life Coolant) does not require the frequent additions of any supplemental cooling additives which are associated with the present conventional coolants. The Cat ELC Extender only needs adding once.

#### NOTICE

Use only Cat Extended Life Coolant (ELC) Extender with Cat ELC.

Do NOT use conventional supplemental coolant additive (SCA) with Cat ELC. Mixing Cat ELC with conventional coolants and/or conventional SCA reduces the Cat ELC service life.

Check the cooling system only when the engine is stopped and cool.

#### 

Personal injury can result from hot coolant, steam and alkali.

At operating temperature, engine coolant is hot and under pressure. The radiator and all lines to heaters or the engine contain hot coolant or steam. Any contact can cause severe burns.

Remove cooling system pressure cap slowly to relieve pressure only when engine is stopped and cooling system pressure cap is cool enough to touch with your bare hand.

Do not attempt to tighten hose connections when the coolant is hot, the hose can come off causing burns.

Cooling System Coolant Additive contains alkali. Avoid contact with skin and eyes.

#### NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting, and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Cat Dealer Service Tool Catalog" or refer to Special Publication, PECJ0003, "Cat Shop Supplies and Tools Catalog" for tools and supplies suitable to collect and contain fluids on Cat products.

Dispose of all fluids according to local regulations and mandates.

#### NOTICE

When any servicing or repair of the engine cooling system is performed, the procedure must be performed with the engine on level ground. This procedure will allow you to check accurately the coolant level. This procedure will also help in avoiding the risk of introducing an air lock into the coolant system.

- 1. Loosen the cooling system filler cap slowly in order to relieve pressure. Remove the cooling system filler cap.
- 2. If necessary, drain enough coolant from the cooling system in order to add the Cat ELC Extender.
- **3.** Add Cat ELC Extender according to the requirements for your engines cooling system capacity. Refer to the Operation and Maintenance Manual, "Refill Capacities and Recommendations" article for more information.

4. Clean the cooling system filler cap. Inspect the gaskets on the cooling system filler cap. Replace the cooling system filler cap if the gaskets are damaged. Install the cooling system filler cap.

i09430682

### **Coolant Level - Check**

SMCS Code: 1395-082

#### 🏠 WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

Check the coolant level when the engine is stopped and cool.

#### NOTICE

When any servicing or repair of the engine cooling system is performed, the procedure must be performed with the engine on level ground. This procedure will allow you to check accurately the coolant level. This procedure will also help in avoiding the risk of introducing an air lock into the coolant system.

- 1. Remove the cooling system filler cap slowly to relieve pressure.
- 2. Maintain the coolant level at the maximum mark that is correct for your application. If the engine is equipped with a sight glass, maintain the coolant level to the correct level in the sight glass.

Illustration 76 Typical filler cap gaskets or the sealing surface (1) are damaged.


Inspect the cooling system for leaks.

**Note:** The Diesel Exhaust Fluid (DEF) tank requires coolant flow around the tank. The Coolant Diverter Valve (CDV) will turn the flow on or off. If the coolant system has been filled with the CDV in the closed position, coolant level will drop because of the opening of the CDV. The coolant flow will be diverted when the ambient temperature is approximately -5° C (23° F).


### **Open Power Unit (OPU) Radiators**

The following information is provided for the correct coolant level on OPU radiators.

q06165279



3. Clean the cooling system filler cap and check the condition of the filler cap gasket (1). Replace the cooling system filler cap if the filler cap gasket (2)



### Illustration 77

g06743628

Typical example

- The coolant level (A) is for C3.6 OPU radiator.
- The coolant level (B) is for C2.8 OPU radiator.
- 1. Remove the cooling system filler cap slowly to relieve the pressure within the cooling system.
- 2. The coolant level (A) and (B) is 61.5 mm (2.42 inch) below the top of the radiator neck.
- 3. Check the cooling system filler cap and install.

i04913603

### Coolant Sample (Level 1) -Obtain

SMCS Code: 1350-008; 1395-554; 1395-008; 7542

Note: Obtaining a Coolant Sample (Level 1) is optional if the cooling system is filled with Cat ELC (Extended Life Coolant). Cooling systems filled with Cat ELC should have a Coolant Sample (Level 2) that is obtained at the recommended interval as stated in the maintenance interval schedule.

Note: Obtain a Coolant Sample (Level 1) if the cooling system is filled with any other coolant instead of Cat ELC including the following coolants:

- Commercial long life coolants that meet the Caterpillar Engine Coolant Specification -1 (Caterpillar EC-1)
- Cat DEAC (Diesel Engine Antifreeze/Coolant)

Commercial heavy-duty coolant/antifreeze

#### Table 26

Recommended Interval					
Type of Coolant	Level 1 Level 2				
Cat DEAC					
Conventional heavy duty-coolant	E 050 i	Every year <sup>(1)</sup>			
Commercial coolant that meets the re- quirements of the Caterpillar EC-1 standard	Every 250 service hours				
Cat ELC or conven- tional EC-1 coolant	Optional	Every year <sup>(1)</sup>			

(1) The Level 2 Coolant Analysis should be performed sooner if a problem is suspected or identified.

#### NOTICE

Always use a designated pump for oil sampling, and use a separate designated pump for coolant sampling. Using the same pump for both types of samples may contaminate the samples that are being drawn. This contaminate may cause a false analysis and an incorrect interpretation that could lead to concerns by both dealers and customers.

#### Note: Level 1 results may indicate a need for Level 2 Analysis.

Obtain the sample of the coolant as close as possible to the recommended sampling interval. In order to receive the full effect of S·O·S analysis, establish a consistent trend of data. In order to establish a pertinent history of data, perform consistent samplings that are evenly spaced. Supplies for collecting samples can be obtained from your Caterpillar dealer.

Use the following guidelines for proper sampling of the coolant:

- Complete the information on the label for the sampling bottle before you begin to take the samples.
- Keep the unused sampling bottles stored in plastic • bags.
- Obtain coolant samples directly from the coolant sample port. You should not obtain the samples from any other location.
- Keep the lids on empty sampling bottles until you are ready to collect the sample.
- Place the sample in the mailing tube immediately after obtaining the sample in order to avoid contamination.

i03644817

- Never collect samples from expansion bottles.
- Never collect samples from the drain for a system.

Submit the sample for Level 1 analysis.

For additional information about coolant analysis, see this Operation and Maintenance Manual, "Refill Capacities and Recommendations" or consult your Caterpillar dealer.

i04913805

# Coolant Sample (Level 2) - Obtain

SMCS Code: 1350-008; 1395-554; 1395-008; 7542

#### NOTICE

Always use a designated pump for oil sampling, and use a separate designated pump for coolant sampling. Using the same pump for both types of samples may contaminate the samples that are being drawn. This contaminate may cause a false analysis and an incorrect interpretation that could lead to concerns by both dealers and customers.

#### NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting, and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Cat Dealer Service Tool Catalog" or refer to Special Publication, PECJ0003, "Cat Shop Supplies and Tools Catalog" for tools and supplies suitable to collect and contain fluids on Cat products.

Dispose of all fluids according to local regulations and mandates.

Refer to Operation and Maintenance Manual, "Cooling System Coolant Sample (Level 1) - Obtain" for the guidelines for proper sampling of the coolant.

Submit the sample for Level 2 analysis.

For additional information about coolant analysis, see Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engines Fluids Recommendations" or consult your Caterpillar dealer.

### Cooling System Supplemental Coolant Additive (SCA) - Test/ Add

SMCS Code: 1352-045; 1395-081

#### 

Cooling system coolant additive contains alkali. To help prevent personal injury, avoid contact with the skin and the eyes. Do not drink cooling system coolant additive.

**Note:** Test the concentration of the Supplemental Coolant Additive (SCA) or test the SCA concentration as part of an  $S \cdot O \cdot S$  Coolant Analysis.

#### **Test for SCA Concentration**

#### Coolant and SCA

NOTICE

Do not exceed the recommended six percent supplemental coolant additive concentration.

Use the 8T-5296 Coolant Conditioner Test Kit or use the 4C-9301 Coolant Conditioner Test Kit in order to check the concentration of the SCA. Refer to this Operation and Maintenance Manual, "Refill Capacities and Recommendations" for more information.

#### Water and SCA

#### NOTICE

Do not exceed the recommended eight percent supplemental coolant additive concentration.

Test the concentration of the SCA with the 8T - 5296 Coolant Conditioner Test Kit. Refer to the Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" for more information.

#### S·O·S Coolant Analysis

 $S \cdot O \cdot S$  coolant samples can be analyzed at your Caterpillar dealer.  $S \cdot O \cdot S$  Coolant Analysis is a program that is based on periodic samples.

#### Level 1

Level 1 is a basic analysis of the coolant. The following items are tested:

- Glycol Concentration
- Concentration of SCA

- pH
- Conductivity

The results are reported, and recommendations are made according to the results. Consult your Caterpillar dealer for information on the benefits of managing your equipment with an  $S \cdot O \cdot S$  Coolant Analysis.

#### Level 2

This level coolant analysis is recommended when the engine is overhauled. Refer to this Operations and Maintenance Manual, "Overhaul Considerations" for further information.

### Add the SCA, If Necessary

#### NOTICE

Do not exceed the recommended amount of supplemental coolant additive concentration. Excessive supplemental coolant additive concentration can form deposits on the higher temperature surfaces of the cooling system, reducing the engine's heat transfer characteristics. Reduced heat transfer could cause cracking of the cylinder head and other high temperature components. Excessive supplemental coolant additive concentration could also result in radiator tube blockage, overheating, and/or accelerated water pump seal wear. Never use both liquid supplemental coolant additive and the spin-on element (if equipped) at the same time. The use of those additives together could result in supplemental coolant additive concentration exceeding the recommended maximum.

### 🛕 WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

#### NOTICE

When any servicing or repair of the engine cooling system is performed the procedure must be performed with the engine on level ground. This will allow you to accurately check the coolant level. This will also help in avoiding the risk of introducing an air lock into the coolant system.

 Slowly loosen the cooling system filler cap in order to relieve the pressure. Remove the cooling system filler cap.

**Note:** Always discard drained fluids according to local regulations.

- If necessary, drain some coolant from the cooling system into a suitable container in order to allow space for the extra SCA.
- **3.** Add the proper amount of SCA. Refer to the Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engines Fluids Recommendations" for more information on SCA requirements.
- **4.** Clean the cooling system filler cap. Inspect the gaskets of the cooling system filler cap. If the gaskets are damaged, replace the old cooling system filler cap with a new cooling system filler cap. Install the cooling system filler cap.

i07383194

### DEF Filler Screen (Emission Related Component) - Clean

SMCS Code: 108K-070

NOTICE Ensure that the engine is stopped before any servicing or repair is performed.




Illustration 78
Typical example

g03725939

- 1. Ensure that the area around cap on the Diesel Exhaust Fluid (DEF) tank is clean. Remove cap (1).
- **2.** Using a suitable tool, press the tabs (2) to release the tabs. With the tabs released remove the filler screen (3) from DEF tank neck adapter (4).
- **3.** The filler screen can be cleaned in clean water and dried using compressed air. Refer to this Operation and Maintenance Manual, "General Hazard Information" for information on using compressed air.
- **4.** If the filler screen cannot be cleaned or the filler screen is damaged, then the filler screen must be replaced.
- **5.** Install filler screen (3) into DEF tank neck adapter (4). Press filler screen into neck adapter and ensure that tabs (2) are located correctly. Install cap (1).

i07383199

### DEF Manifold Filters (Emission Related Component) - Replace

SMCS Code: 108K-510




Illustration 79 Typical example g06302888

**1.** Remove DEF tank manifold. Refer to Disassembly and Assembly, Manifold (DEF Heater) - Remove and Install for more information.

- **2.** Remove screw (5) and remove filter (4) and bracket (3) and bracket (2) from assembly (1). Discard old filter.
- **3.** Ensure that new filter (4) is clean and free from damage.
- 4. Place bracket (2) onto assembly (1). Install bracket (3) onto assembly (1).
- Align new filter (4) to assembly suction pipe (1) and install new filter (4). Install screw (5) and tighten to a torque of 2 N·m (16 lb in).
- **6.** Install DEF manifold, refer to Disassembly and Assembly, Manifold (DEF Heater) Remove and Install for more information.

i07383319

### Diesel Exhaust Fluid (Emission Related Component) - Fill

SMCS Code: 108K-544




Illustration 80 Typical example g06303219

Ensure that the correct specification Diesel Exhaust Fluid (DEF) is used. Ensure the cleanliness of the DEF, refer to this Operation and Maintenance Manual, "Fluid Recommendations" for more information.

Care should be taken when dispensing DEF. Spills should be cleaned immediately. All surfaces should be wiped clean and rinsed with water.

DEF that has been spilt will crystallize when the water within the liquid evaporates. Spilt DEF will attack paint and metal. If DEF is spilt, wash the area with water.

Caution should be used when dispensing DEF near an engine that has recently been running. Spilling DEF onto hot components may cause the release of ammonia vapors. Do not breathe ammonia vapors. Do not clean up any spills with bleach.

Ensure that the DEF tank is full before starting work.

- 1. Before filling the DEF tank, ensure that the DEF lines have been purged. Purging of the DEF lines will take place, after the engine has stopped. Only after the DEF lines have purged, should the DEF tank be filled. For more information on the time taken for purging the DEF lines, refer to this Operation and Maintenance Manual, "Battery Disconnect Switch".
- **2.** Ensure that the DEF cap (1) and the surrounding area are clean and free from dirt. Ensure that all equipment use in filling the tank is clean and free from dirt.
- **3.** Remove the DEF cap from the tank.
- **4.** Fill the tank with the required amount of DEF. Ensure that dirt is not introduced into the tank during filling. Do not over fill the tank. The DEF will require room for expansion.

**Note:** Always fill the DEF tank on level ground. Cold weather can affect DEF, refer to this Operation and Maintenance Manual, "Diesel Exhaust Fluid in cold Weather" for more information.

**5.** The opening on the DEF tank (2) is a special diameter. Ensure that the correct nozzle is used when filling the DEF tank.

**Note:** At key on the DEF level gauge will show the last known DEF level and will transition to the new DEF level value.

**6.** Install the DEF cap. Check visually the DEF tank for leakage.

i07383609

121

### Diesel Exhaust Fluid Filter (Emission Related Component) - Replace

SMCS Code: 108K-510

#### 


Personal injury can result from improper handling of chemicals.

Make sure you use all the necessary protective equipment required to do the job.


Make sure that you read and understand all directions and hazards described on the labels and material safety data sheet of any chemical that is used.

Observe all safety precautions recommended by the chemical manufacturer for handling, storage, and disposal of chemicals.

The Diesel Exhaust Fluid (DEF) pump can be located next to the DEF tank. On some application the DEF pump can be installed away from the DEF tank.



- 1. Ensure that the area around the DEF filter is clean and free from dirt. Use a 27mm Bi-Hex socket to remove filter cap (4).
- 2. Remove the expansion device (3).



g06215916

Illustration 82 Typical example

- **3.** Use supplied tool (5) to remove filter element (2) from DEF pump assembly (1).
- **4.** Install new filter element (2) into DEF pump assembly (1).
- Install expansion device (3) into filter element (2). Install filter cap (4) and tighten cap to 20 N⋅m (177 lb in).

i07385681

### Diesel Exhaust Fluid Injector (Emission Related Component) - Replace

SMCS Code: 108I-510




Illustration 83 Typical example

For a detailed procedure to remove and install the DEF injector (1), refer to Disassembly and Assembly, DEF Injector and Mounting - Remove and Install.

After installation of the DEF injector, use the electronic service tool to perform the "DEF Dosing System Verification test".

i07383720

### Diesel Exhaust Fluid Tank -Flush

SMCS Code: 108T-046

#### **Required Tools**

Table 27

Required Tools				
Tool	Part Number	Part Description	Qty	
А	-	Plugs	2	

### **Flushing Procedure**


1. Turn the key switch to the OFF position. The key switch must be OFF to allow the DEF pump to purge, ensuring the system is free of pressurized DEF.

**Note:** Allow the full 2 minutes after turning the key switch to the OFF position before turning the battery disconnect switch to the OFF position. Refer to Operation and Maintenance Manual, "Battery Disconnect Switch" for more information.

2. Drain the existing DEF from the DEF tank.

**Note:** All DEF drained or flushed during this procedure must be disposed of as per local regulations and mandates.

**3.** Drain the engine coolant to an appropriate level that will allow the coolant lines to be removed from the tank header. Refer to Operation and Maintenance Manual for more information.



#### Illustration 84

#### Typical example

(1) DEF suction line

(2) Manifold (DEF heater)


(3) Harness assembly

(4) DEF backflow line(5) Coolant return to the engine

- (6) Coolant supply to manifold (DEF heater)
- 4. Remove the manifold (DEF heater) from the DEF tank. Refer to Disassembly and Assembly,
  "Manifold (DEF Heater) Remove and Install" for the correct procedure.

g03708638

g06357828



g06357825

Typical example

(7) Filter

- 5. Remove the filter from the manifold (DEF heater). Refer to Disassembly and Assembly, "Manifold (DEF Heater) - Remove and Install" for the correct procedure.
- 6. Flush the DEF suction and backflow connections on the manifold (DEF heater) using distilled water. Install a new filter onto the manifold (DEF heater). Refer to Disassembly and Assembly, "Manifold (DEF Heater) - Remove and Install" for the correct procedure.
- **7.** Position the suitable container under the DEF tank drain and flush the DEF tank thoroughly.
- Reinstall the manifold (DEF heater) into the DEF tank. Refer to Disassembly and Assembly, "Manifold (DEF Heater) - Remove and Install" for the correct procedure.




Illustration 86 Typical example (8) DEF pump (9) DEF filter cap

- **9.** Replace the Diesel Exhaust Fluid (DEF) filter. Refer to Operation and Maintenance Manual for the correct procedure.
- 10. Flush the DEF suction and backflow lines into a suitable container using distilled water. The minimum quantity of distilled water that is required is 7.57 L (2 US gal).
- **11.** Reconnect all lines to the DEF pump and to the manifold (DEF heater). Refer to Disassembly and Assembly for the correct procedures.
- **12.** Fill the DEF tank to the appropriate level with new DEF. Operation and Maintenance Manual for more information. The new DEF must meet ISO 22241 standards.
- **13.** Start the engine. Refer to Operation and Maintenance Manual for the correct procedure.
- 14. Connect to the electronic service tool.

<sup>(2)</sup> Manifold (DEF heater)

**15.** Perform the "Aftertreatment System Functional Test" in the electronic service tool. This test will verify that the DEF system is working correctly following the flush and filter replacement.

i02151646

### **Driven Equipment - Check**

#### SMCS Code: 3279-535

Refer to the OEM specifications for more information on the following maintenance recommendations for the driven equipment:

- Inspection
- Adjustment
- Lubrication
- · Other maintenance recommendations

Perform any maintenance for the driven equipment which is recommended by the OEM.

i07819515

### **Engine - Clean**

#### SMCS Code: 1000-070

#### WARNING

Personal injury or death can result from high voltage.

Moisture can create paths of electrical conductivity.

Make sure that the electrical system is OFF. Lock out the starting controls and tag the controls "DO NOT OPERATE".

#### NOTICE

Accumulated grease and oil on an engine is a fire hazard. Keep the engine clean. Remove debris and fluid spills whenever a significant quantity accumulates on the engine.

Periodic cleaning of the engine is recommended. Steam cleaning the engine will remove accumulated oil and grease. A clean engine provides the following benefits:

- · Easy detection of fluid leaks
- Maximum heat transfer characteristics
- Ease of maintenance

**Note:** Caution must be used to prevent electrical components from being damaged by excessive water when the engine is cleaned. Pressure washers and steam cleaners should not be directed at any electrical connectors or the junction of cables into the rear of the connectors. Avoid electrical components such as the alternator, the starter, and the ECM. Protect the fuel injection pump from fluids to wash the engine.

Ensure that care is taken that the safety labels, emission label, and all other information labels are not removed during engine cleaning.

#### Aftertreatment

During the engine cleaning process, ensure that water or cleaning fluids cannot enter the aftertreatment system. If cleaning fluids enters the aftertreatment system, damage could occur.

i09430686

### Engine Air Cleaner Element -Replace

SMCS Code: 1051-510; 1054-510

NOTICE

Never run the engine without an air cleaner element installed. Never run the engine with a damaged air cleaner element. Do not use air cleaner elements with damaged pleats, gaskets or seals. Dirt entering the engine causes premature wear and damage to engine components. Air cleaner elements help to prevent airborne debris from entering the air inlet.

#### NOTICE

Never service the air cleaner element with the engine running since this will allow dirt to enter the engine.

### Servicing the Air Cleaner Elements

**Note:** The air filter system may not have been provided by Caterpillar. The procedure that follows, is for a typical air filter system. Refer to the OEM information for the correct procedure.

If the air cleaner element becomes plugged, the air can split the material of the air cleaner element. Unfiltered air will drastically accelerate internal engine wear. Refer to the OEM information for the correct air cleaner elements for your application.

- Check the precleaner (if equipped) and the dust bowl daily for accumulation of dirt and debris. Remove any dirt and debris, as needed.
- Operating in dirty conditions may require more frequent service of the air cleaner element.

• The air cleaner element should be replaced at least one time per year.

Replace the dirty air cleaner elements with clean air cleaner elements. Before installation, the new air cleaner elements should be thoroughly checked for tears and/or holes in the filter material. Inspect the gasket or the seal of the air cleaner element for damage. Maintain a supply of suitable air cleaner elements for replacement purposes.

#### **Air Cleaners**

Do not replace the air cleaner filter elements in a dirty environment, as dirt can enter the air system when the elements are removed.




Illustration 87 Typical example

g06217098


- (1) Top Cover
- (2) Air Cleaner Body
- (3) Primary Air Filter Element
- (4) End Cover
- (5) Vacuum Valve
- 1. Ensure that the outer body of the air cleaner to be serviced is clean and free from dirt.
- Inspect the top cover (1) and if necessary remove top cover to clean cover. Ensure that dirt cannot enter the air cleaner system with top cover removed. If necessary, clean top cover and install.

- **3.** Remove end cover (4) from air cleaner body (2). If necessary, clean end cover and ensure that the vacuum valve (5) is clean and free from dirt. Check the vacuum valve (5) for wear or damage, replace if necessary.
- **4.** Remove primary air filter element (3). Discard all old air filter elements.
- 5. Install new primary air filter element (3).
- 6. Install end cover (4) to air cleaner body (2) and secure end cover. If necessary, reset the air service indicator, refer to this Operation and Maintenance Manual, Engine Air Cleaner Service Indicator - Inspect for more information.

#### **Dual Element Air Cleaners**

Some application can have dual elements. The dual air cleaner contains a primary air cleaner element and a secondary air cleaner element. Both element must be replaced at the same time.

Do not replace the air cleaner filter elements in a dirty environment, as dirt can enter the air system when the elements are removed.



#### Illustration 88

- Typical example
- (1) Service Indicator
- (2) Top Cover
- (3) Air Cleaner Body
- (4) Primary Air Filter Element (5) Secondary Air Filter Element
- (6) End Cover
- (7) Vacuum Valve
- (8) Clips
- 1. Ensure that the outer body of the air cleaner to be serviced is clean and free from dirt.

g06966204

- **2.** Release clips (8) and remove end cover (6) from air cleaner body (3). If necessary, clean end cover and ensure that the valve (7) is clean and free from dirt. Check the valve (7) for wear or damage, replace if necessary.
- **3.** Remove primary air filter element (5) and, remove the secondary air filter element (4). Discard all old air filter elements.
- **4.** Install new secondary air filter element (4) and install new primary air filter element (5)
- **5.** Install end cover (6) to air cleaner body (3) and secure end cover clips (8). If necessary, reset the air service indicator (1), refer to this Operation and Maintenance Manual, Engine Air Cleaner Service Indicator Inspect for more information.

i09119853

g00103777

### **Engine Air Cleaner Service** Indicator - Inspect


SMCS Code: 7452-040

Some engines may be equipped with a different service indicator.

Some engines are equipped with a differential gauge for inlet air pressure. The differential gauge for inlet air pressure displays the difference in the pressure that is measured before the air cleaner element and the pressure that is measured after the air cleaner element. As the air cleaner element becomes dirty, the pressure differential rises. If your engine is equipped with a different type of service indicator, follow the OEM recommendations to service the air cleaner service indicator.

### **Type 1 Service Indicator**

The service indicator may be mounted on the air cleaner element or in a remote location.



Observe the service indicator. The air cleaner element should be cleaned or the air cleaner element should be replaced when one of the following conditions occurs:

- The yellow diaphragm enters the red zone.
- The red piston locks in the visible position.

### **Type 2 Service Indicator**

The service indicator is installed on the air cleaner element. The service indicator is to be tightened by hand, ensuring the o ring seal is in place.




Illustration 90

g07079288

Typical example of type 2 service indicator

Observe the service indicator. The air cleaner element should be cleaned or the air cleaner element should be replaced when one of the following conditions occurs:

- The yellow diaphragm enters the red zone.
- The red piston locks in the visible position.

### Test the Service Indicator

Service indicators are important instruments.

- Check for ease of resetting. The service indicator should reset in fewer than three pushes.
- Check the movement of the yellow core when the engine is accelerated to the engine rated speed. The yellow core should latch at the greatest vacuum that is attained.

If the service indicator does not reset easily, or if the yellow core does not latch at the greatest vacuum, the service indicator should be replaced. If the new service indicator will not reset, the hole for the service indicator may be restricted.

The service indicator may need to be replaced frequently in environments that are severely dusty.

i07819526

### Engine Air Precleaner - Check/ Clean

SMCS Code: 1055-535; 1055-070




Illustration 91

g01453058

Typical engine air precleaner

- (1) Wing nut
- (2) Cover
- (3) Body

Remove wing nut (1) and cover (2). Check for an accumulation of dirt and debris in body (3). Clean the body, if necessary.

After cleaning the precleaner, install cover (2) and wing nut (1).

**Note:** When the engine is operated in dusty conditions, more frequent cleaning is required.

Do not tap or strike the air cleaner element.

i02456872

### **Engine Mounts - Inspect**

SMCS Code: 1152; 1152-040

Inspect the engine mounts for deterioration and for proper bolt torque. Engine vibration can be caused by the following conditions:

- · Improper mounting of the engine
- · Deterioration of the engine mounts

Any engine mount that shows deterioration should be replaced. Refer to Special Publication, SENR3130, "Torque Specifications" for the recommended torques. Refer to the OEM recommendations for more information. i08055063

q06525971


g06551003

### Engine Oil Level - Check

SMCS Code: 1348-535-FLV

#### 

Hot oil and hot components can cause personal injury. Do not allow hot oil or hot components to contact the skin.



Do not overfill the crankcase. Engine damage can result.

### **Before Operating the Engine**




Illustration 92

Typical example of type 2 oil level gauge (dipstick)

(L) Low

(H) High

- (A) Crosshatched area
- (B) Warning symbol




Illustration 93

Typical example of type 1 oil level gauge (dipstick)

(H) High

 Maintain the oil level between the mark (L) and the mark (H) on the engine oil level gauge (dipstick). Do not fill the crankcase above the (H).

#### NOTICE

The oil level checked that falls in the crosshatched ( Position "A" ) area between the (H) and below the warning triangle ( Position "B" ) is safe for engine operation.

Operating your engine when the oil level is the in warning triangle area (Position "B") above crosshatched section (Position "A") could cause your crankshaft to dip into the oil. The air bubbles created from the crankshaft dipping into the oil reduces the oils lubricating characteristics and could result in the loss of power.

- 2. Remove the oil filler cap and add oil, if necessary.
- 3. Clean the oil filler cap. Install the oil filler cap.
- 4. If necessary, drain a small quantity of oil from the crankcase to reduce the oil level. The oil level needs to be between the mark (L) and the mark (H) before operating the engine. Refer to the "Operation and Maintenance Manual", Engine Oil and Filter Change, "Drain the Engine Lubricating Oil" for more information.

### After Operating the Engine

**Note:** Before checking the oil level, the engine must have been switched off for a minimum of 30 minutes to allow the oil to drain down to the crankcase.

	imple of type	e 2 oil level ga	uge (di	<sup>g06553532</sup> pstick)
(L) Low (H) High 				
	L		Η	
Illustration 95 Typical exa (L) Low (H) High	imple of type	e 1 oil level ga	iuge (di	<sup>g06551003</sup> pstick)

- Check the oil level and maintain the oil level between the mark (L) and the mark (H) on the engine oil level gauge (dipstick). Do not fill the crankcase above the mark (H).
- 2. If necessary, remove the oil filler cap and add oil.

**Note:** When the oil level is shown to be at the (L) mark, 1 L (0.3 US gal) of oil added will bring up the oil level within the (L) and (H) marks.

3. Clean the oil filler cap and install the oil filler cap.

If an increase in the oil level is noticed, refer to Troubleshooting, "Oil Contains Fuel".

i08397634

### **Engine Oil Sample - Obtain**

SMCS Code: 1348-554-SM

In addition to a good preventive maintenance program, Caterpillar recommends using  $S \cdot O \cdot S$  oil analysis at regularly scheduled intervals.  $S \cdot O \cdot S$  oil analysis provides infrared analysis, which is required for determining nitration and oxidation levels.

## Obtain the Sample and the Analysis

#### 🛕 WARNING

Hot oil and hot components can cause personal injury. Do not allow hot oil or hot components to contact the skin.

Before you take the oil sample, complete the Label, PEEP5031 for identification of the sample. To help obtain the most accurate analysis, provide the following information:

- Engine model
- · Service hours on the engine
- The number of hours that have accumulated since the last oil change
- The amount of oil that has been added since the last oil change

To ensure that the sample is representative of the oil in the crankcase, obtain a warm, mixed oil sample.

To avoid contamination of the oil samples, the tools and the supplies that are used for obtaining oil samples must be clean. Caterpillar recommends using the sampling valve to obtain oil samples. The quality and the consistency of the samples are better when the sampling valve is used. The location of the sampling valve allows oil that is flowing under pressure to be obtained during normal engine operation.

The 169-8373 Fluid Sampling Bottle is recommended for use with the sampling valve. The fluid sampling bottle includes the parts that are needed for obtaining oil samples. Instructions are also provided.

#### NOTICE

Always use a designated pump for oil sampling, and use a separate designated pump for coolant sampling. Using the same pump for both types of samples may contaminate the samples that are being drawn. This contaminate may cause a false analysis and an incorrect interpretation that could lead to concerns by both dealers and customers.

If the engine is not equipped with a sampling valve, use the 1U-5718 Vacuum Pump. The pump is designed to accept sampling bottles. Disposable tubing must be attached to the pump for insertion into the sump.

For instructions, see Special Publication, PEGJ0047, "How To Take A Good S $\cdot$ O $\cdot$ S Oil Sample". Consult your Cat dealer for complete information and assistance in establishing an S $\cdot$ O $\cdot$ S program for your engine.

i08068432

### **Engine Oil and Filter - Change**

SMCS Code: 1318-510

#### 🚯 WARNING

Hot oil and hot components can cause personal injury. Do not allow hot oil or hot components to contact the skin.

#### NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Dispose of all fluids according to local regulations and mandates.

NOTICE Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.

Do not drain the engine lubricating oil when the engine is cold. As the engine lubricating oil cools, suspended waste particles settle on the bottom of the oil pan. The waste particles are not removed with draining cold oil. Allow 30 minutes after the engine is stopped, before draining the oil pan. Drain the oil pan with the oil warm. This draining method allows the waste particles that are suspended in the oil to be drained properly.

Failure to follow this recommended procedure will cause the waste particles to be recirculated through the engine lubrication system with the new oil.

#### **Oil and Filter Change Intervals**

The standard engine oil and filter change period is 500 hours or 1 year. There are several other factors that can alter the standard engine oil and filter change of 500 hours or 1 year.

- If the engine is using engine oil analysis to determine oil and filter change period.
- The engine is working in a severe service environment/Load Factor
- · Infrequent operation of the engine

Refer to this Operation and Maintenance Manual, "Severe Service Application" for more information on reducing the engine oil and filter change period. For severe service applications the recommended oil and filter change period is 250 hours.

If the engine is operated in severe service conditions, Caterpillar recommends the use of engine oil sampling. Refer to this Operation and Maintenance Manual, Engine Oil sample - Obtain for more information.

If the engine is operated infrequently less than 500 hours in a 12-month period, then the engine oil and filter change should be conducted yearly.

## Drain the Engine Lubricating Oil From a Standard Oil Pan

**Note:** Ensure that the vessel that will be used is large enough to collect the waste oil.

After the engine has been run at the normal operating temperature, stop the engine. Use the following method to drain the engine oil pan:




Illustration 96 g06512019 Typical example of a nonmetallic oil pan.

- **1.** Place container below oil drain plug (1). Remove oil drain plug (1) and allow the oil to drain into the container for storage or disposal.
- **2.** Remove drain plug seal (2) from the drain plug. Discard the drain plug seal.
- **3.** Clean oil drain plug (1) and install new drain plug seal (2). Install oil drain plug (1) into oil pan (3).

**Note:** The torque given for the oil drain plug is for a nonmetallic oil pan.


4. Tighten oil drain plug (1) to a torque of 24 N⋅m (212 lb in). Remove container below oil drain plug (1) and discard waste oil in accordance with local regulations.

**Note:** A drain valve may be installed. Tighten the drain valve to a torque of  $24 \text{ N} \cdot \text{m}$  (212 lb in).

### Draining the Engine Lubricating Oil From an Oil Pan Equipped With a Balancer

**Note:** Ensure that the vessel that will be used is large enough to collect the waste oil.

After the engine has been run at the normal operating temperature, stop the engine. Use the following method to drain the engine oil pan:



#### Illustration 97

Typical example of an engine oil pan with a balancer

- **1.** Place container below oil drain plug (1) and oil drain plug (5).
- **2.** Remove oil drain plug (1) and oil drain plug (5) from engine oil pan (3) and allow the oil to drain into the container for storage or disposal.
- **3.** Remove drain plug seal (2) and drain plug seal (4). Discard the seals.
- Clean the oil drain plugs and install new drain plug seal (2) and new drain plug seal (4). Install oil drain plug (1) and oil drain plug (5) into oil pan (3).

g06511911

5. Tighten oil drain plug (1) and oil drain plug (5) to a torque of 24 N·m (212 lb in). Remove container below oil drain plug (1) and discard waste oil in accordance with local regulations.

### **Replace the Oil Filter Element**




Illustration 98

Typical example

g06304150

- 1. Remove cap (1) from filter body (4). The filter element (3) will be attached to cap (1). Remove filter element (3) from cap (1). Discard old filter element.
- 2. Remove O ring seal (2) from cap (1). Discard O ring seal.
- 3. Ensure that cap and filter body are clean and free from dirt or damage. Inspect new filter element for damage before installing.
- 4. Install new O ring seal (2) onto cap (1). Install new filter element (3) into cap (1). Install new filter element (3) and cap (1) to filter body (4).

5. Tighten cap (1) to a torque of 24 N·m (212 lb in)

### Fill the Oil Pan





Illustration 99

Typical example

(1) Top mounted fill cap

(2) Side-mounted filler cap



#### Illustration 100

g06512039

Typical example of engines equipped with a balancer (3) Oil pan-mounted filler

1. Refer to this Operation and Maintenance Manual, "Fluid Recommendations" for more information on suitable oils.

2. Fill the oil pan with the correct amount of new engine lubricating oil. Refer to this Operation and Maintenance Manual, "Refill Capacities" for more information on refill capacities.

**Note:** If the oil is filled through the oil filler cap, allow the oil to drain down to the oil pan for a minimum of 30 minutes before starting the engine.

- **3.** After installing the oil filler cap, start the engine and run the engine at "LOW IDLE" for 2 minutes. Perform this procedure to ensure that the lubrication system has oil and that the oil filter is filled. Inspect the oil filter for oil leaks.
- **4.** Stop the engine and allow the oil to drain back to the oil pan for a minimum of 30 minutes.
- 5. Remove the engine oil level gauge to check the oil level. Maintain the oil level between "L" and "H" marks on the engine oil level gauge. Do not fill the crankcase above the "H" mark.

**Note:** For more information on accurate oil level check, refer to this Operation and Maintenance Manual, "Engine Oil Level - Check".


i09430697

### Fan Clearance - Check

SMCS Code: 1356; 1359; 1360

Ensure that the engine is stopped. Ensure that the battery disconnect switch is in the OFF position. Ensure that the cooling system is full.

### C3.6TA Open Power Unit (OPU)




#### Illustration 101 Typical example

g06739966

The clearance between the cover (2) and the fan (1) will require checking. The gap between the edge of the cover and the tip of the fan blade must be checked at positions (A) and (B).

- (A) equals 5.5 mm (0.21654 inch)
- (B) equals 5.5 mm (0.21654 inch)

### C2.8 Open Power Unit (OPU)



The clearance between the cover (2) and the fan (1) will require checking. The gap between the edge of the cover and the tip of the fan blade must be checked at positions (A) and (B).

- (A) equals 9 mm (0.35433 inch)
- (B) equals 9.5 mm (0.37402 inch)

i07669646

### **Fuel System - Prime**

SMCS Code: 1250-548; 1258-548

Note: Refer to Systems Operation, Testing, and Adjusting, "Cleanliness of Fuel System Components" for detailed information on the standards of cleanliness that must be observed during ALL work on the fuel system.

Ensure that all adjustments and repairs are performed by authorized personnel that have had the correct training.

#### NOTICE

Do not crank the engine continuously for more than 30 seconds. Allow the starting motor to cool for two minutes before cranking the engine again.

If air enters the fuel system, the air must be purged from the fuel system before the engine can be started. Air can enter the fuel system when the following events occur:

- The fuel tank is empty or the fuel tank has been partially drained.
- The low-pressure fuel lines are disconnected.
- A leak exists in the low-pressure fuel system.
- The fuel filter has been replaced.

### **Electric Fuel Priming Pump**

Use the following procedure to remove air from the fuel system:

- 1. Ensure that the fuel system is in working order. Check that the fuel supply valve (if equipped) is in the "ON" position.
- 2. Turn the keyswitch to the "RUN" position.
- **3.** The keyswitch will allow the electric priming pump to operate. Operate the electric priming pump. The ECM will stop the pump after 2 minutes.
- **4.** Turn the keyswitch to the "OFF" position. The fuel system should now be primed and the engine should be able to start.

**5.** Operate the engine starter and crank the engine. After the engine has started, operate the engine at low idle for a minimum of 5 minutes. Ensure that the fuel system is free from leaks.

**Note:** Operating the engine for this period will help ensure that the fuel system is free of air.**DO NOT loosen the high-pressure fuel lines to purge air** from the fuel system. This procedure is not required.

After the engine has stopped, you must wait for 10 minutes to allow the fuel pressure to be purged from the high-pressure fuel lines before any service or repair is performed on the engine fuel lines. The 10 minute wait will also allow static charge to dissipate from the low-pressure fuel system. If necessary, perform minor adjustments. Repair any leaks from the low-pressure fuel system and from the cooling, lubrication, or air systems. Replace any high-pressure fuel line that has leaked. Refer to Disassembly and Assembly Manual, "Fuel Injection Lines - Install".

If you inspect the engine in operation, always use the proper inspection procedure to avoid a fluid penetration hazard. Refer to Operation and Maintenance Manual, "General hazard Information".

If the engine will not start, refer to Troubleshooting, "Engine Cranks but will not Start".

### Mechanical Fuel Priming Pump

Use the following procedure to remove air from the fuel system:

- 1. Ensure that the fuel system is in working order. Check that the fuel supply valve (if equipped) is in the "ON" position.
- Operate the hand priming pump. Count the number of operations of the pump. After approximately 80 depression of the pump stop.

**Note:** As the fuel system is primed, the pressure will increase within the fuel system and this increase in pressure can be felt during priming.

- **3.** The fuel system should now be primed and the engine should be able to start.
- 4. Operate the engine starting motor and crank the engine. After the engine has started, operate the engine at low idle for a minimum of 5 minutes. Ensure that the fuel system is free from leaks.

**Note:** Operating the engine for this period will help ensure that the fuel system is free of air.**DO NOT loosen the high-pressure fuel lines to purge air** from the fuel system. This procedure is not required. After the engine has stopped, you must wait for 10 minutes to allow the fuel pressure to be purged from the high-pressure fuel lines before any service or repair is performed on the engine fuel lines. The 10 minute wait will also allow static charge to dissipate from the low-pressure fuel system. If necessary, perform minor adjustments. Repair any leaks from the low-pressure fuel system and from the cooling, lubrication, or air systems. Replace any highpressure fuel line that has leaked. Refer to Disassembly and Assembly Manual, "Fuel Injection Lines - Install".

If you inspect the engine in operation, always use the proper inspection procedure to avoid a fluid penetration hazard. Refer to Operation and Maintenance Manual, "General hazard Information".

If the engine will not start, refer to Troubleshooting, "Engine Cranks but will not Start".

i07385499

### **Fuel System Primary Filter** (Water Separator) Element -Replace

SMCS Code: 1260-510-FQ; 1263-510-FQ

### WARNING

Fuel leaked or spilled onto hot surfaces or electrical components can cause a fire. To help prevent possible injury, turn the start switch off when changing fuel filters or water separator elements. Clean up fuel spills immediately.

Note: Refer to Systems Operation, Testing, and Adjusting, "Cleanliness of Fuel System Components" for detailed information on the standards of cleanliness that must be observed during ALL work on the fuel system.

NOTICE Ensure that the engine is stopped before any servicing or repair is performed.

#### **Fuel System Primary Filter (Water** Separator) Element for Electric **Fuel Priming Pump**

#### **Remove the Element**

1. Turn the fuel supply valve (if equipped) to the OFF position before performing this maintenance.

2. Place a suitable container under the water separator to catch any fuel that might spill. Clean up any spilled fuel. Clean the outside body of the filter assembly.




Illustration 103

g06304505

Typical example

- 3. Install a suitable tube onto drain (2). Open the drain valve (1). Rotate the drain valve fully counterclockwise. Two full turns are required.
- Allow the fuel to drain into the container.
- 5. Remove the tube from the drain (2).
- 6. Remove the wiring harness from connection (3).
- 7. Rotate filter bowl (5) counterclockwise and remove the filter bowl from assembly.

Note: If a strap wrench is required to loosen the filter bowl (5), ensure that the strap is positioned in the middle of the ribbed section. To avoid damage or mechanical failure, do not position the strap around the clear area. Do not apply loads to the clear plastic bowl and the joint of the black plastic section of the lower bowl.





Illustration 104 Typical example

8. Remove the filter element (4). Clean the filter bowl.

#### Install the New Filter Element



g06304524

- **1.** After repositioning the self-venting drain up, locate the thread in the new filter element (6) onto the thread (7). Spin on the filter element and tighten the drain valve (2) securely.
- Lubricate the lip (Position (X)) with clean engine oil. Do NOT fill the bowl with fuel before the assembly is installed.

Note: Do not use a tool to install the filter assembly.

- **3.** Align the filter bowl (5) to the assembly. Rotate the filter bowl (5) clockwise by hand. Rotate the filter bowl (5) until there is no visible gap between the element and the filter bowl and the assembly.
- **4.** Remove the container and dispose of the fuel in a safe place.
- 5. Install the wiring harness to connection (3).
- 6. The secondary filter element (if equipped) must be replaced at the same time as the primary filter element. Refer to the Operation and Maintenance Manual, "Fuel System Secondary Filter Replace".

#### Fuel System Primary Filter (Water Separator) Element for Manual Fuel Priming Pump

#### **Remove the Element**

- **1.** Turn the fuel supply valve (if equipped) to the OFF position before performing this maintenance.
- 2. Place a suitable container under the water separator to catch any fuel that might spill. Clean up any spilled fuel. Clean the outside body of the filter assembly.




Illustration 106 Typical example

- **3.** Install a suitable tube onto drain (2). Open the drain valve (1). Rotate the drain valve fully counterclockwise. Two full turns are required.
- 4. Allow the fuel to drain into the container.
- 5. Remove the tube from the drain (2).
- 6. Remove the wiring harness from connection (3).
- **7.** Rotate filter bowl (5) counterclockwise and remove the filter bowl from assembly.

**Note:** If a strap wrench is required to loosen the filter bowl (5), ensure that the strap is positioned in the middle of the ribbed section. To avoid damage or mechanical failure, do not position the strap around the clear area. Do not apply loads to the clear plastic bowl and the joint of the black plastic section of the lower bowl.




Illustration 107

g06398147

g06398170

Typical example

8. Remove the filter element (4). Clean the filter bowl.

#### Install the New Filter Element




Illustration 108 Typical example

- 1. After repositioning the self-venting drain up, locate the thread in the new filter element (6) onto the thread (7). Spin on the filter element and tighten the drain valve (2) securely.
- Lubricate the lip (Position (X)) with clean engine oil. Do NOT fill the bowl with fuel before the assembly is installed.

Note: Do not use a tool to install the filter assembly.

- **3.** Align the filter bowl (5) to the assembly. Rotate the filter bowl (5) clockwise by hand. Rotate the filter bowl (5) until there is no visible gap between the element and the filter bowl and the assembly.
- **4.** Remove the container and dispose of the fuel in a safe place.
- 5. Install the wiring harness to connection (3).
- 6. The secondary filter element (if equipped) must be replaced at the same time as the primary filter element. Refer to the Operation and Maintenance Manual, "Fuel System Secondary Filter Replace".

i07385529

### Fuel System Primary Filter/ Water Separator - Drain

SMCS Code: 1260-543; 1263-543

### 🏠 WARNING

Fuel leaked or spilled onto hot surfaces or electrical components can cause a fire. To help prevent possible injury, turn the start switch off when changing fuel filters or water separator elements. Clean up fuel spills immediately.

NOTICE

Ensure that the engine is stopped before any servicing or repair is performed.

NOTICE

The water separator is under suction during normal engine operation. Ensure that the drain valve is tightened securely to help prevent air from entering the fuel system.

### **Drain Procedure**

1. Place a suitable container under the water separator to catch any fluid that might spill. Clean up any spilled fluid.

**2.** Ensure that the outer body of the filter assembly is clean and free from dirt.




Illustration 109

Typical example

- **3.** Install a suitable tube onto drain (2). Open the drain valve (1). Rotate the drain valve fully counterclockwise. Two full turns are required.
- **4.** Visually check that the fluid will drain. Allow the fluid to drain into the container.
- **5.** When fluid free from water comes from the primary fuel filter, tighten the drain valve clockwise by hand only. Remove the tube and remove the container.

i07694301

g06304526

### Fuel System Secondary Filter -Replace

SMCS Code: 1261-510-SE

#### 

Fuel leaked or spilled onto hot surfaces or electrical components can cause a fire. To help prevent possible injury, turn the start switch off when changing fuel filters or water separator elements. Clean up fuel spills immediately.

#### NOTICE

Ensure that the engine is stopped before any servicing or repair is performed. Refer to Systems Operation, Testing, and Adjusting, "Cleanliness of Fuel System Components" for detailed information on the standards of cleanliness that must be observed during ALL work on the fuel system.

### **Remove the Element**

- **1.** Turn the fuel supply valve (if equipped) to the OFF position before performing this maintenance.
- **2.** Place a suitable container under the fuel filter to catch any fuel that might spill. Clean up any spilled fuel. Clean the outside body of the filter assembly.




Illustration 110

g03088718

- Install a suitable tube onto drain (4). Open the drain valve (3). Rotate the drain valve counterclockwise. Two full turns are required. Loosen vent screw (1).
- **4.** Allow the fuel to drain into the container and remove the tube.
- 5. Tighten the vent screw (1) to a torque of 2.5 N⋅m (22 lb in).
- **6.** Remove the filter bowl (2). Rotate the filter assembly counterclockwise to remove the assembly.




Illustration 111

#### g02546456

**7.** Rotate the filter element (5) counterclockwise and remove the filter element. Clean the filter bowl.

#### Install the Element




Illustration 112

g03088837

- Locate the thread (7) in the filter element onto the threads (8). Spin on the element and tighten the drain valve (3) by hand.
- Lubricate the O ring seal (6) with clean engine oil. Do NOT fill the filter bowl (2) with fuel before the filter assembly is installed.

- **3.** Do not use a tool to install the filter assembly. Tighten the assembly by hand. Install the filter bowl (2). Turn the filter bowl clockwise until the filter bowl locks into position against the stops.
- **4.** Turn the fuel supply valve to the ON position.
- **5.** The primary and secondary fuel filters must be replaced at the same time. Refer to the Operation and Maintenance Manual, "Fuel System Primary Filter (Water Separator) Element Replace".
- **6.** Prime the fuel system. Refer to the Operation and Maintenance Manual, "Fuel System Prime" for more information.

i02348492

# Fuel Tank Water and Sediment - Drain

SMCS Code: 1273-543-M&S

#### NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Dispose of all fluids according to local regulations and mandates.

### **Fuel Tank**

Fuel quality is critical to the performance and to the service life of the engine. Water in the fuel can cause excessive wear to the fuel system.

Water can be introduced into the fuel tank when the fuel tank is being filled.

Condensation occurs during the heating and cooling of fuel. The condensation occurs as the fuel passes through the fuel system and the fuel returns to the fuel tank. This causes water to accumulate in fuel tanks. Draining the fuel tank regularly and obtaining fuel from reliable sources can help to eliminate water in the fuel.

### Drain the Water and the Sediment

Fuel tanks should contain some provision for draining water and draining sediment from the bottom of the fuel tanks.

Open the drain valve on the bottom of the fuel tank in order to drain the water and the sediment. Close the drain valve.

Check the fuel daily. Allow five minutes after the fuel tank has been filled before draining water and sediment from the fuel tank.

Fill the fuel tank after operating the engine in order to drive out moist air. This will help prevent condensation. Do not fill the tank to the top. The fuel expands as the fuel gets warm. The tank may overflow.

Some fuel tanks use supply pipes that allow water and sediment to settle below the end of the fuel supply pipe. Some fuel tanks use supply lines that take fuel directly from the bottom of the tank. If the engine is equipped with this system, regular maintenance of the fuel system filter is important.

### **Fuel Storage Tanks**

Drain the water and the sediment from the fuel storage tank at the following intervals:

- · Weekly
- · Service intervals
- Refill of the tank

This will help prevent water or sediment from being pumped from the storage tank into the engine fuel tank.

If a bulk storage tank has been refilled or moved recently, allow adequate time for the sediment to settle before filling the engine fuel tank. Internal baffles in the bulk storage tank will also help trap sediment. Filtering fuel that is pumped from the storage tank helps to ensure the quality of the fuel. When possible, water separators should be used.

i07819616

### Hoses and Clamps - Inspect/ Replace

**SMCS Code:** 7554-510; 7554-040

### 🚯 WARNING

Contact with high pressure fuel may cause fluid penetration and burn hazards. High pressure fuel spray may cause a fire hazard. Failure to follow these inspection, maintenance and service instructions may cause personal injury or death.

If you inspect the engine in operation, always use the proper inspection procedure to avoid a fluid penetration hazard. Refer to Operation and Maintenance Manual, "General hazard Information" and Operation and Maintenance Manual, "High Pressure Fuel Lines" for the correct procedures.

Inspect all hoses for leaks that are caused by the following conditions:

- · Cracking
- Softness
- Loose clamps

Replace hoses that are cracked or soft. Tighten any loose clamps.

Check for the following conditions:

- End fittings that are damaged or leaking
- · Outer covering that is chafed or cut
- · Exposed wire that is used for reinforcement
- · Outer covering that is ballooning locally
- · Flexible part of the hose that is kinked or crushed
- Armoring that is embedded in the outer covering

A constant torque hose clamp can be used in place of any standard hose clamp. Ensure that the constant torque hose clamp is the same size as the standard clamp.

Due to extreme temperature changes, the hose will harden. Hardening of the hoses will cause hose clamps to loosen. This can result in leaks. A constant torque hose clamp will help to prevent loose hose clamps.

Each installation application can be different. The differences depend on the following factors:

- Type of hose
- Type of fitting material
- Anticipated expansion and contraction of the hose
- Anticipated expansion and contraction of the fittings

#### **Replace the Hoses and the Clamps**

Refer to the OEM information for further information on removing and replacing fuel hoses (if equipped).

The following text describes a typical method of replacing coolant hoses. Refer to the OEM information for further information on the coolant system and the hoses for the coolant system.

### 🔒 WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

- 1. Stop the engine. Allow the engine to cool.
- 2. Loosen the cooling system filler cap slowly to relieve any pressure. Remove the cooling system filler cap.

**Note:** Drain the coolant into a suitable, clean container. The coolant can be reused.

- **3.** Drain the coolant from the cooling system to a level that is below the hose that is being replaced.
- 4. Remove the hose clamps.
- 5. Disconnect the old hose.
- 6. Replace the old hose with a new hose.
- 7. Install the hose clamps with a torque wrench.

**Note:** For the correct coolant, see this Operation and Maintenance Manual, "Fluid Recommendations".

- **8.** Refill the cooling system. Refer to the OEM information for further information on refilling the cooling system.
- **9.** Clean the cooling system filler cap. Inspect the cooling system filler cap's seals. Replace the cooling system filler cap if the seals are damaged. Install the cooling system filler cap.
- **10.** Start the engine. Inspect the cooling system for leaks.

i04224312

### **Overhaul Considerations**

#### SMCS Code: 7595-043

Reduced hours of operation at full load will result in a lower average power demand. A decreased average power demand should increase both the engine service life and the overhaul interval.

The need for an overhaul is indicated by increased fuel consumption, increased oil consumption, excessive engine blowby, and reduced power. Arctic temperatures, extreme high temperatures, corrosive environments, or extreme dusty conditions contribute to premature wear and the need for an overhaul.

The following factors are important when a decision is being made on the proper time for an engine overhaul:

- · The need for preventive maintenance
- The quality of the fuel that is being used
- The operating conditions
- The results of the S·O·S analysis

# Oil Consumption as an Overhaul Indicator

Oil consumption, fuel consumption, and maintenance information can be used to estimate the total operating cost for your Caterpillar engine. Oil consumption can also be used to estimate the required capacity of a makeup oil tank that is suitable for the maintenance intervals.

Oil consumption is in proportion to the percentage of the rated engine load. As the percentage of the engine load is increased, the amount of oil that is consumed per hour also increases.

The oil consumption rate (brake-specific oil consumption) is measured in grams per kW/h (lb per bhp). The brake-specific oil consumption (BSOC) depends on the engine load. Consult your Caterpillar dealer for assistance in determining the typical oil consumption rate for your engine.

When an engines oil consumption has risen to three times the original oil consumption rate due to normal wear, an engine overhaul should be scheduled. There may be a corresponding increase in blowby and a slight increase in fuel consumption.

#### **Overhaul Options**

#### **Before Failure Overhaul**

A planned overhaul before failure may be the best value for the following reasons:

- · Costly unplanned downtime can be avoided.
- Many original parts can be reused according to the standards for reusable parts.
- The engines service life can be extended without the risk of a major catastrophe due to engine failure.
- The best cost/value relationship per hour of extended life can be attained.

#### After Failure Overhaul

If a major engine failure occurs and the engine must be removed, many options are available. An overhaul should be performed if the engine block or the crankshaft needs to be repaired.

If the engine block is repairable and/or the crankshaft is repairable, the overhaul cost will be less than the cost of a new engine with a similar exchange core.

This lower cost can be attributed to three aspects:

- · Specially designed Caterpillar engine features
- · Caterpillar dealer exchange components

Caterpillar Inc. remanufactured exchange components

### **Overhaul Recommendation**

To minimize downtime, Caterpillar Inc. recommends a scheduled engine overhaul by your Caterpillar dealer before the engine fails. This process will provide you with the best cost/value relationship.

**Note:** Overhaul programs vary according to the engine application and according to the dealer that performs the overhaul. Consult your Caterpillar dealer for specific information about the available overhaul programs and about overhaul services for extending the engine life.

#### Aftertreatment

The aftertreatment system can be expected to function properly for the useful life of the engine (emissions durability period), as defined by regulation, subject to prescribed maintenance requirements being followed.

#### **Rebuild or Exchange**

If an overhaul is performed without overhaul service from your Caterpillar dealer, be aware of the following maintenance recommendations.

## Cylinder Head Assembly, Oil Pump, and Fuel Transfer Pump

These components should be inspected according to the instructions that are found in various Caterpillar reusability publications. The Special Publication, SEBF8029 lists the reusability publications that are needed for inspecting the engine parts.

If the parts comply with the established inspection specifications that are expressed in the reusable parts guideline, the parts should be reused.

Parts that are not within the established inspection specifications should be dealt with in one of the following manners:

- Salvaging
- Repairing
- · Replacing

Using out-of-spec parts can result in the following problems:

- Unscheduled downtime
- · Costly repairs
- · Damage to other engine parts
- Reduced engine efficiency

Increased fuel consumption

Reduced engine efficiency and increased fuel consumption translates into higher operating costs. Therefore, Caterpillar Inc. recommends repairing outof-spec parts or replacing out-of-spec parts.

#### Inspection and/or Replacement

## Crankshaft Bearings Crankshaft Seals and Pistons

The following components may not last until the second overhaul.

- Thrust bearings
- Main bearings
- Rod bearings
- · Crankshaft seals
- Piston assembly

Caterpillar Inc. recommends the installation of new parts at each overhaul period.

Inspect these parts while the engine is disassembled for an overhaul.

Inspect the crankshaft for any of the following conditions:

- Deflection
- Damage to the journals
- Bearing material that has seized to the journals

Check the journal taper and the profile of the crankshaft journals. If the wear patterns on the rod bearing or the main bearing show a problem, the crankshaft will need to be measured with specialist equipment.

Inspect the camshaft for damage to the journals and to the lobes.

**Note:** If the camshaft is removed for any reason, use the magnetic particle inspection process to check for cracks in the camshaft.

Inspect the following components for signs of wear or for signs of scuffing:

- Camshaft bearings
- · Lifters

Caterpillar Inc. recommends replacing the crankshaft vibration damper.

#### **Oil Cooler Core**

During an overhaul, Caterpillar Inc. recommends the removal of the oil cooler core. Clean the oil cooler core. Then, pressure test the oil cooler core.

NOTICE Do not use caustic cleaners to clean the core.

Caustic cleaners can attack the internal metals of the core and cause leakage.

**Note:** Use this cleaning procedure to clean the oil cooler core.

- 1. Remove the oil cooler core.
- **2.** Remove any debris from the oil cooler core. To remove debris from the oil cooler core, turn the oil cooler core onto one end.
- **3.** Flush the oil cooler core internally with cleaner in order to loosen foreign substances. This flushing will also help to remove oil from the oil cooler core.

**Note:** Caterpillar Inc. recommends the use of Hydrosolv Liquid Cleaners. Table 28 lists the Hydrosolv Liquid Cleaners that are available from your Caterpillar dealer.

#### Table 28

Hydrosolv Liquid Cleaners				
Part Number	Description	Size		
10-8812		4 L(1 US gallon)		
10-5490	Hydrosolv4165	19 L (5 US gallon)		
8T-7570		208 L (55 US gallon)		
1U-8804		4 L (1 US gallon)		
10-5492	Hydrosolv100	19 L (5 US gallon)		
8T-5571		208 L (55 US gallon)		

- **4.** Use steam to clean the oil cooler core. The steam will remove any remaining residue from the cleaner. Flush the fins of the oil cooler core. Remove any other trapped debris.
- **5.** Wash the oil cooler core with hot, soapy water. Rinse the oil cooler core thoroughly with clean water.

### 🏠 WARNING

Personal injury can result from air pressure.

Personal injury can result without following proper procedure. When using pressure air, wear a protective face shield and protective clothing.

Maximum air pressure at the nozzle must be less than 205 kPa (30 psi) for cleaning purposes.

- **6.** Dry the oil cooler core with compressed air. Direct the air in the reverse direction of the normal flow.
- 7. Inspect the components in order to ensure cleanliness. The oil cooler core should be pressure tested. Repair the oil cooler core, if necessary. Install the oil cooler core.

For more information about cleaning the cores, consult your Caterpillar dealer.

#### **Obtain Coolant Analysis**

The concentration of supplemental coolant additive (SCA) should be checked regularly with test kits or with  $S \cdot O \cdot S$  Coolant Analysis (Level 1). Further coolant analysis is recommended when the engine is overhauled.

For example, considerable deposits are found in the water jacket areas on the external cooling system, but the concentrations of coolant additives were carefully maintained. The coolant probably contained minerals that were deposited on the engine over time.

A coolant analysis can be conducted in order to verify the condition of the water that is being used in the cooling system. A full water analysis can be obtained by consulting your local water utility company or an agricultural agent. Private laboratories are also available for water analysis.

Caterpillar Inc. recommends an  $S \cdot O \cdot S$  Coolant Analysis (Level 2).

#### S·O·S Coolant Analysis (Level 2)

An S $\cdot$ O $\cdot$ S Coolant Analysis (Level 2) is a comprehensive coolant analysis which completely analyzes the coolant and the effects on the cooling system. An S $\cdot$ O $\cdot$ S Coolant Analysis (Level 2) provides the following information:

- Complete S·O·S Coolant Analysis (Level 1)
- Visual inspection of properties
- · Identification of metal corrosion
- Identification of contaminants
- Identification of built up impurities (corrosion and scale)

 $S\cdot O\cdot S$  Coolant Analysis (Level 2) provides a report of the results of both the analysis and the maintenance recommendations.

For more information about coolant analysis, see your Caterpillar dealer.

i08254039

# **Radiator - Clean**

SMCS Code: 1353-070

**Note:** Adjust the frequency of cleaning according to the effects of the operating environment.

Inspect the radiator for these items: damaged fins, corrosion, dirt, grease, insects, leaves, oil, and other debris. Clean the radiator, if necessary.

### 

Personal injury can result from air pressure.

Personal injury can result without following proper procedure. When using pressure air, wear a protective face shield and protective clothing.

The maximum air pressure for cleaning purposes must be reduced to 205 kPa (30 psi) when the air nozzle is deadheaded.

Pressurized air is the preferred method for removing loose debris. Direct the air in the opposite direction of the air flow. Hold the nozzle approximately 6 mm (0.25 inch) away from the fins. Slowly move the air nozzle in a direction that is parallel with the tubes. This movement will remove debris that is between the tubes.

Pressurized water may also be used for cleaning. The maximum water pressure for cleaning purposes must be less than 275 kPa (40 psi). Use pressurized water to soften mud. Clean the core from both sides.

Use a degreaser and steam for removal of oil and grease. Clean both sides of the core. Wash the core with detergent and hot water. Thoroughly rinse the core with clean water.

After cleaning, start the engine and bring the engine to high idle. This procedure will help in the removal of debris and drying of the core. Stop the engine. Use a light bulb behind the core to inspect the core for cleanliness. Repeat the cleaning, if necessary.

Inspect the fins for damage. Bent fins may be opened with a "comb". Inspect these items for good condition: welds, mounting brackets, air lines, connections, clamps, and seals. Make repairs, if necessary.

# **Radiator Mounts - Inspect**

#### SMCS Code: 1353-040-MT

There are 2 anti vibration mounts (AVM) (2) on the radiator support bracket (1). The anti vibration mounts require inspection at specific maintenance intervals.




Illustration 113


g06745030

g06745041

Typical example

(1) Radiator support bracket

(2) Radiator anti vibration mounts



#### Illustration 114

Typical example with a portion of the radiator cutaway for clarity

- (2) Radiator anti vibration mounts
- (3) Radiator anti vibration mounts rubber compound

The radiator may need to be lifted to inspect the 2 anti vibration mounts (AVM). Refer to Disassembly and Assembly, Radiator - Remove and Install.

Inspect the anti vibration mounts for wear, cracking, and damage. If the anti vibration mounts appear to be worn, cracked, or damaged replace the anti vibration mount. Refer to Disassembly and Assembly, Radiator Anti Vibration Mounts - Remove and Install.

i02348493

# **Starting Motor - Inspect**

**SMCS Code:** 1451-040; 1453-040

Caterpillar recommends a scheduled inspection of the starting motor. If the starting motor fails, the engine may not start in an emergency situation.

Check the starting motor for correct operation. Check the electrical connections and clean the electrical connections. Refer to the Systems Operation, Testing and Adjusting Manual, "Electric Starting System -Test" for more information on the checking procedure and for specifications or consult your Caterpillar dealer for assistance.

i08187031

# **Turbocharger - Inspect**

SMCS Code: 1052-040

#### 🛕 WARNING

Hot engine components can cause injury from burns. Before performing maintenance on the engine, allow the engine and the components to cool.

#### NOTICE

Turbocharger bearing failures can cause large quantities of oil to enter the air intake and exhaust systems. Loss of engine lubricant can result in serious engine damage.

Minor leakage of oil into a turbocharger under extended low idle operation should not cause problems as long as a turbocharger bearing failure has not occured.

When a turbocharger bearing failure is accompanied by a significant engine performance loss (exhaust smoke or engine rpm up at no load), do not continue engine operation until the turbocharger is renewed.

A visual inspection of the turbocharger or turbochargers can minimize unscheduled downtime. A visual inspection of the turbocharger or turbochargers can also reduce the chance for potential damage to other engine parts. Do not inspect the engine with the engine in operation.




Illustration 115 Typical example g06304904

1. Ensure that the turbocharger is clean and free from dirt before removing components for inspection.

- 2. Remove the pipe from the turbocharger exhaust outlet and remove the air intake pipe (1). Visually inspect the piping for the presence of oil. Clean the interior of the pipes to prevent dirt from entering during reassembly.
- **3.** Check for obvious heat discoloration of the turbocharger. Check for any loose bolts or any missing bolts. Check for damage to the oil supply line and the oil drain line. Check for cracks in the housing of the turbocharger. Ensure that the compressor wheel can rotate freely.
- **4.** Check for the presence of oil. If oil is leaking from the back side of the compressor wheel, there is a possibility of a failed turbocharger oil seal.

The presence of oil may be the result of extended engine operation at low idle. The presence of oil may also be the result of a restriction of the line for the intake air (clogged air filters), which causes the turbocharger to slobber.

**5.** Install the air intake pipe and the exhaust outlet pipe to the turbocharger housing. Ensure that all clamps are installed correctly and that all clamps are tightened securely. For more information, refer to Systems Operation, Testing, and Adjusting, "Turbocharger - Inspect".

# Walk-Around Inspection

SMCS Code: 1000-040

# Inspect the Engine for Leaks and for Loose Connections

A walk-around inspection should only take a few minutes. When the time is taken to perform these checks, costly repairs and accidents can be avoided.

For maximum engine service life, make a thorough inspection of the engine compartment before starting the engine. Look for items such as oil leaks or coolant leaks, loose bolts, worn belts, loose connections, and trash buildup. Make repairs, as needed:

- The guards must be in the correct place. Repair damaged guards or replace missing guards.
- Wipe all caps and plugs before the engine is serviced to reduce the chance of system contamination.

#### NOTICE

For any type of leak (coolant, lube, or fuel) clean up the fluid. If leaking is observed, find the source and correct the leak. If leaking is suspected, check the fluid levels more often than recommended until the leak is found or fixed, or until the suspicion of a leak is proved to be unwarranted.

#### NOTICE

Accumulated grease and/or oil on an engine is a fire hazard. Remove the accumulated grease and oil. Refer to this Operation and Maintenance Manual, "Engine - Clean" for more information.

- Ensure that the cooling system hoses are correctly clamped and that the cooling system hoses are tight. Check for leaks. Check the condition of all pipes.
- Inspect the water pump for coolant leaks.

Excessive coolant leakage may indicate the need to replace the water pump. Remove the water pump. Refer to Disassembly and Assembly, "Water Pump - Remove and Install".

- Inspect the lubrication system for leaks at the front crankshaft seal, the rear crankshaft seal, the oil pan, the oil filters, and the rocker cover.
- Inspect the piping for the air intake system and the elbows for cracks and for loose clamps. Ensure that hoses and tubes are not contacting other hoses, tubes, wiring harnesses.

- Ensure that the areas around the rotating parts are clear.
- Inspect the alternator belts and any accessory drive belts for cracks, breaks, or other damage.
- Inspect the wiring harness for damage.

Belts for multiple groove pulleys must be replaced as matched sets. If only one belt is replaced, the belt will carry more load than the belts that are not replaced. The older belts are stretched. The additional load on the new belt could cause the belt to break.

# **High-Pressure Fuel Lines**

# 🚯 WARNING

Contact with high pressure fuel may cause fluid penetration and burn hazards. High pressure fuel spray may cause a fire hazard. Failure to follow these inspection, maintenance and service instructions may cause personal injury or death.

After the engine has stopped, wait 10 minutes to allow the fuel pressure to be purged from the highpressure fuel lines before any service or repair is performed. The 10 minute wait will also allow static charge to dissipate from the low-pressure fuel system. If necessary, perform minor adjustments. Repair any leaks from the low-pressure fuel system and from the cooling, lubrication, or air systems. Replace any high-pressure fuel line that has leaked. Refer to Disassembly and Assembly Manual, "Fuel Injection Lines - Install".

If you inspect the engine in operation, always use the proper inspection procedure to avoid a fluid penetration hazard. Refer to Operation and Maintenance Manual, "General hazard Information".

Visually inspect the high-pressure fuel lines for damage or signs of fuel leakage. Replace any damaged high-pressure fuel lines or high-pressure fuel lines that have leaked.

Ensure that all clips on the high-pressure fuel lines are in place and that the clips are not loose.

- Inspect the rest of the fuel system for leaks. Look for loose fuel line clamps.
- Drain the water and the sediment from the fuel tank daily.
- Inspect the wiring and the wiring harnesses for loose connections and for worn wires or frayed wires. Check for any loose tie-wraps or missing tie-wraps.
- Inspect the ground strap for a good connection and for good condition.

- Disconnect any battery chargers that are not protected against the current drain of the starting motor. Check the condition and the electrolyte level of the batteries, unless the engine is equipped with a maintenance free battery.
- Check the condition of the gauges. Replace any gauges that are cracked. Replace any gauge that cannot be calibrated.

#### **Engine Aftertreatment**

Check the condition of the coolant lines, Diesel Exhaust Fluid (DEF) lines, and electrical connections. Check that all clamps, clips, and tiewraps are secure and in good condition. Check that the DEF filler cap is secure and that the cap is clean and free from dirt.

i07385598

# Water Pump - Inspect

#### **SMCS Code:** 1361-040

A failed water pump may cause severe engine overheating problems that could result in the following conditions:

- · Cracks in the cylinder head
- · A piston seizure
- · Other potential damage to the engine




Illustration 116

g06304598

Visually inspect the water pump for leaks between water pump pulley (1) and water pump body (2).

The water pump is not a serviceable item. To install a new water pump, refer to Disassembly and Assembly, "Water Pump - Remove" and Disassembly and Assembly, "Water Pump - Install".

# Warranty Section

# Warranty Information

i08769122

# Emissions Warranty Information

#### SMCS Code: 1000

The certifying engine manufacturer warrants to the ultimate purchaser and each subsequent purchaser that:

- New non-road diesel engines and stationary diesel engines less than 10 L per cylinder (including Tier 1 and Tier 2 marine engines < 37 kW, but excluding locomotive and other marine engines) operated and serviced in the United States and Canada, including all parts of their emission control systems ("emission related components"), are:
  - a. Designed, built, and equipped so as to conform, at the time of sale, with applicable emission standards prescribed by the United States Environmental Protection Agency (EPA) by way of regulation.
  - b. Free from defects in materials and workmanship in emission-related components that can cause the engine to fail to conform to applicable emission standards for the warranty period.
- 2. New non-road diesel engines (including Tier 1 and Tier 2 marine propulsion engines < 37 kW and Tier 1 through Tier 4 marine auxiliary engines < 37 kW, but excluding locomotive and other marine engines) operated and serviced in the state of California, including all parts of their emission control systems ("emission related components"), are:
  - a. Designed, built, and equipped so as to conform, at the time of sale, to all applicable regulations adopted by the California Air Resources Board (ARB).
  - b. Free from defects in materials and workmanship which cause the failure of an emission-related component to be identical in all material respects to the component as described in the engine manufacturer's application for certification for the warranty period.

- 3. New non-road diesel engines installed in construction machines conforming to the South Korean regulations for construction machines manufactured after January 1, 2015, and operated and serviced in South Korea, including all parts of their emission control systems ("emission related components"), are:
  - a. Designed, built, and equipped so as to conform, at the time of sale, with applicable emission standards prescribed in the Enforcement Rule of the Clean Air Conservation Act promulgated by South Korea MOE.
  - b. Free from defects in materials and workmanship in emission-related components that can cause the engine to fail to conform to applicable emission standards for the warranty period.
- 4. New China non-road 4 mobile diesel engines operated and serviced in China, including all parts of their emission control systems ("emission related components"), are:
  - a. Designed, built, and equipped so as to conform, at the time of manufacture, sale, and import with applicable emission standards in the promulgated by Enforcement Rule of the Clean Air Conservation Act Ministry of Ecology and Environment (MEE).
  - b. Free from defects in materials and workmanship in emission-related components that can cause the engine to fail to conform to applicable emission standards for the warranty period.

A detailed explanation of the Emission Control Warranty that is applicable to new non-road and stationary diesel engines, including the components covered and the warranty period, is found in the Emission Control Warranty statement available at the Cat Warranty website. Consult your authorized Cat dealer to determine if your engine is subject to an Emission Control Warranty, and to obtain a copy of the applicable warranty publication.

# **Reference Information** Section

# **Engine Ratings**

i07853902

# **Engine Rating Conditions**

SMCS Code: 1000

It is important to know the use of the engine so that the rating will match the operating profile. The correct rating selection is also important so that the perception of price and value is realized by the customer.

In selecting a rating for a specific application, the most important consideration is the time that is spent at full throttle. The rating definitions identify the percent of time at full throttle. The definitions also identify the corresponding times below rated rpm.

**Note:** For an exact determination of the appropriate rating, follow the OEM specifications or consult your Caterpillar dealer.

The C3.6 industrial engine can have two ratings.

For C3.6 industrial engine with power rating from 56 to 90 kW (75 to 120.7 hp) the rating is C.

For C3.6 industrial engine with power ratings of 95 kW (127.4 hp) and 100 kW (134 hp), the rating is D.

For C2.8 industrial engine, the rating is C.

**C** – Intermittent service along with maximum power and/or speed are cyclic. The engine at full load should not exceed 50 percent of the duty cycle.

**D** – For service when the rated power is required for periodic overloads. The maximum horsepower and the rpm of the engine can be utilized continuously for a maximum of 30 uninterrupted minutes. This run is followed by one hour of operation at rating C. The engine should be run at full load. The engine should not exceed 10 percent of the duty cycle.

NOTICE

Operating engines above the rating definitions can result in shorter service life before overhaul.

# **Engine Rating Definitions**

#### SMCS Code: 1000

All engine ratings are in compliance with the following standard ambient air conditions of "ISO14396:2002":

- 100 kPa (29.3 Inches Hg)
- · 30 percent relative humidity
- A temperature of 25 °C (77 °F)

The engine ratings are based on the following fuel specifications:

- The Low Heat Value (LHV) of the fuel at 29 °C (84.2 °F) at 42780 kJ/kg (18390 Btu/lb)
- Specific gravity of .833 837 at 15 °C (60 °F)

The engine ratings are gross output ratings.

**Gross Output Ratings** – The total output capability of the engine that is equipped with standard accessories.

Standard accessories include the following components:

- Oil pumps
- Fuel pumps
- · Water pumps

Subtract the power that is required to drive auxiliary components from the gross output. This process will produce the net power that is available for the external load (flywheel).

# **Customer Service**

i07191578

# **Customer Assistance**

SMCS Code: 1000; 4450

### **USA and Canada**

When a problem arises concerning the operation or the service of an engine, the problem will normally be managed by the dealer in your area.

# Outside of the USA and of Canada

If a problem arises outside the USA and outside Canada, and if the problem cannot be resolved at the dealer level, consult the appropriate Caterpillar office.

Latin America, Mexico, Carribean Caterpillar Americas Co. 701 Waterford Way, Suite 200 Miami, FL 33126-4670 USA Phone: 305-476-6800 Fax: 305-476-6801

Europe, Africa, and Middle East Caterpillar Overseas S.A. 76 Route de Frontenex P.O. Box 6000 CH-1211 Geneva 6 Switzerland Phone: 22-849-4444 Fax: 22-849-4544

Far East Caterpillar Asia Pte. Ltd. 7 Tractor Road Jurong, Singapore 627968 Republic of Singapore Phone: 65-662-8333 Fax: 65-662-8302

China Caterpillar China Ltd. 37/F., The Lee Gardens 33 Hysan Avenue Causeway Bay G.P.O. Box 3069 Hong Kong Phone: 852-2848-0333 Fax: 852-2848-0440 Australia and New Zealand Caterpillar of Australia Ltd. 1 Caterpillar Drive Private Mail Bag 4 Tullamarine, Victoria 3043 Australia Phone: 03-9953-9333 Fax: 03-9335-3366

i03655027

# **Ordering Replacement Parts**

**SMCS Code:** 4450; 7567



When replacement parts are required for this product Caterpillar recommends using Caterpillar replacement parts or parts with equivalent specifications including, but not limited to, physical dimensions, type, strength and material.

Failure to heed this warning can lead to premature failures, product damage, personal injury or death.

Quality Caterpillar replacement parts are available from Caterpillar dealers throughout the world. Caterpillar dealers' parts inventories are up-to-date. The parts stocks include all of the parts that are normally needed to protect your Caterpillar engine investment.

When you order parts, please specify the following information:

- When a Caterpillar engine requires maintenance and/or repair, provide the dealer with all the information that is stamped on the Information Plate. Refer to this Operation and Maintenance Manual, "Plate Locations and Film Locations".
- Part number
- Part name
- Quantity

If there is a question concerning the part number, please provide your dealer with a complete description of the needed item.

Discuss the problem with the dealer. Inform the dealer about the conditions of the problem and the nature of the problem. Inform the dealer about when the problem occurs. This will help the dealer in troubleshooting the problem and solving the problem faster.

# **Reference Materials**

i08530562

# Maintenance Records

SMCS Code: 1000; 4450

Caterpillar recommends the retention of accurate maintenance records. Accurate maintenance records can be used for the following purposes:

- · Determine operating costs.
- Establish maintenance schedules for other engines that are operated in the same environment.
- Show compliance with the required maintenance practices and maintenance intervals.

Maintenance records can be used for various other business decisions that are related to engine maintenance.

Maintenance records are a key element of a maintenance program that is managed. Accurate maintenance records can help your Cat dealer to fine-tune the recommended maintenance intervals to meet the specific operating situation. These recommendations should result in a lower engine operating cost.

Records should be kept for the following items:

**Fuel Consumption** – A record of fuel consumption is essential to determine when the load sensitive components should be inspected or repaired. Fuel consumption assists in determining overhaul intervals.

**Service Hours** – A record of service hours is essential to determine when the speed sensitive components should be inspected or repaired.

**Documents** – These items should be easy to obtain, and these items should be kept in the engine history file. All documents should show this information: date, service hours, fuel consumption, unit number, and engine serial number. The following types of documents should be kept as proof of maintenance or repair for warranty:

Keep the following types of documents as proof of maintenance for warranty. Also, keep these types of documents as proof of repair for warranty:

- Dealer work orders and itemized bills
- · Owner repair costs
- · Owner receipts
- Maintenance log

# Maintenance Log

#### SMCS Code: 1000; 4450

Table 29

Engine Model		Customer Identifier			
Serial Number		Arrangement Number			
Service Hours	Quantity Of Fuel	Servic	ce Item	Date	Authorization

# **Reference Material**

#### SMCS Code: 1000; 4450

The following literature can be obtained through any Caterpillar dealer.

### Lubricants

- Operation and Maintenance Manual, SEBU5898, "Cold-Weather Recommendations"
- Operation and Maintenance Manual, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations"
- Special Publication, PEHP6001, "How To Take A Good Oil Sample"

### Coolants

- Special Publication, PEHP4036, "Data Sheet -Extended Life Coolant"
- Special Publication, PEHP7057, "Data Sheet -S·O·S Coolant Analysis"
- Special Publication, SEBD0518, "Know Your Cooling System"
- Label, PEEP5027, "Extended Life Coolant/ Antifreeze"

### **Miscellaneous**

- Service Manual, REG1139F, "Service Manual Contents Microfiche"
- Service Manual, UENR7548, "C3.6 and C2.8 Industrial Engines"
- Troubleshooting, M0107940, "C3.6 Engines"
- Troubleshooting, M0112481, "C2.8 Engines"
- Systems Operation, Testing, and Adjusting, M0107832, "C3.6 and C2.8 Industrial Engines"
- Specifications, M0107642, "C3.6 Industrial Engines."
- Specifications, M0109805, "C2.8 Industrial Engines."
- Disassembly and Assembly, M0108719, "C3.6 and C2.8 Industrial Engines"
- Specifications, SENR3130, "Torque Specifications"

- Special Publication, PECP9067, "One Safe Source" English language for use in NACD
- Special Publication, SEBF8029, "Index to Guidelines for Reusable Parts and Salvage Operations"
- Special Publication, SEBF8062, "Procedure to Inspect and Clean Air Filters"
- Special Instruction, SEHS9031, "Storage Procedure for Caterpillar Products"
- Special Publication, NEHS0526, "Service Technician Application Guide"
- Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations"
- Special Instruction, SEHS7633, "Battery Test Procedure"

# Index

### A

Additional Messages	16
After Starting Engine	71
After Stopping Engine	88
Aftercooler Core - Clean/Test (Air-To-Air	
Aftercooler)	104
Aftercooler Core - Inspect	104
Aftertreatment Operation	76
Alarms and Shutoffs	53
Alarms	53
Shutoffs	53
Testing	54
Alternator - Inspect	104
Alternator and Fan Belts - Replace	104

### В

Battery - Replace	104
Battery Disconnect Switch (If Equipped)	54
Battery Electrolyte Level - Check	105
Battery or Battery Cable - Disconnect	105
Before Starting Engine	27, 69
Belt - Inspect	
Belt Tensioner - Check	107
Burn Prevention	21
Batteries	22
Coolant	
Diesel Fuel	22
Engine and Aftertreatment System	22
Induction System	22
Oils	22

### С

Cold Weather Operation	
Hints for Cold-Weather Operation	. 83
Idling the Engine	. 84
Recommendations for Coolant Warm Up	. 84
Recommendations for the Coolant	. 84
Viscosity of the Engine Lubrication Oil	. 84
Cold Weather Starting	. 69
Coolant (DEAC) - Change	
Cooling Systems with Heavy Deposits or	
Plugging	.111
Drain	
Fill	.111
Flush	.110
Coolant (ELC) - Change	.112
Drain	

Fill	114
Flush	114
Coolant Extender (ELC) - Add	115
Coolant Level - Check	116
Open Power Unit (OPU) Radiators	116
Coolant Sample (Level 1) - Obtain	117
Coolant Sample (Level 2) - Obtain	118
Cooling System Supplemental Coolant	
Additive (SCA) - Test/Add	118
Add the SCA, If Necessary	119
S·O·S Coolant Analysis	118
Test for SCA Concentration	118
<b>Crushing Prevention and Cutting Prevention</b>	า 25
Customer Assistance	. 152
Outside of the USA and of Canada	. 152
USA and Canada	. 152
Customer Service	. 152

#### D

DEF Filler Screen (Emission Related Component) - Clean	119
DEF Manifold Filters (Emission Related	
Component) - Replace	120
Diagnostic Flash Code Retrieval	67
Diagnostic Lamp	67
Diesel Exhaust Fluid (Emission Related	
Component) - Fill	120
Diesel Exhaust Fluid Filter (Emission	
Related Component) - Replace	121
Diesel Exhaust Fluid in Cold Weather	86
Diesel Exhaust Fluid Injector (Emission	
Related Component) - Replace	122
Diesel Exhaust Fluid Tank - Flush	123
Flushing Procedure	123
Required Tools	
Driven Equipment - Check	

### Е

Electrical System	28
Grounding Practices	
Emergency Stopping	
Emissions Certification Film	47
Emissions Warranty Information	150
Engaging the Driven Equipment	74
Engine - Clean	125
Aftertreatment	125
Engine Air Cleaner Element - Replace	125

Servicing the Air Cleaner Elements
Inspect 127
Test the Service Indicator 127
Type 1 Service Indicator 127
Type 2 Service Indicator 127
Engine Air Precleaner - Check/Clean
Engine Diagnostics
Engine Electronics
Engine Mounts - Inspect 128
Engine Oil and Filter - Change
Drain the Engine Lubricating Oil From a
Standard Oil Pan 130
Draining the Engine Lubricating Oil From an
Oil Pan Equipped With a Balancer
Fill the Oil Pan
Oil and Filter Change Intervals
Replace the Oil Filter Element
Engine Oil Level - Check
After Operating the Engine 129
Before Operating the Engine
Engine Oil Sample - Obtain
Obtain the Sample and the Analysis 129
Engine Operation73
C2.8 Industrial Engine74
C3.6 Industrial Engine74
Carbon Dioxide (CO <sub>2</sub> ) Emissions
Statement74
Engine Operation and the Aftertreatment
System 73
Engine Operation with Active Diagnostic
Codes
Engine Operation with Intermittent
Diagnostic Codes 68
Engine Rating Conditions 151
Engine Rating Definitions
Engine Ratings 151
Engine Starting
Engine Stopping

#### F

Fan Clearance - Check	134
C2.8 Open Power Unit (OPU)	134
C3.6TA Open Power Unit (OPU)	134
Fault Logging	67
Features and Controls	53
Fire Prevention and Explosion Prevention.	23
Ether	24
Fire Extinguisher	24
Lines, Tubes, and Hoses	25
Fluid Recommendations	94

Coolant	
Diesel Exhaust Fluid	97
Engine Lubrication Oil	94
Fuel	97
Lubricating Grease	96
S·O·S Coolant Analysis	
Foreword	
California Proposition 65 Warning	
Literature Information	
Maintenance	
Maintenance Intervals	
Operation	
Overhaul	
Safety	
Fuel and the Effect from Cold Weather	
Fuel Conservation Practices	
Fuel Related Components in Cold Weather	
Fuel Filters	
Fuel Heaters	
Fuel Tanks	
Fuel System - Prime	
Electric Fuel Priming Pump	
Mechanical Fuel Priming Pump	
Fuel System Primary Filter (Water	
Separator) Element - Replace	. 136
Fuel System Primary Filter (Water Separa	
Element for Electric Fuel Priming Pump.	. 136
Fuel System Primary Filter (Water Separa	ator)
Element for Manual Fuel Priming Pump.	. 137
Fuel System Primary Filter/Water	
Separator - Drain	. 139
Drain Procedure	. 139
Fuel System Secondary Filter - Replace	. 139
Install the Element	
Remove the Element	. 140
Fuel Tank Water and Sediment - Drain	. 141
Drain the Water and the Sediment	
Fuel Storage Tanks	. 141
Fuel Tank	. 141

### G

Gauges and Indicators	54
Aftertreatment Lamps and gauges	56
Indicator Lamps	55
General Hazard Information	17
Containing Fluid Spillage	19
Diesel Exhaust Fluid	21
Dispose of Waste Properly	21
Fluid Penetration	19
Inhalation	20
Pressurized Air and Water	18

Static Electricity Hazard when Fueling with	
Ultra-low Sulfur Diesel Fuel	19
General Information	31

### н

High Pressure Fuel Lines	25
Hoses and Clamps - Inspect/Replace	141
Replace the Hoses and the Clamps	142

#### I

Important Safety Information 2
--------------------------------

### L

Lifting and Storage 49
------------------------

#### Μ

Maintenance Interval Schedule	
Daily	
Every 10 000 Service Hours	
Every 1000 Service Hours	
Every 12 000 Service Hours or 6 Years	
Every 2000 Service Hours	102
Every 250 Service Hours	102
Every 3000 Service Hours	102
Every 3000 Service Hours or 3 Years	103
Every 4000 Service Hours	
Every 4500 Service Hours	
Every 50 Service Hours	
Every 500 Service Hours or 1 Year	
Every 6000 Service Hours	
Every 6000 Service Hours or 3 Years	
Every Week	
Every Year	
Overhaul	
When Required	
Maintenance Log	
Maintenance Recommendations	
Maintenance Records	
Maintenance Section	
Model View Illustrations	
C2.8 Industrial Engine Views	,
C2.8 OPU	
C3.6 Industrial Engine Views	
C3.6 Industrial Engine Views For Engine	
Equipped With A Balancer	
C3.6 Open Power Unit (OPU)	
Loose or Off Engine Components 3	10, 38

Monitoring System (Engine Indicators and	
Aftertreatment Indicators)	56
Engine Indicator Lamps	56
Mounting and Dismounting	25

### 0

Operation Section	49
Ordering Replacement Parts	
Overhaul Considerations	142
Oil Consumption as an Overhaul	
Indicator	143
Overhaul Recommendation	143

#### Ρ

Plate Locations and Film Locations	. 47
Serial Number Plate	. 47
Product Description ((Engine and	
Aftertreatment))	. 44
Aftermarket Products and Caterpillar	
Engines	. 46
Aftertreatment System	
C2.8 Industrial Engine	
C3.6 Industrial Engine	
Electronic Engine Features	
Engine Cooling and Lubrication	
Engine Diagnostics	
Engine Service Life	
Engine Specifications	
Product Identification Information	
Product Information Section	. 31
Product Lifting	
C2.8 Industrial Engine	
C2.8 Open Power Unit (OPU)	. 51
C3.6 Industrial Engine	
C3.6 Industrial Engine Equipped With A	
Balancer	. 50
C3.6 Open Power Unit (OPU)	. 50
Product Storage	
Aftertreatment	. 52

### R

Radiator - Clean	. 145
Radiator Mounts - Inspect	. 146
Radiator Restrictions	85
Reference Information	48
Record for Reference	48
Reference Information Section	. 151
Reference Material	. 155
Coolants	. 155

Lubricants	155
Miscellaneous	155
Reference Materials	153
Refill Capacities	. 93
Cooling System	. 94
DEF System	. 94
Lubrication System for Engines Equipped	
With a Balancer Oil Pan	. 93
Lubrication System for Engines Equipped	
With a Standard Oil Pan	. 93

### S

Safety Messages	
C2.8 Industrial Engine	8
C3.6 Industrial Engine	
C3.6 Industrial Engine With A Balanc	er 11
C3.6 Open Power Unit (OPU)	14
Ether Warning	9, 12, 16
Hand (High Pressure)	
Hand (High Pressure) 2	12
Hand (High Pressure) 3	15
Hot Fluid Under Pressure 2	15
Universal Warning	8
Universal Warning 1	
Safety Section	
Selective Catalytic Reduction Warning	
System	
Warning Indicators	
Warning Levels	
Warning Strategy	
Self-Diagnostics	
Sensors and Electrical Components	57
C2.8 Industrial Engine	63
C3.6 Industrial Engines	
Off Engine Sensors and Electrical	
Components	62
Severe Service Application	
Improper Maintenance Procedures	
(Maintenance Procedures Which Ma	ау
Contribute to a Severe Service	•
Application)	
Severe Environmental Factors	
Severe Operating Conditions	
Starting Motor - Inspect	146
Starting the Engine	70
Starting the Engine	70
Starting with Jump Start Cables (Do No	t
Use This Procedure in Hazardous	
Locations that have Explosive	
Atmospheres)	

Stopping the Engine	88
Delayed Engine Shutdown (if Equipped)	88
System Pressure Release	90
Coolant System	90
Engine Oil	90
Fuel System	90

#### т

Table of Contents	3
Turbocharger - Inspect	146

#### W

Walk-Around Inspection High-Pressure Fuel Lines	
Inspect the Engine for Leaks and for Loo	se
Connections	147
Warranty Information	150
Warranty Section	150
Water Pump - Inspect	148
Welding on Engines with Electronic	
Controls	90

# **Product and Dealer Information**

Note: For product identification plate locations, see the section "Product Identification Information" in the Operation and Maintenance Manual.

Delivery Date: \_\_\_\_\_

# **Product Information**

Model:
Product Identification Number:
Engine Serial Number:
Transmission Serial Number:
Generator Serial Number:
Attachment Serial Numbers:
Attachment Information:
Customer Equipment Number:
Dealer Equipment Number:

# **Dealer Information**

Name:	Branch:			
Address:				
	Dealer Contact	Phone Number	Hours	
	Dealer Contact		HOUIS	
Sales:				
Parts:				
Service:				

M0108394 ©2022 Caterpillar All Rights Reserved CAT, CATERPILLAR, LET'S DO THE WORK, their respective logos, "Caterpillar Corporate Yellow", the "Power Edge" and Cat "Modern Hex" trade dress as well as corporate and product identity used herein, are trademarks of Caterpillar and may not be used without permission.

