

Air Conditioner Troubleshooting Guide



BEFORE CALLING FOR SERVICE

Your air conditioner is equipped with an automatic error-monitoring system to detect and diagnose problems at an early stage. If your Air conditioner does not function properly, or does not function at all, check the following before you call service.

Problem	Possible Causes	Possible Solutions
OPERATIONS		
Will not start	 Unit is not plugged in 	 Make sure electrical plug is plugged into a live, properly grounded outlet.
	 House fuse is blown or circuit breaker has tripped 	Replace the fuse or reset the breaker.
	Power failure	 Wait 3 minutes after power resumes before starting.
	 The integrated circuit breaker in the plug has tripped 	Press the reset button on the unit's plug .
	Room temperature is less than the set temperature	This is normal.
Does not cool properly	Air filter is dirty	Clean air filter at least every 2 weeks.
	Not enough time allowed for cooling	When first turned on allow for enough time to cool the area.
	Cold air is escaping	Close furnace floor registers.
	 Cooling coils have iced up 	Set the controls to high fan or high cool and set to a warmer temperature.
	Air flow is restricted	Provide sufficient clearance around the unit and that the air inlet and outlet are not blocked by furniture, curtains etc.
Runs too often or too long	Too large of an area for unit	Consult dealer for the A/C capacity necessary to cool the desired area.
	 Doors or windows are open 	Close doors and windows.



BEFORE CALLING FOR SERVICE (Cont.)

Problem	Possible Causes	Possible Solutions		
ERROR CODES				
Refer to your Owner's Manual				

