



lack

Read the instructions and warnings in this manual CAREFULLY BEFORE using this firearm.



WARNING: READ THESE INSTRUCTIONS AND WARNINGS CAREFULLY. BE SURE YOU UNDERSTAND THESE INSTRUCTIONS AND WARNINGS BEFORE

USING THIS FIREARM. FAILURE TO READ THESE INSTRUCTIONS AND TO FOLLOW THESE WARNINGS MAY RESULT IN SERIOUS INJURY OR DEATH TO YOU AND OTHERS

This SAFETY & INSTRUCTION MANUAL should always accompany this firearm and be transferred with it upon change of ownership or when presented to another person.

A copy of the SAFETY & INSTRUCTION MANUAL is available FREE upon request from:

WAITHER ARMS Inc.

Attn: Service Dept 1-479-242-8500 Phone:

7700 Chad Colley Boulevard F-mail· service@waltherarms.com

Fort Smith, AR 72916

www WaltherArms com

Note: This manual refers to the use of the pistol by civilian users. Instructions for law enforcement use may differ from what is described in this manual

Throughout this instruction manual, position designations such as "left." "right." "forward." "rear." and so on, are referenced to a pistol held in a normal firing position. In other words, pointed away from the shooter, barrel in a generally horizontal direction, and with the grip of the pistol pointing downwards.

Explanations in this manual are based on right hand operation. Left-handed users should operate vice versa. Note that the illustrations in this manual are for explanation purposes and may differ from the actual gun.

DISCLAIMER OF LIABILITY: The first concern when handling any firearm is safety. The failure to do so may result in property damage, serious bodily injury or even death, WALTHER specifically disclaims any and all liability from anyone arising out of the use of this firearm and its accessory. Under no circumstances shall WALTHER be responsible for incidental or consequential damages with respect to economic loss or injury to person or property due to negligence, improper use, failure to following instructions in this manual, unsafe handling, failure to maintain the pistol, unauthorized replacement of parts, disregard of statutory rules or laws or any other modification to the pistol.



CONTENTS

1. YOUR SAFETY RESPONSIBILITIES	4 - 11
1.1 Safety is your number one responsibility!	4 - 8
1.2 Safe storage and transportation	9 - 11
2. AMMUNITION	12
3. OPERATING INSTRUCTIONS	12 - 16
3.1. Main Features	12
3.2. Functional Elements	13
3.3. Manual safety	14
3.4. Sights	14
3.5. Loaded chamber indicator	15
4. INSPECTION	17
5. LOADING THE PISTOL	18
5.1. Loading the chamber with the first cartridge	19
6. DECOCKING	20
7. TRADITIONAL DOUBLE / SINGLE ACTION	21 - 22
8. UNLOADING THE PISTOL	22
9. RELOADING THE PISTOL	23
10. CLEARING MISFIRES	24
11. DIASSEMBLY AND ASSEMBLY OF THE PISTOL	24 - 25
12. CLEANING	26
13. STORAGE	26
14. REPAIR OF WALTHER PISTOLS	26
15. ACCESSORIES	27
16. WARRANTY + CONTACT	28 - 30
17. NOTES	31



1. YOUR SAFETY RESPONSIBILITIES

1.1 SAFETY IS YOUR NUMBER ONE RESPONSIBILITY!

At home, in the field, at the range, or anywhere, the first concern of every firearm owner should be safety. Apply the following safety rules in every situation, with any kind of firearm. If you feel uncertain about any operational aspects of your handgun, please contact

WALTHER ARMS, Inc. at 1-479-242-8500 before proceeding with its operation.



YOU MUST FOLLOW ALL OF THESE SAFETY RULES TO ENSURE THE SAFE LISE OF YOUR FIREARM. THE FAILURE TO FOLLOW THESE

BASIC FIREARM SAFETY RULES MAY RESULT IN AN UNINTENDED DISCHARGE WHICH COULD CAUSE SERIOUS PERSONAL INJURY OR DEATH TO YOU OR OTHERS AND DAMAGE TO PROPERTY.

ALWAYS KEEP YOUR FIREARM POINTED IN A SAFE DIRECTION.

Never point a firearm at anyone or anything you do not intend to shoot, whether or not it is loaded. This is particularly important when loading, unloading, or field stripping the gun. ALWAYS control the direction of the firearm.

ALWAYS TREAT EVERY FIREARM AS IF IT IS LOADED AND WILL FIRE IF THE TRIGGER IS PULLED.

Do not take anyone's word that the firearm is unloaded – always check for yourself. Never pass your firearm to another person until the action is open and you visually check that it is unloaded. Keep your firearm unloaded and safely stored when not in use.

1. YOUR SAFETY RESPONSIBILITIES



 NEVER PLACE YOUR FINGER INSIDE THE TRIGGER GUARD OR ON THE TRIGGER UNLESS YOU INTEND TO FIRE.

Ensure that other objects do not touch the trigger.

ALWAYS BE SURE OF YOUR TARGET AND WHAT IS BEYOND IT.

Always be sure of where the bullet will strike and shoot only where there is a safe back stop free of obstructions, water or other surfaces which can cause ricochets. Be sure your bullet will stop behind your target. Bullets can glance off many surfaces like rocks or surface water and travel in unpredictable directions with considerable velocity. Do not fire randomly into the sky.

- NEVER CROSS OBSTACLES SUCH AS FENCES OR STREAMS WITH A LOADED FIREARM.
- SAFE GUN HANDLING IS YOUR PERSONAL RESPONSIBILITY at all times.
 Firearms are dangerous and can cause serious injury or death if they are
 misused or used inappropriately. Safety must be the prime consideration of
 anyone who owns or handles firearms. Accidents are the result of violating the
 rules of safe gun handling and common sense. Firearm safety training is
 available. Contact your dealer, law enforcement agency, local sportsman's club,
 etc. for availability.
- YOU ARE RESPONSIBLE FOR THE FIREARM AT ALL TIMES.

In owning a firearm, you must undertake full-time responsibility for your firearm's safety and security. You must protect yourself and all others against injury or death from misuse of the firearm 24 hours a day.

 FIREARM SECURITY IS YOUR RESPONSIBILITY. You must secure firearms safely from children and/or unauthorized users. Your firearm should always be kept unloaded and locked when not in use. A lock has been provided for



- this purpose. Never assume that the use of this lock is sufficient to safely secure your firearm. You must always evaluate your personal situation and employ the security system(s) that meets your needs and prevents children and unauthorized users from gaining access to your firearm.
- APPROPRIATE USE FOR YOUR FIREARM MEANS USING YOUR FIREARM FOR LEGAL PURPOSES. For example - target shooting and lawful resistance of deadly criminal force. It is your responsibility to ensure that you are in compliance with all applicable laws and ordinances regarding the use of your firearm.
- NEVER RELY ON MECHANICAL FEATURES ALONE. Only your safe gun-handling
 habits will ensure the safe use of your firearm. This is your responsibility
- ALWAYS SAFELY STORE AND SECURE YOUR FIREARM.
 Safe and secure storage of your firearm is one of your most important responsibilities. It is a full-time responsibility. You must always secure your firearm and ammunition separately so that they are not accessible to children and/or other unauthorized persons.
- NEVER KEEP AMMUNITION IN THE SAME LOCATION AS THE HANDGUN.
 Store each in a separate and secure place.
- ALWAYS WEAR EYE AND EAR PROTECTORS THAT ARE SPECIFIED FOR FIREARM
 USE every time you discharge your firearm. Make sure others in the vicinity of
 where you will be shooting do so as well.
- NEVER USE ALCOHOL OR DRUGS BEFORE OR WHILE SHOOTING.
 Do not use your firearm if you are on any medication which impairs, even slightly, your mental or physical ability.

1. YOUR SAFETY RESPONSIBILITIES



ALWAYS HAVE ADEQUATE VENTILATION.

Discharging firearms in poorly ventilated areas, cleaning firearms, or handling ammunition may result in exposure to lead and other substances known to cause birth defects, reproductive harm, and other serious physical injury. Review the warnings and labels for all ammunition and cleaning products carefully. Wash hands thoroughly after exposure.

BEFORE HANDLING ANY FIREARM, UNDERSTAND ITS OPERATION.

Not all firearms are the same. Familiarize yourself with the mechanical features of any firearm you intend to use. If you feel uncertain about any operational aspects of your handgun, please contact WALTHER ARMS, Inc. at 1-479-242-8500 before proceeding with its operation.

- NEVER ALLOW A FIREARM TO BE USED BY INDIVIDUALS WHO DO NOT UNDERSTAND ITS SAFE OPERATION OR HAVE NOT READ THESE FIREARM SAFETY RULES.
- ALWAYS USE THE CORRECT AMMUNITION FOR YOUR PARTICULAR FIREARM as indicated by the marking on the barrel. Never use non-standard, reloaded, or "handloaded" ammunition which has not been subjected to internal ballistic pressure testing.
- BEWARE OF BARREL OBSTRUCTIONS. Be sure the barrel is clear of obstructions before shooting. Mud, water snow or other objects may inadvertently lodge in the barrel bore. A small obstruction can cause a dangerous increase in pressure and may damage your firearm and cause injury to yourself and others.
- BE SURE ALL ACCESSORIES, SUCH AS HOLSTERS AND GRIPS, ARE COMPATIBLE with the handgun and that the accessories do not interfere with safe operation.



- NEVER DISASSEMBLE YOUR HANDGUN beyond the field stripping procedure outlined in this manual. Improper disassembly or reassembly of your handgun may be dangerous and can lead to serious injury or death.
- NEVER MANIPULATE. ADJUST OR CHANGE ANY OF THE INTERNAL COMPONENTS. OF YOUR FIREARM including the firing, sear, or drawbar. Improper manipulation of any internal component may affect the safety and reliability of your firearm and may cause serious injury or death.
- NEVER ALLOW ANY ALTERATION OR REPLACEMENT OF PARTS IN YOUR WALTHER FIREARM UNLESS PERFORMED BY A QUALIFIED GUNSMITH using genuine WALTHER parts. If you do otherwise, improper functioning of your firearm may occur and serious injury or death and damage to property may result.

WARNING SAFE USE OF A FIREARM IS YOUR PERSONAL RESPONSIBILITY AND THE FAILURE TO FOLLOW ALL OF THESE BASIC SAFETY RULES MAY RESULT IN SEVERE

PERSONAL INJURY OR DEATH TO YOU OR OTHERS, YOU ARE THE MOST IMPORTANT SAFETY DEVICE WHEN IT COMES TO THE USE OF YOUR FIREARM AND WALTHER WILL NOT BE RESPONSIBLE FOR ANY PERSONAL INJURY, DEATH OR PROPERTY DAMAGE THAT RESULTS FROM:

- (1) THE CRIMINAL OR NEGLIGENT USE OF THIS HANDGUN;
- (2) A DISREGARD OF THESE SAFETY INSTRUCTIONS AND WARNINGS;
- (3) IMPROPER OR CARELESS HANDLING OF THIS FIREARM:
- (4) THE USE OF NON-STANDARD, DEFECTIVE, IMPROPER OR RELOADED AMMUNITION; OR
- (5) IMPROPER OR NEGLIGENT MODIFICATIONS OR REPAIRS TO THE HANDGUN.



1.2 SAFE STORAGE AND TRANSPORTATION

A WARNING

FIREARMS ARE DANGEROUS WHEN USED AND STORED IMPROPERLY – THEY POSE A RISK OF SERIOUS OR FATAL INJURIES

FIREARMS CAN BE ESPECIALLY DANGEROUS TO CHILDREN WHEN THEY ARE STORED IN AN IRRESPONSIBLE AND UNSAFE MANNER.

FOR YOUR SAFETY AND THE SAFETY OF OTHERS, IT IS IMPERATIVE THAT YOU KEEP YOUR FIREARM LOCKED AND UNLOADED IN A SECURE PLACE.

THE AMMUNITION SHOULD BE STORED IN A SEPARATE, SECURE LOCATION WHEN IT IS NOT IN USE.

SAFE AND SECURE STORAGE OF YOUR FIREARM IS ONE OF THE MOST IMPORTANT RULES OF FIREARM SAFETY. YOUR FAILURE TO FOLLOW THESE RULES MAY RESULT IN SERIOUS INJURY OR DEATH TO YOU OR OTHERS

- ALWAYS SECURE YOUR FIREARM IN A MANNER THAT WILL PREVENT UNAUTHORIZED ACCESS.
- Whenever your firearm is not in use, keep it unloaded and locked. Your safety
 and the safety of others requires that you always secure and store your firearm
 in a manner that will prevent unauthorized access. Never leave a firearm
 unattended unless it is locked, unloaded and secured.
- ALWAYS USE THE LOCK PROVIDED BY WALTHER TO SECURE YOUR FIREARM.
- Please read and follow the instructions packaged separately for the use of this lock. A lock, when properly used, can be an effective tool in preventing unauthorized access to your firearm. There are other alternative locks and safe storage containers available in the marketplace which may also be appropriate for your particular needs.



• Consult your local gun shop, hardware store, or local police department for quidance on the variety of other safe storage devices or practices which may be appropriate for your particular needs. By purchasing this firearm you have accepted the responsibility of safely securing the firearm at all times and preventing its unauthorized use. Never assume that the use of this lock alone is sufficient to safely secure your firearm. It is your personal responsibility to select and use whatever measures or practices that will enable you to be absolutely certain that your firearm is secure at all times.



WARNING: NEVER LOCK A LOADED FIREARM AND NEVER LOAD A LOCKED FIREARM.

- ALWAYS STORE YOUR FIREARM AND AMMUNITION SEPARATELY so that they are not accessible to children or other unauthorized persons. Safe and secure storage of your firearm and ammunition are your responsibility. It is a full-time responsibility.
- NEVER ASSUME THAT A "HIDING" PLACE IS A SECURE STORAGE METHOD. Others may be aware of your storage location or come upon it by chance. It is your personal responsibility to use common sense when storing your firearm and ammunition and to always make sure they are not accessible to children or other unauthorized persons.
- NEVER TRANSPORT A LOADED FIREARM. When transporting your firearm, be sure it is unloaded and locked. Safe and secure transportation of your firearm is your responsibility.





ALWAYS FOLLOW THE LAW!

Many jurisdictions have laws that make it a crime to keep a firearm unlocked and in an area accessible to children or others. Keeping a firearm locked and unloaded when not in use is not only common sense safety practice ... IT IS THE LAW. You must be familiar with all local, state, and federal laws regarding the safe storage and transportation of your firearm. Failure to know and follow the law may result in unauthorized access or use of your firearm by another. Obey all laws relating to the storage and transportation of firearms. Your local police department or gunshop can furnish you with available information on storing and/or transporting a firearm safely and legally.

YOUR FIREARM IS YOUR RESPONSIBILITY.

You must prevent your firearm from being stolen or from being used by untrained or unqualified individuals. Keep it locked, unloaded and secured when not in use.

3. OPERATING INSTRUCTIONS



 Use only commercially manufactured ammunition with internal ballistic pressure which are in strict accordance with the specifications of the Sporting Arms and Ammunition Manufacturers'Institute (SAAMI). If you are uncertain, contact your ammunition supplier for verification.

2. AMMUNITION

- Use only ammunition specifically recommended by Walther for your firearm.
- · Never mix ammunition.
- Never use a cartridge not specifically designated for use in your firearm.
 Pressure from the wrong type of ammunition may exceed the capability of your firearm and may damage or even rupture your firearm.
- In some cases, a round of ammunition not specified on your handgun may fit into the chamber. Firing ammunition not specified on your handgun may cause it to rupture and cause serious injury or death to you or others.
- Always inspect your ammunition before using it. Never use dirty, corroded or damaged ammunition which can lead to a burst cartridge which may cause damage to the handgun and personal injury or death.
- "Plus-P" (+P) ammunition generates pressures in excess of the pressure associated with standard ammunition. Such pressures may affect the wear characteristics or exceed the margin of safety. Use of (+P) ammunition may require more frequent service.
- "Plus-P-Plus" (+P+) ammunition is not recommanded for use in Walther firearms. This
 marking on the ammunition designates that it exceeds established industry standards, but the
 designation does not represent defined pressure limits and therefore such ammunition may
 vary significantly as to the pressures generated and could be DANGEROUS.

3.1 Main Features

PK 380 - Black PK 380 - Two-Tone Nickel



3.2 Functional Elements







ALWAYS LEAVE THE MANUAL SAFETY ENGAGED UNTIL YOU INTEND TO FIRE.

3.3 Manual safety

SAFE POSITION - rotate the safety lever to lower position (fig. 1).

FIRE POSITION - rotate the safety lever to upper position (fig. 2).





3.4 Adjusting rear sight

For **windage** adjustment the sight must strongly be pushed to the right or left (fig. 3):

If the gun shoots to the right: push to the left

If the gun shoots to the left: push to the right









3.5 Loaded chamber indicator

The slot above the extractor allows inspection of the chamber to see if a cartridge has been loaded.

The Walther Arms PK380 has a loaded chamber indicator. This indicator can be observed by looking at the side of the slide/ejection port, (fig.4a, 4b), noting an opening just above the extractor. By looking into this opening, you can observe whether or not a round is in the firearm's chamber. If a round is in the chamber, you would see the actual brass or silver colored rim through this opening.





WARNING: NEVER RELY UPON THE LOADED CHAMBER INDICATOR ALONE TO VERIFY THE PRESENCE OR ABSENCE OF A ROUND IN THE CHAM-

BER, THE SUREST METHOD TO DETERMINE THE PRESENCE OR ABSENCE OF A ROUND IN THE CHAMBER IS TO VISUALLY CHECK THE CHAMBER OF YOUR FIREARM BY REMOVING THE MAGAZI-NE AND PULLING AND LOCKING THE SLIDE IN THE OPEN POSITION.



ALWAYS TREAT EVERY FIREARM AS IF IT WERE LOADED AND WOULD FIRE IF THE TRIGGER IS PULLED. A LOADED CHAMBER

INDICATOR MAY HELP DETERMINE WHETHER THE CHAMBER IS LOADED OR UNLOADED. THE AMOUNT OF LIGHT CLEANLINESS OF THE PISTOL. DISCOLORATION OF THE AMMUNITION AND OTHER FACTORS MAY LIMIT THE EFFECTIVENESS OF THE LOADED CHAMBER INDICATOR.

WARNING: ALWAYS INSPECT THE CHAMBER OF YOUR PISTOL AFTER THE MAGAZINE HAS BEEN REMOVED FROM THE GUN. MAKE SURE THAT NO CARTRIDGE IS LEFT IN THE CHAMBER.



4. Inspection

WARNING: MAKE SURE THAT THE PISTOL IS UNLOADED (CHAMBER CLEARED, BARREL CLEAR OF ANY OBSTRUCTIONS, MAGAZINE EMPTY) FOR INSPECTION AND THAT THE SAFETY IS IN THE SAFE POSITION AND THE PISTOL IS POINTED IN A SAFE DIRECTION

A WARNING:

GRIP FROM ABOVE OR FROM THE BACK WHEN PULLING THE SLIDE (FIG. 5). NEVER PUT YOUR HAND IN FRONT OF THE MUZZLE (FIG. 6).

Functional inspection:

- Make sure that chamber and magazine of your gun are empty. Remove the magazine and retract the slide by pulling the slide rearward. Release the slide to return the slide fully forward into battery.
- 2. Insert the empty magazine, retract the slide. The slide should be locked back in its rearmost position.
- 3. Remove the magazine, pull the slide back slightly and release the slide. Release the slide to return the slide fully forward into battery.







5. Loading the pistol

WARNING: MAKE SURE THAT THE PISTOL IS UNLOADED (CHAMBER CLEARED, BARREL CLEAR OF ANY OBSTRUCTIONS, MAGAZINE EMPTY) FOR INSPECTION AND THAT THE SAFETY IS IN THE SAFE POSITION AND THE PISTOL IS POINTED IN A SAFE DIRECTION

Press magazine release and remove empty magazine (fig. 7). Holding the empty magazine in your hand, push the cartridge under the magazine lips, at the same time pushing down the follower (fig. 8). Do not use excessive force. Insert the loaded magazine until the magazine catch locks it in position (fia. 9).









5.1 Loading the chamber with the first cartridge

Pick up the pistol with your shooting hand and point the muzzle in a safe direction. Use your other hand to retract and release the slide (fig. 10). Never put your hand in front of the muzzle. As the slide travels forward it inserts the first round into the chamber. The hammer is now cocked. You are now in the single action firing mode. Leave the safety in the safe position until you are ready to fire.

A WARNING:

ALWAYS LOAD A ROUND INTO THE CHAMBER BY FEEDING IT FROM THE MAGAZINE, FAILURE TO FOLLOW THIS WARNING CAN RESULT IN SEVERE INJURY OR DEATH TO YOU OR OTHERS. NEVER ATTEMPT TO LOAD THE PISTOL BY INSERTING A ROUND INTO THE OPEN EJECTION PORT.

WARNING: WALTHER ARMS PK380 PISTOLS ARE DESIGNED SO THAT THEY ARE ABLE TO FIRE WHEN THE MAGAZINE IS REMOVED. THEREFORE, WHEN THE MAGAZINE IS REMOVED FROM THE PISTOL AND THERE IS A LOADED ROUND IN THE CHAMBER, IT WILL FIRE IF THE TRIGGER IS PULLED, AFTER INSERTING A MAGAZINE, ALWAYS TEST TO MAKE SURE IT IS LOCKED IN PLACE BY APPLYING SOME REMOVAL PRESSURE TO THE EXPOSED PORTION OF THE MAGAZINE BUTT PLATE.

WARNING: YOUR PISTOL IS NOW READY TO FIRE. KEEP YOUR FINGER OFF THE TRIGGER AND OUT OF THE TRIGGER GUARD UNTIL YOU ARE READY TO FIRE





6. Decocking



WARNING: KEEP THE PISTOL POINTING IN A SAFE DIRECTION WITH THE SAFE-TY IN THE SAFE POSITION WHEN DECOCKING. FAILURE TO DO THIS CAN RESULT IN SERIOUS INJURY OR DEATH.

- If you decide not to fire and the hammer is in the cocked position, keep the pistol pointed in a safe direction.
- Remove your finger from within the trigger guard.
- Place the manual safety in the SAFE position (fig. 11)
- Hold the hammer securely with your thumb, lightly pull the trigger and lower the hammer slowly forward (fig.12).
- The pistol may now be holstered and carried safely. Keep the manual safety in the SAFE position.









7. Traditional Double Action / Single Action

Single Action - shorter, lighter trigger pull that can be used for continuous firing.

 keep muzzle pointed in a safe direction and your finger outside the trigger guard, place the manual safety in the fire position, the first shot may be fired in the single action mode when so desired.

Double action - Pistol can be safely carried in double action mode by decocking the hammer with a round in the chamber as described in section 6 Decocking.

- keep muzzle pointed in a safe direction and your finger outside the trigger guard, place the manual safety in the fire position.
- As the trigger is pulled fully to the rear, the hammer moves rearward and is released to strike the firing pin.

Upon firing, the slide moves rearward thereby extracting and ejecting the spend cartrige case and rotating the hammer to the fully cocked position.

7. TRADITIONAL DOUBLE ACTION / SINGLE ACTION 8. UNLOADING THE PISTOL

WARNING: IN THE SINGLE ACTION OR DOUBLE ACTION MODE YOUR PISTOL IS NOW READY TO FIRE. LEAVE YOUR FINGER OFF THE TRIGGER AND OUT OF THE TRIGGER GUARD UNTIL YOU ARE READY TO FIRE.

- The slide then returns forward feeding the next cartrige from the magazine to the barrel chamber. The hammer remains in the cocked position so that subsequent shots will be fired in the single action mode. This sequence can be repeated until the last round has been fired at which time the magazine follower exerts upward pressure on the internal slide stop causing it to engage the slide and hold it in the open position.

8. Unloading the pistol

Point the muzzle in a safe direction. Place the manual safety in the safe position. Remove the magazine. Ensure that the chamber is empty by pulling back on the slide to visually inspect the chamber (fig. 13). Keep firearm pointed in a safe direction. Hold the hammer securely with your thumb, lightly pull the trigger and lower the hammer slowly forward.

WARNING: KEEP THE PISTOL POINTING IN A SAFE DIRECTION WHEN UNLOADING. FAILURE TO DO THIS CAN RESULT IN SERIOUS INJURY OR DEATH.





9. Reloading the Pistol

After the last round has been fired, the internal slide stop holds the slide in the open position (fig. 14). Place the manual safety in the safe position.

Continue shooting - Replace the empty magazine with a full one. Pull slide reward and release (fig. 10), the slide will travel forward and load the chamber with the first round. Keep your pistol in your shooting hand, finger off the trigger and pointed in a safe direction.



THE PISTOL IS NOW READY TO FIRE, LEAVE YOUR FINGER OFF THE TRIGGER AND OUT OF THE TRIGGER GUARD UNTIL YOU ARE READY TO FIRE



No more shooting - Remove magazine and inspect the chamber to verify it does not contain any ammunition (fig. 13).

Close the slide and follow the unloading procedure detailed in chapter 8.



A WARNING: MAKE A VISUAL INSPECTION OF THE BARREL CHAMBER - IT MUST NOT CONTAIN ANY AMMUNITION (FIG. 13)!

10. Clearing misfires

IF YOUR FIREARM GIVES ANY INDICATION THAT IT IS NOT PERFORMING PRO-PERLY OR THE OPERATION OF YOUR FIREARM HAS CHANGED "THE WAY IT

FEELS OR SOUNDS", STOP FIRING, MAKE SURE THE FIREARM IS POINTED IN A SAFE DIRECTION, UNLOAD THE FIREARM AND HAVE IT INSPECTED AND TEST FIRED BY A GUNSMITH QUALIFIED TO PERFORM SERVICE ON WALTHER ARMS FIREARMS.

- If a cartridge fails to fire, wait 10 seconds while keeping the muzzle pointed in a safe direction.
- Keep your finger off the trigger and out of the trigger guard.
- Remove the magazine. Place the manual safety in the safe position
- Grasp the slide and briskly pull it fully rearward to eject the misfired round. Check the barrel chamber and bore visually for any obstructions.
- You must be certain there are no cartridges in the chamber or obstructions in the barrel. Remember that any time you release the slide while a magazine containing cartridges is in the pistol, you will have reloaded the pistol and it will be capable of firing.

WARNING: NEVER TRY TO USE A MISFIRED CARTRIGE AGAIN.

11. Disassembling and assembling the pistol

WARNING:

ALWAYS KEEP THE BARREL POINTED IN A SAFE DIRECTION.

AWARNING:


ALWAYS FOLLOW THE FIELD STRIPPING INSTRUCTIONS EXACTLY. NEVER DO ANYTHING BEYOND WHAT YOU ARE SPECIFICALLY INSTRUCTED TO DO IN THIS MANUAL. NEVER ALTER OR MODIFY THE PARTS IN YOUR PISTOL

A WARNING:

WEAR SAFETY GLASSES EVERY TIME YOU ASSEMBLE OR DISASSEMBLE YOUR FIREARM.

A WARNING:


DO NOT ALTER. MODIFY OR REPLACE ANY OF THE PARTS OF YOUR FIREARM LINESS THIS WORK IS PERFORMED BY A QUALIFIED GUNSMITH USING GENUINE WALTHER PARTS. IF YOU DO OTHERWISE, IMPROPER FUNCTIONING MAY OCCUR AND SERIOUS INJURY, DEATH OR DAMAGE TO PROPERTY MAY RESULT.





Put hammer in de-cocked position. Insert key into the takedown release hole (Fig 15). Check to make sure the takedown lever is in the up position. Rotate key counter clock wise 135 degrees (Fig 16). After key rotation pull takedown lever straight down (Fig 17). Slowly pull slide with the harrel (Fig 18). Put hammer in the rest position. Reinstall slide and barrel (Fig 19). Push take down lever up (Fig 20). Rotoate key clock wise 135 degrees (Fig 21). Remove key (Fig 22).

















12 Cleaning

In order to keep the pistol functional and to extend its service life, the Walther Arms PK 380 should be cleaned and maintained at regular intervals.

WARNING: PLACE THE MANUAL SAFETY IN THE SAFE POSITION, REMOVE THE MAGAZINE, OPEN THE SLIDE, AND INSPECT THE CHAMBER TO MAKE

SURE IT DOES NOT CONTAIN ANY AMMUNITION!

Disassemble the pistol; Remove fouling from breech, magazine lips, follower, and receiver with a brush and a cloth (fig. 23). Clean the barrel with an appropriate gun cleaning solvent and then dry it with cleaning patches; always begin at the chamber. Repeat until barrel is clean. Apply a thin coat of oil to all metal parts. Reassemble pistol and check for proper function.



13 Storage

A WARNING:

NEVER LEAVE A LOADED FIREARM UNATTENDED AND NEVER STORE YOUR FIREARM IN A LOADED POSITION.

Always store your pistol in an unloaded condition with the safety in the safe position. Keep the pistol and ammunition away from children and unauthorized persons. Firearms should be stored separately from ammunition.

14 Repair of Walther Arms Pistols



CAUTION

A FIREARM WHICH FAILS TO FUNCTION PROPERLY IS DANGEROUS. IT SHOULD BE SAFELY STORED IN A WAY THAT PREVENTS ITS USE LINTIL IT IS REPAIRED



ONLY AN AUTHORIZED AND QUALIFIED GUNSMITH SHOULD INSPECT AND REPAIR YOUR FIREARM!



15. Accessories



laser art.-no.: 2.1130

Walther Arms laser

The laser was developed especially for the PK380 and is designed to be a perfect fit. The quick-release catch allows the laser to be mounted or removed instantly without the need for additional tools. LEDs on either side of the laser, illuminate indicating that the laser is on. Standard equipment incl. batteries and adjustment wrench.



16. WARRANTY

WALTHER ARMS warrants that the enclosed firearm was originally manufactured free of defects in material, workmanship and mechanical function.

LIMITED ONE YEAR WARRANTY

This firearms is warranted to the original owner for one (1) year from date of purchase against defects in material and workmanship and is not transferable.

WHAT IS COVERED

Replacement parts and labor.

WHAT IS NOT COVERED

Parts, labor, and shipping charges to WALTHER ARMS for defective product and damages caused by abuse or failure to perform normal maintenance as well as any other expense. Consequential damages, or incidental expenses, including damage to property. WALTHER ARMS will not be responsible for unauthorized adjustments or modifications, use of defective or improper ammunition, corrosion, criminal misuse, negligence, resale, careless handling, and/or use under the influence of drugs or alcohol. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. WALTHER ARMS reserves the right to determine what constitutes ordinary wear and tear.

WARRANTY CLAIMS

Warranty Claims and Repair for U.S. customers. Call WALTHER ARMS (479)-242-8500 and ask for the Service Department. If it is determined a return is necessary, you will be issued a Firearm Return Authorization Number. Write this number boldly on the box and return the product prepaid to WALTHER ARMS. Your name, address, phone number and a note with the model name/number, serial number, and explanation of the defect found must be included with the firearm. A copy of the original dated cash register receipt, or a copy of ATF Form 4473, indicating date of purchase must accompany the return.

16. WARRANTY



IMPLIED WARRANTIES

Any implied warranties, including the implied warranties of merchantability and fitness for a particular purpose, are limited in duration to one (1) year from date of retail purchase, SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS. SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU, TO THE EXTENT ANY PROVISION OF THIS WARRANTY IS PROHIBITED BY FEDERAL STATE, OR MUNICIPAL LAW. WHICH CANNOT BE PREEMPTED. IT SHALL NOT BE APPLICABLE. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. AND YOU MAY ALSO HAVE OTHER RIGHTS. WHICH VARY FROM STATE TO STATE AND COUNTRY TO COUNTRY

LINDER NO CIRCUMSTANCES SHALL WALTHER ARMS AND CARL WALTHER GMRH BE RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES WITH RESPECT TO ECONOMIC LOSS. INJURY. DEATH OR PROPERTY DAMAGE, WHETHER AS A RESULT OF BREACH OF THIS WARRANTY, NEGLIGENCE OR OTHER-WISF



WARNING: WHEN TRANSPORTING A FIREARM, MAKE SURE THAT IT IS UNLOADED AND THAT THE SAFETY IS IN THE SAFE POSITION.

Note: All liability is excluded in the event that the instructions and warnings in this manual are not observed

CONTACT & SHIPPING

For Owners within the United States

WALTHER ARMS. Inc.

Attn: Service Dept Phone: 1-479-242-8500


7700 Chad Colley Boulevard F-mail· service@waltherarms.com

Fort Smith AR 72916 www WaltherArms com



- Call or e-mail the Customer Service Dept. for authorization and shipping instructions.
- ENSURE THAT THE FIREARM IS UNLOADED.
- DO NOT SHIP ANY AMMUNITION.
- Enclose a letter which includes your full name and address (no P.O. Boxes, please), daytime telephone number, e-mail address, the serial number of the firearm, and details of the problem experienced (stating the brand and type of ammunition used when the problem occurred) or work desired.
- Record the serial number before shipping and retain in a secure place.
- Please remove all custom parts and accessories, such as stocks, special sights, or holsters from your firearm before returning.
- Place the handgun in its original case or in a similarly secure container and pack securely.
- When returning a pistol, please include all magazines ensuring they are unloaded; they
 are important to the proper function of the handgun.
- The package must NOT bear any markings which indicate the identity of the contents.
- It is most important that you comply with federal, state, and local laws and regulations.
 The following guidelines are meant to help, but you must seek assistance from the appropriate authorities if necessary.
- Do not attempt to ship a handgun via US Postal Service; only federally licensed dealers may ship a firearm by US Postal Service.





WARNING THIS HANDGUN IS NOT EQUIPPED WITH A DEVICE THAT FULLY BLOCKS USE BY UNAUTHORIZED USERS. MORE

THAN 200,000 FIREARMS LIKE THIS ONE ARE STOLEN FROM THEIR OWNERS EVERY YEAR IN THE UNITED STATES. IN ADDITION, THERE ARE MORE THAN A THOUSAND SUICIDES EACH YEAR BY YOUNGER CHILDREN AND TEENAGERS WHO GET ACCESS TO FIREARMS. HUNDREDS MORE DIE FROM ACCIDENTAL DISCHARGE. IT IS LIKELY THAT MANY MORE CHILDREN SUSTAIN SERIOUS WOUNDS OR INFLICT SUCH WOUNDS ACCIDENTALLY ON OTHERS. IN ORDER TO LIMIT THE CHANCE OF SUCH MISUSE, IT IS IMPERATIVE THAT YOU KEEP THIS WEAPON LOCKED IN A SECURE PLACE AND TAKE OTHER STEPS NECESSARY TO LIMIT THE POSSIBILITY OF THEFT OR ACCIDENT. FAILURE TO TAKE REASONABLE PREVENTATIVE STEPS MAY RESULT IN INNOCENT LIVES BEING LOST, AND IN SOME CIRCUMSTANCES MAY RESULT IN YOUR LIABILITY FOR THESE DEATHS.



WALTHER ARMS, INC.

7700 CHAD COLLEY BOULEVARD FORT SMITH, AR 72916 PHONE: 1-479-242-8500

JAL7HE

Copyright © 2012 · Carl Walther GmbH · All rights reserved · Subject to change without notice.

8.505.82.01-10.2012 Rev.A