



# Freon™ M099

Refrigerant

## 8 Basic Steps to Retrofit from R-22 to Freon™ M099 Refrigerant

### Quick Switch Pocket Retrofit Guide



**Chemours™**

**STEP 1:** Review Freon™ MO99 retrofit guidelines, available on [freon.com](http://freon.com).



**STEP 2:** Check baseline performance of R-22 system.



**STEP 3:** Remove R-22 refrigerant from the system.



**STEP 4:** Remove old filter drier, and replace with a new filter drier.



**STEP 5:** Replace Schrader valve core seals.



**STEP 6:** Pull vacuum on the system.



**STEP 7:** Charge system with Freon™ M099, and check system performance.





**STEP 8:** Add the Freon™ MO99 label, and you're done!



For Freon™ MO99 retrofit guidelines, retrofit success stories, and product information, visit: [freon.com](http://freon.com).



For more information on Freon™, or other refrigerants from Chemours, please contact your local representative.

The Chemours Company  
1007 Market Street  
Wilmington, DE 19899  
Tel: 800-235-7882

[freon.com](http://freon.com)

The information set forth herein is furnished free of charge and based on technical data that Chemours believes to be reliable. It is intended for use by persons having technical skill, at their own risk. Because conditions of use are outside our control, Chemours makes no warranties, expressed or implied, and assumes no liability in connection with any use of this information. Nothing herein is to be taken as a license to operate under, or a recommendation to infringe, any patents or patent applications.

© 2015 The Chemours Company FC, LLC. Freon™ and any associated logos are trademarks or copyrights of The Chemours Company FC, LLC. Chemours™ and the Chemours Logo are trademarks of The Chemours Company.

Replaces: K-23356-4  
C-10272 (9/15)