

HBF Hickory, NC 28601
828-328-2064

ASSEMBLY INSTRUCTIONS

POWER INFEED CABLE / WIRE CLIP / LEG ASSEMBLY INSTRUCTIONS

GENERAL NOTES

- 1.) REPORT DAMAGE BEFORE PROCEEDING.
- 2.) ALWAYS PROTECT THE WORKSURFACE DURING INSTALLATION.
- 3.) ALWAYS LEVEL UNIT AT FINAL LOCATION
- 4.) THESE INSTRUCTIONS ARE FOR A COSTA TABLE LEG IN WHICH A POWER INFEED CABLE IS BEING INSTALLED ONLY.

ATTACH WIRE CLIP TO LEG

STEP 1) REMOVED COVER ON LEG IN WHICH POWER INFEED CABLE IS TO BE INSTALLED.

STEP 2) SECURE CABLE IN PLACE USING WIRE CLIP (P/N: A1907-3002-24) INTO .25" DIA HOLES AT THE TOP AND BOTTOM OF THE LEG POST. MAKE SURE CLIP IS SEATED FULLY INTO THE .25" DIA HOLES AND WILL NOT POP OUT.



P/N: A1907-3002-24



WRAP THE WIRE CLIP AROUND THE CONDUIT BEFORE INSERTING INTO THE POST

RE-ATTACH LEG COVER

STEP 3) RE-ATTACH LEG COVER (SHOW WITH HARD-WIRED CABLE VERSION).

