



# 2018 TELEHANDLER PARTS REFERENCE GUIDE

**BUILT FOR IT.™**




# PROTECT YOUR INVESTMENT WITH GENUINE CAT® PARTS

Thank you for selecting the Cat® Telehandler.

This guide is designed to provide you with a quick reference for the parts and part numbers you need to keep your Cat Telehandler running at peak efficiency.



### MAINTENANCE

Proactive preventative maintenance extends the life of your machine and protects your investment. Only Caterpillar knows Cat equipment’s filtration and lubrication requirements and offers parts to match your machine’s maintenance cycles.

SCHEDULED MAINTENANCE PARTS	
	GREASES
	PLANNED MAINTENANCE PARTS

### REPLACEMENT PARTS

Proper maintenance minimizes the need for repair and replacement. In the event that replacement parts are required, the use of genuine Cat parts helps maximize machine performance and maintains high resale value.

WEAR PARTS	
	BATTERY
	WEARPAD SHIMS
REPAIR PARTS	
	CAB GLASS
	MIRRORS AND LIGHTS
	ENGINE PARTS
	QUICK DISCONNECTS

### GREASES

Product Name	Cat Extreme Application Grease - 1 (5 Moly #1)	Cat Extreme Application Grease - 2 (5 Moly #2)	Cat Prime Application Grease (3 Moly)	Cat Extreme Application Grease - Arctic (Platinum)	Cat Extreme Application Grease - Desert (Gold)	Cat Utility Grease (Multipurpose)	Cat Ball Bearing Grease	Hammer Paste
Grade (NLGI)	1	2	2	0	2	2	2	2
Melting point (deg C)	260	260	260	230	280	260	260	230
Ambient Temperature (deg C)	-35 to +40	-30 to +50	-20 to +40	-35 to +40	-30 to +50	-30 to +40	-20 to +40	-20 to +1100
Base Oil Type	Mineral	Mineral	Mineral	Semi-Synthetic	Mineral	Mineral	Mineral	Mineral
Color	Dark Grey	Dark Grey	Dark Grey	Dark Grey	Dark Grey	Blue	Blue-Green	Bronze
Cartridge (390 g / 14 oz)	452-5996	452-6001	452-6006	508-2184	452-6016	452-6011	454-0291	130-6951 (standard) 317-8491 (autolube)
Plastic Pail (5 kg / 11 lb)	-	-	-	-	-	-	-	133-8807
Plastic Pail (16 kg / 35 lb)	452-5999	452-6004	452-6009	508-2187	452-6019	452-6014	-	-
Keg (55 kg / 120 lb)	452-5998	452-6003	452-6008	508-2186	452-6018	452-6013	-	-
Drum (180 kg / 400 lb)	452-5997	452-6002	452-6007	508-2185	452-6017	452-6012	-	-



# PLANNED MAINTENANCE PARTS

TH D SERIES				FIRST 250 HOURS													EVERY 500 HOURS							EVERY 750 HOURS			
				Transmission Oil Change			Transfer Case Fluid	Front Differential Oil Change			Front Final Drive Oil Change (each side)		Rear Differential Oil Change			Rear Final Drive Oil Change (each side)		Engine Oil/Filter Change		Fuel Filter Change			Lubricate Machine	Cabin Air		Hydraulic Oil/Filter Change	Hydraulic Tank
Sales Model	Serial Number	Engine	Engine Serial Number Prefix	Filter Change	Oil Qty (L)	Breather	Oil Qty (L)	Oil Qty (L)	Plug (w/ sealing washer)	Friction Modifier	Oil Qty (L)	Plug (w/ sealing washer)	Oil Qty (L)	Plug (w/ sealing washer)	Friction Modifier	Oil Qty (L)	O-Ring	Filter Number	Oil Qty (L) DEO-ULS™	Primary (In-Line)	Fuel Filter	Fuel Water Separator Element	Prime App Grease	Recirculating Element	Fresh Air Element	Filter Element	Breather
TH357D TH408D TH3510D	TD6 TH9 TH3	4.4	JKT	471-7003	14	9G-5127	2.75	6.15*	304-2241	197-0017*	1.6	299-7170	7.5*	304-2241	197-0017*	1.6	299-7170	7W-2326	9	472-1149	472-1148	384-8512	360-8960	479-4133	481-6649	481-6649	473-9271
		3.4	CJ4, CN5	471-7003	14	9G-5127	2.75	6.15*	304-2241	197-0017*	1.6	299-7170	7.5*	304-2241	197-0017*	1.6	299-7170	441-6852	8.8	472-1149	472-1148	-	360-8958	311-3901	481-6649	481-6649	-

TH D SERIES				EVERY 1,000 HOURS													EVERY 1,500 HOURS				EVERY 2,000 HOURS					
				Cabin Air		Auxiliary Drive Belt		Transmission Oil Change			Transfer Case Fluid	Front Differential Oil Change			Front Final Drive Oil Change (each side)		Rear Differential Oil Change			Rear Final Drive Oil Change (each side)		Def Pump Filter	Engine Coolant	Engine Breather	Hydraulic Oil	DEF Tank Filter
Sales Model	Serial Number	Engine	Engine Serial Number Prefix	Recirculating Element	Fresh Air Element	With AC	Without AC	Filter Change	Oil Qty (L)	Breather	Oil Qty (L)	Oil Qty (L)	Plug (w/ sealing washer)	Friction Modifier	Oil Qty (L)	Plug (w/ sealing washer)	Oil Qty (L)	Plug (w/ sealing washer)	Friction Modifier	Oil Qty (L)	O-ring	Filter Element	Coolant (L)	Engine crankcase breather	Oil Qty (L)	Filter
TH357D TH408D TH3510D	TD6 TH9 TH3	4.4	JKT	528-8853	473-2651	365-2985	286-7845	471-7003	14	9G-5127	2.75	6.15*	304-2241	197-0017*	1.6	299-7170	7.5*	304-2241	197-0017*	1.6	299-7170	466-8288	22.6	339-1048	97	461-9113
		3.4	CJ4, CN5	528-8853	473-2651	365-2985	422-0655	471-7003	14	9G-5127	2.75	6.15*	304-2241	197-0017*	1.6	299-7170	7.5*	304-2241	197-0017*	1.6	299-7170	466-8288	22.6	481-3598	97	461-9113

The 1,000 hour and 1,500 hour services include the 500 hour interval parts. \*If axle fluid does not contain LS Additives, up to 5% Friction Modifier must be added. Reduce oil by 5% to accommodate. Pre-Mix before placing in axle. See Service Manual for details.

TH 255C SERIES				FIRST 250 HOURS						EVERY 500 HOURS				EVERY 1,000 HOURS										EVERY 1,500 HOURS						
				Front Axle Drop Box		Differential Oil Change		Final Drive Oil Change (x4)		Engine Oil/Filter Change		Air Filter		Fuel Filter Change		Cabin Air	Auxiliary Drive Belt		Front Axle Drop Box		Differential Oil Change			Final Drive Oil Change (x4)		Hydraulic Filter Change		Hydraulic Oil	Engine Coolant	
Sales Model	Serial Number	Engine	Engine Serial Number Prefix	Plug (w/ sealing washer)	Oil Qty (L)	Oil Qty (L)	Plug (w/ sealing washer)	Friction Modifier	Oil Qty (L)	Plug (w/ sealing washer)	Filter Element	Oil Qty (L)	Primary Element	Secondary Element	Fuel Filter	Fuel Water Separator Element	Filter Element	With AC	Without AC	Plug (w/ sealing washer)	Oil Qty (L)	Oil Qty (L)	Plug (w/ sealing washer)	Friction Modifier	Oil Qty (L)	Plug (w/ sealing washer)	Small	Large	Oil Qty (L)	Coolant (L)
TH255C	JK2	Deutz TD 2.9 L4	-	322-0771	0.6	3.3	322-0771	197-0017*	0.7	299-7170	440-6232	7.1	428-7984	428-7985	440-6213	466-4177	340-7564	447-1420	449-2389	322-0771	0.6	3.3	322-0771	197-0017*	0.7	299-7170	126-1815	465-6502	103	13.2

The 1,000 hour and 1,500 hour services include the 500 hour interval parts. \*If axle fluid does not contain LS Additives, up to 5% Friction Modifier must be added. Reduce oil by 5% to accommodate. Pre-Mix before placing in axle. See Service Manual for details.



# PLANNED MAINTENANCE PARTS

			FIRST 250 HOURS										FIRST 500 HOURS					EVERY 500 HOURS						
TL D SERIES			Front Differential Oil Change			Front Final Drive Oil Change (each side)		Rear Differential Oil Change			Rear Final Drive Oil Change (each side)		Transmission Oil Change			Transfer Case Fluid	Engine Oil/Filter Change		Fuel Filter Change			Air Filter		
Sales Model	Serial Number	Engine Serial Number Prefix	Oil Qty (L)	Plug (w/ sealing washer)	Friction Modifier	Oil Qty (L)	Plug (w/ sealing washer)	Oil Qty (L)	Plug (w/ sealing washer)	Friction Modifier	Oil Qty (L)	O-Ring	Filter Change	Oil Qty (L)	Breather	Oil Qty (L)	Filter Element	Oil Qty (L) DEO-ULSTM	Primary (In Line)	Fuel Filter	Fuel Water Separator Element	Primary Element	Secondary Element	
642D	ML8	CJ4, CN5	7.2	304-2241	197-0017*	1.1	299-7170	6.7	304-2241	197-0017*	1.3	299-7170	299-0900	17	9G-5127	3.2	441-6852	8.3	-	360-8958	311-3901	472-1149	472-1148	
943D	MLJ	CJ4, CN5	12.5	322-0771	197-0017*	1.6	299-7170	12.1	322-0771	197-0017*	1.6	299-7170	299-0900	17	9G-5127	3.2	441-6852	8.3	-	360-8958	311-3901	472-1149	472-1148	
1055D	ML5	JKT	14.2	322-0771	197-0017*	1.7	299-7170	13.2	322-0771	197-0017*	1.4	299-7170	299-0900	17	9G-5127	3.2	7W-2326	8.1	384-8512	360-8960	363-6572	473-1345	473-1344	
1255D	ML7	JKT	14.2	322-0771	197-0017*	1.7	299-7170	13.2	322-0771	197-0017*	1.4	299-7170	299-0900	17	9G-5127	3.2	7W-2326	8.1	384-8512	360-8960	363-6572	473-1345	473-1344	

			EVERY 750 HOURS		EVERY 1,000 HOURS																		EVERY 1,500 HOURS				EVERY 2,000 HOURS
TL D SERIES			Hydraulic Filter Change	Hydraulic Tank	Drive Belt		Cabin Air		Transmission Oil Change			Transfer Case Fluid	Front Differential Oil Change			Front Final Drive Oil Change (each side)		Rear Differential Oil Change			Rear Final Drive Oil Change (each side)		Def Pump Filter	Hydraulic Oil	Engine Breather	Engine Coolant	DEF Tank Filter
Sales Model	Serial Number	Engine Serial Number Prefix	Filter Element	Breather	With AC	Without AC	Oil Qty (L)	Plug (w/ sealing washer)	Filter Change	Oil Qty (L)	Breather	Oil Qty (L)	Oil Qty (L)	Plug (w/ sealing washer)	Friction Modifier	Oil Qty (L)	Plug (w/ sealing washer)	Oil Qty (L)	Plug (w/ sealing washer)	Friction Modifier	Oil Qty (L)	O-Ring	Filter Element	Oil Qty (L)	Engine Crankcase Breather	Coolant (L)	Filter
642D	ML8	CJ4, CN5	481-6649	473-9271	365-2985	422-0655	473-2650	473-2651	299-0900	17	9G-5127	3.2	7.2	304-2241	197-0017*	1.1	299-7170	6.7	304-2241	197-0017*	1.3	299-7170	466-8288	152	481-3598	22.6	461-9113
943D	MLJ	CJ4, CN5	481-6649	473-9271	365-2985	422-0655	473-2650	473-2651	299-0900	17	9G-5127	3.2	12.5	322-0771	197-0017*	1.6	299-7170	12.1	322-0771	197-0017*	1.6	299-7170	466-8288	176	481-3598	22.6	461-9113
1055D	ML5	JKT	481-6649	473-9271	365-2985	286-7845	473-2650	473-2651	299-0900	17	9G-5127	3.2	14.2	322-0771	197-0017*	1.7	299-7170	13.2	322-0771	197-0017*	1.4	299-7170	466-8288	184	339-1048	22.6	461-9113
1255D	ML7	JKT	481-6649	473-9271	365-2985	286-7845	473-2650	473-2651	299-0900	17	9G-5127	3.2	14.2	322-0771	197-0017*	1.7	299-7170	13.2	322-0771	197-0017*	1.4	299-7170	466-8288	189	339-1048	22.6	461-9113

The 1,000 hour and 1,500 hour services include the 500 hour interval parts. \*If axle fluid does not contain LS Additives, up to 5% Friction Modifier must be added. Reduce oil by 5% to accommodate. Pre-Mix before placing in axle. See Service Manual for details.

			FIRST 250 HOURS														EVERY 500 HOURS								EVERY 750 HOURS		
TH 514 D SERIES			Transmission Oil Change			Transfer Case Fluid	Front Differential Oil Change			Wheel End Oil (each side)		Fuel Filter Change		Rear Differential Oil Change			Rear Final Drive Oil Change		Engine Oil/Filter Change		Air Filter		Fuel Filter Change			Hydraulic Filter Change	Hydraulic Tank
Sales Model	Serial Number	Engine Serial Number Prefix	Filter Change	Oil Qty (L)	Breather	Oil Qty (L)	Oil Qty (L)	Plug (w/ sealing washer)	Friction Modifier	Oil Qty (L)	Plug (w/ sealing washer)	Fuel Filter	Fuel Water Separator Element	Oil Qty (L)	Plug (w/ sealing washer)	Friction Modifier	Oil Qty (L)	O-Ring	Filter Element	Oil Qty (L)	Primary Element	Secondary Element	Primary (In Line)	Fuel Filter	Fuel Water Separator Element	Filter Element	Breather
TH514D	MWG	CJG	471-7003	16.1	9G-5127	2.8	6.2	304-2241	197-0017*	1.6	385-3599	6.6	304-2241	197-0017*	1.6	299-7170	1.3	299-7170	441-6852	8	472-1149	472-1148	-	360-8958	311-3901	481-6649	473-9271

			EVERY 1,000 HOURS																		EVERY 1,500 HOURS				EVERY 2,000 HOURS
TH 514 D SERIES			Drive Belt		Cabin Air		Transmission Oil Change			Transfer Case Fluid	Front Differential Oil Change			Wheel End Oil (each side)		Rear Differential Oil Change			Rear Final Drive Oil Change		Def Pump Filter	Engine Breather	Hydraulic Oil	DEF Tank Filter	
Sales Model	Serial Number	Engine Serial Number Prefix	With AC	Without AC	Recirculating Element	Fresh Air Element	Filter Change	Oil Qty (L)	Breather	Oil Qty (L)	Oil Qty (L)	Plug (w/ sealing washer)	Friction Modifier	Oil Qty (L)	Plug (w/ sealing washer)	Oil Qty (L)	Plug (w/ sealing washer)	Friction Modifier	Oil Qty (L)	O-Ring	Breather	Engine Crankcase Breather	Oil Qty (L)	Filter	
TH514D	MWG	CJG	365-2985	422-0655	473-2650	473-2651	471-7003	16.1	9G-5127	2.8	6.2	304-2241	197-0017*	1.6	385-3599	6.6	304-2241	197-0017*	1.6	299-7170	481-3374	481-3598	160	461-9113	

The 2,000 hour interval includes the 1,000 hour and 500 hour. The 1,500 hour interval includes the 750 hour. 1,000 hour interval includes the 500 hour. \*If axle fluid does not contain LS Additives, up to 5% Friction Modifier must be added. Reduce oil by 5% to accommodate. Pre-Mix before placing in axle. See Service Manual for details.

# BATTERIES

Machine Model	Battery Part Number	Voltage	CCA (Amps)	Type	Length (mm)	Width (mm)	Height (mm)
TL D Series	175-4390	12	1000	Wet	324	163	236
TH D Series	175-4390	12	1000	Wet	324	163	236
TH255C	115-2422	12	1000	Wet	324	163	240

# WEARPAD SHIMS

Machine Model	Section	Wear Pad	Quantity	Spacer	Quantity	Shim	Quantity	
TH 357D TH 408D	Boom Section 1 (outer)	459-1954	4 (upper top & side)	459-1953	4	-	-	
		499-2172	2 (bottom)	-	-	-	-	
	Boom Section 2 (inner)	513-3276	2 (upper rear)	459-1976	2	513-3277	2	
		459-1954	2 (upper rear)	459-1953	2	553-6981	2	
		513-3278	1 (bottom)	-	-	-	-	
TH 3510D	Boom Section 1 (outer)	459-1954	4 (upper top & side)	459-1953	4	-	-	
		499-2172	2 (bottom)	-	-	-	-	
	Boom Section 2 (intermediate)	459-1954	4 (front top & Side)	459-1953	4	459-1976	4	
		459-1954	2(front bottom)	-	-	-	-	
		459-4310	2 (rear top)	459-3542	2	459-3543	2	
		459-1954	2 (rear outer top)	459-1953	2	459-1976	2	
	Boom Section 3	495-7758	2 (rear bottom)	-	-	-	-	
		459-1954	4 (upper top & side)	459-1953	4	-	-	
	TH 514D	Boom Section 1	476-7677	6	474-1584	1 per	-	-
					476-7685	as needed	-	-
476-7680			2 (lower front only)	485-1669	2 per	-	-	
Boom Section 2		476-7677	10	-	-	485-7365	1 per	
		476-7680	2 (upper rear only)	-	-	-	-	
		485-7364	2 (bottom rear only)	-	-	-	-	
Boom Section 3 (Head)		476-7677	8	474-1584	1 per	-	-	
				476-7685	as needed (top only)	-	-	
TH 255C		Boom Section 1 (outer)	309-6295	6	309-6300 (1.9mm)	6	317-3293 (.036 in)	6
			309-6297	2	309-6293 (.075 mm)	2	317-3292 (.036 in)	2
	Boom Section 2 (inner)	309-6297	2	309-6293 (.075 mm)	-	-	-	
		309-6295	2	309-6300 (1.9mm)	-	-	-	
		309-6258	2 (rear bottom)	-	-	-	-	
TL 642D	Boom Section 1	474-1546	4	480-9034 (upper only)	2 per	-	-	
				474-1885 (bottom only)	2 per	-	-	
				474-1584	2 per	-	-	
	Boom Section 2	474-1906	4	474-1914	1 per	-	-	
				474-1584	1 per (bottom only)	-	-	
		474-1906	8	480-9034	2 per (bottom only)	-	-	
				474-1914	1 per	-	-	
		474-1608	2 (upper rear only)	480-9042	2 per	-	-	
				474-1595	1 per	-	-	
	480-9033			2 (lower rear only)	480-9038	2 per	480-9039	1 per
	Boom Section 3 (Head)	474-1546	2 (upper rear only)	-	-	-	-	
				474-1906	2 (upper rear only)	474-1914	1 per	-
				480-9033	2 (lower rear only)	482-6406	2 per	480-9039
TL 943D	Boom Section 1	474-1546	2 (upper only)	474-1584	1 per	-	-	
				480-9034	2 per	-	-	
		474-1906	4	474-1914	1 per	-	-	
				474-1585	1 per	-	-	
		474-1544	2 (lower only)	483-7786	2 per	-	-	

Machine Model	Section	Wear Pad	Quantity	Spacer	Quantity	Shim	Quantity
TL 943D (cont.d)	Boom Section 2	474-1546	4 (front)	474-1584	1 per	-	-
				480-9034 (bottom only)	2 per	-	-
		474-1906	8	474-1914	1 per	-	-
		474-1544	2 (upper rear)	474-8417	2 per	-	-
				474-1585	1 per	-	-
		480-9033	2	480-9038	2 per	480-9039	1 per
	Boom Section 3 (Head)	474-1546	2 (upper only)	-	-	-	-
				474-1906	2	474-1914	1 per
		480-9033	2	482-6406	2 per	480-9039	1 per
				-	-	-	-
TL 1055D	Boom Section 1	474-1546	6	474-1584	1 per	-	-
				474-1585	1 per	-	-
		474-1544	2 (bottom only)	474-1545	2 per	-	-
	Boom Section 2	474-1546	6	474-1584	1 per	-	-
				474-1610	4	474-1602	1 per
		474-1608	2 (lower front only)	474-1599	1 per	-	-
				474-1544	2 (rear upper only)	474-1585	1 per
	Boom Section 3	474-1546	8	474-1912	2 - 1 per (upper front only)	-	-
				474-1584	8 (lower front only)	-	-
				474-1887	2 - 1 per (lower front only)	-	-
474-1885				2 - 1 per (lower rear only)	474-1886	1 per	
474-1608		2 (rear upper only)	474-1599	1 per	-	-	
			474-1595	1 per	-	-	
			474-1906	4 (front only)	474-1914	1 per	493-3316
Boom Section 4 (Head)	474-1546	2 (lower rear only)	474-1887	1 per	-	-	
			474-1584	1 per	474-1886	1 per	
	474-1906	2 (upper inside only)	474-1914	1 per	-	-	
			474-1608	2 (upper only)	474-1595	1 per	-
TL 1255D	Boom Section 1	474-1546	6	474-1584	1 per	-	-
				474-1544	2 (bottom only)	474-1585	1 per
		474-1545	2 per	-	-		
	Boom Section 2	474-1546	6	474-1584	1 per	-	-
				474-1610	4	474-1602	1 per
		474-1608	2 (lower front only)	474-1599	1 per	-	-
				474-1544	2 (rear upper only)	474-1585	1 per
	Boom Section 3	474-1546	8	474-1885	4 - 1 per	474-1886	1 per
				474-1584	4 - 1 per	-	-
				474-1887	1 per (bottom front only)	-	-
474-1608		2 (rear upper only)	474-1599	1 per	-	-	
			474-1595	1 per	-	-	
Boom Section 4 (Head)	474-1906	4 (front only)	474-1914	1 per	493-3316	1 per	
			474-1887	1 per	-	-	
	474-1546	2 (lower rear only)	474-1584	2 per	474-1886	1 per	
			474-1906	2 (upper inside only)	474-1914	1 per	493-3316
	474-1608	2 (upper only)	474-1595	2 per	-	-	
474-1937	1 (upper rear only)	-	-	-	-		



## CAB GLASS

	TH357D (TD7), TH408D (TH9), TH3510D (TH3)	TH514D (MWG)	TL642D (ML8), TL943D (MLJ), TL1055D (ML5), TL1255D (ML7)	TH255C (JK2)
Roof	495-6211	473-8918	473-8918	330-9060
R/H Side	473-8920	473-8920	473-8920	330-9058
Front	495-6212	473-8921	473-8921	330-9057
L/H Side	473-8917	473-8917	473-8917	330-9059
Rear no latch	-	473-6835	473-6835	-
Rear with latch	495-3427	473-6962	-	330-9062
Updated Door Glass	513-3137	513-3137	513-3137	-
Updated Door Kit	513-3136	513-3136	513-3136	-
Fixed Door Glass	-	-	-	330-8252
Hinged Door Glass	-	-	-	330-8257
Lower Door Glass	495-6140	-	-	-
Front Window Guard	471-6162	471-6162	471-6162	502-2018
Roof Guard	471-6160	471-6160	471-6160	502-2017
Blade, Rear Wiper	459-2710	459-2710	459-2710	478-1404
Blade, Roof Wiper	459-9783	459-9783	459-9783	478-1404
Blade, Wiper	459-7645	459-7645	459-7645	336-7170

## MIRRORS

	TH357D (TD7), TH408D (TH9), TH3510D (TH3)	TH514D (MWG)	TL642D (ML8), TL943D (MLJ), TL1055D (ML5), TL1255D (ML7)	TH255C (JK2)
Internal Rear View	257-8403	257-8403	257-8403	-
External Cab	299-0334	-	299-0334	317-0089
Front Chassis	-	-	309-2991	-
Rear View RH	476-0760	491-0603	-	441-6962
Hitch	-	424-0720	-	-
Front Light RH	-	424-0720	-	-
Rear View RH Convex	424-0720	424-0720	-	317-0089
Rear Chassis	220-4050	-	-	-
Rear Chassis Fish Eye	336-7619	-	-	-
Rear Chassis Convex	424-0720	424-0720	-	336-7619

## LIGHTS

	Description	TH357D (TD7), TH408D (TH9), TH3510D (TH3), TH514D (MWG)	TL642D (ML8), TL943D (MLJ), TL1055D (ML5), TL1255D (ML7)	TH255C (JK2)
Lamp Flood-Work Light (Boom)	-	-	511-0671	-
Flood Lamp (Cab)	Front & Rear	312-3332	312-3332	312-3332
Bulb	55w/12v	323-5646	323-5646	323-5646
Lamp (Head & Signal)	(RH)	195-0190	195-0190	316-7999
Lamp (Head & Signal)	(LH)	195-0190	195-0190	303-4955
Bulb	55w/12v (Head)	9w-3324	9w-3324	305-2108
Bulb	21w/12v (Signal)	226-4560	226-4560	305-2109
Bulb	5w/12v (Minature)	226-4561	226-4561	305-2107
Beacon (Fixed)	Roof mounted	526-1946	526-1946	526-1946
Bulb	55w/12v (Beacon)	323-5644	323-5644	323-5644
Lamp (Signal & Stop)	Rear RH	316-8039	316-8039	303-4975
Lamp (Signal & Stop)	Rear LH	316-8038	316-8038	303-4976
Bulb	12v (Stop)	305-2109	305-2109	305-2109
Bulb	21w/12v (Signal)	323-5648	323-5648	319-7633
Bulb	12v (Turn)	323-5649	323-5649	305-2109

# ENGINE PARTS

Engine Sales Model	Engine Prefix	Starting		Charging		Cooling System			Auxiliary Drive Belt		Fueling System					
		Starter Motor		Alternator		Water Pump		Thermo-stat	Belt Drive		Fuel Pump		Fule Injector		Turbo	
		New	Reman	New	Reman	New	Gasket Set		With AC	Without AC	New	Reman	New	Reman	New	Reman
3.4	CJ4, CN5	390-3144	No Reman	390-2384 (120 Amp)	No Reman	477-5624	389-2863	481-4381	450-0003	422-0665	390-3122	No Reman	463-8812	No Reman	465-3458	No Reman
4.4	JKT	331-7010		321-8927 (150 Amp)	20R-3601	397-5684	353-8578	497-3998	365-2985	285-2040	370-8363	20R-4783	418-3229		450-1871	
Deutz	-	449-2391		449-2347	No Reman	449-2387	447-2193	449-2342	447-1420	449-2389	449-2343	No Reman	449-2440		449-2388	

# QUICK DISCONNECTS

	Push to Connect			
	Male	Cap	Male	Cap
TL Models	300-6079	300-6103	300-6078	300-6103
TH Models	300-6079	340-5953	300-6078	340-5954
TH255C	327-5529	300-6103	327-5530	344-7188

**BUILT FOR IT.™**

PEBJ0126-01  
August 2018

© 2018 Caterpillar. All Rights Reserved. CAT, CATERPILLAR, BUILT FOR IT, their respective logos, "Caterpillar Yellow," the "Power Edge" trade dress, as well as corporate and product identity used herein, are trademarks of Caterpillar and may not be used without permission.

