



UTILITY VEHICLE PARTS REFERENCE GUIDE




» PROTECT YOUR INVESTMENT WITH GENUINE CAT® PARTS

Thank you for selecting the Cat® Utility Vehicle.

This guide is designed to provide you with a quick reference for the parts and part numbers you need to keep your Cat Utility Vehicle running at peak efficiency.


MAINTENANCE

Proactive preventative maintenance extends the life of your machine and protects your investment. Only Caterpillar knows Cat equipment's filtration and lubrication requirements and offers parts kits to match your machine's maintenance cycles.

SCHEDULED MAINTENANCE PARTS	
	GREASES
	PLANNED MAINTENANCE KITS

REPLACEMENT PARTS

Proper maintenance minimizes the need for repair and replacement. In the event that replacement parts are required, the use of genuine Cat parts helps maximize machine performance and maintains high resale value.

REPAIR PARTS	
	BATTERY
	ENGINE PARTS
	ENGINE HARDWARE
	FRAME AND ROPS
	SUSPENSION
	ACCESSORIES

GREASES UTV

Cat Product Name	STANDARD MAINTENANCE GREASES			GREASES FOR UNIQUE APPLICATIONS AND ENVIRONMENTS		
	Cat Extreme Application Grease – 1 (5% MOS2)	Cat Extreme Application Grease – 2 (5% MOS2)	Cat Prime Application Grease (3% MOS2)	Cat Extreme Application Grease – Arctic (5% MOS2)	Cat Extreme Application Grease – Desert (5% MOS2)	Cat Utility Grease
Grade (NLGI)	1	2	2	0	2	2
Melting point (deg C)	260	260	260	230	280	260
Ambient Temperature (deg C)	-35 to +40	-30 to +50	-20 to +40	-35 to +40	-30 to +50	-30 to +40
Base Oil Type	Mineral	Mineral	Mineral	Semi-Synthetic	Mineral	Mineral
Color	Dark Grey	Dark Grey	Dark Grey	Dark Grey	Dark Grey	Blue
Cartridge (390 g / 14 oz)	452-5996	452-6001	452-6006	452-7459	452-6016	452-6011
Plastic Pail (5 kg / 11 lb)	–	–	–	–	–	–
Plastic Pail (16 kg / 35 lb)	452-5999	452-6004	452-6009	452-6020	452-6019	452-6014
Keg (55 kg / 120 lb)	452-5998	452-6003	452-6008	452-7461	452-6018	452-6013
Drum (180 kg / 400 lb)	452-5997	452-6002	452-6007	452-7460	452-6017	452-6012




PLANNED MAINTENANCE KITS

Utility Vehicle		Initial 50 Hours				Every 100 Hours	Every 200 Hours			
		Transaxle Oil Change	Front Differential Oil Change	Engine Oil/Filter Change		Engine Air Filter	Engine Oil/Filter Change		Fuel Filter Change	Alternator Belt
Sales Model	Serial Number	Oil Qty (L)	Oil Qty (L)	Oil Qty (L)	Filter	Primary Element	Oil Qty (L)	Filter	Primary Element	Part No.
CUV82/85	M82/K85	1.2	0.2	1.9	560-7613	561-6538	1.9	560-7613	–	544-2382
CUV102 D/105 D	PD2/GD5	1.2	0.2	2.4	562-0328	561-6538	2.4	562-0328	562-0276	562-0337

Utility Vehicle		Every 400 Hours				Every 24 Months	Every 36 Months	
		Transaxle Oil Change	Front Differential Oil Change	Engine Air Filter	Brake Fluid Change	Engine Coolant Change	Seat Belts	
Sales Model	Serial Number	Fluid Qty (L)	Fluid Qty (L)	Second Element	Fluid Qty (L)	Fluid Qty (L)	Driver	Passenger
CUV82/85	M82/K85	1.2	0.2	561-6539	0.35	5.7	544-2128	544-2131
CUV102 D/105 D	PD2/GD5	1.2	0.2	561-6539	0.35	5.7	544-2128	544-2131



BATTERY UTV

Model	Part Number	Voltage	
Standard Battery	560-6649	12	

ENGINE PARTS UTV

Part Description	Alternator	Fuel Pump	Oil Pump	Water Pump	Starter Motor	Drive Clutch	Driven Clutch
CUV 82/85	544-2381	544-2282	558-9385	559-6643	544-2380	562-2060	548-2668
CUV 102 D/105 D	562-0559	544-2284	562-0450	562-0505	562-0581	564-8004	562-2063

ENGINE HARDWARE UTV

Part Description	CUV 82/102 D	Quantity	CUV 85/105 D	Quantity
Filter – Engine Oil	560-7613	1	562-0328	1
Filter – Fuel	–	0	562-0276	1
Filter – Air (Primary)	561-6538	1	561-6538	1
Filter – Air (Secondary)	561-6539	1	561-6539	1
Thermostat - Engine Coolant	544-2399	1	562-0480	1
Alternator Belt	544-2382	1	562-0337	1
Spark Plug	544-2398	3	–	0
Spark Arrestor	–	0	562-0376	3
Fuel Injector	564-5258	3	–	–
Fuel Rail w/ Injectors	559-7014	1	562-0427	1
Fuel Cap	544-2279	1	544-2301	1
Oil Cap	559-6990	1	–	0
Oil Drain Plug	569-7095	1	562-0281	1
Oil Drain Plug Washer	569-7091	1	562-0270	1
CVT Belt	548-2683	1	548-2683	1
Sway Bar Link	552-3899	2	552-3899	2
Sway Bar Link Bushing	545-8207	8	545-8207	8
Sway Bar Bushing	552-3896	2	552-3896	2

FRAME AND ROPS UTV

Part Description	CUV 82	Quantity	CUV 102 D	Quantity	CUV 85	Quantity	CUV 105 D	Quantity
Frame – ROPS (F)	560-6612	1	560-6558	1	560-6612	1	560-6558	1
Frame – ROPS (M)	–	0	–	0	571-7421	1	572-8757	1
Frame – ROPS (R)	559-0126	1	559-0127	1	571-7424	1	572-8756	1
Seat Belt – Driver	544-2128	1	544-2128	1	563-5024	1	563-5024	1
Seat Belt – Center 1	–	0	–	0	544-2131	2	544-2131	2
Seat Belt – Center 2	–	0	–	0	571-7578	1	571-7578	1
Seat Belt – Passenger	544-2131	1	544-2131	1	562-5857	1	562-5857	1
Shoulder Guard (L)	560-6614	1	–	0	560-6614	2	–	0
Shoulder Guard (R)	560-6613	1	–	0	560-6613	2	–	0
Door Assembly (R)	544-2151	1	–	0	544-2151	2	–	0
Door Assembly (L)	544-2152	1	–	0	544-2152	2	–	0
Door Handle (L)	544-2149	1	–	0	544-2149	2	–	0
Door Handle (R)	544-2148	1	–	0	544-2148	2	–	0
Door, Tailgate	544-2332	1	544-2332	1	544-2332	1	544-2332	1



SUSPENSION UTV

Part Description	Part Number	Quantity
Wheel Assembly	545-8258	4
Lug Nut	545-8232	16
Tire	545-8257	4
Tire Hub	545-8263	4
Brake Pads (F)	561-5140	2
Brakes Pads (R)	561-6555	2
Suspension Spring (F)	545-8242	2
Suspension Springs (R)	545-8248	2
Suspension Springs (R)	571-6486	2

ACCESSORIES UTV

Part Description	CUV 82/102 D	Quantity	CUV 85/105 D	Quantity
Soft Canvas Doors (Front)	576-3041	1	576-3041	1
Soft Canvas Doors (Rear)	–	1	576-3056	1
Cab Seal Kit	576-9838	1	576-9838	1
Rack (Headache)	545-8289	1	545-8289	1
Wiring Kit (Standard Beacon)	571-4921	1	571-4921	1
Light Rail Harness (5 Seat)	–	–	571-4919	1
Accessory Switch	575-5462	1	575-5462	1
Extra Battery Holder Kit	576-9846	1	576-9846	1
Hard Shell Doors (Front)	546-0910	1	546-0910	1
Rear Hard Doors (Crew)	–	–	575-9446	1
Modular Heater	546-0917	1	546-0917	1
Grill Guard	545-8285	1	545-8285	1
Brush Guard	545-8283	1	545-8283	1
A-Arm Guards	546-0912	1	546-0912	1
Rearview Mirror	548-9159	1	548-9159	1
Off Road Tire	570-1025	1	570-1025	1
Aluminum Rim	570-1029	1	570-1029	1
Overhead Console	546-0909	1	546-0909	1
Overhead Console Harness	571-4890	1	571-4890	1
Light (Interior Dome)	546-0918	1	546-0918	1
Light (Beacon Modular)	548-4754	1	548-4754	1
Light (Work Modular)	548-9157	1	548-9157	1
Light (Light Bar)	546-0922	1	546-0922	1
Light (Light Rail)	545-8297	1	545-8297	1
Light Rail Harness (2 Seat)	571-4919	1	–	–
Underseat Storage (Modular)	545-8299	1	545-8299	1
Engine Block Heater	571-1974	1	571-1974	1
Roof (Soft Shell, 2 Seat)	559-5043	1	–	–
Roof (Bimini, Soft Shell, 5 Seat)	–	–	571-4909	1
Roof (Hard Shell, 2 Piece, 5 Seat)	–	–	571-4902	1
Windshield Wiper	546-0919	1	546-0919	1
Windshield Washer Kit	546-0920	1	546-0920	1
Winch Kit (Pv5000, 2 Seat)	546-0916	1	–	–
Winch Kit (Pv5000, 5 Seat)	–	1	548-9161	1
Winch (Pv5000)	571-1976	1	571-1976	1
Cargo Bed Mat	546-0915	1	546-0915	1
Electro-Hydraulic Bed Dump	546-0923	1	546-0923	1