

ASSEMBLY


Flywheel Group

< NEW MODEL

INV2000 *Flywheel Group*

IN

OUT



Page design © 2004-2017 by ARI Network Services, Inc.

Click and drag to move diagram view

Tag	Part #	Description	USD	CAD
1	530-1188	Oil Level Sensor Group Includes oil level sensor and mounting hardware.	Call Us	Call Us
2	530-1187	Ignition Coil Group Includes ignition coil, spark plug wire and cap, and mounting hardware	Call Us	Call Us
3	530-1186	Flywheel Group Includes flywheel, and mounting hardware.	Call Us	Call Us