


# ASSEMBLY

Fuel Tank Group

< NEW MODEL

INV4000 E Fuel Tank Group

IN OUT



Page design © 2004-2017 by ARL Network Services, Inc.

Click and drag to move diagram view

Tag	Part #	Description	USD	CAD
1	589-6188	Fuel Tank Group   Includes fuel tank, fuel level sensor, fuel filter, and mounting hardware	Call Us	Call Us
2	589-6230	Fuel Level Sensor   Fuel Level Sensor	Call Us	Call Us
3	589-6231	Fuel Filter   Fuel Filter	Call Us	Call Us
4	589-6189	Fuel Cap Group   Includes fuel cap and strainer	Call Us	Call Us
5	589-6232	Fuel Strainer   Fuel Strainer	Call Us	Call Us
6	589-6190	Fuel Tank Cover Group   Includes upper cover, box cover accessory, end plug, and hardware	Call Us	Call Us
7	589-6233	Storage Box Door   Tool Compartment door	Call Us	Call Us
8	589-6191	Fumes Disposal Group FOR CARB UNIT ONLY   Includes carbon collector fasten plate, fuel steam collector, rubber jacket, fuel evap hoses, air cleaner hose, clamps and hardware	Call Us	Call Us