

207-1556 Starter

QTY	UNIT	PART	PART DESCRIPTION
5	PC	0S-1597	BOLT
1	PC	3E-7775	HOUSING AS
8	PC	3R-8797	SCREW AS
1	PC	3T-3422	WIRE AS-STARTER
6	PC	3T-3434	PLUG
1	PC	4M-1831	PLUG-STARTER
4	PC	5S-7349	BOLT
1	PC	6N-3826	DRIVE AS-MOTOR
4	PC	6V-8188	NUT-HEX
3	PC	6V-8378	NUT
1	PC	7L-2894	GASKET
1	PC	7T-3267	BUSHING KIT
1	PC	7T-3268	LEVER KT-STARTER
1	PC	7T-3276	ARMATURE AS-24 V
1	PC	7T-3277	COIL AS-FIELD
1	PC	7T-3278	HOLDER AS-BRUSH
1	PC	7T-3279	HOUSING AS
1	PC	7T-3451	INSULATOR KIT
1	PC	7T-3454	INSULATOR
1	PC	7T-3974	HOUSING AS-DRIVE
4	PC	7X-0562	WASHER-HARD
6	PC	7X-3373	BOLT
1	PC	8C-3655	BRUSH KT
2	PC	8F-1434	LOCKWASHER
4	PC	8H-1141	SHOE-POLE
3	PC	8T-0328	WASHER-HARD
4	PC	8T-4205	WASHER-HARD
1	PC	8T-8566	TERMINAL AS
1	PC	8T-8569	INSULATOR-TERM
1	PC	8T-9884	INSULATOR KIT
1	PC	9X-4824	COVER-STARTER
1	PC	283-1107	CONNECTOR KT
1	PC	338-3454	MOTOR GP-ELEC
1	PC	548-9596	SOLENOID KT