

MTRAIN240

marucci

PRO BALL CADDY OWNER'S MANUAL



DICK'S Sporting Goods 345 Court Street Coraopolis, PA 15108

TABLE OF CONTENTS

SECTION	PAGE
BEFORE YOU BEGIN	1
IMPORTANT SAFETY NOTICE	2
IMPORTANT CARE AND MAINTENANCE	2
PARTS LIST	2
ASSEMBLY INSTRUCTIONS	3-4
LIMITED WARRANTY	5

BEFORE YOU BEGIN

Thank you for selecting the marucci PRO BALL CADDY. For your safety and benefit, read this manual carefully before using the product. If you have any questions, or find there are missing or damaged parts, please contact our Customer Service Agents.

Toll-Free Customer Service Number
1-877-846-9997
Mon. – Fri. 9 a.m. – 5 p.m. EST

RETAIN THESE INSTRUCTIONS FOR FUTURE USE



IMPORTANT SAFETY NOTICE

Read these instructions before using this product. This product is intended to be used by a single user during baseball and softball training drills. **To avoid serious injury** during assembly, disassembly, use, adjustment and/or movement of the marucci Pro Ball Caddy, **the following warnings and instructions MUST be observed at all times:**

WARNING

Important Instructions for Safe Assembly and Use

1. This product is not intended for children under age 12. Adult supervision during use is required. Never leave the product unattended. Unsupervised children can be injured.
2. The caddy should be placed on a flat surface that is suitable for play while ensuring maximum user safety. Placing on uneven or sloped surfaces can lead to injury.
3. **NEVER** climb on or hang from the caddy. The caddy is not intended to be weight bearing and will collapse if significant weight is applied.
4. **DO NOT** put arms, hands, or other body parts in holes or net. Entrapment can occur.
5. **WARNING: Pinch Point.** Keep hands clear of moving parts and hinges while folding or adjusting the frame.
6. **WARNING: Pinch Point.** Exercise caution while pressing push-pins to assemble and disassemble the ball caddy frame.



IMPORTANT! CARE AND MAINTENANCE

1. **DO NOT** leave the caddy outdoors in inclement weather as moisture and other elements may adversely affect the performance of the unit. Do not use in severe winds.
2. To extend the life of the product, unit should be stored indoors when not in use.
3. Examine your caddy regularly for wear and tear. Discontinue use immediately if any defect or damaged parts are found.
4. Keep away from fire and heat sources.

PRO BALL CADDY PARTS LIST

Part #	Description	Qty
1	FRAME	1
2	LEGS	4
3	BALL CADDY	1
4	CARRYING BAG	1

ASSEMBLY INSTRUCTIONS



Pinch Point. Exercise caution while pressing push-pins to assemble and disassemble the ball caddy frame.

1. To Assemble Legs, place legs (x4) (Part 2) into each Pole on the Frame (Part 1).



2. To open legs, Unstrap Hook and Loop closure.



3. Open Frame so it is standing upright.



4. To assemble Ball Caddy (Part 3) to Frame (Part 1), Take Tabs with Eyelets in each of the corners of the Ball Caddy and pull over each Corner Post on Frame (Part 1) until they click into place ensuring that each corner is secure.



Holds up to 100 Baseballs



Holds up to 60 12" Softballs

5. To secure legs for transport, collapse frame and legs together and secure with hook and loop strap and place inside carrying bag (Part 4).



LIMITED WARRANTY

Dick's Sporting Goods, Inc. (the "Company") warrants this product to be free from defects in workmanship and materials as follows:

Who is Covered

This Limited Warranty covers only the person who first bought the product. This Limited Warranty is not transferable to anyone else.

What the Warranty Covers

This Limited Warranty covers defects in materials and workmanship.

What the Warranty Does Not Cover

This Limited Warranty does not cover:

- Expendable items, including by way of example only and not by way of limitation: batteries, light bulbs, fuses, zippers, tires, belts, shoe soles, fabric, and other items that experience wear as a result of normal use.
- Damage through improper use, negligence, abuse, misuse, transportation, acts of nature, or accident, including failure to perform routine maintenance or follow the assembly and/or operating instructions supplied with the product.
- Products used in commercial or rental applications.
- Products that have been modified or repaired by anyone not authorized by the Company.

This Limited Warranty does not cover any consequential or incidental damages of any kind, including transportation to get warranty service, loss of time, and loss of use. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you.

What the Period of Coverage Is

This Limited Warranty lasts for a period of one year from the date of your original purchase. Any implied warranty arising under state law is limited in duration to the one-year period of this Limited Warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

What the Company Will Do to Correct Problems

The Company will furnish a replacement part at no charge to you.

How You Can Get Service

Please direct all warranty service inquiries as follows:

If in writing, mail to:

**Dick's Sporting Goods, Inc.
345 Court St.
Coraopolis, PA 15108
Attn: Customer Service**

If by telephone, call: **1-877-846-9997**

How State Law Applies

This Limited Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.