

MTRAIN281

marucci

7' MINI PLASTIC TRAINING NET

***FRAME NOT INCLUDED**

OWNER'S MANUAL



DICK'S Sporting Goods 345 Court Street Coraopolis, PA 15108

TABLE OF CONTENTS

SECTION	PAGE
BEFORE YOU BEGIN	1
IMPORTANT SAFETY NOTICE	2
IMPORTANT CARE AND MAINTENANCE	3
PARTS LIST	3
ASSEMBLY INSTRUCTIONS	4-7
LIMITED WARRANTY	8

BEFORE YOU BEGIN

Thank you for selecting the Marucci 7' MINI PLASTIC TRAINING NET. For your safety and benefit, read this manual carefully before using the product. If you have any questions, or find there are missing or damaged parts, please contact our Customer Service Agents.

Toll-Free Customer Service Number
1-877-846-9997
Mon. – Fri. 9 a.m. – 5 p.m. EST

RETAIN THESE INSTRUCTIONS FOR FUTURE USE



IMPORTANT SAFETY NOTICE

Read these instructions before using this product. To avoid injury during assembly, disassembly, use, adjustment and/or movement of the Marucci 7' Mini Plastic Training Net, the following warnings **MUST** be observed at all times:

WARNING

Important Instructions for Safe Assembly and Use


1. This product is not intended for children under age 12. Adult supervision during use is required. Never leave the product unattended. Unsupervised children can be injured.
2. Adult assembly required for assembly, disassembly, adjusting, and moving the net. All components must be properly assembled prior to use.
3. Always anchor the net prior to use. Drive all ground stakes completely into the ground on a flat surface. An unsecured net can cause serious injury. Players may trip on anchors that are not fully driven into the ground.
4. Adults only should move the net and handle steel ground stakes.
5. When used independently, 7' Mini Net must only be used with plastic, mini plastic or foam practice balls.
6. When 7' Mini net is used with the 7' Instant Net, regular baseballs, softballs, and practice balls may be used.
7. The net should be placed on a flat surface that is suitable for play while ensuring maximum user safety. Placing on uneven or sloped surfaces can lead to injury.
8. Bungee cord net loops are under tension during assembly, use, and disassembly. **EXERCISE EXTREME CAUTION** during assembly and disassembly, as the cords may rebound unexpectedly.
9. **NEVER** climb on or hang from the net. The net is not intended to be weight bearing and will collapse if significant weight is applied.
10. **DO NOT** put arms, head, or other body parts in holes or net. Entrapment and/or strangulation can occur.
11. **DO NOT** leave the net outdoors in inclement weather as moisture and other elements may adversely affect the performance of the unit. Do not use in severe winds.
12. To extend the life of the product, unit should be stored indoors when not in use. The net should be removed during extended storage.
13. Examine your net regularly for wear and tear. Discontinue use immediately if any defect or damaged parts are found.
14. Keep away from fire and heat sources.



IMPORTANT! CARE AND MAINTENANCE

1. **DO NOT** leave product outdoors in inclement weather as moisture and other elements may adversely affect the performance of the unit. Do not use in severe winds. Instant Net and anchors can come loose and hit players, causing serious injury.
2. To extend the life of the product, unit should be stored indoors when not in use.
3. Examine the product regularly for wear and tear. Discontinue use immediately if any defect or damaged parts are found.
4. Keep away from fire and heat sources.

7' MINI PLASTIC TRAINING NET PARTS LIST

Part #	Photo	Qty	Description
1		1	NET


ASSEMBLY INSTRUCTIONS

NOTE: 7' MINI PLASTIC TRAINING NET CAN BE ATTACHED TO THE FRAME INDEPENDENTLY OR IN CONJUNCTION WITH THE 7' INSTANT NET (MTRAIN235)

STEPS TO ATTACH 7' MINI NET INDEPENDENTLY

⚠ WARNING When using the 7' Mini Net independently, only use plastic, mini plastic, or foam training balls.


1. Ensure the 7' frame is assembled properly (see 7' instant net instructions)
2. Locate white Marucci badge in the upper left corner (fig a). Place white rope loop over pole top (fig. B).



3. Locate top right corner of the net and attach white rope loop over pole top (fig c).



4. Securely wrap the toggle straps attached to the sides of net (shown in fig d) to the left and right poles of the frame (fig e). Note: there will be toggles on the top of the net. These do not need to be used when setting up the 7' mini net independently.



5. Hook the black bungee loops on the bottom corners of the net around the metal stud on both end legs (fig. F).



STEPS TO ATTACH 7' MINI NET WITH THE 7' INSTANT NET

NOTE: When using the 7' Mini Net with the 7' Instant Net, you may use both regulation baseballs/softballs as well as plastic, mini plastic, or foam training balls. If using regulation baseballs/softballs, the 7' Mini Net must be attached with the 7' Instant Net.

1. Ensure the 7' frame is assembled properly with the 7' instant net.
2. Locate white Marucci badge in the upper left corner (fig g). Place white rope loop over pole top (fig. H). There should now be two net loops on the pole top (both the 7' instant net and the 7' mini net)


⚠ WARNING IF USING REGULATION BASEBALLS AND SOFTBALLS, THE 7' MINI NET SHOULD ALWAYS BE ATTACHED BEHIND THE 7' INSTANT NET.



3. Locate top right corner of the net and attach white rope loop over pole top (fig. I).



4. Securely wrap the toggle straps attached to the sides of net (shown in fig. J) around the 7' instant net and around the left and right poles of the frame (fig. K). Secure.



5. Wrap the toggles along the top of the net around the 7' instant net and secure. This will hold both nets together.
6. Hook the black bungee loops on the bottom corners of the net around the metal stud on both end legs (fig. L).



LIMITED WARRANTY

Who is Covered?

This Limited Warranty covers only the original purchaser of the product. This Limited Warranty is not transferable to anyone else.

What the Warranty Covers

DICK'S Sporting Goods Inc. ("The Company") warrants to the original purchaser of this product that the product shall be free from defects in workmanship and materials for the period designated for the specific product (listed in Exhibit A) when the product is used under normal uses and conditions.

What the Warranty Does Not Cover

This Limited Warranty does not cover :

- Expendable items, including by way of example only and not by way of limitation: batteries, light bulbs, fuses, zippers, tires, belts, shoe soles, fabric, and other items that experience wear as a result of normal use.
- Damage through improper use, negligence, abuse, misuse, transportation, acts of nature or accident including failure to perform routine maintenance or follow the assembly and/or operating instructions supplied with the product.
- Products used in rental applications.
- Products that have been modified or repaired by anyone not authorized by the Company.
- Please see Exhibit A for additional product-specific limitations.

The Limited Warranty does not cover any consequential or incidental damages of any kind, including, but not limited to transportation, loss of time, loss of use, etc., unless otherwise dictated by the laws of your state.

What the Period of Coverage Is

Please see Exhibit A for product-specific coverage terms.

Any implied warranty arising under state law is limited to the same duration provided for the specific product listed in Exhibit A, unless the laws of your state dictate otherwise.

What the Company Will Do to Correct Problems

The Company will furnish a replacement part at no charge to you.

How You Can Get Service

Please direct all warranty service inquiries as follows:

If by telephone, call: 1-877-846-9997

If in writing, mail to:
Dick's Sporting Goods Inc.
345 Court St.
Coraopolis, PA 15108
Attn: Customer Service