



Installation



Connect top bar and hanger with a machine screw.

Install hangers into solid wall with screws.

Place the kayak on hangers.



- 1. Do not exceed a max load of 100lbs.
- 2. Ensure that the hooks are secured before hanging the kayak.
- 3. Do not move your kayak side to side after hanging.
- 4. Do not mount/screw into unsupported drywall, sheet-rock, or paneling. Unit must be mounted to study or a solid wall.
- 5. This hanger is not a toy. Please keep children away from mounted/loaded unit.



Disclaimer

Repair or replacement of a defective product, or the issue of a refund or credit (as determined by the Company) is the original retail purchaser's sole and exclusive remedy under this warranty. Except to the extent provided above or prohibits by law, the Company disclaims all other warranties, whether express, implied, statutory or otherwise.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

TO MAKE A CLAIM:

If the product is believed to be defective, the original retail purchaser should contact the Company, who will give the original retail purchaser instructions on how to proceed at the following:

If in writing, mail to:

Dick's Sporting Goods, Inc. 345 Court St. Coraopolis, PA 15108 Attn: Customer Service

If by telephone, call:1-866- 677- 4771

If by e-mail, to: customer.service@dcsg.com

In the event that the product must be returned to the Company, a representative at the email address above will provide the original purchaser with return shipping instructions. The original purchaser will be responsible for the cost of mailing the product to the Company. In order to be eligible to receive any remedy under this warranty, a copy of the original purchase receipt, a description of the defect and a return address must be provided.