



To temporarily disable a single access code...

- 1 Go to the main app screen, then tap on  in the bottom left corner.



For **Aura locks**, you will need to be within Bluetooth range of the lock to access some features.

- 2 Tap on the Access Code you would like to disable/enable.



- 3 Tap on "Disable Access Code" to toggle the setting.

