

## Nautilus ® Buckle Replacement Guide

©2013 Graco PD246351A 5/13


## To Remove Existing Harness Tongues and Buckle and Attach Replacement Buckle






To loosen straps, lift lever and pull harness straps.

Remove harness strap loops from splitter plate.







Remove chest clip. DO NOT DISCARD the chest clip.



Unbuckle harness by tilting top of buckle down, press top of red button, and pull tongues out of buckle.




tongues.



Slide NEW buckle onto harness straps. MAKE sure not to twist straps.




Re-attach chest clip. MAKE sure not to twist straps.



through slots in seat pad and seat back. See carseat owner's manual for inserting the straps into the correct set of harness


slots for your child.


Re-insert straps



Route harness straps **OVER** red rollers and re-insert straps back onto splitter plate.

Turn page over to finish the rest of the assembly Steps 11 to 20 for the buckle replacement.







## **FINAL CHECK:**

- Tug on the buckle to be sure it is properly secured in the bottom of the seat and does not come out.
- MAKE SURE the harness straps are not twisted.
- Make sure the chest clip is properly threaded as shown in Step 8.

Any questions please contact us at:

Graco Children's Products 3 Glenlake Parkway Atlanta, GA 30328 1-800-345-4109 www.gracobaby.com