

## Litterless™ Juice Boxes

3115, 3117

The patented sipping sprout offers comfortable, easy drinking for all ages. The straw snaps tight for a leak-resistant fit and is a perfect size for on-the-go transportation. By refilling your Litterless™ Juice Box instead of using bottled water or disposable juice boxes, you can save money and help the environment.



### Care & Use

To keep your new containers performing at their best, please read the following:

- Remove label and wash before use.
- Do not use abrasive cleansers or scrubbers since they may dull the finish.
- This item is made of materials that are safe for normal household dishwashers. Be sure that the item is secured in the top rack so that it does not come in contact with the dishwasher element to avoid melting.
- This item is made of materials that are safe for freezer use. Please note that plastics are less flexible when cold or frozen and may break if dropped. Also note that water expands when frozen, so when filled to capacity the container could expand and crack.
- As with most disposable drink boxes, liquid will squirt from the straw when a full bottle is squeezed.
- For best drinking results, be sure the spout is in the full open position. If straw is not fully open, air can be sipped along with the liquid.
- To restore proper air intake, remove bottle lid and apply pressure to the white valve button, separating the halves.
- Dairy, Juice, or other liquids that spoil easily should not be kept in product for prolonged periods. Juice may start to ferment in as little as a day.
- CAUTION: Not intended for use with hot liquids or carbonated beverages. Hot liquids may cause the sides of the bottle to get very hot to the touch, and any pressure build-up in the container could cause the lid to pop open unexpectedly, leading to injury or spills