




Assembly Instructions & User's Manual for

Member's Mark 57" Smokeless Round Firepit with 360° Wood Storage

Item Number:990342963

Model Number:RFP2105S

Customer Assistance (spare/replacement parts): +852 2815 0729 or Email: info@haloobrand.com



**THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.**



Assembly Instructions & User's Manual

Table of Contents

Quality Statement	3
Important Safety Information	3
Before Assembly	3
Care & Use	3
Package Contents	4
Product Information	5
Components	5-6
Hardware	6
Tools	6
Step 1 – Step 14	7-13
 Warning	14
 Danger	14
Troubleshooting	14
Care & Use and Storage Instructions	15
Technical Data	15
Warranty Information	15



Assembly Instructions & User's Manual

Quality Statement

Questions or Comments? We would love to hear about your Member's Mark experience! Visit us at: [Samsclub.com/membersmarkhelp](https://samsclub.com/membersmarkhelp)

Important Safety Information

- Please read all instructions carefully before assembling this product.
- Where applicable, and for your safety, assembly by an adult is strongly recommended.
- Use only vendor-supplied hardware to assemble this item. Using unauthorized hardware could jeopardize the structural integrity of the item.
- Hardware may loosen overtime. Periodically check that all connections are tight.
- For outdoor use only. Not for commercial use.
- Burn WOOD logs only. Maximum amount 5 kgs /11 lbs.


Before Assembly

- Remove all parts and hardware from the box. Place all items on a carpeted or scratch-free work surface, as this will avoid damaging parts during assembly.
- The shipping box can provide an ideal work surface if none is available.
- Use the components and hardware lists below to identify, inventory and separate each of the hardware and components included.
- To avoid accidentally discarding small components or hardware, do not dispose of any packaging or contents of the shipping carton until assembly is complete.
- DO NOT USE power tools unless it is explicitly identified in this manual as required for use during assembly. Power tools can damage the fasteners, hardware and/or components.
- Do not fully tighten all fasteners / bolts until all parts are in place. Failure to follow these instructions may cause the fasteners / bolts to misalign during assembly.

Care & Use

- Use a soft, clean cloth that will not scratch the surface when cleaning.
- Glass media may have sharp edges. Wear safety glasses and gloves when handling.
- Always use dry wood when possible. Wet wood will take longer to burn and will produce more smoke.
- Use provided soft cover when it's not in use.
- Keep flammable or combustible objects away from this product.
- Always extinguish fire completely after use. Never leave a fire unattended.
- Make sure all parts are completely cool before cleaning.

Package Contents



Componnt	Description	Qty
P1	Lid	1
P2	Rim for fireglass	1
P3	Heat protection mesh	1
	Firebowl	1
	Ash pan	1
	Soft cover	1
	Sparkguard	1
P4	Hardware	1
	Handle	1
	Bracket	4
P5	Fireglass	2
P6	Poker	1
	Firebowl holder	1
P7	Leg	4
P8	Tabletop panel	4
P9	Storage panel	4












Assembly Instructions & User's Manual

Product Information




Product size: 57"L x 57"W x 22"H

Product weight: 146.89 lbs (66.63 kg)



Components

Component A Bracket Qty 4 	Component B Leg Qty 4 	Component C Tabletop panel Qty 4 
Component D Storage panel Qty 4 	Component E Firebowl holder Qty 2 	Component F Heat protection mesh Qty 1 
Component G Firebowl Qty 1 	Component H Ash pan Qty 1 	Component I Rim for fireglass Qty 1 
Component J Lid Qty 1 	Component K Fireglass Qty 2 	Component L Poker Qty 1 

Components

Component M Soft cover Qty 1 	Component N Sparkguard Qty 1 	Component O Lid Handle Qty 1 
---	---	---

Hardware

Cross Head Bolt M6 x 16 mm (AA) Qty: 60 + 4(Spare) 	Stainless steel M6 x12mm Cross Head Bolt & Stainless steel washer (BB) Qty: 12 + 2(Spare) 	Stainless steel Cross Head Bolt M5 x 8 mm (CC) Qty: 2 + 1(Spare) 
---	--	---


Tools

Phillips Screwdriver (Not Included) PH2 		
--	--	--

Step 1


Assembly Tip: Do not fully tighten bolts until the end.

Step 1: Attach bracket (A) to leg (B) using bolts (AA). Repeat this step for the remaining legs (B).



Step 2

Place all four tabletop panels (C) upside down on a carpeted or scratch-free surface, arranging them in a circle.




Step 3

Assembly Tip: Do not tighten bolts until the end.


Align the holes in the assembled legs (B) with the corresponding holes in the tabletop panels (C), ensuring they overlap. Then, connect the tabletop panels (C) to the legs (B) using bolts (AA).

AA M6 x 16 mm Bolt  x 32



Step 4

Insert one storage panel (D) into each slot on legs (B) as shown. Repeat this step for the remaining three panels (D).




Step 5

Assembly Tip: Do not tighten bolts until the end.

Align the holes in the assembled legs (B) with the corresponding holes in the storage panels (D) so that they overlap. Then, secure the storage panels (D) to the legs (B) using bolts (AA).


AA M6 x 16 mm Bolt  x 16



Step 6


Attach the firebowl holders (E) to the storage panels (D) using stainless steel bolts and washers (BB).

BB M6 x 12 mm Bolt  x 4




Step 7

Turn the assembled product right side up.




Step 8

Place the heat protection mesh (F) on the outside of the firebowl (G). Then, put both the heat protection mesh (F) and the firebowl (G) into the center of the tabletop.



Step 9

Place the rim (I) on top of the firebowl (G). Align the holes in the rim (I) with the holes in the bracket (A) so that they overlap.




Step 10

Assembly Tip: Do not tighten bolts until the end.

Connect the rim (I) to the bracket (A) using stainless steel bolts and washers (BB x 8).


BB M6 x 12 mm Bolt  x 8



Step 11

Before proceeding, please ensure to wear safety glasses and gloves. Next, spread the fireglass (K) evenly into the rim (I).


Place the ash pan (H) into the firebowl (G).



Step 12

If desired, you can add wood logs (not included) onto the storage shelf.

The spark guard (N) can be placed on the rim of the firebowl and can be lifted on/off using the fire poker (L).



Step 13

WARNING:

Do not cover with lid (J) when the firebowl is in use.



To prepare for storage:

Turn the spark guard upside down and place it on top of the opening of the firebowl (G).
Always ensure the firebowl is completely cooled before covering with the lid.

To clean ashes from the ash pan:


Remove the ash pan and rinse it with water.

Dry the clean ash pan and firebowl after use and before storing.



Step 14

It is recommended to use the included weatherproof soft cover (M) when the product is not in use.





Assembly Instructions & User's Manual



Warning

- Do not use for burning coal, hardwood lump charcoal, leaves or any other combustible materials.
- Do not use on wood decks or any wooden surfaces. For use on a non-flammable surfaces only such as stone, brick or concrete.
- Do not cover with the lid when the product is in use. Always make sure the product is completely cooled before covering with the lid.
- Do not install the soft cover until this product has been cooled completely.
- Do not use the product for indoor heating. Toxic carbon monoxide can accumulate and cause asphyxiation and possibly death.
- Do not use water to extinguish the fire as this could cause damage to the product as well as injury to the user.
- Do not touch the fireglass with your unprotected hands. Please put on gloves.
- Burn WOOD logs only. Maximum amount 5 kgs/11 lbs.
- Keep flammable or combustible objects away from this product.
- Always extinguish the fire completely after use. Never leave a fire unattended.
- Make sure all parts are completely cool before cleaning.

California Proposition 65



WARNING: Combustion byproducts produced when using this product including carbon monoxide, a chemical known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov



Danger

- Toxic carbon monoxide can accumulate and cause asphyxiation and possibly death if use indoor.
- Touching with unprotected hands could result in serious injury or burns when this product is in use.

Troubleshooting

Problem	Possible Cause	Prevention / Solution
Fire lights slowly	The wood logs are wet.	Replace with dry wood logs.
	Accumulated ashes block air circulation	Lift the ash tray and remove the ashes.
Where to store the sparkguard when not in use	See Step 13.	Place the spark guard upside down under the lid.
Uneven tabletop	The adjustable foot pads underneath each leg has not been adjusted.	Lift the product a little and rotate the foot pads under each leg to adjust the height.



Assembly Instructions & User's Manual

Care & Use Instructions

If cleaning is required, gently wash with a sponge using mild soap and water. Do not use bleach, chemicals, abrasive cleaners or wire brushes when cleaning. Do not use a power washer. After cleaning, rinse well and allow to air dry.

To repair any scratches, nicks or chips on the finish, purchase matching touch-up paint that is suitable for metal, outdoor and high temperature use. Closely follow the instructions provided on the paint can.

Always place the lid and soft cover on the product when it is not being used or is stored for the off season.

Remove ashes from the bottom of fire bowl. It is important to remove the accumulated ashes from the fire bowl when they are cold. Ashes absorb moisture and may promote premature rusting and will also prevent the proper air flow.

Storage Instructions

- When not in use, please store this product in a cool, dry place away from sunlight.
- Exposing this product to excessive heat or humidity may damage this product.
- When this product is not in use, put the provided cover on.

Technical Data

Assembled dimensions: 57"L x 57"W x 22"H

Product Weight: 146.89lbs / 66.63 kg

Tabletop area: 57" diameter

Fire poker: 30.7" length

Soft Cover: 360g(400x400D) R-PET, with PVC backing

Fire wood: 16" Max. (not included)

Fire glass: 15.43 lbs / 7kg

Spark guard: 17.32"L x 17.32"W x 5.51"H

Warranty Information

This product is covered by the Sam's Club Member Satisfaction Guarantee.

Please visit samsclub.com for more information.

NOTE: Please consider recycling all applicable packaging materials.



Assembly Instructions & User's Manual

Distributed by Sam's West Inc.
2101 SE Simple Savings Dr.
Bentonville, Arkansas 72716-0745
Made in China

Need Assistance? Visit us at: samsclub.com/membersmarkhelp