


MODEL: 6736

v04



OWNER'S MANUAL

36" CABINET KITCHEN MODULE

TABLE OF CONTENTS

ASSEMBLY GUIDE	02
ACTIVATE YOUR WARRANTY	07



For the latest version of this manual,
scan this code or visit
BlackstoneProducts.com/support

IMPORTANT:

This instruction manual contains important information necessary for the proper assembly and safe use of the appliance.

Read and follow all warnings and instructions before assembling and using the appliance.

Follow all warnings and instructions when using the appliance.

Keep this manual for future reference.

Installer/Assembler: Leave these instructions with the consumer.

SAFETY ALERT KEY

⚠ DANGER

Indicates a hazardous situation that, if not avoided, will result in death or serious injury.

⚠ CAUTION

Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

⚠ WARNING


Indicates a hazardous situation that, if not avoided, could result in death or serious injury.

NOTICE















Indicates information considered important, but not hazard-related (e.g. messages related to property damage).

ASSEMBLY GUIDE

EXPLODED VIEW



PARTS LIST

1 Left cabinet panel (1 piece) 	2 Right cabinet panel (1 piece) 	3 Rear cabinet panel (1 piece) 			
4 Cart base (1 piece) 	5 Toe kick (1 piece) 	6 Caster wheels (4 pieces) 	7 Caster plates (2 pieces) 	8 Inner shelves (2 pieces) 	9 Countertop (1 piece) 
10 Shelf support (1 piece) 	11 Left door (1 piece) 	12 Right door (1 piece) 	13 Hinge mounts (4 pieces) 	14 Corner braces (4 pieces) 	15 Inner door panels (2 pieces) 
a. Leveling feet (4 pieces) 	b. Decorative caps (4 pieces) 	c. Wing nuts (2 pieces) 	d. Wing screws (2 pieces) 	e. Large screws (64 pieces) 	f. Small screws (18 pieces) 
g. Zinc washers (32 pieces) 	h. Zinc lock nuts (8 pieces) 	i. Zinc bolts (24 pieces) 	j. Rubber bumpers (4 pieces) 	k. #8 flat washer black oxide (4 pieces) 	l. M4x6 screw black oxide (4 pieces) 
m. #8x0.5 sheet metal screws silver (16 pieces) 					




ASSEMBLY INSTRUCTIONS

Find a large, clean area to assemble your appliance.
Remove all packing material before assembling.

CAUTION

Sharp edges. Wear gloves while assembling.


STEP 01 Use sixteen (16) zinc bolts [i.] and sixteen (16) zinc washers [g.] to attach four (4) caster wheels [6] to two (2) caster plates [7]. Screw four (4) leveling feet [a.] into the caster plates so that they extend above the wheels.




TOOL NEEDED:
Adjustable wrench

TOOLS NEEDED:
Phillips driver, H4 Hex driver & Impact driver


STEP 02 Use eight (8) zinc bolts [i.], sixteen (16) zinc washers [g.], and eight (8) zinc lock nuts [h.] to attach the caster plates to the underside of the cart base [4].




STEP 03 Use six (6) large screws [e.] to attach the left [1] and right [2] cabinet panels to the cart base [4]. Press four (4) decorative caps [b.] into the side panels.




STEP 04 Use eleven (11) large screws [e.] to attach the rear cabinet panel [3] to the left and right cabinet panels.




STEP 05 Slide the countertop **9** into the cabinet panels. Use eleven (11) large screws **[e.]** to secure.




STEP 06 Use four (4) large screws **[e.]** to attach the toe kick **5** to the left and right cabinet panels.



STEP 07 Use six (6) large screws **[e.]** to attach two (2) inner shelves **8** to the inside of the cabinet.





STEP 08 Use four (4) large screws **[e.]** to attach the shelf support **10** to the inside of the cabinet.



**STEP 09** Set the cabinet on its back.



Use sixteen (16) large screws [e.] to attach four (4) corner braces [14] to the cabinet corners.

**STEP 10** Use eight (8) small screws [f.] to attach the four (4) door hinge mounts [13] to the left corner brackets.**STEP 11** Use eight (8) large black screws [f.] to attach one (1) door inner panel [15] to one (1) door front panel [11].

Repeat with the other door [12].


Press two (2) bumpers [j.] into the door. (marked with a solid arrow)

Repeat with the other door.

**STEP 12** Use eight (8) small screws [f.] to attach the left and right doors to the door hinges.




STEP 13 Enjoy using your Blackstone Outdoor Kitchen.



INSTALLING YOUR KITCHEN

Use the wing screws and wing nuts to connect the modules (Press four (4) decorative caps [b.] into the side panels, or remove the decorative caps as needed).

Open the doors, and use the included H4 hex driver to adjust the leveling feet.



ACTIVATE YOUR WARRANTY

Blackstone Products warrants this Griddle Cabinet against defects in materials and workmanship for a period of one (1) year from the original date of purchase under normal use. To the extent any such defects occur, Blackstone Products, in its discretion, will provide the appropriate replacement part(s) at no charge.

In no event shall Blackstone Products, LLC be liable for consequential, indirect or incidental damages resulting from the installation, use or failure of the product.

This warranty does not cover:

- Inspection costs or labor for replacement of any defective part(s);
- Cosmetic defects which DO NOT affect product performance or integrity;
- Normal wear and tear;
- Damage due to vandalism; acts of nature, including but not limited to wind, storms, hail, floods;
- Improper assembly, installation, or use;
- Discoloration or fading of the finish as a result of exposure to chemicals, spills, pool or salt water
- Corrosion / rust.

Your Griddle Cabinet has been designed for safety and quality. Any modifications made to the original product could compromise its structural integrity or function and could lead to product failure or personal injury. As such, modifying this product voids all warranties.

This product is warranted for RESIDENTIAL USE ONLY, and is not for commercial, contract or other non-residential purposes. Blackstone Products disclaims all other representations and warranties of any kind, express or implied.

The warranty applies to the original purchaser and is non-transferable. It does not apply to purchases of display models, or when the product is sold on clearance or "as is". To activate your warranty, register your product at www.BlackstoneProducts.com/register.

Blackstone Products, LLC makes no warranty whatsoever in respect to accessories or parts not supplied with it. This warranty shall apply only within the boundaries of the United States of America and Canada. This warranty gives the original purchaser specific rights, and the original purchaser may also have other rights, which vary from state to state.

This warranty is the exclusive warranty of Blackstone Products, LLC and is in lieu of all other warranties expressed or implied. Blackstone Products, LLC reserves the right to change or modify this warranty at any time.



Register your product at
BlackstoneProducts.com/register



This product may be covered by one or more issued U.S. and/or international patents and may include patent applications pending. For more information, please visit: BlackstoneProducts.com/patents