



MODELS ENDING IN 2412, 2417, 1518

FOR HUMIDIFIER MODELS ENDING IN 2412, 2417, 1518 WITH MANUAL HUMIDIFIER CONTROL (MHC) AND BLOWER ACTIVATION RELAY – ACTIVATES FURNACE BLOWER ON CALL FOR HUMIDITY



90-1810


FOR HUMIDIFIER MODELS ENDING IN 2412, 2417, 1518 WITH HUMIDITRAC™ HUMIDIFIER CONTROL AND BLOWER ACTIVATION RELAY – ACTIVATES FURNACE BLOWER ON CALL FOR HUMIDITY




90-1811

## MODEL ENDING IN 1418

### FOR HUMIDIFIER MODEL ENDING IN 1418 WITH MANUAL HUMIDIFIER CONTROL (MHC) AND BLOWER ACTIVATION RELAY – ACTIVATES FURNACE BLOWER ON CALL FOR HUMIDITY




### FOR HUMIDIFIER MODEL ENDING IN 1418 WITH HUMIDITRAC™ HUMIDIFIER CONTROL AND BLOWER ACTIVATION RELAY – ACTIVATES FURNACE BLOWER ON CALL FOR HUMIDITY




**MODEL ENDING IN 3034**

**FOR HUMIDIFIER MODEL ENDING IN 3034 WITH MANUAL HUMIDIFIER CONTROL (MHC) AND BLOWER ACTIVATION RELAY – ACTIVATES FURNACE BLOWER ON CALL FOR HUMIDITY**



90-1814

**FOR HUMIDIFIER MODEL ENDING IN 3034 WITH HUMIDITRAC™ HUMIDIFIER CONTROL AND BLOWER ACTIVATION RELAY – ACTIVATES FURNACE BLOWER ON CALL FOR HUMIDITY**



90-1815

© 2012 CAC/BDP  
7310 West Morris St., Indianapolis, IN 46231