



INSTALL INSTRUCTIONS FOR CONSOLIDATED COIL/HAIL GUARDS FOR LENNOX (CAT# 24M51)

A CAUTION

WHEN INSTALLING COIL GUARD BE SURE NOT TO PUNCTURE CONDENSER COIL

- 1. THE LCG24M51 COIL GUARDS ARE DESIGNED TO PROTECT THE CONDENSOR COIL OF THE HVAC UNIT. THE FOLLOWING ARE INCLUDED:—
 SHIPPING AND PACKING LIST
- 1- SMALL COIL GUARD
- 1- LARGE COIL GUARD
- 1- HARDWARE BAG W/ 1-INSTRUCTIONS 12-#10-1/2" SCREWS





INSTALLATION


- 1. DISCONNECT ALL POWER SOURCES TO THE UNIT.
- 2. SLIDE THE TOP FLANGE OF SMALL COIL GUARD UNDERNEATH THE TOP FLANGE OF THE HVAC UNIT. (SEE ILL. 2 AND 2A)
- 3. SCREW THE SIDE FLANGES OF THE GUARD WITH THE UNIT. TO AVOID COIL DAMAGE, USE ONLY 1/2" SCREWS PROVIDED.
- 4. REPEAT THE PROCESS FOR THE LARGE GUARD. TO AVOID COIL DAMAGE USE ONLY 1/2" SCREWS PROVIDED.

NOTE:- BE CAREFUL NOT TO DAMAGE THE COIL WHILE INSTALLING THE GUARD. THE SELF DRILLING SCREWS PROVIDED CAN BE USED ON ALL THE SIDES WITH OR WITHOUT MATCHING HOLES IN THE UNIT.

5000409 LCG24M51 JUL. 25 / 23



INSTALL INSTRUCTIONS FOR CONSOLIDATED COIL/HAIL GUARDS TO SUIT LENNOX CAT# 24M51



5. REPEAT THE PROCESS FOR THE MEDIUM AND LARGE GUARDS. TO AVOID COIL DAMAGE USE ONLY 1/2" SCREWS PROVIDED.

5000409 LCG24M51 JUL. 25 / 23