


QUICK START GUIDE



COMFORT SYNC A3

Due to our policy of continuous improvement, specifications are subject to change without notice.

Printed in U.S.A.
©2020 Allied Air Enterprises LLC,
a Lennox International Inc. Company

Form No. A3QS-100 (3/20) PC94166

COMFORT SYNC A3

WELCOME TO YOUR COMFORT SYNC® A3 ULTRA-SMART THERMOSTAT.

LET'S GET STARTED



1 Download the Comfort Sync® A3 App

Available at the iTunes App Store and Google Play. With the mobile app, you can control your thermostat remotely from anywhere your smart device is connected.

2 Connect with your home's Wi-Fi

Having a Wi-Fi connected thermostat lets you take control of your system from anywhere at any time with your connected iOS or Android device.



To set up, go to **menu > settings > wi-fi > wi-fi network**. The thermostat will automatically search for the Wi-Fi network in your home. Select the desired network and enter the password (if necessary).

You can also manually add a Wi-Fi network by pressing the "Other" button.

3 Create an account/login

Once the Wi-Fi has been set up, you are ready to create an account and take control of your Comfort Sync® A3 Ultra-Smart Thermostat.

If you already have an account, go to **menu > settings > account** to log in.

If you don't have an account, select "**Create new account.**" Enter your account information and home address, then tap on "**create account.**"

Remember to check the box that will allow your dealer to receive service alerts.

A green check mark above the server icon means your setup is complete.

Now you can access your account at www.comfortsync.com or through the Comfort Sync® A3 app on your smart device.

4 Generate pin

If you have already created a consumer account through the Comfort Sync mobile app or consumer web portal (www.comfortsync.com), then you can use the "**generate pin**" option to add the system to your account.

PLEASE NOTE: The "**generate pin**" option is not required if the account was set up from the thermostat.

First-time login


The first time you log into your account, the screen will indicate "**No Comfort Sync Detected.**"

Select the ▼ icon next to your email address. A drop-down menu will appear. Select "**Add Comfort Sync.**" When you do this, a pop-up window will appear on the screen. Enter your pin number, which was generated by the thermostat. (To get your PIN on your thermostat, go to **Menu > Account > Generate PIN**. Then press "Add.")

Successful setup

When successful, the setup will continue to the next applicable screen. If you already have an address associated with your account, you will have the option of selecting that address or adding a new one.

Horseshoe-shaped
Temperature
Adjustment Control



Settings

Modes/Schedules

The Comfort Sync® A3 Ultra-Smart Thermostat provides complete, personalized control over your home's indoor environment.



Temperature Adjustment

The horseshoe-shaped control on your thermostat's home screen is the temperature set-point control. To adjust the set-point, drag the knob up or down along the horseshoe. You can also use the "+" or "-" buttons.

If your system is in **heat/cool mode**, use the red knob to control the heating set-point and the blue knob to control the cooling set-point.



Schedule Sync™

Schedule Sync adapts to your schedule. To enable, go to **modes/schedules > schedules > edit schedules > schedule sync**. You can select your preferred temperatures for up to four time periods throughout the day by sliding the blue and red circles along the line on the screen. Add the Comfort Sync A3 app to your smart device and your system will automatically adjust its set points when you are away, saving energy and money.



Away Sync™

Away Sync uses the GPS in your smartphone to detect when you're leaving and automatically changes the temperature to a more efficient setting.

To enable via the mobile app, go to **settings > away > turn Away Sync "on."**

The factory default is a 2-mile radius. To adjust the radius, press the "+" or "-" buttons under **Away Fence**.



Allergy Sync™

Allergy Sync helps to filter your home's air when allergy levels are high in your local area. To enable, go to **settings > fan (menu on left) > set Allergy Sync**.



Climate Sync™

Climate Sync monitors humidity levels and removes excess moisture for cleaner, more comfortable air. To enable, go to **settings > humidity control > Climate Sync**.

For additional setup and troubleshooting information, go to <http://www.support.comfortsync.com/help/index.html>