HOW CAT® PRODUCTIVITY WORKS:

EXECUTE: GPS TRACKERS ON LOADERS AND HAULERS

Ping machine locations

- Tracks where your machines are
- Monitors how long they take to get to a location

DUMP EVENT:

LOAD EVENT:

Created when a loader

and hauler come into


set amount of time

proximity and stop for a

Created when the hauler leaves the loading area and stops at its next specified location

EXECUTE: CLOUD-BASED PLATFORM:

- Reports how much time your machines spend loading, hauling and dumping
- Available on mobile, tablet or a desktop device



EXAMPLE 20NES (GEOFENCES)ON YOUR SITE CAN BE DEVELOPED AND ANALYZED

You see when machines enter
 or leave zone areas

- + Cat® Productivity logic can be used on older Cat machines and non Cat machines with a cellular Product Link™ device.
- + Cat Productivity is also capable of sending advanced productivity data off machines equipped with a payload system [Cat Production Measurement (CPM) or Truck Payload Measurement System (TPMS)], which makes the system more intelligent and accurate.