





OPERATING INSTRUCTIONS Ceramic Heat Emitter

Model # DL180060A
DL180100A
DL180150A



COMPONENTS



A Ceramic Heat Emitter
(1 pc)
Part # 1

IMPORTANT INSTRUCTIONS

READ AND SAVE ALL SAFETY INSTRUCTIONS BEFORE OPERATING THE CERAMIC HEAT EMITTER

Please read these instructions prior to use of your new Ceramic Heat Emitter, and contact the retailer or manufacturer if anything is missing or unclear.



WARNING

1. For use with a Thrive Dome Lamp Fixture.
2. KEEP OUT OF REACH OF CHILDREN.
3. Keep the Ceramic Heat Emitter away from CURTAINS or other highly flammable objects.
4. Make sure your Reptile Dome Lamp fixture attaches FIRMLY to the top rim of your terrarium.
5. Avoid contact with hot surface.
6. Keep the ceramic heat emitter at least 11.8 in (30 cm) above surrounding objects.


(Continued)

7. For household and indoor use ONLY. DO NOT immerse in water.
8. Read all instructions before using.
9. DO NOT splice, repair or modify. DO NOT use in wet conditions. For indoor use only.
10. Keep children and pets (other than your terrarium reptiles) away from the fixture.
11. Fully extend the cord before using. DO NOT use if the cord is damaged. Inspect the cord periodically.
12. DO NOT cover with blankets, rugs or any material.
13. DO NOT exceed electrical rating.

DESCRIPTION

Main Parts:

1. Screw Shell
2. Ceramic Emitter



The Thrive Ceramic Heat Emitter is the latest technology in heating reptile, amphibian or plant terrariums.

When used according to the directions, it can increase ambient terrarium temperature 21-30°F (8 to 11°C) above the outside room temperature.

TECHNICAL DATA

1. Ratings 120V ac, 60Hz.

USAGE

1. The models of Thrive Ceramic Heat Emitters include DL180060A, DL180100A and DL180150A.
2. ATTACHMENT TO TERRARIUM: Make sure the Reptile Dome Lamp Fixture attaches FIRMLY to the top rim of your terrarium. When the heat emitter is securely attached to the dome lamp, you should be able to gently tap the clamp with your finger without it falling off the terrarium rim.
3. PLACEMENT OVER TERRARIUM: Always place the Ceramic Heat Emitter on top of the terrarium screen cover. DO NOT place it on glass.
4. Use the proper wattage heat emitter for your specific sized terrarium (10-20 gal: 60 watt; 30-40 gal: 100 watt; 50-100 gal: 150 watt).

(Continued)

5. Keep your Thrive Ceramic Heat Emitter up and out of reach of children.

If you are not satisfied with this product, return it with your valid proof of purchase for a refund. Conditions apply. See store or PetSmart.com for details.

For more information about Thrive products, please call 1-888-839-9638.

Dist. by/par: Pacific Coast Distributing, Inc., SKU #5290810
19601 N. 27th Ave., Phoenix, AZ USA 85027 5290811

Made in China. Last revisions 04/17/19 5290812