




FLEXIBLE NANO LED



INSTRUCTION MANUAL

IMPORTANT SAFETY INSTRUCTIONS

WARNING:


To guard against injury, basic safety precautions should be observed, including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

DANGER:

To avoid possible electric shock, special care should be taken since water is employed in the use of aquarium and pond equipment. For each of the following situations, do not attempt repairs by yourself. Return the appliance to an authorized service facility for service or discard the appliance.

1. Carefully examine the appliance after installation. It should not be plugged in if there is water on parts not intended to be wet.
2. Do not operate any appliance if it has a damaged cord or plug, or if it is malfunctioning or has been dropped or damaged in any manner.
3. To avoid the possibility of the appliance, plug, or outlet getting wet, position aquarium stand and tank to one side of a wall-mounted outlet to prevent water from dripping onto the outlet or plug. A drip-loop, shown in the figure below, should be arranged by the user for each cord connecting an aquarium appliance to an outlet. The drip-loop is the part of the cord below the level of the outlet, or the connector if an extension cord is used, to prevent water traveling along the cord and coming in contact with the outlet.
4. Close supervision is necessary when any appliance is used by or near children.
5. Always unplug an appliance from an outlet when not in use, before putting on or taking off parts, and before cleaning. Never yank the cord to pull the plug from the outlet. Grasp the plug and pull to disconnect.
6. Do not use an appliance for anything other than its intended use. The use of attachments not recommended or sold by the appliance manufacturer may cause an unsafe condition.
7. Do not install or store the appliance where it will be exposed to weather or temperatures below freezing.
8. Make sure an appliance mounted on a tank is securely installed before operating it.
9. Read and observe all the important notices on the appliances.
10. The appliance is intended FOR HOUSEHOLD USE ONLY.
11. This appliance has no user serviceable parts.





SAVE THESE INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS

INSTALLATION:

1. Clip the LED light to tank. The magnetic clip will fit glass 2 mm to 8 mm thick. (See Fig. 1)
2. Connect adapter DC cord to the clip terminal. (See Fig. 2)



SAFETY AND MAINTENANCE:

1. Properly use the product by following the instruction manual.
2. This product is not submersible.
3. Unplug from the main power whenever product is moved.

TECHNICAL DATA:

Model	Input Voltage	Output Voltage	White LED
BCL-C	100-240 VAC	DC 12V	4X0.5W

SAVE THESE INSTRUCTIONS

FCC INSTRUCTIONS

CAUTION:

Please note that changes or modifications of this product not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

If you are not satisfied with this product, return it with your valid proof of purchase for a refund. Conditions apply.

See store or PetSmart.com for details.

For more information about Top Fin® products, please call 1-888-839-9638.



Dist. by/par: Pacific Coast Distributing, Inc.
19601 N. 27th Ave., Phoenix, AZ USA 85027

TF-19-438285 IM