

HUSKY




PETMATE HUSKY DOG HOUSE OWNER'S MANUAL

READ ALL INSTRUCTIONS BEFORE ASSEMBLY. SAVE THIS OWNER'S MANUAL FOR FUTURE REFERENCE.

COMPONENTS

- A. TOP
- B. MIDDLE
- C. BOTTOM
- D. VENT
- E. SCREWS (3/4" LONG #8)
12 TOTAL




ASSEMBLY INSTRUCTIONS

1. ATTACH TOP TO MIDDLE

PLACE TOP (A) UPSIDE-DOWN ON GROUND AND ALIGN MIDDLE (B) WITH THE E-Z ALIGN TABS.


ONCE ALIGNED, USE 5-SCREWS (E) AND ATTACH TOP & MIDDLE PIECES TOGETHER.



2. ATTACH TOP/MIDDLE TO BOTTOM

TAKE THE NOW CONNECTED TOP/MIDDLE, AND PLACE ON THE BOTTOM (C) OF THE DOG HOUSE. THE E-Z ALIGN TABS WILL HELP PROPERLY ALIGN THE PIECES.


ONCE ALIGNED, USE 5-SCREWS (E) TO ATTACH THE TOP/MIDDLE TO THE BOTTOM (C) OF THE DOG HOUSE.



3. ATTACH VENT

SLIDE IN THE VENT (D) ON THE TOP OF THE DOG HOUSE. ATTACH IT IN PLACE WITH 2-SCREWS (E).


NOTE: DO NOT DRAG DOG HOUSE AROUND BY THE VENT. IF MOVING THE DOG HOUSE AROUND THE YARD, TEAM LIFT WITH TWO PEOPLE.



ADDITIONAL STABILITY

FOR MAXIMUM STABILITY, THE DOG HOUSE CAN BE SECURED TO THE GROUND USING STANDARD 3/16" TENT/GARDEN STAKES. (NOT INCLUDED)

STAKES CAN BE SECURED TO THE GROUND THROUGH EACH OF THE THREE SETS OF DRAINAGE HOLES ALONG THE PERIMETER OF THE DOG HOUSE.



CLEANING

KEEP DOG HOUSE CLEAN BY WASHING WITH SOAP AND WATER. A HOSE OR POWER WASHER CAN BE USED TO RINSE.

CAUTION

- **DO NOT** STAND OR SIT ON DOG HOUSE.
- FOR PET USE ONLY. **NOT** INTENDED FOR USE BY CHILDREN.
- ALWAYS PLACE DOG HOUSE ON A FLAT, LEVEL SURFACE.
- **DO NOT** DRAG DOG HOUSE AROUND BY THE VENT. IF MOVING THE DOG HOUSE AROUND THE YARD, TEAM LIFT WITH TWO PEOPLE.
- DOG HOUSE IS INTENDED FOR ONE-TIME ASSEMBLY. DO NOT ASSEMBLE AND DISASSEMBLE PRODUCT.
- IF DOG HOUSE BECOMES BROKEN, DISCONTINUE USE AND CALL **CUSTOMER SUPPORT: 1-877-PETMATE**

LIMITED LIFETIME WARRANTY

WARRANTED FOR THE LIFETIME OF THE PRODUCT AGAINST DEFECTS IN MATERIAL AND WORKMANSHIP. SOLELY FOR THE BENEFIT OF THE ORIGINAL CONSUMER PURCHASER.

PURCHASE MUST BE MADE IN NEW CONDITION, FROM AN AUTHORIZED RESELLER. RETAIN YOUR DATED SALES RECEIPT AS PROOF OF PURCHASE.

COVERED: SOLE REMEDY IS REPLACEMENT OF DEFECTIVE PARTS OR SHIPMENT OF NEW OR COMPARABLE UNIT TO THE CONSUMER.

NOT COVERED: DAMAGES CAUSED BY ABUSE OR FAILURE TO PERFORM NORMAL MAINTENANCE. ANY OTHER EXPENSE. THIS WARRANTY SHALL NOT APPLY TO ANY DEFECT, MALFUNCTION OR FAILURE TO CONFORM WITH THE WARRANTY PROVISIONS IF CAUSED BY DAMAGE (NOT RESULTING FROM DEFECT OR MALFUNCTION) DUE TO UNREASONABLE USE BY THE PURCHASER.

THIS INCLUDES **CONSEQUENTIAL DAMAGES, INCIDENTAL DAMAGES OR INCIDENTAL EXPENSES, INCLUDING DAMAGE TO PROPERTY. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.**

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS.

ADDITIONAL LIMITATIONS: THE WARRANTY DOES NOT COVER DAMAGES IN EXCESS OF THE ORIGINAL PURCHASE PRICE. WARRANTY APPLIES FOR CONSUMER USE ONLY NOT COMMERCIAL USE.

QUALIFICATION FOR WARRANTY PERFORMANCE: RETURN PRODUCT WITH PROOF OF PURCHASE AND NARRATIVE DESCRIPTION OF THE DEFECT TOGETHER WITH YOUR NAME AND ADDRESS, FREIGHT PREPAID, TO: DOSKOCIL MANUFACTURING COMPANY, INC, WARRANTY DIVISION, P.O. BOX 1246, ARLINGTON, TX USA 76004-1246.

THIS PRODUCT WILL BE REPAIRED OR REPLACED AT DOSKOCIL'S OPTION AND WILL BE RETURNED TO YOU, WITHIN 45 DAYS AFTER RECEIVED BY DOSKOCIL.

REQUEST FOR WARRANTY ACTION: PLEASE DIRECT ALL REQUESTS FOR ACTION ON THIS WARRANTY OR ANY OTHER PRODUCT INQUIRIES TO DOSKOCIL MANUFACTURING COMPANY, INC, WARRANTY DIVISION, P.O. BOX 1246, ARLINGTON, TX USA 76004-1246 OR YOU MAY SEND YOUR INQUIRIES TO **CONSUMERSERVICES1@PETMATE.COM.**

CUSTOMER SUPPORT:

1-877-PETMATE (1-877-738-6283)