


TIMER INSTALLATION & OPERATION

To install, connect timer power supply to timer, and then the timer to the base of UVC unit as shown in the image.



To run UVC unit continuously:

Press the timer Power button. The Operating Status light should illuminate in Green to indicate normal functionality.

To run the UVC unit intermittently:

After turning the timer power on, continue pressing the Stopwatch button to cycle through the various operating time periods: 4, 6, 8, 10 and 12 hours. A Blue light will appear next to the operating time currently engaged.

Operating Status Light:

This indicates the life cycle of the UVC bulb/unit. A Green light represents proper UVC bulb functionality. A Red light designates the bulb has expired, requiring complete UVC unit replacement.

Power Interruption:

If the timer is unplugged or endures a power failure, the UVC unit will revert to the same operating time that was initially selected once it is reconnected to a power source. For example, if the timer was set to operate for 4 hours within a 24-hour period, it will continue to operate for 4 hours from the moment power is re-established. As the timer does not keep track of the time of day, if you want the UVC unit to continue running for 4 hours as of 8 am, for example, the unit should be connected to a power source at 8 am. To switch from a specific timer period to continuous 24-hour operation, press the Power button off and then on again. This will re-establish the UVC unit to run full time.

FOR AUTHORIZED WARRANTY REPAIR SERVICE

For Authorized Warranty Service please return (well packaged and by registered post) to the address below enclosing dated receipt and reason for return.

If you have any queries or comments about the operation of this product, please let us try to help you before you return the product to your retailer. Most queries can be handled promptly with a phone call. When you call (or write), please have all relevant information such as model number, age of product, details of aquarium set-up, as well as the nature of the problem.

CANADA: Rolf C. Hagen Inc., 20500 Trans Canada Hwy, Baie-D'Urfé, QC, H9X 0A2

U.S.A.: Rolf C. Hagen (U.S.A.) Corp., 305 Forbes Blvd, Mansfield, MA 02048

UK: Rolf C. Hagen (UK) Ltd, Customer Service Department California Drive, Whitwood Ind Est., Castleford West Yorkshire WF10 5QH

CALL US ON OUR TOLL-FREE NUMBER:

Canada only: 1-800-554-2436 between 9:00 a.m. and 4:30 p.m. Eastern Standard Time. Ask for Customer Service.

U.S. only: 1-800-724-2436 between 9:00 a.m. and 4:00 p.m. Eastern Standard Time. Ask for Customer Service.

U.K. only: Helpline Number 01977 521015. Between 9:00 AM and 5:00 PM, Monday to Thursday and 4:00 PM on Friday (excluding Bank Holidays).

RECYCLING

This product bears the selective sorting symbol for waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European Directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. For further information, please contact your local or regional Authorities.

Electronic products not included in the selective sorting process are potentially dangerous for the environment and human health due to the presence of hazardous substances.



2 YEAR STANDARD WARRANTY

The Fluval UVC in-line Clarifier is guaranteed for defective parts and workmanship for a period of 2 years from the date of purchase. This guarantee is valid with proof of purchase only. The guarantee is limited to repair or replacement only and does not cover consequential loss, loss or damage to livestock and personal property or damage to animate or inanimate objects, irrespective of the cause thereof. This guarantee is valid only under normal operating conditions for which the unit is intended. It excludes any damage caused by unreasonable use, negligence, improper installation, tampering, abuse or commercial use. The warranty does not cover wear and tear, breakage of glass or parts which have not been adequately or correctly maintained.

THIS DOES NOT AFFECT YOUR STATUTORY RIGHTS.

DEUTSCH

WAS IST ENTHALTEN?

1. 47 cm langer geriffelter Schlauch
2. UVC-Reiniger, 3 W
3. Zwei (2) Verschlussmuttern
4. 100-240V/24V Netzteil
5. Zwei (2) Befestigungsschrauben
6. 24-Stunden-Zeitschaltuhr



WICHTIGE SICHERHEITSHINWEISE

WARNUNG – Zum Schutz vor Verletzungen sind beim Umgang mit diesem Gerät grundlegende Sicherheitsvorkehrungen zu beachten, einschließlich der folgenden Hinweise:

1. LESEN UND BEFOLGEN SIE ALLE SICHERHEITSHINWEISE

sowie alle wichtigen Hinweise auf dem Gerät vor der Benutzung. Eine Nichtbeachtung kann zu Schäden an dem Gerät oder Verletzungen führen.

2. **GEFAHR** – Zur Vermeidung eines möglichen elektrischen Schlags sollten Sie besonders vorsichtig sein, weil bei der Benutzung von Aquariengeräten Wasser verwendet wird. In den folgenden Situationen sollten Sie nicht versuchen, das Gerät selbst zu reparieren, sondern es an einen autorisierten Kundendienst zur Reparatur geben oder das Gerät entsorgen. Wenn das Gerät eine abnormale Wasserleckage aufweist, trennen Sie es umgehend vom Stromnetz.

A. Dieses Gerät darf NICHT unter Wasser getaucht werden. Sollte das Gerät ins Wasser fallen, greifen Sie NICHT danach! Trennen Sie es erst vom Stromnetz, bevor Sie es aus dem Wasser holen.

- B. Wenn das Gerät einen abnormalen Stromverlust zeigt oder wenn sich der FI- bzw. Fehlerstromschutzschalter ausschaltet, ziehen Sie den Netzstecker aus dem Stromnetz.
- C. Gerät nach der Installation sorgfältig überprüfen. Es darf nicht an das Stromnetz angeschlossen werden, wenn Teile nass geworden sind, die nicht nass werden dürfen. Wenn elektrische Komponenten des Geräts nass werden, trennen Sie es sofort vom Stromnetz.

3. VORSICHT – NIEMALS IN EINE UV-LAMPE SCHAUEN, WENN DIESE IN BETRIEB IST.

Ultraviolette Strahlung kann Augen und Haut schaden.

4. **WARNUNG** – Sorgfältige Aufsicht ist notwendig, wenn ein Gerät von Kindern oder in der Nähe von Kindern benutzt wird. Dieses Gerät kann von Kindern ab einem Alter von acht (8) Jahren und von Personen mit eingeschränkten physischen, sensorischen oder geistigen Fähigkeiten oder einem Mangel an Erfahrung und/oder Wissen verwendet werden, wenn sie beaufsichtigt werden oder bezüglich des sicheren Gebrauchs des Geräts unterwiesen wurden und die daraus resultierenden Gefahren verstanden haben. Kinder dürfen nicht mit dem Gerät spielen. Reinigung und Benutzerwartung dürfen nicht durch Kinder ohne Beaufsichtigung durchgeführt werden. Um Verletzungen zu vermeiden, berühren Sie keine sich bewegenden oder heißen Teile.

5. **VORSICHT** – Grundsätzlich alle Geräte im Aquarium vom Stromnetz trennen, bevor Hände ins Wasser getaucht, Teile ein- bzw. abgebaut oder Geräte installiert bzw. gewartet werden. Nie am Netzkabel ziehen, um den Stecker aus der Steckdose zu ziehen. Immer am Stecker anfassen und ziehen. Geräte, die nicht benutzt werden, immer vom Stromnetz trennen.

6. Das Gerät kann nicht repariert werden. Versuchen Sie NICHT das Gerät auseinanderzubauen, da es versiegelt ist und NICHT repariert werden kann. Die ganze Einheit muss im Schadensfall ausgetauscht werden.
7. Das Gerät ist mit einer 3-Watt-Lampe ausgestattet, die nicht erneuert werden kann.
8. Dieses Gerät muss nicht gereinigt oder gewartet werden. Reinigen Sie die Einheit NICHT mit Wasser oder anderen Substanzen.
9. Das Gerät darf nur mit dem im Lieferumfang enthaltenen Netzanschluss verwendet werden.