



INSTRUCTION MANUAL

5.5" DOME LAMP

8.5" DOME LAMP



DPDL-55

DL-85

Ratings

DPDL-55/:120V AC, 60Hz, 100W Max.

DL-85:120V AC, 60Hz, 150W Max.

If you are not satisfied with this product, return it
with your valid proof of purchase for a refund.
Conditions apply. See store or PetSmart.com for details.

For more information about Thrive products,
please call 1-888-839-9638.

Dist. by/par: Pacific Coast Distributing, Inc.,
19601 N. 27th Ave., Phoenix, AZ USA 85027

Made in China

TH-19-312039 IM

Product SKU #: 5320042
5315228

Last revision: 08/12/21

(Continued)

IMPORTANT INSTRUCTIONS

READ AND FOLLOW ALL SAFETY INSTRUCTIONS BEFORE OPERATING THE REPTILE DOME LAMP

Please read these instructions prior to use of your new Reptile Dome Lamp, and contact the retailer or manufacturer if anything is missing or unclear.

5.5" Dome Lamp is designed to accept a bulb or ceramic heat emitter of up to 100 watts; 8.5" Dome Lamp is designed to accept a bulb or ceramic heat emitter of up to 150 watts.

CAUTION:

- **5.5" dome use with 100W max. or smaller lamp with Type E-26 screw base; 8.5" dome use with 150W max. or smaller lamp with Type E-26 screw base.**
- **For indoor household use only.**
- **DO NOT IMMERSE.**

CAUTION - Hot Surface. Avoid contact when lamp is in use.

Attention: This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

WARNING:

- **DO NOT USE A BULB OR CERAMIC HEAT EMITTER OF MORE THAN 150 WATTS FOR 8.5" DOME LAMP AND 100 WATTS FOR 5.5" DOME LAMP.**
- **DO NOT splice, repair or modify.**
- **DO NOT use in wet conditions.**
- **For indoor use only.**
- **Keep children and pets away from direct contact with the fixture.**
- **Fully insert the plug into the electrical outlet.**
- **Unplug when not in use.**
- **Unplug the appliance before cleaning or servicing.**
- **Fully extend cord before using.**
- **DO NOT cover with blankets, rugs or any material.**
- **DO NOT use damaged cord sets – inspect periodically.**
- **DO NOT exceed electrical rating.**
- **Avoid overheating your terrarium. Use a thermometer to measure terrarium temperature.**

(Continued)


- Make sure wattage of bulb or ceramic heat emitter is correctly rated for your size terrarium.
- Turn off electric switch and allow bulb to cool before removing from lamp fixture.

SAVE THESE INSTRUCTIONS

USAGE:

To use the Reptile Dome Lamp, make sure it is unplugged and that the inline switch is in the “OFF” position. Insert an appropriate Lamp or Ceramic Heat Emitter into the Reptile Dome and then securely mount the Reptile Dome Lamp in the desired, safe location always outside of the reptile habitat.

SEE WARNING SECTION FOR DETAILS.



ON/OFF SWITCH

Remarks: There are ON/OFF markings on the switch.

INSTALLATION:

- 1) Put the Reptile Dome Lamp Above the terrarium at the proper distance from the reptile to provide the correct environmental temperature.
- 2) Do not use the dome in an upward position.

INSTRUCTIONS IMPORTANTES VEUILLEZ LIRE ET SUIVRE TOUTES LES INSTRUCTIONS DE SÉCURITÉ AVANT UTILISATION DE CETTE LAMPE CHAUFFANTE

Veillez lire ces instructions avant d'utiliser votre nouvelle lampe chauffante et contacter votre vendeur ou le fabricant en cas de manquement ou imprécision du produit. 5.5" cette lampe chauffante est conçue pour un émetteur de chaleur en ampoule ou céramique de forme en lampe-plafonnier de jusqu'à 150 watts. 8.5" cette lampe chauffante est conçue pour un émetteur de chaleur en ampoule ou céramique de forme en lampe-plafonnier de jusqu'à 150 watts.

AERTISSEMENT :

- **Afin de réduire le risque de d'incendie, pour utilisation avec 100W ou petitelampe de type A avec le type E-26 culot à vis.**
- **Uniquement pour usage domestique et à l'intérieur de bâtiment.**
- **Ne pas l'immerger.**

AERTISSEMENT - Surface chaude. Eviter le contact lorsque la lampe est en cours d'utilisation.

ATTENTION: Cet appareil possède une lame polarisée (dont une lame est plus large que l'autre). Pour réduire le risque de choc électrique, cette lame n'est conçue que pour être tenue dans une prise polarisée dans un sens unique. Si la lame ne rentre pas complètement dans la prise, inversez la lame. Si elle ne rentre jamais, contactez un électricien qualifié.

Ne pas tenter de modifier la lame à une manière quelconque.

AERTISSEMENT

- **NE PAS** utiliser l'émetteur de chaleur en ampoule ou en céramique de plafonnier de plus de 150 watts pour 5.5" verre de lampe; 8.5" verre de lampe.
- **NE PAS** raccorder, réparer ou modifier.
- **NE PAS** l'utiliser dans les conditions humides.
- **Uniquement pour une utilisation intérieure de bâtiment.** Tenez l'appareil hors de portée des enfants et des animaux de compagnie.
- Insérez complètement la lame dans la prise électrique.
- Débranchez l'appareil lorsqu'il n'est pas en service.
- Débranchez l'appareil avant le nettoyage ou l'entretien.
- Étendez complètement le câble avant de l'utiliser.

(Continued)

- NE PAS le couvrir avec des couvertures, des tapis ou tout autre matériau.
- NE PAS utiliser les câbles endommagés - inspectez périodiquement.
- NE PAS dépasser la puissance électrique.
- Éviter de surchauffer votre préparation. Utilisez un thermomètre pour mesurer la température.
- Assurez que la puissance de l'émetteur de chaleur en ampoule ou céramique est proportionnelle à la taille de votre préparation.
- Éteignez l'interrupteur électrique pour que l'ampoule puisse se refroidir avant de retirer la lampe préparée.

CONSERVEZ CES INSTRUCTIONS