PORTABLE CANVAS CRATE ASSEMBLY INSTRUCTIONS



TOP·PAW for the love of dogs "





Step 1:

Remove crate from packaging. Release the crate clips – which are used to keep crate in the folded position. Unzip top door opening. Unfold frame to standing position.



Step 2:

Hold the top bar ① with your hand and slide the horizontal bar ② from the middle of top bar ① to the end of it and fix ②. Be careful not to pinch your hand at the connection point. Repeat the same process for the other side.



YOU SHOULD NOT PLACE ANYTHING ON TOP OF THE CRATE AT ANY TIME.



SELF-LOCK ZIPPER

Smart Advice:

Your new crate includes an important feature designed for your pet's safety. The self-lock zipper helps prevent your pet from getting out of the crate.



THE FRONT WINDOW IS REMOVABLE.

If you are not satisfied with this product, return it with your valid receipt to the place of purchase for a refund. For more information about Top Paw® products, please call 1-888-839-9638.

Dist. by/par: Pacific Coast Distributing, Inc. 19601 N. 27th Ave. Phoenix, AZ USA 85027

Made in China