

# WET BOX™

Model No. 255

## WATERPROOF Box Call

U.S. Patent No. D415,054

- **100% WATERPROOF**
- **Best Sounding WATERPROOF Box Call Ever**

Don't let the weather stop you from using your box call. The Wet Box™ is coated with our special proprietary formula that will last for years and is unaffected by repeated soakings. If you're the type of hunter that isn't going to let the rain stop you, then this is the call for you. The Wet Box™ yelps, cuts and purrs even when wet.

Speak The Language®,

*Will Primos*

Will Primos

**IMPORTANT:** Please read all instructions and warnings before using this product to ensure safe and proper use.

### INSTRUCTIONS

**ANGLE & TENSION:** The angle and tension of the lid have been pre-set for you. This eliminates much of the practice required to develop proper lid angle and tension.

**HOLDING:** There are different ways to hold and operate the Wet Box™ Call, but we recommend you start by holding as shown in Diagram 1. Grip the box loosely, just let it rest in your hand. Avoid touching the sides of the box, as this may change the tone. Hold the lid in your right hand with your thumb on top and your index finger on the bottom (See Diagram 1).

**NOTE:** Very light pressure is needed on the paddle when using the Wet Box™. If the call starts to sound too high pitched or scratchy, there is too much pressure being applied.

**CONDITIONING:** The Wet Box™ requires very little maintenance. To clean the playing surface (paddle and both tone boards) if it should need it, rub with a light abrasive pad (**Do Not Sand**).

### EXERCISES

**Purr** - Pull the lid across the lip, applying just enough lid-to-lip pressure to make the lid vibrate as it travels over the lip.

**Yelp** - Hold the Wet Box™ Call (See Diagram 1). With the paddle, softly stroke the side of the Wet Box™ Call with a forward, then upward motion, similar to a scooping movement.

**Cluck** - Strike the lip with a very short movement of the lid, pulling the lid up off the lip as you make the stroke, or you can make the cluck by simply laying the lid on the lip. With the lid open about an inch, place your thumb on the lip and barely hold it in place with your thumb. Now, lightly tap the handle of the lid with the index finger of your right hand - just enough to make the single note of the cluck (See Diagram 2).

**Cut & Cutting** - Make this call the same as you would the cluck, only use moderate thumb pressure and sharply tap the lid in an irregular rhythm (See Diagram 2).

**Cackle** - The cackle is a series of very fast yelps, which trail off to normal yelps. A total of 10 to 12 notes is usually made.

**VISIT OUR WEBSITE AT PRIMOS.COM**

Diagram 1





Diagram 2



**WARNING:** Primos® game calls are so accurate that you might attract other hunters, as well as game. The user of this product assumes all risk of injury in association with the use of this product.

Made in U.S.A.



Primos® Hunting Calls™

604 First St., Flora, MS 39071

**LIFETIME  
SERVICE  
GUARANTEE:**

All Primos® game calls come with a Limited Lifetime Service Guarantee. For warranty or service information, email [service@primos.com](mailto:service@primos.com) or call customer service at (601) 879-9323.

**PRIMOS®**  
**HUNTING CALLS™**

SPEAK THE LANGUAGE®