

Hellrazor[®] Installation Instructions

Hellrazor is the one-piece, all-steel broadhead that is shaving sharp!

- Ultra-strong all stainless steel construction
- Tough 0.040" thick blades
- One-piece no loose blades ever
- Super-accurate
- Easily resharpened



- 1. Remove broadhead from tray and insert into wrench (supplied).
- 2. Screw arrow shaft onto broadhead until tight.

HANDLE WITH EXTREME CAUTION - This product may be extremely dangerous and will cause injury if handled improperly.

To avoid injury use the enclosed safety wrench when attaching and removing broadhead. Store heads in quiver after assembly.