



nüvi[®] 2505 series quick start manual

nüvi models: 2515, 2545, 2555, 2565, 2595



Getting Started

WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

Setting Up Your Device

When using your device for the first time, complete the following tasks.

- 1 Connect the device to vehicle power (page 2).
- 2 Mount the device (page 2).
- 3 Register the device (page 3).
- 4 Check for updates.
 - Software updates (page 4).
 - Free map update (page 4).
- 5 Download the full owner's manual (page 4).

Connecting the Device to Vehicle Power

WARNING

This product contains a lithium-ion battery. To prevent the possibility of personal injury or product damage caused by battery exposure to extreme heat, remove the device from the vehicle when exiting or store it out of direct sunlight.

NOTICE

Before mounting the device, see the *Important Safety and Product Information* guide for information about laws pertaining to windshield mounting.

Charge your device as you drive before using it on battery power.

- 1 Plug the vehicle power cable ① into the USB port ② on the device ③.
- 2 Press the suction cup ④ to the windshield.

- 3 While pressing, flip the lever ⑤ back toward the windshield.



- 4 Snap the mount ⑥ onto the suction cup.
- 5 Fit the bottom of your device into the mount.
- 6 Tilt your device back until it snaps into place.
- 7 Plug the other end of the vehicle power cable into a power outlet in your vehicle.
- 8 If necessary, connect the external antenna to the vehicle power cable and secure it to the windshield using the suction cups.

About myDashboard

You can use myDashboard to register your device, check for software and map updates, access product manuals and support, and more.

Setting Up myDashboard

- 1 Connect the mini-USB cable ① to the mini-USB port ② on the device (page 2).



- 2 Connect the mini-USB cable to the USB port on your computer.
- 3 Go to www.garmin.com/dashboard.
- 4 Follow the on-screen instructions.

Registering your Device

- 1 From myDashboard, click **Register Now**.

- 2 Follow the on-screen instructions.
- 3 Keep the original sales receipt, or a photocopy, in a safe place.

nüMaps Guarantee™

If you register the device at <http://my.garmin.com> within 90 days of acquiring satellites while driving, your device could be eligible for one free map update. Go to www.garmin.com/numaps for terms and conditions.

Using myDashboard Services


- 1 Open myDashboard ([page 3](#)).
- 2 Select an option:
 - To update the software, click **Update Now** under Software Updates.
 - To update the maps, click **Update Now** under Map Updates.
 - To download the owner's manual, click **Manuals**, and then click **Download** next to the manual you want.

- 3 Follow the on-screen instructions.

Using the Power Key



Select an option:

- To turn off the device, hold the **Power** key ① for 4 seconds.
- To reset the device, hold the **Power** key for 10 seconds.
- To put the device in sleep mode, press the **Power** key.
- To bring the device out of sleep mode, press the **Power** key and double-tap .

Finding a Location Using the Search Bar

You can use the search bar to search for locations by entering a category, brand name, address, or city name.

- 1 Select **Where To?**.
- 2 Select the search bar.




- 3 Enter a search term.

Suggested search terms appear below the search bar as you type.

- To search for a type of business, enter a category name, such as “movie theaters” or “coffee shops.”
- To search for a business by name, enter all or part of the name.
- To search for an address near you, enter the street number and street name.

- To search for an address in another city, enter the street number, street name, city, and state.
- To search for a city, enter the city and state.
- To search for coordinates, enter latitude and longitude coordinates.

- 4 Select an option:


- To search using a suggested search term, select the term.
- To search using the text you entered, select .

- 5 If necessary, select a location.

Searching Near Another Location

From the main menu, select **Where To?** > **Searching Near**.

Adding a Stop

- 1 From the navigation screen, select  > **Points of Interest**.
- 2 Search for the extra stop.
- 3 Select the stop from the search results.
- 4 Select **Go!**.
- 5 Select **Add to Active Route**.

Your Route on the Map

NOTICE


The speed limit icon feature is for information only and does not replace the driver's responsibility to abide by all posted speed limit signs and to use safe driving judgment at all times. Garmin will not be responsible for any traffic fines or citations that you may receive for failing to follow all applicable traffic laws and signs.

Your route is marked with a magenta line on the map. If you depart from the original route, your device recalculates the route. A speed limit icon could appear as you travel on major roadways.



- Select **1** to view the next turn.
If a view of a junction exists, the junction view appears.
- Select **2** to view the turn list.
- Select **3** to stop the route you are currently navigating.
- Select **4** to view the Where Am I? page.

Taking a Detour

From the navigation page, select  > **Detour**.

If the route you are currently taking is the only reasonable option, the device might not calculate a detour.


About Traffic

NOTICE

Garmin is not responsible for the accuracy or timeliness of the traffic information.

Traffic information may not be available in all areas or countries.

A traffic receiver is included in some packages. It is built into the vehicle power cable. The traffic receiver and the device must be in data range of a station transmitting traffic data to receive traffic information. You do not need to activate the subscription included with your traffic receiver.

When you are receiving traffic information, a traffic icon  changes color to indicate the severity

of traffic conditions on your route or on the road you are currently traveling.

Go to www.garmin.com/traffic for more information.

Pairing Your Phone

Hands-free calling is available on some nüvi models. Before you can pair, your phone and the device must be turned on and within 33 ft. (10 m) of each other.

- 1 Enable the Bluetooth® component on your phone.
- 2 Select **Settings > Bluetooth**.
- 3 Select **Bluetooth**.
- 4 Select **Add Phone > OK**.
- 5 Select your phone, and touch **OK**.
- 6 Enter the Bluetooth PIN (**1234**) for your device in your phone.

www.garmin.com/support



913-397-8200
1-800-800-1020



00 32 2672 5254



0180 5 / 42 76 46 - 880
0180 5 / 42 76 46 - 550



00800 4412 454
+44 2380 662 915



0808 2380000
+44 (0) 870.8501241



00 45 4810 5050



00 39 02 3669 9699



00 35 1214 447 460



1-866-429-9296



00 358 19 311 001



0800-0233937



00 902 00 70 97



43 (0) 3133 3181 0



00 33 1 5517 81 89



815 69 555



00 46 7744 52020

Garmin International, Inc.

1200 East 151st Street,
Olathe, Kansas 66062, USA

Garmin (Europe) Ltd.

Liberty House, Hounsdown Business Park
Southampton, Hampshire, SO40 9LR UK

Garmin Corporation

No. 68, Zhangshu 2nd Road, Xizhi Dist.
New Taipei City, 221, Taiwan (R.O.C.)

Garmin®, the Garmin logo, and MapSource® are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. nūMaps Guarantee™ is a trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc., and any use of such name by Garmin is under license.

