


Trampoline Attachment



MODEL RGM1941.1



BEFORE YOU BEGIN

Thank you for selecting the AZOOGA SPORTS ARENA Volley Ball Net Attachment. The AZOOGA SPORTS ARENA game accessories, when combined with a properly placed and maintained trampoline and enclosure, will provide many years of backyard fun. This information must be read by all supervisors and users before any person is allowed to use the game accessories.

If you have any questions after reading this manual, please call our toll-free Customer Care Hot Line at 1-866-603-Jump (5867), Monday through Friday, 8 a.m. until 5 p.m. Mountain Time (excluding holidays). To help us assist you, please mention the name of the product when calling (Azooga Sports Arena Volley Ball Net Attachment).

www.skywalkertrampolines.com

CARE AND MAINTENANCE

Continued exposure over a long period of time to the sun, especially to ultraviolet rays, will shorten the life of the game attachment fabric. For longer fabric life, store the game attachments when they are not being used. Dry game attachments, properly stored, will provide the longest life of the fabric, sewing, and hardware. Remove the game attachments from the trampoline during harsh weather conditions or during long periods of non-use.


CAUTION

Users should remove the volley ball net while not in use or in the case of high wind or snow. The warranty does not cover damage caused by wind or inclement weather.

The volley ball net is not to be used for anything other than for the game. Do not jump into the volley ball net. Do not hang on the volley ball net or allow others to do so. This can result in serious injury. Place volley ball net, pole, ground stakes and tie down ropes away when not in use. Users should be mindful of the ground stakes and tie down ropes while in use as these can cause a tripping or entanglement hazard.

ASSEMBLY for Volley Ball net


- 1. Attach the upper upright (8) to the lower upright (9) gapole. The upper upright has four metal loops welded to it. Align the loops so four loops face the same direction.
- 2. Secure with bolt (1) and nut (2)
- 3. Attach the net (7) to the upright pole at the desired height using the metal clips. There are two choices for the game net height. Tie the straps attached to the net to the metal loops on the upright poles.
- 4. Attach the opposite end of the game net to a Trampoline enclosure upright pole by tying the straps (10) around the enclosure pole. Be sure to attach at a similar height as the game pole upright.
- 5. Stretch out the game net away from the Trampoline until the net is tight and in the location you prefer the game to be located.
- 6. Push into the ground the upright ground stake (5) at the location that the game net is tight.
- 7. Slide the game upright poles into upright ground stake and secure with the furnished bolt (1) and nut (2).
- 8. Tie the ends of the ropes (4) to the upper game upright and pull away to secure the upright pole.



9. On the opposite end of the rope secure the rope (4) though the eyelet in the ground stake (6). Take the tensioning device (3) with the four holes and loop the rope though the three grouped hole. Starting from the outside, loop into one hole and then the opposite direction into the next hole. When exiting the third hole place the line into the eyelet on the ground stake (6) and loop into the fourth hole and tie a knot around to secure. This function is similar to erecting a tent. Place a ground stake (6) into the ground and pull the line out away from the tensioning device (3) into a large loop to tension the rope.


Ground Stake 9. Tie A Knot Tension Device Pull String to Adjust Tension

10. Once the game upright pole is secured the game is ready to play.



EXPLODED DRAWING AND PARTS LIST

Key No.	Qty.	Description
1	2	Bolts
2	2	Nuts
3	3	Tension Device
4	3	Rope
5	1	Upright Ground Stake
6	3	Rope Ground Stake
7	1	Net
8	1	Upper Upright
9	1	Lower Upright
10	2	Straps



ORDERING REPLACEMENT PARTS

To order replacement parts, visit our web site at www.skywalkertrampolines.com . For any questions regarding parts or assembly call our toll-free Customer Care Hot Line at 1-866-603-Jump (5867), Monday through Friday, 8 a.m. until 5 p.m. Mountain Time (excluding holidays). To help us assist you, please provide the following information when calling:

- the KEY NUMBER and DESCRIPTION of the part (see the PARTS LIST above)
- the quantity needed

Azooga Volley Ball Net

The Azooga Volley Ball Net is the perfect addition to your trampoline. It sets up easily attaching to the side of your trampoline enclosure and quickly rolls up and straps on to the side of the enclosure for simple and convenient storage when not in use.

Aside from your traditional volley ball game, try out these fun variations. They give a fun twist on your traditional game and can include players of multiple skill levels.

1. Fire Ball

- For this fun game you will need any light weight ball, a volley ball or you can even use a balloon. A timer or someone to run a radio with music.
- Divide the group into two teams. One team on each side of the net. Designate someone as the "Music Player" or "Time Keeper" who will not be included in the teams.
- When the time starts, or the music is turned on the game begins. Toss, or hit the ball over the top of the net back and forth. The goal is to keep the "Fire Ball" out of your field. Different from traditional volley ball, it does not score against anyone if the ball hits the ground or goes out of bounds. When the timer goes off or the music stops the game must freeze.
- The player holding the ball or the last person to hit or touch the ball when the music stops or the timer goes off is then out of the game.
- Start the music or the timer again and continue the game until one of the teams is eliminated.

2. Volley-Over

- For this game you will need a volley ball.
- The Group is divided into two teams. One on each side of the net.
- Traditional volleyball rules are used for this game, however instead of each team scoring a point, they choose a member from the opposite team to join their team.
- The game can be played for as long as desired with the winning team having the most players in the end or until one team is completely eliminated.

LIMITED WARRANTY

Skywalker Holdings, LLC warranties its trampoline products to be free from defects in material and workmanship under normal use and service conditions. The steel frame is warranted for one (1) year after the date of purchase. All other parts are warranted for ninety (90) days after the date of purchase.

All warranty coverage extends only to the original retail purchaser from the date of purchase. Skywalker Holdings, LLC obligation under this Warranty is limited to replacing or repairing, at Skywalker Holdings, LLC option, the product at one of this authorized service centers. All products for which a warranty claim is made must be received by Skywalker Holdings, LLC at one of its authorized locations. Preauthorization may be obtained by calling Skywalker Holding, LLC Customer Care Hot Line at 1-866-603-Jump(5867). This Warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage, or repair not provided by a Skywalker Holdings, LLC authorized service center, or to products used for commercial or rental purpose. No other Warranty beyond that specifically set forth above is authorized by Skywalker Holdings, LLC. SKYWALKER HOLDINGS, LLC IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUE NTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU. This Warranty gives you specific LEGAL RIGHTS. You may also have other rights which vary state to state.

THIS WARRANTY IS VALID ONLY IN THE UNITED STATES.

Skywalker Holdings, LLC, PO Box 574, Brigham City, UT 84302 USA.

Printed in China © 2013 Skywalker Holdings, LLC,