




Most Kwik Goal products carry a **Lifetime Guarantee**. For details or claims, visit **kwikgoal.com** or contact customer service at 1-800-531-4252.


ASSEMBLY INSTRUCTIONS FOR 16B6 (ALL-SURFACE SOCCER TENNIS)

- 1. Unpack all parts and check for damage that may have occurred during shipping. If damage has occurred, notify trucking company immediately. Lay out all parts. Remove all cardboard and packaging immediately. Wet or damp packaging may damage contents.
- 2. Read through entire instruction before beginning assembly and installation.
- 3. Assemble net onto frame as shown.



CAUTION

All sports equipment must be anchored at all times. Sports equipment not in use must be disassembled and stored in a safe, secure place. Assembled sports equipment should not be left unattended. Do not use this equipment during the threat of high winds. Sports equipment should be checked for safety on a regular basis. Any modifications to this or any Kwik Goal product will void any and all warranties.



To view videos on Kwik Goal product instructions, drills and demos please visit kwikgoal.com/videos.

CAUTION

All sports equipment must be anchored at all times. Sports equipment not in use must be disassembled and stored in a safe, secure place. Assembled sports equipment should not be left unattended. Do not use this equipment during the threat of high winds. Sports equipment should be checked for safety on a regular basis. Any modifications to this or any Kwik Goal product will void any and all warranties.