mobo

ASSEMBLY www.mobocruiser.com







A. Remove Outer Nut From Wheel Bo







C. Tighten Using Wrenches



QUESTIONS? Call 877-869-6451 email info@asaproducts.com



D. With Stoppers Facing Forward Attach Rear & Front Frames.Hand Screw Bolt & Washer.



E. Tighten Using Allen Wrench and Wrench



F. Linkage Steering Set Up



* If you have a seat belt, please attach before moving forward with the next step.



G. Place Screws and Washers in Seat on Frame



H. Tighter









I. Remove Cap

J. Place Fender and Replace Cap

K. Tighten Cap







L. Adjust length to fit

30 DAY MANUFACTURER'S LIMITED WARRANTY: THIS WARRANTY IS EXPRESSLY LIMITED TO THE REPAIR OR REPLACEMENT OF A DEFECTIVE PART AND SOLE REMEDY OF THE WARRANTY.

ASA WILL SUPPLY REPLACEMENT PARTS AT NO COST TO THE CONSUMER, HOWEVER, THE CONSUMER WILL BE RESPONSIBLE FOR APPLICABLE SHIPPING CHARGES RELATED TO RETURNED ITEMS. THIS WARRANTY DOES NOT COVER NORMAL WEAR AND TEAR, IMPROPER ASSEMBLY, AND DAMAGE DUE TO MISUSE, ABUSE, OR NEGLECT. THIS WARRANTY EXTENDS THIRTY (30) DAYS FROM THE DATE OF THE RECEIPT, APPLIES ONLY TO THE ORIGINAL OWNER, AND IS NON-TRANSFERABLE. PROOF OF PURCHASE AND AN EXPLANATION OF PROBLEM ARE REQUIRED.



www.mobocruiser.com or call 1-877-869-6451

WARNING:

- · Never ride your Mobo on public streets or roads.
- The recommended riding age for the Mobo Tot is 2 years and up.
- The maximum weight capacity for the Mobo Tot is 100 lbs.
- Always wear protective foot wear and head gear. Head gears should conform to U.S. CPSC Standard 16 CFR 203. It is strongly advised that knee and elbow pads be worn while riding.
- The Mobo is designed for use on dry, flat, and smooth surfaces. Never ride on dirt, gravel, sand, grass, slick or wet surfaces.
- Never ride the Mobo over jumps or off curbs. The Mobo was not designed for this type of use.
- Keep your hands, feet, hair, and shoestrings away from all moving parts.
- Please ensure that all screws and bolt are securely tightened for a safe riding experience.
- Adult assembly required. Choking hazard to children under the age of 3 years - contains small parts prior to assembly.

⚠ WARNING

TO AVOID SERIOUS INJURY: Continuous adult supervision required; never use near motor vehicles; never use near streets, swimming pools, hills, steps, or sloped driveways; Always wear shoes when using the tricycle. Never allow more than 1 rider.

CRUISE IN STYLE