

ASSEMBLY

INSTRUCTIONS

mobo®




TRI·TON
and
TRI·TON Pro




ASSEMBLY

PARTS



front frame set

rear frame




wheels



rear fenders



saddle



seat cushion



steering arm



fender tool



wrench



steering handle screws



seat screw set
frame screw set



allen wrenches



reflector



screwdriver



rubber
tire hubs



safety flag
and pole

Welcome to the Mobo Family!

Use This Manual or



Scan for Assembly Video




mobo 




ASSEMBLY

www.mobocruiser.com



PARTS




Remove screws from back of front wheel frame.



Attach rear frame and tighten screw.



Remove screw from wheel axle.



QUESTIONS? Call 877-869-6451 email info@asaproducts.com



D
Remove rubber hubs from wheel.
Insert wheel into wheel axle.



E
Fasten screw.



F
Replace rubber hub.
Repeat on second side



G
Align steering arm to center of frame.



H
Fasten steering handle screw.



I
Align second steering arm to frame
and fasten steering handle screw.



mobo

ASSEMBLY

www.mobocruiser.com



Remove screw from linkage steering.



Align linkage steering and fasten screw.



Remove screw from linkage steering on second side.



Align linkage steering and fasten screw



Align saddle with seat cushion.
Fasten screws.



Align saddle with frame.
Insert screw and nuts.



QUESTIONS? Call 877-869-6451 email info@asaproducts.com



Tighten nut.



Remove chrome cap from
rear wheel frame.




Place rear fender and tighten
chrome cap. Repeat on other side.



Unfold pedals.



Loosen knob to adjust length.
Tighten knob.



Remove screw from reflector.
Place over center saddle and tighten.



WARNING:

- Never ride your Mobo on public streets or roads
- The recommended riding age for the Mobo Triton is 7 yrs. & up; The Mobo Triton Pro is 12 yrs.& up.
- The maximum weight capacity for the Mobo Triton is 220 lbs, and for the Mobo Triton Pro is 250 lbs.
- Always wear protective head gear. It is strongly advised that knee and elbow pads be worn while riding.
- Always wear appropriate footwear.
- The Mobo is designed for use on dry, flat, and smooth surfaces. Never ride on dirt, gravel, sand grass, slick or wet surfaces.
- Never ride the Mobo over jumps or off curbs. The Mobo was not designed for this type of use.
- Never ride the Mobo with more than one rider or with any passenger.
- Keep your hands, feet, hair, and shoestrings away from all moving parts.
- Never leave children alone with the Mobo.
- Please ensure that all screws and bolts are securely tightened for a safe riding experience.

CRUISE IN STYLE

: THIS WARRANTY IS EXPRESSLY LIMITED TO THE REPAIR OR REPLACEMENT OF A DEFECTIVE PART AND SOLE REMEDY OF THE WARRANTY.

ASA WILL SUPPLY REPLACEMENT PARTS AT NO COST TO THE CONSUMER, HOWEVER, THE CONSUMER WILL BE RESPONSIBLE FOR APPLICABLE SHIPPING CHARGES RELATED TO RETURNED ITEMS. THIS WARRANTY DOES NOT COVER NORMAL WEAR AND TEAR, IMPROPER ASSEMBLY, AND DAMAGE DUE TO MISUSE, ABUSE, OR NEGLIGENCE. THIS WARRANTY EXTENDS THIRTY (30) DAYS FROM THE DATE OF THE RECEIPT, APPLIES ONLY TO THE ORIGINAL OWNER, AND IS NON-TRANSFERABLE. PROOF OF PURCHASE AND AN EXPLANATION OF PROBLEM ARE REQUIRED.