



Most Kwik Goal products carry a **Lifetime Guarantee**. For details or claims, visit **kwikgoal.com** or contact customer service at 1-800-531-4252.

## ASSEMBLY INSTRUCTIONS FOR 2B2201 (PROJECT STRIKEFORCE)

- 1. Unpack all parts and check for damage that may have occurred during shipping. If damage has occurred, notify trucking company immediately. Lay out all parts. Remove all cardboard and packaging immediately. Wet or damp packaging may damage contents.
- 2. Read through entire instruction before beginning assembly and installation.
- 3. If goal is to be used in a portable application continue to step 4. If goal is to be used in a more permanent application skip steps 4 through 6 and begin assembly with step 7.



This goal has been designed to be used for the game of soccer only. Goal posts must be anchored AT ALL TIMES and shall be secured against overturning. Do not climb on the net or goal framework at any time! All fastenings must be checked to insure they are fully tightened before and after each use of this product. Goal posts not in use must be disassembled and properly stored in a safe, secure area (See included Guidelines for Moveable Soccer Goal Safety.). Assembled goal posts should not be left unattended. Remove nets when goals are not in use. Do not use this equipment during the threat of high winds. Goal posts should be checked for safety before and after each use. All warning and safety labels included with this product must be visible at all times.

Any modifications to this or any Kwik Goal product will void any and all warranties.

140 Pacific Drive Quakertown, PA 18951 (P) 215-536-2200 / (P) 800-531-4252 / (F) 215-536-4309 / (F) 800-778-8869 Visit our website @ kwikgoal.com ©2002, Rev. 2013 Kwik Goal Ltd. 4. Assemble crossbar, bases and posts as shown.



5. Attach net to goal using net fastener, provided. Be sure to cut net fastener into 9"-10" pieces to ensure a 2" overlap.



## \*\*\*CAUTION\*\*\*

This goal has been designed to be used for the game of soccer only. Goal posts must be anchored AT ALL TIMES and shall be secured against overturning. Do not climb on the net or goal framework at any time! All fastenings must be checked to insure they are fully tightened before and after each use of this product.

Goal posts not in use must be disassembled and properly stored in a safe, secure area (See included Guidelines for Moveable Soccer Goal Safety.). Assembled goal posts should not be left unattended. Remove nets when goals are not in use. Do not use this equipment during the threat of high winds. Goal posts should be checked for safety before and after each use. All warning and safety labels included with this product must be visible at all times.

Any modifications to this or any Kwik Goal product will void any and all warranties. NZ186 Rev. 10/24/13

7. Assemble crossbars, base and post as shown.



## \*\*\*CAUTION\*\*\*

This goal has been designed to be used for the game of soccer only. Goal posts must be anchored AT ALL TIMES and shall be secured against overturning. Do not climb on the net or goal framework at any time! All fastenings must be checked to insure they are fully tightened before and after each use of this product. Goal posts not in use must be disassembled and properly stored in a safe, secure area (See included Guidelines for Moveable Soccer Goal Safety.). Assembled goal posts should not be left unattended. Remove nets when goals are not in use. Do not use this equipment during the threat of high winds. Goal posts should be checked for safety before and after each use. All warning and safety labels included with this product must be visible at all times.

Any modifications to this or any Kwik Goal product will void any and all warranties.

10. Weave base through net and attach to crossbar as shown.



11. Disconnect post from goal and weave through net as shown. Reconnect post to base and crossbar as shown.



To view videos on Kwik Goal product instructions, drills and demos please visit kwikgoal.com/videos.