




Assembly Instructions & User's Manual 6 Piece Folding Dining Set 155507



Please keep this instruction manual for future reference

Customer Service: (888) 922-2336

7:00 am to 12:00 am CST (daily)

Live Chat at: www.academy.com

Email: customerservice@academy.com

-----OR-----

**(877) 579-1550 8:30am to 5:30pm Monday thru Friday, EST
(Made in China)**

Table of Contents

Warnings.....1

Tools, Parts and Hardware.....2

Assembly Instructions.....3-8

Care and Maintenance..... 9

Warranty Information.....10




Warnings

- Weight Limit Chair: 250Lb
- Weight Limit Table: 100 Lb
- Ensure that all parts are securely fastened and that all nuts and bolts are fully tightened before use.




Note: Before beginning assembly of product, make sure all parts are present. Compare parts with package content list and contents on next page. If any part is missing or damaged do not attempt to assemble the unit. Contact customer service for replacement parts.

Sku: 113386579
Style#: 155507





Tools Required

1	Allen Wrench (included)	
2	Wrench (included)	
3	Phillips Screwdriver (not included)	

Parts List

A	Table Top		1
B	Table Leg		4
C	Center Ring		1


Hardware

D	M6x50 Bolt		4
E	M6x35 Bolt		4
F	Nut		8
H	Screw		4

Assembly Instructions

Step 1:

Place the Table Top (A) on a soft and non-abrasive surface, remove all packing material. Attach table Legs (B) into each corner bracket on the Table Top (A). Attach all the legs with screws (H) using a philips screwdriver (3).




Step 2:

Attach the Center Ring (C) to the legs with M6 x 50 Bolts (D) and Nut (F).

Further secure the table with Bolts (E) and Nut (F).

Tighten with Allen Wrench (1) and Wrench (2) after all the bolts are in position and hand tightened, then turn the table upright.



Assembly Instructions

Step 3:

Turn the table upright.



Step 4:


Pull out the chair and remove the packaging



Assembly Instructions


Step 5:

open the chair according to the right figure.



Step 6:

Pull the back till fully open




Assembly Instructions

Step 7:


Pull out the umbrella and remove the packaging. Hold the upper umbrella pole and insert into the bottom pole.

Lock the pole according to the figure on the right.



Step 8:

Hand open the umbrella by pushing upwards until the button locks in place.



Assembly Instructions


Step 9:

Umbrella setup finish.



Step 10:


Press the button and pull the umbrella downwards, and pull the lock upwards according to the right figure.



Assembly Instructions

Step 11:

Pull the up pole out of the bottom pole.



Care and Maintenance

This patio set should be cleaned on a regular basis to promote safe use and prolonged product life.

Wipe the frame with a smooth damp cloth and air dry.

Do not use abrasive cleaners as they may damage or scratch the surface paint. Do not leave this product in severe weather conditions for extended periods. For extended life, the patio set should be stored indoors or covered during prolonged periods of non-use. Storing in a dry location will help prevent rust.

Warranty Information

This product has been manufactured under the highest standards of quality and workmanship. We warrant to the original consumer purchaser that all aspects of this product will be free of defects in material and workmanship for one year from the date of purchase. A replacement for any defective part will be supplied free of charge for installation by the consumer. Defects or damage caused by the use of other than genuine parts are not covered by this warranty. This warranty shall be effective from the date of purchase as shown in the purchaser receipt.

This warranty is valid for the original consumer purchaser only and excludes industrial, commercial or business use of the product, product damage due to shipment or failure which results from alteration, product abuse, or product misuse, whether performed by a contractor , service company , or consumer. We will not be responsible for labor charges and/or damage incurred in installation, repair or replacement nor for incidental or consequential damage.