

# USER MANUAL

## PRODUCT INFORMATION:

Read this information before proceeding. It is the user's responsibility to take the following precautions at all times.

- Always stake or weigh down your canopy. Do not use in any potentially windy or rainy weather. Wind and rain can damage your canopy and may also result in injury to you or others. Therefore, do not rely on canopy for protection in heavy or prolonged rain storms.
- This product is designed as a temporary sun canopy. Do not leave up for extended periods.
- Use caution when handling the canopy's frame. Avoid pinching hands or fingers as frame opens or closes.
- Do not use canopy in a lightning storm.
- Do not leave your canopy unattended.
- Do not build fires under canopy.
- DO NOT USE FOR VEHICLE STORAGE.

## PRODUCT CARE & MAINTENANCE:

For long lasting durability and the best possible protection for your canopy, follow these care & maintenance instructions:

- Use a mild soap (not detergent) and plenty of water for top cleaning.
- Let the canopy top and frame dry completely before closing or storing to avoid mildew.
- The canopy frame will operate and look better if occasionally wiped with silicone spray, especially before and after use in damp conditions. Remove excess silicone residue before attaching top.
- Slightly tighten bolts if frame becomes loose.

## 2 YEAR LIMITED WARRANTY

Z-Shade Co. Ltd., manufacturer of the product, warrants to the original purchaser who provides a dated sales receipt from an Authorized Dealer, each part of the Z-Shade product to be free from defects in material or workmanship for a period of two (2) years after the date of original purchase. The frame is covered under a limited two (2) year warranty and guarantees the frame to be free from defects in material or workmanship. This warranty applies only for normal and expected uses, as determined by the manufacturer.

Z-Shade Co. Ltd. obligation and liability under this warranty is limited to the repair or replacement (*at its option*) of the product or its parts, after its own review and examination.

**RETURN GOODS:** Before returning any part or product to Z-Shade, please phone or write to obtain specific return shipping instructions. All shipping costs must be prepaid, and Z-Shade is not responsible for products damaged in transit.

**CONDITIONS:** This warranty shall be void as to any product which has been altered or modified in any manner. This warranty does not apply to damages caused by wind, rain, or other forces of nature, not to accidental or deliberate damage of the product, nor to use of the product that does not conform with the product instructions.

This warranty is provided in lieu of all other warranties, expressed or implied.

©2017 Z-Shade Co. Ltd. All Rights Reserved.

101317

# EVEREST

## Instant Canopy



**20ft. x 10ft.**  
(6.1m x 3.05m)



**16ft. x 8ft.**  
(4.87m x 2.4m)



Z-Shade Co. Ltd.  
**(855) 4 Z-SHADE**  
(855) 497-4233

[www.zshadeusa.com](http://www.zshadeusa.com)






## PACKAGE INCLUDES

- Z-Shade Frame and Canopy Top
- (20'x10') includes:
- Dust Cover
  - 6-Piece Stake Kit
- (16'x8') includes:
- Roll Away Bag
  - 12-Piece Stake Kit
  - Tie Downs & Guy Ropes






## INITIAL SET UP

Please read each step before you attempt to set up. Save these instructions for future reference.




- 1 With partner, grasp (2) outer legs, slightly lift off the ground, and step backwards – stopping at full arms' length - approximately 3/4 its total size.
- 2 Unfold the canopy top and place it over the open frame. – Align all corners of the canopy top over the corners of the frame.
- 3 Secure the canopy top to the frame by attaching the canopy locking strips to the locking strips on the frame. *Fully pull the corners down.*


## SET UP



- 1 With partner on opposite side, place your frame in the center of area to be shaded. Grasp (2) outer legs, lift off the ground, and step backwards - stopping at full arms' length.
- 2 Grasp the top and bottom of the truss on opposite sides. Slightly lift canopy up and push hands together while stepping backwards until canopy is fully opened. Be careful not to pinch fingers or push too hard so as to avoid damage to truss.
- 3 To engage slider at each corner, first lift the fabric off of the slider. Then, with one hand hold the top of the leg while PUSHING UP the push button slider with other hand the until slider engages. *Repeat on center legs.*





**Height Adjustment:**  
Press push button lock to release and adjust legs to desired height.  
*Repeat on remaining legs.*





- 4 With partner, lift outer legs up & slide out the INNER legs until the push button locks into outer legs. *Repeat on opposite legs.*  
– Next, with partner, push button to release and adjust center legs.

**Tie Downs (6):** (Available on 16'x8' only.) Attach guy ropes to stake in the ground (roughly at 45°) to support the canopy. *Repeat on remaining tie downs.*

## TAKE DOWN



- 1 **NOTE: Release Tie Downs prior to Take Down.** With partner, raise & slightly lift up CENTER legs, push button to unlock and telescope inner legs into outer legs.  
– Next, lift up outer legs and push button to unlock and telescope inner legs into outer legs. *Repeat on opposite legs.*
- 2 Release push button slider at each corner by first lifting fabric away from slider. Push button slider to release slider and unlock from truss. *Repeat on center legs.*



- 3 Grasp the top and bottom of the truss on opposite sides. Slightly lift canopy up and pull hands apart while stepping towards your partner until canopy is 3/4 opened.
- 4 With partner on opposite side, grasp (2) outer legs, push frame (slightly and shake canopy) together while stepping towards your partner until fully closed. Be careful not to pinch fingers! Store canopy in dust cover or roll away bag.

**⚠ WARNING:** Keep all flame and heat sources away from all product fabrics. These fabrics meet the flammability requirements of CPAI-84 and NFPA-701 specifications. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the fabric may render the flame-resistant properties ineffective. This product contains TDCPP and/or TCEP, flame retardant chemicals known to the State of California to cause cancer, birth defects or other reproductive harm or both.