



**User Manual**  
**XL Sport Wagon and Cooler**  
Style # 156766



**Please keep this instruction manual for future reference**

**Customer Service: (888) 922-2336**

**7:00am to 12:00am Daily CST**

**Live Chat @ Academy.com: 24/7**

**Email: customerservice @academy.com**

**-----OR-----**

**(877) 579-1550, 8:30am to 5:30pm Monday thru Friday, EST**

**(Made in China)**


# Warnings

Carefully follow the conditions listed below to avoid product breakage and possible injury.

- This folding cart holds a maximum weight of 225 LB (102.1 KG). Do not exceed.
- Care should be taken to avoid finger injuries while folding and unfolding the cart.
- Do not take cart over curbs or drop offs to avoid damage.
- Keep children away from the cart during folding/unfolding
- This product is not a toy for children. Do not sit in it.
- This product is designed for storing and transporting only. Don't carry passengers or pets.
- Please secure all products in the cart to avoid dropping.
- Regularly inspect the cart for damage, wear and tear that might affect the integrity of the cart.
- Wheel performance may vary depending on terrain and load. For best results, use on flat even surfaces.
- Note: Before beginning assembly of product, make sure all parts present. Compare parts with package content list and hardware contents. If any part is missing or damaged don't attempt to assemble the unit. Contact customer service for replacement parts

# INSTRUCTIONS

**1. To Open:** Release the buckles, then pull the front and rear ends of the frame apart until they are fully extended. To fully extend the handle, pull until it clicks.



**2. To Set-up Cooler:** Enlarge the cooler compartment and attach the coolers two sides to the cart through the hook and loop fastener.



**3. To Fold:** Push the front and rear ends of the frame together and clip the buckle together. With handle extended, wagon can be conveniently rolled for transport. Push button and retract handle for storage.



## Care and Maintenance

- This cart is designed to be enjoyed outdoors.
- This wagon should be cleaned on a regular basis to promote safe use and prolonged product life.
- Wipe the frame with a smooth damp cloth and air dry
- Do not use abrasive cleaner as they may damage or scratch the surface paint.
- Do not leave this product in harsh weather conditions for extended periods of time.
- During prolonged periods of non-use, this cart may be stored indoors or by using a cloth cover. Storing in a dry location will help.

## Warranty Information

The appliance has been manufactured under the highest standards of quality and workmanship. We warrant to the original consumer purchaser that all aspects of this product will be free of defects in material and workmanship for one year from the date of purchase. A replacement for any defective part will be supplied free of charge for installation by the consumer. Defects or damage caused by the use of other than genuine parts are not covered by this warranty. This warranty shall be effective from the date of purchase as shown in the purchaser receipt.

This warranty is valid for the original consumer purchaser only and excludes industrial, commercial or business use of the product, product damage due to shipment or failure which results from alteration, product abuse, or product misuse, whether performed by a contractor, service company, or consumer. We will not be responsible for labor charges and/or damage incurred in installation, repair or replacement nor for incidental or consequential damage.

**XL Sport Wagon and Cooler: Black**

**156766**

**SKU: 117505192**

**MAX WEIGHT LIMIT: 225 LB ( 102.1 KG)**