









VOLLEYBALL SET

ASSEMBLY INSTRUCTIONS

MODEL: NET100_097D

NET100_097D PARTS LIST

1  x2 Pulley cap FOR FIG. 1	2  x2 Top Pole FOR FIG. 1	3  x2 Middle Pole FOR FIG. 1	4  x2 Bottom Pole FOR FIG. 1	5  x4 Eye Bolt Set FOR FIG. 2
6  x2 Pole Anchor FOR FIG. 1	7  x6 Strap FOR FIG. 3	8  x1 Net FOR FIG. 3	9  x4 Ground Stakes FOR FIG. 6	10  x2 Top guide rope FOR FIG. 2
11  x2 Bottom guide rope FOR FIG. 2	12  x1 Volleyball	13  x1 Air Pump	14  x1 Circle site	15  x2 Elastic FOR FIG. 3
16  x2 Score Clip FOR FIG. 1	17  x1 Storage Bag			

NET100_097D PRE-INSTALLED PARTS

P1  x4 Push Button FOR FIG. 1

WARNING:
Please Do Not sit, climb or lean on the product.

WARNING:
CHOKING HAZARD - This item contains small parts. Not suitable for children under 3 years.

WARNING:
Adult supervision is required at all times when children are in the area. Being struck by a thrown object can cause serious injury.

WARNING:
This item is not a toy, adult supervision is required at all times for children. Please be sure to carefully read the instructions, proper use of this item will reduce the risk of injury.



1		X 2
2		X 2
3		X 2
4		X 2
6		X 2
16		X 2
P1		X 4

FIG. 1

FIG. 1A



1. POLE ASSEMBLY

5		X 4
10		X 2
11		X 2

FIG. 2




FIG. 2A

2. TOP & BOTTOM GUIDE ROPE ATTACHMENT


- | | | |
|----|---|-----|
| 7 |  | X 6 |
| 8 |  | X 1 |
| 15 |  | X 2 |

FIG. 3

FIG. 3A

Connecting Cord Loop

FIG. 3B

FIG. 3D

FIG. 3C

3. NET ATTACHMENT

FIG. 4


FIG. 4A

FIG. 4B

Note: Run the clip of the top cable through the wheel of the pulley cap (#1).

4. TOP CABLE ATTACHMENT


FIG. 5



5. NET SET UP

Stretch the assembled Net and poles across the playing area until the Net is taut. Press the Pole Anchors into the ground with the poles touching the ground. Slip the poles onto the anchors. Holding the poles in the vertical position, press the Guide Rope stakes into the ground at a 45° angle, 3 feet to 5 feet from the pole and 3 feet to 5 feet apart. Make sure that the hooks on the stakes are facing away from the poles.

9




X 4

FIG. 6

TIP: After the net is completely assembled and the pole tension is correct, the net can be tightened by adjusting the tension clips up or down along the top cable.

FIG. 6A




Tension Clip

6. BOTTOM GUIDE ROPE SET UP

Make the loops on the Bottom Guide Rope tension clips large enough to slip over the stakes already in the ground. Make sure that the Guide Rope loops are placed under the stake hooks as shown in FIG. 6


FIG. 7



6. NET HEIGHT ADJUSTMENT

The height of the net can be adjusted by depressing the push buttons on the poles (#2 & #3) and raising or lowering the poles until the push buttons are aligned with the holes in the poles (#3 & #4).

FIG. 8



7. COURT MARKING KIT

Lay out green rope (#14) as per diagram. Slip the metal stakes into the holes at the bottom and secure the rope to the metal stakes with the flags in an upright position at each corner.

DUNLOP™ - VOLLEYBALL SET - PLAYING RULE INSTRUCTIONS -

MODEL: NET100_097D

VOLLEYBALL RULES:

COURT SIZE:

The standard size of a volleyball court is 30 feet wide and 60 feet long. The playfield can be increased or decreased based on the space available.

NET:

Stretch the net across the center of the court dividing it in half. The net height should be set at 7 feet when playing volleyball, but it can be set to 6 feet or 5 feet 1 inch if all of the players agree to the change.

NUMBER OF PLAYERS:

Each team should have the same number of players and there shouldn't be more than 6 total per team.

A singles match is played with one player on each side of the net.

SERVICE:

Each player shall serve in turn and will continue to serve until their team loses the point (called "siding out"). When serving, the ball must go over the net; if the ball hits the net when served and goes over the net, the ball must be re-served. If the ball does not go over the net when served or is out of bounds or touches any team-mate before touching an opponent or opponent's court, they "side out" and the opponent takes possession and becomes the serving team.

SERVING AREA:

The serving area should be a minimum of 5 feet behind the back boundary of the court. In the event that the playing area does not provide enough space for such an area, then the serving area shall extend into the court.

The serving area should be located in the right end section of each court; the width should not exceed 8 feet. (see diagram).

VOLLEY:

Each team is allowed three consecutive ball touches before it is returned to the opponent's area.

ROTATION:

After a team has lost its serve, the team receiving the ball for the serve should rotate clockwise, with every player moving round one position.

GAME:

The game shall be played to 21 or 15 points. In order to win the match, a team must win two out of three games.

SCORING:

Only the serving team can score. When the serving team fails to score, it is "side out" and the receiving team becomes the serving team.

VOLLEY:

Each team is allowed three consecutive ball touches before it is returned to the opponent's area.

ROTATION:

After a team has lost its serve, the team receiving the ball for the serve should rotate clockwise, with every player moving round one position.

GAME:

The game shall be played to 21 or 15 points. In order to win the match, a team must win two out of three games.

SCORING:


Only the serving team can score. When the serving team fails to score, it is "side out" and the receiving team becomes the serving team.

ERRORS AND FAULTS:

- 1) When a player does not clearly hit the ball or allows the ball to rest on any part of his/her body.
- 2) A player hits the ball out of bounds.
- 3) A player allows the ball to hit the floor or any other object outside the established play area (except the net), before being legally returned to the opponent's side of the court.
- 4) When a player touches or hits the ball two times in a row.
- 5) When a player fails to make a good serve within the play area.
- 6) The ball is caught and/or thrown; it does not rebound from the hit.
- 7) If the ball touches any part of the body, except the hands or forearms.
- 8) Touching the net with any part of the body or reaching over the net.
- 9) If a player plays out of position when ball is being served.







PENALTY:

Touching the net with any part of the body or reaching over the net.



Caution: Stand clear of the court area to avoid being injured while a player is taking his or her turn.

NET100_097D LISTA DE PARTES

1  x2 Tapa de Polea FOR FIG. 1	2  x2 Poste superior FOR FIG. 1	3  x2 Palo del medio FOR FIG. 1	4  x2 Palo de fondo FOR FIG. 1	5  x4 Cáncamo del ojo FOR FIG. 2
6  x2 Ancla de poste FOR FIG. 1	7  x6 Correa FOR FIG. 3	8  x1 Red FOR FIG. 3	9  x4 Postes de piso FOR FIG. 6	10  x2 Cuerda guía superior FOR FIG. 2
11  x2 Cuerda guía inferior FOR FIG. 2	12  x1 Balón de voleibol	13  x1 Bomba de aire	14  x1 Sitio de círculo	15  x2 Elástico FOR FIG. 3
16  x2 Grampa de puntaje FOR FIG. 1	17  x1 Bolsa			

NET100_097D PIEZAS PREINSTALADAS

P1  x4 Botón de presión FOR FIG. 1



ADVERTENCIA:

Por favor No sientes, subas o inclíne el producto.



ADVERTENCIA:

PELIGRO DE ASFIXIO - Este artículo contiene piezas pequeñas. No es conviene para los menores de 3 años de edad.



ADVERTENCIA:

Se requiere la supervisión de adulto en todo el momento cuando están los niños en el área. Si fuera golpeado por un objeto lanzado se pudiera causar herida grave.



ADVERTENCIA:

Este artículo no es un juguete; se requiere la supervisión de los niños por adulto en todo el momento. Asegúrese de leer cuidadosamente las instrucciones; el uso apropiado de este artículo reducirá el riesgo de lesiones.



1		X 2
2		X 2
3		X 2
4		X 2
6		X 2
16		X 2
P1		X 4

FIG. 1

FIG. 1A



1. ENSAMBLADURA DE POSTE

5		$\times 4$
10		$\times 2$
11		$\times 2$

FIG. 2




FIG. 2A

2. ADJUNTADO LA CUERDA GUIA SUPERIOR E INFERIOR


- | | | |
|----|---|-----|
| 7 |  | X 6 |
| 8 |  | X 1 |
| 15 |  | X 2 |

FIG. 3

FIG. 3A

Bucle de Conexión de Lazo

FIG. 3B

FIG. 3D

FIG. 3C

Correa

3. ATADURA DE LA RED

FIG. 4


FIG. 4A

Nota: Pase el clip del cable superior a través de la rueda de tapa de la polea (#1).

FIG. 4B

4. ATADURA DEL CABLE SUPERIOR

FIG. 5



5. MONTAR LA RED

Estirar la red ensamblada y los palos a través de los niños del juego hasta que la red quede tensa. Presione las Anclas de Poste al suelo con los postes tocando el suelo. Deslice los postes sobre las anclas. Mantenga los postes en la posición vertical, presione las estacas del Lazo de Guía al suelo en un ángulo de 45°, 3 pies a 5 pies del poste y 3 pies a 5 pies de distancia. Asegúrese de que los ganchos de las estacas están de espaldas de los postes.

9




X 4

FIG. 6

TIP: Luego de que la red está completamente montada y la tensión del polo está correcta, La red se puede apretar ajustando los clips de tensión hacia arriba o abajo a lo largo del cable superior.

FIG. 6A




Clip de Tensión

6. MONTAR EL LAZO DE GUIA SEGUNDO

Haga suficiente largo las clips de tension del bucle del Lazo de Guía Segundo para deslizar sobre las estacas en el suelo. Asegúrese de que los bucles del Lazo de Guía están colocados debajo de los ganchos de estaca como mostrado en la FIG. 6.


FIG. 7



6. AJUSTE DE LA ALTURA DE RED

La altura de red se puede ajustar presionando los botones de los postes (#2 & #3) y elevando o bajando los postes hasta que los botones estén alineados con agujeros en los postes (#3 & #4).

FIG. 8



7. JUEGO MARCADOR DE GANCHA

Trace la cuerda verde (#14) según el diagrama. Deslice los postes de metal en los hoyos en el fondo sujetando la cuerda en los postes de metal con las banderitas en posición vertical en cada rincón.

REGLAS DEL VOLEIBOL:

TAMAÑO DE LA CANCHA:

El tamaño estándar de una cancha de voleibol es de 30 pies de ancho y 60 pies de largo. El campo de juego se puede aumentar o disminuir en base al espacio disponible.

RED:

Estire la red a través del centro de la cancha dividiéndola por la mitad. La altura de la red debe fijarse a 7 pies cuando se juega voleibol, pero se puede poner a 6 pies o a 5 pies 1 pulgada si todos los jugadores están de acuerdo con el cambio.

NÚMERO DE JUGADORES:

Cada equipo debe tener el mismo número de jugadores que no deben ser más de 6 en total por equipo.

SERVICIO:

Cada jugador debe servir en turno y continuará sirviendo hasta que su equipo pierda de punto (conocido como "echado de lado"). Para servir, la pelota debe pasar por sobre la red; de tocar la red la pelota en el servicio y pasa por la red, la pelota se debe servir de nuevo. Si la pelota no pasa por sobre la red en el servicio ó sale para afuera de los límites ó toca cualquier jugador compañero antes de tocar un jugador opuesto ó la cancha opuesta, queda "echado de lado" y el equipo opuesto tiene la posesión de la pelota para servir.

ÁREA DE SERVICIO:

El área de servicio debe estar a un mínimo de 5 pies detrás de la línea de delimitación trasera de la cancha. En el caso de que el área de juego no ofrezca suficiente espacio para tal área, entonces el área de servicio se extenderá en la cancha. El área de servicio debe estar ubicada en la sección del extremo derecho de cada cancha; el ancho no debe exceder los 8 pies (ver el diagrama).

VOLEO:

Cada equipo tiene derecho a tres toques consecutivos de balón antes de devolverlo al área rival.

ROTACIÓN:

Después de que un equipo pierda su servicio, el equipo que reciba la pelota para servir debe girar en el sentido contrario del reloj, moviéndose los jugadores en la posición de la primera vuelta.

JUEGO:

El juego se jugará a 21 o 15 puntos. Para ganar el partido, el equipo deberá ganar dos de tres juegos.

PUNTUACIÓN:

Sólo el equipo que está realizando el servicio puede anotar. Cuando el equipo que está realizando el servicio deja de anotar un punto, "pierde la bola" y el equipo receptor se convierte en el equipo que realiza el saque.

VOLEO:

Cada equipo tiene derecho a tres toques consecutivos de balón antes de devolverlo al área rival.

ROTACIÓN:

Después de que un equipo pierda su servicio, el equipo que reciba la pelota para servir debe girar en el sentido contrario del reloj, moviéndose los jugadores en la posición de la primera vuelta.

JUEGO:

El juego se jugará a 21 o 15 puntos. Para ganar el partido, el equipo deberá ganar dos de tres juegos.

PUNTUACIÓN:

Sólo el equipo que está realizando el servicio puede anotar. Cuando el equipo que está realizando el servicio deja de anotar un punto, "pierde la bola" y el equipo receptor se convierte en el equipo que realiza el saque.


ERRORES Y FALTAS:

- 1) Cuando un jugador no golpea claramente la pelota o permite que la bola toque cualquier parte de su cuerpo.
- 2) Un jugador golpea la bola fuera de los límites.
- 3) Un jugador permite que la bola toque el suelo o cualquier otro objeto fuera de la zona establecida de juego (excepto la red), antes de ser devuelta legalmente al lado contrario de la cancha.
- 4) Cuando un jugador toca o golpea el balón dos veces seguidas.
- 5) Cuando un jugador no hace un buen saque dentro del área de juego.
- 6) La pelota se agarra y/o se lanza; no rebota por el golpe.
- 7) Si la pelota toca cualquier parte del cuerpo, exceptuando las manos o los antebrazos.
- 8) Si se toca la red con cualquier parte del cuerpo o se pasa por encima de la red.
- 9) Si un jugador juega fuera de su posición cuando se está sirviendo el balón.

SANCIÓN:

Tocar la red con cualquier parte del cuerpo o estirarse por encima de la red.

DISPOSICIÓN DE LA CANCHA ESTÁNDAR



LÍNEA CENTRAL DE LA RED

Precaución: Manténgase alejado de la zona de la cancha para evitar recibir lesiones mientras un jugador está tomando su turno.