



**Academy**<sup>®</sup>  
SPORTS+OUTDOORS

## PLASMA LIGHTER

165515

### INSTRUCTIONS



### PRODUCT SPECIFICATIONS

Product type: DOUBLE ARC LIGHTER

Rated voltage: 3.7V

Charge Voltage: DC 5.0 ± 0.25V

Charge Time: ≤1.5hours

Battery Capacity: 220mAh

Battery Life: ≥300 Charges

#### CHARGING:

Charge your PLASMA LIGHTER BY inserting the provided micro USB cable into the charging port and connecting it to a computer USB or compatible wall adaptor. A blue indicator light will be on while charging is in progress.

It will take around 1.5 hours to fully charge.

During charging, the blue indicator light is on. When fully charged, the blue indicator light will be off.

Note: To avoid shortening the battery life, unplug the lighter once fully charged.

### WARNING

#### PLEASE READ CAREFULLY FAILURE TO FOLLOW SAFETY WARNINGS MAY RESULT IN INJURY

1. **USE AWAY** from face, body, clothing and other flammable materials
2. **DO NOT** place it in direct sunlight for long period of time.
3. **DO NOT** expose to high temperature above 122°F (50°C) for a long time.
4. **KEEP AWAY** from Children, lighters are NOT toys.
5. **DO NOT** allow the electronic bolt to make contact with yourself or others.  
RISK OF SHOCK AND BURNING.
6. Never puncture or expose to fire.
7. Always wipe away any ash or debris leftover from lighting.
8. Keep dry. Keep away from water and areas of high humidity.
9. **DO NOT** continue to expose the lighter to the open flame.  
Ensure the electronic bolt is extinguished after use.
10. Only use the micro USB cable included with this lighter.