
# OPERATION MANUAL ZP5138



#### 1. Directory

Before use	
specification	
afety Precautions	
arts	
arts	
ssembly diagram	
lotice when using	
use	
Charging	_
laintenance and repair	
rouble Shooting	-:

#### 2. Before use □

Please read carefully before using our product manual, which tells you the detailed installation and correct use, Then can avoid damage and injury caused by improper operation. Particularly important is that it tells you a lot about safety precautions, Please memorize these and guide your child with patience. Please place the instructions in easily accessible place for future reference.


## 3. Specification


External dimensions	124*75*68cm	Power Mode	Rechargeable	
User's proper age	suitable for children around 37-96 months old	Charging Spec	12V 1000mA	
Loading limitation	30 KGS	Charging Time	8-12 hours.	
Speed	3.5/7 km/hr	Power life	280 times charging.	
Battery Spec	12V,7AH/12V,10AH	Fuse Spec	Self-resetting fuse	

#### 4. Cautions For Safety


- (1). The product must be assembled by adults. Before use check whether the adult assemble correctly according to the instructions.
- (2). To avoid injury to small parts, children under 3 years old prohibited.
- (3). Children should stay away from the plastic bags, prevent children from covering the head leading to choking hazard
- (4). When using, Children should wear safety helmets and must be guarded and guided by adults, and not to leave the child alone to avoid accidents.
- (5). Max Capacity is 30kgs. Please donnot overload.
- (6). The motorcycle should drive on the plat surface It is prohibited to drive on streets, slopes or any other dangerous places.
- (8) When the motorcycle moving, user should not be free to turn forward, backward switch, After the motorcycle stopped, then can switch the forward and backward switch.
- (9) Do not reverse push and lateral pull the motorcycle in the normal driving to prevent the rollover risk.
- (10). The battery charger to be operated by an adult, do not let children charge the battery.
- (11). Do not directly wash the motorcycle with water or rain the motorcycle. To prevent water damage to the motor circuit
- (12) Adults should check regularly (once every two weeks suggested), wires, plugs, electrical, housing, steering systems, fastening is normal or not, If there is any problem, then stop use until the fully restored.
- (13). The motorcycle battery and the charger is not a separate toy, donnot let the children play the battery and charger.
- (14). Please use the matched battery and charger, and a stable charging voltage to ensure safe when charging, and extend battery life.
- (15). Spare parts exchange should be operated by an adult, because the battery is very heavy, and the internal acidic electrolyte, if any leakage should avoid contact with liquid, and need a professional disposition. If accidental contact with the electrolyte, it is timely at least 15 minutes rinse with cold water and seek medical treatment.
- (16). Avoid the short circuit of the power, to prevent the risk of burning.
- (17) This product cannot store in the high-temperature places or near the fire, prevent plastic parts melt, charging away from flammable materials to prevent fires.
- (18). Shall not use the different specifications fuse.
- (19). No using or long-term no use the motorcycle, please pull out the battery on the red line, the switch is "off" position, to ensure circuit safety.
- (20). Donnot exposure the motorcycle to the sun or using the motorcycle in the rainy days.
- (21). Keep the package bags in the proper place for further use because there is important information on it.


# 5. Parts Drawing






# 7. Product Assembly Chart










steering rod is inserted into the oval hole on the steering

gear, and then the rear axle is inserted into the


corresponding hole of the car body.








6. Open the toolbox and use 4pcs of 4\*12 large head screws to fix the tool box to the corresponding position




7. Open the seat cushion with a screwdriver and connect the two motor plug-ins and the body plug-in respectively, and then insert the battery plug-in with the body plug-in, and finally install the seat cushion.

## 8. THE USE OF INFORMATION

- (1) The vehicle has the music.
- (2) when the vehicle is running at a slow speed, it should be charged in time and charged for 8-12 hours. Don't charge the battery over 15 hours, the charger has a slight heat phenomenon when charging, which is a normal phenomenon.
- (3) the function of the vehicle is as follows
  - Functions: 1. The vehicle has pedal driving function and step the pedal when using.
  - 2. Forward / backward switch device. Push forward, the vehicle will go forward and press backward, the vehicle will go backward
  - 3. This vehicle has fast speed and slow speed.
  - 4. the handle has horn and music function.
  - 5. The vehicle has a drag function. The handle is behind the exhaust pipe decoration. If the car is not available or not used, you can pull the vehicle directly by pulling out the handle.
  - 6. This vehicle can directly remove the battery and charge the battery separately.





#### 9. Fused tube

The vechile use self-tapping fuse.


When overloading or improper use, the fuse will be automatically cut off in 10-20 seconds and then will automatically connect the power.


To avoid the cutting off, please pay attention:

- (1). The maximum weight limited of the motorcycle is 30KG.
- (2). Not stall the car running or heavy trailer behind.
- (3). May not liquid immersion, it may cause the short circuit.
- (4). Donnot revise the vehicle's circuit or the structure.

#### 10. Charging

- 1. Insert the charger jack into the charging hole.
- 2. Insert the charger plug into the stable matching AC power supply.
- 3. The battery can be taken out and charged individually. When taking out the battery, first pulls out the plug-in on the battery, then presses the button on the battery, and then rotates the iron sheet until the battery can be taken out.





#### Attention when charging:

- 1. To assure the safety, Adults should do the battery charging,
- 2. First using , fully charged, need to charge another 8-12 hours.
- 3. Charge the battery if the vehicle runs slower, can charge 8-12 hours. But cannot charge over 15 hours.
- Cannot open or decompose the battery and charger, should use the matched charger and battery.
- 5. When charging, cannot upside down the battery.
- 6. Before charging, check the charger ,battery and the plug is ok or not.lf broken,no use. After repaired,then can use.

#### 11. Care and maintenance

- (1). Adults should check regularly (once every two weeks suggested), wires, plugs, electrical, housing, steering systems, fastening is normal or not, If there is any problem, then stop use until the fully restored
- (2). Clean vehicles please use soft, dry cloth to wipe, can not use water or fuel cleaning, that will lead to corrosion switch and caused switch failure.
- (3). This product cannot store in the high-temperature places or near the fire, or in moist places, The product should be covered in the snowy and rainy days..
- (4). Charge the battery fully if you will store it for a long time, then charge it every 3 month, in this way you can extent the lifetime of the battery.
- (5). Stop using pls take off the battery from the motorcycle and make the switched on "OFF" position. Also cut off the power. Keep the battery in proper place. Donnot allow children play the battery.
- (6). When maintenance, donnot revise the motorcycle's circuit and structure. The key parts should be maintained and guided by the professional staff.
- (7). Don't recharge the non-rechargeable batteries, don't mix the old and new or different types of batteries. Pay attention to the Positive and negative.
- (8). In the unstable supply voltage region. We recommended to install voltage stabilizer to protect the battery

#### 12. Trouble Shooting

The vehicle does not move.

- Check forward and back switch is in neutral position switch or not. (Middle of the switch is neutral position)
- 2. Check the power's positive and negative cord is plugged firmly
- 3. Fuse melted or jump off.
- 4.Check the charger is pluging into the charging hole or not.If yes,the motorcycle will cut off automatically. After pluging off the charger, then can use.
- 5. Foot switch or manual button is stuck down then cannot press?
- 6. Whether there is debris stuck wheels

The vehicle moves slowly.

- 1. Whether battery power is sufficient, If so, need timely charge.
- 2. Whether there is debris stuck wheels
- 3. Whether the vehicle is overloaded.
- 4. Whether the charger is broken then the battery cannot be charged.

The battery cannot be fully charged.

- 1. Check the charger is ok or not. When chargring, the charger will be warm is normal.
- 2 Chacktha hattary is ak ar not

Exhausted batteries are to be removed from the toy.

Rechargeable batteries are only to be charged under adult supervision.

Warning. Not to be used in traffic. This toy has no backe.

The toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.

Batteries are to be inserted with the correct polarity.

Rechargeable batteries are only to be charged under adult supervision.

Rechargeable batteries are to be removed from the toy before being charged.

The instruction shall state that transformers or battery charger used with the toy are to be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage, they must not be used until that damage had been repaired.

Our products are suitable	for the following standard:
GB6675,GB19865	
EN71 AND EN62115	5

7	