
Recommended Ages 2-4 years old Maximum Weight: 80 lbs.



This product contains small parts, sharp points & edges prior to assembly.



PARTS LIST:

- 1. Handlebar
- 2. Minimum Insertion Mark
- 3. Seat and Seat Post
- 4. Headset
- Fork Assembly
- 6. Seat Post Clamp
- 7. Main Frame
- 8. Front Wheel

Tools Required:

13mm Wrench 15mm Wrench

Assembly Steps:

- 1) Slide the stem into the fork's steer tube.
- 2) Lower the stem until the mark that says "minimum insertion" is not visible.
- 3) Tighten the stem center bolt so that the handlebar assembly is in line with the fork.
- 4) Loosen axle nuts on front wheel.
- 5) Slide washers to inside of axle nut.
- 6) Slide front wheel between the fork dropouts.
- 7) Center the wheel in the fork and tighten both axle nuts evenly.
- 8) Make sure the wheel is tightened securely on both sides.
- 9) Open seat quick-release lever on the bicycle frame.
- 10) Insert seat, with seat post, into the frame at desired height (make sure the seat post is inserted far enough into the frame to hide the "minimum insertion" mark on the seat post.
- 11) Tighten the quick-release clamp so that the seat may not turn left or right, or move up and down. If the seat moves after locking the quick-release lever, open the lever and tighten the adjusting nut further, then close the quick-release lever again.

Check the Function of the Balance Bike:

Check that all functions of steering and bolts are properly installed:

- 1) With the front wheel between your legs, try to rotate the handle bar left or right. It should stay in place. If it rotates, check that the steer clamp is fully installed and tighten the clamp bolt further.
- 2) Check the saddle is secure and can not move. Tighten bolts further if excess play is found.

BEFORE EACH USE:

Check all bolts to ensure they are tight, taking care not to over tighten the bolts.

RIDING YOUR BIKE:

- 1. Children should always wear a properly fitted helmet that complies with US Consumer Product Safety Commission (CPSC) standard 16CFR 1203, Knee pads and other protective equipment.
- 2. Do not ride at night.
- 3. Do not ride in wet conditions.
- 4. Do not ride on rough surfaces.
- 5. Avoid traffic and pedestrians.
- 6. Do not ride on steep hills.
- 7. Children should use product under adult supervision.
- 8. Allow only 1 rider.
- 9. Never use near simming pools.
- 10. Always wear shoes when riding Balance Bike.
- 11. Balance Bikes do not have brakes. Ride on level surfaces only.

PACIFIC CYCLE LIMITED WARRANTY

AND POLICY ON REPLACEMENT PROCEDURES AND RESPONSIBILITIES

Your purchase includes the following warranty which is in lieu of all other warranties whether express or implied. This warranty is extended only to the initial consumer purchaser. No warranty registration is required.

FRAME

The entire frame is guaranteed against faulty materials and workmanship for as long as the initial purchaser has the bicycle, subject to the condition of the warranty listed below. If frame failure should occur due to faulty materials or workmanship during the guarantee period, the frame will be replaced. For frame replacement under this Pacific Cycle Limited Warranty, contact us, stating the nature of the failure, model number, date received and the name of the store from which the Balance Bike was received, at the address given on this page. Frame must be returned for inspection at customer's expense.

PARTS

All other parts of the unit except normal wear parts are warranted against defective materials and workmanship for as long as the initial purchaser has the bicycle, subject to the Terms and Conditions of the warranty listed below. If failure of any part should occur during the warranty period, the part will be replaced for you if the failure was due to faulty materials or workmanship. All warranty claims must be submitted to the address below and must be shipped prepaid and accompanied by the original dated purchase receipt. Normal wear parts are defined as grips, tires, tubes, and cables. These parts are warranted to be free from defects in material and workmanship as delivered with the product. Any claim for repair or replacement of normal wear parts must be made within thirty (30) days of the date of purchase. The warranty does not cover normal wear and tear, improper assembly or maintenance, or installation of parts or accessories not originally intended or compatible with the Balance Bike as sold. The warranty does not apply to damage or failure due to accident, abuse, misuse, neglect, or theft. Claims involving these issues will not be honored.

CONDITIONS OF WARRANTY

- 1. Your Balance Bike has been designed for general transportation and recreational use, but has not been designed to withstand abuse associated with stunting and jumping. This warranty ceases when you rent, sell or give away the Balance Bike, ride with more than one person, or use the Walkabout for stunting or jumping.
- 2. This warranty does not cover ordinary wear and tear or anything you break accidentally or deliberately.
- 3. It is the responsibility of the individual consumer purchaser to assure that all parts included in the factory-sealed carton are properly installed, all functional parts are initially adjusted properly, and subsequent normal maintenance services and adjustments necessary to keep the Balance Bike in good operating condition are properly made. This warranty does not apply to damage due to improper installation of parts or failure to properly maintain or adjust the Balance Bike.

PACIFIC CYCLE, INC., IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. THIS LIMITED WARRANTY DOES NOT COVER ANY PERSONAL INJURIES, DAMAGE TO, OR, FAILURE OF THE BALANCE BIKE OR ANY OTHER LOSSES DUE TO ACCIDENT, MISUSE, ALTERATION, NEGLECT, ABUSE, NORMAL WEAR AND TEAR, IMPROPER ASSEMBLY, IMPROPER FIT, IMPROPER MAINTENANCE OR USE OF UNAUTHORIZED REPLACEMENT PARTS NOT DESIGNED FOR THE BALANCE BIKE.

THIS LIMITED WARRANTY IS THE ONLY WARRANTY APPLICABLE TO THIS BALANCE BIKE, AND IS EXPRESSLY IN LIEU OF ANY OTHER WARRANTY. ANY IMPLIED WARRANTIES, INCLUDING ANY WARRANTY OF MERCHANTABILITY AND WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY. This limited warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

NOTICE: Balance Bike specifications are subject to change without notice.

PACIFIC CYCLE, INC.

P.O. Box 344 4730 E Radio Tower Lane Olney, IL 62450

Customer Service: 1-800-626-2811
Email: service@pacific-cycle.com
Web Address: www.pacific-cycle.com
Monday - Friday: 8:00am to 5:00 Central Time