20IN FOOSBALL

ITEM NUMBER: **54242**

For all your replacement part needs, please visit: www.franklinsports.com/54242



⚠ WARNING: CHOKING HAZARD -- Toy contains small balls and small parts. Not for children under 3 yrs.

Franklin Sports Inc. Stoughton, MA 02072 www.franklinsports.com Made in China





CUSTOMER SERVICE COMMITMENT

Thank you for purchasing this Franklin® product! In the event that the product you've purchased has missing or damaged parts, please contact us at:

parts@franklinsports.com

Visit our website at: www.franklinsports.com/54242

If possible, please include product part number and parts description so we can best assist you.


WE'RE HERE FOR YOU!


PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE IT WAS PURCHASED FROM.

WE ARE COMMITTED TO FULFILLING ALL REPLACEMENT PART NEEDS IMMEDIATELY.

Thank you for your continued support, and welcome to the #FranklinFamily!


YOU ARE NOW READY TO PLAY!





-NOTE-

Install the **Handles** (#6) of the gray players on the left side by pressing them onto the rod. Next install the **Handles** (#6) of the white player rods onto the right side by pressing them into place. After the handles are installed, take the rod **Caps** (#7) and install them onto the end of the rod opposite the handles.






-NOTE

Align the **Scoring Bar** (#11) to the top of the ball return. Make sure to have the end pieces to the scoring bar over the ends before proceeding. Secure the parts by aligning them with the drilled holes and pressing the scoring bar into place. Repeat this step on the other side.

Franklin* ITEM#: 54242

For replacement parts: Visit: www.franklinsports.com/54242 Email: parts@franklinsports.com Call: 1-800-225-8649

PARTS LIST:




2

ASSEMBLY INSTRUCTIONS


– NOTE –

Start by finding a space that is flat and clear of other objects.





Start by aligning one of the Side Panels (#1) with the two End Panels (#2). Secure the pieces by using 4 Large Wood Screws (#8) and 4 Steel Washers (#9) (one washer on each).







-Note

Slide the Soccer Field (#3) into the slot on the previously installed 3 frame parts by sliding it down the slots.

3


For replacement parts: Visit: www.franklinsports.com/54242 Email: parts@franklinsports.com Call: 1-800-225-8649






-NOTE-

Slide one Foam Washer (#10) onto each end of the player rods. Then, insert the player rods into the Side Panel (#1) so that the players from one color are all facing one direction and the other color is facing the other direction.





-NOT

Take the uninstalled **Side Panel** (#1) and align the player rods so they all slide through the pre-installed holes in the side panel. Secure the side panel using 4 **Large Wood Screws** (#8) and 4 **Washers** (#9).