


CORNHOLE

#G214

Instructions

SET INCLUDES:



CARE INSTRUCTIONS:

Cornhole boards are a wood product so please keep your boards out of the weather elements whenever possible. Do not leave the boards outside overnight. These precautions will help prevent the boards from warping and/or deforming.

To keep the duckcloth bags in top condition to not expose the bags to wet weather. If the bags do get wet, let them dry out in a warm environment as soon as possible.

Object of Game


Game Setup

The idea is to pitch or toss a corn bag into the hole or as close as possible onto the cornhole board.

Find a nice flat surface on a lawn, in a parking lot, the beach, etc. Set up the boards directly facing each other with 27 feet between the front edges of each board. The game dimensions can be adjusted to suit the players' ages and abilities.

Game Setup (cont.)

Cornhole can be played with 2 or 4 players. Pick which side of the board each team will throw from. In a 4-player game, each player's pitching box will be directly across from their teammate. In a 2-player game, if a player starts throwing from the left side of the board, the same player will walk directly across to the other board, and throw back from the right side.



Game Play


Decide which team goes first then take turns throwing bags with the opposing team. The first player or team throws, then the opposing player or team throws, alternating until all bags have been tossed.

A player's feet may not go past the front edge of the board. If they do, a foul is called and that bag is removed from the board. Also, a tossed bag may not touch the ground. If it hits the ground and bounces up on the board, remove it before any other bags are thrown. If it's hanging off the board and touching the ground, remove that as well.

A round is completed when all 8 bags have been tossed to the other side. At the end of the round, add up the score (see scoring below). The team that earned the most points in that single round throws first in the next round.

Scoring

After all bags have been thrown, a bag remaining on the board is worth 1 point. A bag that went in the hole is worth 3 points. Add up how many points each team earned and compare scores. Equal points cancel each other out.



Example 1:
If player A scores 5 points and player B scores 3, player A will add 2 points to their overall score and player A's team will throw first in the next round.

Scoring (cont.)



Example 2:
If player A scores 6 points and player B scores 6 as well, there will be no points awarded and whichever team threw first in the last round will throw first again.

Winning the Game

A match shall be played until the first team of contestants reaches (or exceeds) 21 points at the completion of a round. The winning team does not need to win by two or more points.

A match can never end in the middle of a round. Thus, if a team that pitches first reaches or exceeds 21 points, the game can not end until the other side is allowed to pitch all of their corn bags and the round is completed.