


Measuring Stick (MR70) Instructions



Measuring stick (stk MR70) has a Lower Ruler and a sliding Upper Ruler. Upper Ruler Thumb Screw is located in the front. We suggest adding the optional Measuring Stick Arm (stk MR72), which is 9" long and sold separately.

How to use the Measuring Stick(stk MR70)

Set the base of the Measuring Stick near the window or door to be measured. Unlock the Upper Ruler Thumb Screw. Slide the Upper Ruler to the required height to be measured. Lock the Upper Ruler Thumb Screw. The true height can be easily read at the top of the Measuring stick (Figure 3).

** If Measuring Stick Arm is used, readings should be made at the top of the Arm **




Figure 3